



















The symbols on the connecting lines indicate the type of relationship. The top fields (above the line) in the boxes are the key fields used in joining tables.











		N / N		Drowcor
				DIOWSEI
		5		
₹ MySOL	Query Brow	ser - @localhos	:3306 / MOVESDR20070412	-101-
File Edit	View Query	Script Tools	Window Help	
Go back	Next Refres	h	ROH avgspeedbin;	Execute - Stop
	esultset 1	1		Schemata Bookmarks History
8 avg	SpeedBi	avgBinSpeed	avgSpeedBinDesc	2
	1	2.5	speed < 2.5mph	lookuprun1tst
	2	5	2.5mph <= speed < 7.5mph	▼ 🦲 MOVESDB20070412
	3	10	7.5mph <= speed < 12.5mph	agecategory
	4	15	12.5mph <= speed < 17.5mph	▶ 🛄 agegroup
	5	20	17.5mph <= speed <22.5mph	averagetankgasoline
	6	25	22.5mph <= speed < 27.5mph	averagetanktemperature
	7	30	27.5mph <= speed < 32.5mph	avgspeedbin
	8	35	32.5mph <= speed < 37.5mph	avgspeeddistribution
	9	40	37.5mph <= speed < 42.5mph	
	10	45	42.5mph <= speed < 47.5mph	
	11	50	47.5mph <= speed < 52.5mph	Syntax Functions Params Trx
	12	55	52.5mph <= speed < 57.5mph	🗁 Data Manipulation 🔺
•	13	60	57.5mph <= speed < 62.5mph	🚑 DELETE
	14	65	62.5mph <= speed < 67.5mph	A DO
	15	70	67.5mph <= speed < 72.5mph	A HANDLER
	16	75	72.5mph <= speed	A LOAD DATA INFILE
				A REPLACE
				A SELECT
				TO INCATE
16 mays fetc	oed in 0.0066s (0	0003x)	🖌 Edit 🛹 Annia Changer 🛛 💥 Discard Changer 🗌 🖬 Eist	H Last Q Search A LIPDATE
1: 27			Contraction of the second seco	
1127	1			

The Browser can be used to display the contents of the tables in a spreadsheet-like form.









Describe command is used to show you the structure of a table.

You can also right click and edit a table, which will display it's structure as well.

able Name: avgspeed	bin	Database: MOVESD	BDRAFT20C	omment:	
olumns and Indices	able Options Advanced	Options			
 avgBinSpeed avgSpeedBinD opModelDTirew opModelDRunn 	ELDAT CHAR(50) SMALLINT(6) SMALLINT(6)		SIGNED _ ZEROFILL ARY _ ASCII _ U SIGNED _ ZEROFILL SIGNED _ ZEROFILL		
Indices Foreign Key	s Column Details	tings ame: PRIMARY	Index (avgS)	Columns (Use Dr beedBinID	ag'n'Drop)
	Index Ki	od: PRIMARY			+

The F2 function key will show the structure of the table.

You can also right click and edit a table, which will display it's structure as well.

















	Tools Settings Help	no Fair Die Dioressing action Dest Dioressin
On Read/Off Road On Read/Off Read On Read/Off Read Off Read Off Read Store Off Read Regiment Sco Off Read	Always Time Hour Location COUNTY Pollutant for AB Vehicle-Equipment Categories Model Year Fuel Type V Emission Process	Description Scale Time Spans Geographic Bounds Vehicles-Equipment On Road Vehicle Equipment Road Type Politutarts And Processes Manage Input Data Sets

There is only 1 emission process in Indiana.mrs (running), but emission process is selected so that it is identified in the output database rather than being NULL.







MOVE	OVES summary report for th same run:						
👙 Screen Repo	rt.						
Header Body	Decode						
Run	NOx	TotalHC					
	101240	44030					
Print and Close	Report						
Close Report							
			3				





Participants do not have the database used in the following slides.

















ı ıt	o: C sp	opy q reads	uery stater heets for fu	nent uture	s in e ref	to e: erer	xpo nce
Micro	osoft Evcel -	sourceusetype y	c				
E Fil	e <u>E</u> dit <u>V</u> ie	w Insert Form	at <u>T</u> ools <u>D</u> ata <u>W</u> indow <u>H</u> elp	Ado <u>b</u> e PDF			- 8
			9 - 🕑 🔰 🛋 - 🔊 🖬	Σ	- 41 Z1		1 : 3 -
11 mg		No I CON YO I		e le l			-
		2 2 1 2 O 1	Reply with Change	s E <u>n</u> a Revi	ew 🗲		
13 2	1 🚓 💄						
A	20 -	fx	/				
	A	В	с	D	E	F	G
1							7700
2 SE	LECT * FRO	OM sourceusetyp	ie;				
3							
4 so	urceTypeID	HPMSVtypeID	sourceTypeName	rollingTerm	rotatingTer	dragTermC	sourceMa
5	21	20	Passenger Car	0.156461	0.002002	0.000493	1.4788
6	31	30	Passenger Truck	0.22112	0.002838	0.000698	1.86686
7	32	30	Light Commercial Truck	0.235008	0.003039	0.000748	2.05979
8	51	50	Refuse Truck	1.41705	0	0.003572	20.6845
9	52	50	Single Unit Short-haul Truck	0.561933	0	0.001603	7.64159
10	53	50	Single Unit Long-haul Truck	0.498699	0	0.001474	6.25047
11	54	50	Motor Home	0.617371	0	0.002105	6.73483
12	43	40	School Bus	0.746718	0	0.002176	9.06989
13	42	40	Transit Bus	1.0944	0	0.003587	16.556
14	41	40	Intercity Bus	1.29515	0	0.003715	19.5937
15	61	60	Combination Short-haul Truck	1.96354	0	0.004031	29.3275
16	62	60	Combination Long-haul Truck	2.08126	0	0.004188	31.4038
and the second se	11	10	Motorcycle	0.0251	0	0.000315	0.285
17							
17 18		L.	1	and the second sec			and the second























Note that all tables have three parts (frm, myd and myi). All three parts must be copied.

Use the "flush tables;" command to unlock tables that were in use.





Creating a Template Database in MOVES

- A blank database can be created in MOVES from the Manage Input Data Sets screen—this database contains all the tables that the default database does, with the same format, but no data
- This database can then be populated with necessary data







