


GUIDANCE FOR WATER UTILITY RESPONSE, RECOVERY & REMEDIATION ACTIONS FOR MAN-MADE AND/OR TECHNOLOGICAL EMERGENCIES

Office of Water (4601M) EPA 810-R-02-001 www.epa.gov/safewater April 2002

DISCLAIMER



This document was prepared by Michael Baker Jr., Inc. for the EPA's Water Protection Task Force under contract EMW-2000-CO-0002.

Table of Contents

Introduction: 1
Background:1
I. Incident types
II. Development of the Guidance
III. Structure
Response Planning: 2
Notification Considerations: 2
Sampling: 4
Annexes: 4
1. Sample Collection, Identification and Chain-of-Custody Form
2. Incident-specific Guidance
I. Contamination Event: (Articulated Threat with Unspecified Material)
II. Contamination Threat at a Major Event
III. Notification from Health Officials of Potential Water Contamination Annex II- 5
IV. Intrusion through Supervisory Control and Data Acquisition (SCADA) Annex II-7
V. Significant Structural Damage Resulting from an Intentional Act

Introduction:

This document provides uniform response, recovery and remediation guidance for water utility actions in response to man-made and/or technological emergencies. The guidance was developed as an initiative of EPA's Water Protection Task Force and has been reviewed with water utilities and associations, EPA Regions, EPA Office of Water and other federal agencies. The intent of this guidance is to provide the minimum actions that EPA recommends be carried out by a water utility for the events described.

Emergency response planning is primarily a local responsibility. Good business practices suggest that every water utility have an Emergency Operations/Response Plan that is coordinated with state and local emergency response organizations, regulatory authorities and local government officials. Water utilities ought to consider whether the actions contained within this guidance have been thoroughly coordinated with these entities.

The Federal Response Plan (section VI) identifies Federal responsibilities and capabilities that can support the local response effort dependent upon the type and severity of the incident. Throughout this guidance "water system" includes the "system" elements of source water (ground and surface), drinking water treatment, drinking water distribution and storage, wastewater collection and wastewater treatment.

Background:

The Environmental Protection Agency (EPA) has been given the responsibility under Presidential Decision Directive (PDD) 63 for working with the Water Sector (including water and wastewater utilities) to provide for the protection of the nation's critical water infrastructure including the systems used to collect, treat and distribute potable water. The EPA has a similar responsibility for wastewater operations. These critical infrastructures are fundamental to the public health and welfare and are subject to both natural disasters such as floods and earthquakes, and man-made hazards such as terrorist attacks. Such disasters could place surrounding areas and populations at significant risk. In October, 2001 the EPA established an internal Water Protection Task Force to ensure that activities to protect and secure water supply infrastructure are comprehensive and carried out expeditiously. This guidance supports the Task Force's mission of providing information in an expeditious manner to public and private water utilities that can be used to protect public health and critical water infrastructure.

I. Incident types

This guidance was developed for five (5) different incident types:

- Threat of or Actual Intentional Contamination of the Water System
- Threat of Contamination at a Major Event
- Notification from Health Officials of Potential Water Contamination
- Intrusion through the Supervisory Control and Data Acquisition (SCADA); and
- Significant Structural Damage Resulting from an Intentional Act

While this guidance is oriented toward these 5 incident types, it should also serve as a guide for response, recovery and remediation actions for other threatened or actual intentional acts that would affect the safety or security of the water system..

II. Development of the Guidance

Each incident type was assessed for potential impact on water system operations and public safety to identify the minimum actions for each element of the water system to consider taking in response to the incident, recover from the incident and to remediate the impacts of the incident. Response refers to actions immediately following awareness of the incident, recovery refers to actions to bring the system back into operation, and remediation refers to longer term restoration actions. Where applicable, each incident type was assessed as if it had occurred separately at each of the system elements and the potential impacts were assessed upstream and downstream of the incident location. Additionally, the guidance was developed considering the response needs of large, medium and small water and wastewater systems. Water utilities should apply the concepts contained in the guidance to meet their system configuration and capabilities.

III. Structure:

The guidance provides recommended actions in the categories of Response Actions, Recovery Actions, and Remediation Actions in separate tables for each incident type. Each of these categories contain a section on notifications and utility actions. Where applicable, specific actions for each element of the water system are provided under the utility actions section.

The Notification Considerations section recommends standard notifications for any suspicious or threatened intentional man-made or technological emergency. Supplemental notifications are recommended within the incident tables for some events based on the potential impact of the event.

Response Planning:

This response, recovery and remediation guidance to intentional acts can be used to supplement existing water utility emergency operations plans (EOPs) developed to prepare for and respond to natural disasters and emergencies. EPA recommends that established policies and procedures contained in existing plans be used to the maximum extent while incorporating the recommendations in this guidance.

A high quality water utility EOP clearly delineates the organizational structure within the water system that will be responsible for incident response and management. This structure should identify specific individual roles and responsibilities for decision-making, logistics, operations, incident response control and finance. The structure could be based on the Incident Command System, or other similar system, that is compatible with the system(s) used by other elements (Fire, Law Enforcement, Emergency Management, Emergency Medical Services (EMS), etc.) of the community's incident response and management structure. It would be helpful to coordinate potential response requirements and expectations with local response organizations prior to an incident to ensure that the water utility's response needs are met.

Notification Considerations:

Water utilities that have established notification procedures to meet a regulatory requirement, such as the Emergency Planning and Community Right-to-Know Act (EPCRA), should use them as the starting point for developing broader notification procedures. Utilities that do not have established notification procedures should work with their Local Emergency Planning

Committee (LEPC) or similar local emergency planning organization, prior to an incident, to coordinate the specific procedures for contacting local, state and federal officials when an incident occurs. You can find the LEPC for your location at http://www.epa.gov/ceppo/lepclist.htm.

EPA expects that the facility would first call local law enforcement officials to initiate local emergency response actions. This may be accomplished by calling 911 or direct call to local law enforcement. The local notification coordination effort should determine which additional emergency response and management agencies (fire, Emergency Medical Services (EMS), the community emergency management organization and state agencies) need to be notified. For instance, do fire and EMS need to be notified in addition to law enforcement for a water-related incident?

The notification procedures developed within the local notification coordination effort should provide agency-specific names and contact numbers for these notifications on a 24-hour basis and define what information about the incident needs to be provided, who will make the notifications and which authorities are notified when a call is placed. As a minimum, these notification procedures should include protocols for notifying local and state health and environmental authorities, local critical care facilities (hospitals, dialysis centers, etc.) and others as identified in state and local requirements.

An intentional act to disrupt the operations of a water utility or to jeopardize public health is a criminal act. This creates the need for notifications to the appropriate FBI field office, National Response Center and other entities that may not normally be contacted in response to a natural disaster or emergency. Water utilities should work with the LEPC or similar organization, in conjunction with appropriate state offices, to verify how these additional notification requirements will be met and who has responsibility for the notifications.

The procedures developed within the local notification coordination effort should ensure that all of the entities listed below are notified, identify who the utility must contact to initiate the notifications and identify who within the organization should make the notifications. These organizations are not listed in any particular order of preference.

- Notify local law enforcement
- Notify local FBI Field Office (to begin the threat assessment process) Your local FBI field Office can be located by visiting http://www.fbi.gov/contact/fo/info.htm or in the front pages of your local telephone book
- Notify National Response Center 1-800-424-8802 (to notify pre-determined federal response agencies) for more information on NRC see http://www.nrc.uscg.mil
- Notify state/local emergency management organization
- Notify Governor's office
- Notify local EPA CID Special Agent in Charge (SAC)
- Notify other associated system authorities (wastewater, water)
- Notify local government official (responsible authority for the water utility)
- Notify state/local health, water and/or environmental department
- Notify critical care facilities
- Notify employees
- Notify EMS and Fire Department as deemed necessary
- Consider when to notify customers and what notification to issue

The recommendations provided in this guidance are supplemental to regulatory or other promulgated reporting requirements. Normal reporting/notification to state health and/or environmental agencies, or the EPA for states without approved state programs, will still be required when the impacts of an incident result in an inability to meet Water Quality or National Primary Drinking Water Standards or to meet CERCLA and/or EPCRA requirements.

Sampling:

The results of sample analysis after a threatened or actual contamination event can serve a critical role in determining response, recovery and remediation actions; assessing the potential impacts of the contaminant; and, providing data for eventual prosecution. Sampling requirements (quantity, type of sample container, environmental controls, type of sample, sample locations, etc.) can vary significantly depending upon the properties of the contaminant and where the contaminant was introduced into the system. This guidance provides recommendations for when sampling might be beneficial but can not provide specific sampling requirements for every potential contaminant.

It is important to ensure that sampling is conducted by trained personnel and that the safety of sampling and other personnel is fully considered while conducting sampling activities. The diversity of sampling capabilities and resources among large and small water utilities makes it difficult to establish standard requirements for all water utilities. Water utilities should work with their LEPC and appropriate local, state and federal agencies to develop procedures for obtaining requirements or recommendations on taking samples, sample control, sample distribution and use of sample analysis results on an event-by-event basis. The water utility's sampling capabilities and procedures for obtaining sampling recommendations should be contained within the utility's EOP.

In the event of an incident that is suspected or confirmed to be the result of an intentional act to disrupt the operations of a water utility or to jeopardize public health, law enforcement officials may also require/take additional samples for evidence preservation.

Annexes:

Annex I provides a Sample Collection, Identification and Chain-of-Custody Form and instructions for its use. The form is an example of the information needed for recording data on samples taken in response to an intentional act and for maintaining a record for chain-of-custody of the sample.

Annex II provides incident-specific response, recovery and remediation guidance for each of the five (5) incident types.

$\label{lem:continuous} \textbf{Annex} \ \textbf{I} - \textbf{Sample Collection, Identification and Chain-of-Custody Form}$

Sample Collect	ion, Identificati	on and Chain-of-Cu	stody Form
Sample ID # (Place ID Label Here)		Sample Date/Time	
Sample Description		Sample Location	
Comments			
Sampler Signature	Date/Time	Witness Signature	Date/Time
Print	Sample ID	Print	Location
1. Released by: Signature	Date/Time	Received by: Signature	Date/Time Location
Print 2. Released by: Signature	Sample ID Date/Time	Print Received by: Signature	Date/Time
Print	Sample ID	Print	Location
3. Released by: Signature	Date/Time	Received by: Signature	Date/Time
Print	Sample ID	Print	Location
4. Released by: Signature	Date/Time	Received by: Signature	Date/Time
Print	Sample ID	Print	Location

Instructions for Sample Collection, Identification and Chain-of-Custody Form

Whether from an epidemiological or evidentiary standpoint, it is critically important that samples taken in response to an intentional act against a water system be taken in a systematic manner. Each sample collected should have a separate identifying number (Sample ID #) and the transfer of each sample should documented. The Sample Collection, Identification and Chain-of-Custody Form provides a standardized format for annotating this information.

Sample Identification Number (Sample ID #)

Each sample should have separate identification number. A uniform system should be established for assigning sample identification numbers.

Sample Date/Time

Annotate the date and time that the sample was taken.

Sample Description

Describe the type of sample taken (water, sludge, sediment basin, etc.)

Sample Location

Annotate as specifically as possible where the sample was taken so that later samples can be taken (if necessary) from the exact same location.

Comments

Provide any additional comments that may assist in sample analysis (water temperature, humidity, how sample was taken or materials used to take sample, etc.).

Sampler Identification

The person taking the sample should sign his/her name in the **Signature** block, annotate the date/time of signature in the **Date/Time** block, print the sampler's name in the **Print** block and annotate the sample ID number from the **Sample ID**# block at the top of the form.

Witness Identification

The person witnessing the taking of the sample should sign his/her name in the **Signature** block, annotate the date/time of signature in the **Date/Time** block, print the sampler's name in the **Print** block and annotate the location of where the sample was taken from the **Sample Location** block at the top of the form.

Chain-of-Custody Tracking

A record of control for all samples should be maintained. Each person who releases control of the sample should maintain a copy of who the sample was released to. Persons who receive samples should verify the sample identification number **ON THE SAMPLE** before signing for receipt of the sample. The original copy of the form, with original signatures should remain with each sample until final disposition.

The person releasing the sample should sign his/her name in the **Signature** block, annotate the date/time of release in the **Date/Time** block, print the releaser's name in the **Print** block and annotate the sample ID number from the **Sample ID**# block at the top of the form.

The person receiving the sample should sign his/her name in the **Signature** block, annotate the date/time of receipt in the **Date/Time** block, print the receiver's name in the **Print** block and annotate the location where the sample was received in the **Location** block.

Other Considerations

Photographs

When possible a photograph should be taken of each collected sample at the sample location. Ideally, the photograph would show the completed sample ID label and security seals in-place. Photographs should be annotated or dated-stamped with the date and time that the photo was taken.



April 15, 2002

I. Contamination Event: (Articulated Threat with Unspecified Material)

Event Description: This event is based on the threat of intentional introduction of a contaminant into the water system (at any point within the system) without specification of the contaminant by the perpetrator.

within the system) w	rithout specification of the	ne contaminant by the perp	etrator.	•	
Initial Notifications:	 Notify local Law Enforcement Notify local FBI Field Office Notify National Response Center 	 Notify local/state emergency management organization Notify ISAC 	 Notify other associated system authorities (wastewater, water) Notify local government official 	 Notify local/state health and/or environmental department Notify critical care facilities 	 Notify employees Consider when to notify customers and what notification to issue Notify Governor
	Source Water	Drinking Water Treatment Facility	Water Distribution / Storage	Wastewater Collection System	Wastewater Treatment Facility
RESPONSE ACTIONS	 Increase sampling at or near system intakes Consider whether to isolate the water source if possible 	 Preserve latest full battery background test as baseline Increase sampling efforts Consider whether to continue normal operations (if determination is made to reduce or stop water treatment – provide notification to customers/issue alerts) Coordinate alternative water supply 	Consider whether to isolate the water in the affected area if possible	Assess what to do with potentially contaminated water within the system based on contaminant, contaminant concentration, potential for system contamination, and ability to by-pass treatment plant. If by-passed-notify local & appropriate state authorities, & downstream users. Increase monitoring of receiving stream.	 Preserve latest full battery background test as baseline Increase sampling efforts Consider whether to continue normal operations (if determination is made to reduce or stop water treatment – provide notification to customers/issue alerts)

AGENCY AG	Water Utility Response, Recovery & Remediation Guidance for Man-made and/or Technological Emergencies I. Contamination Event: (Articulated Threat with Unspecified Material)					
RECOVERY ACTIONS	Recovery actions should begin once the con-	taminant is through the syste	em.			
Recovery Notifications:	Notify CustomersNotify MediaNotify ISAC					
Appropriate Utility Elements:	• Sample appropriate system elements (storage tanks, filters, sediment basins, solids handling) to determine if residual contamination exists.	 Flush system based on results of sampling Monitor health of employees 	 Plan for appropriate disposition of personal protection equipment (PPE) and other equipment 			
REMEDIATION ACTIONS	 Based on sampling results – assess need to remediate storage tanks, filters, sediment basins, solids handling. 	 Plan for appropriate disposition of PPE and other equipment 	 If waste water treatment plant was by-passed – sample and establish monitoring regime for receiving stream and potential remediation based on sampling results. 			

Notes:

1. Response, recovery and remediation actions may be tailored to a specified (identified) material if the physical properties for the material are known.



April 15, 2002

II. Contamination Threat at a Major Event

Event Description: This event is based on the threat of, or actual, intentional introduction of a contaminant into the water system at a sports arena, convention center or similar facility.

sports arena, convent	tion center or similar facil	lity.			
Initial Notifications:	 Notify local Law Enforcement Notify local FBI Field Office Notify National Response Center Notify ISAC 	 Notify local/state emergency management organization Notify wastewater facility Notify Governor 	 Notify other associated system authorities (wastewater, water) Notify local government official 	 Notify local/state health and/or environmental department Notify critical care facilities 	 Notify employees Consider when to notify customers and what notification to issue
	Source Water	Drinking Water Treatment Facility	Water Distribution / Storage	Wastewater Collection System	Wastewater Treatment Facility
RESPONSE ACTIONS	No recommended action to take	No recommended action to take	 Coordinate isolation of water Assist in plan for draining the contained water Assist in developing a plan for sampling water for potential contamination based on threat notification Provide alternate water source 	 Coordinate acceptance Monitor accepted wate Assist in plan for drainwater Assist in developing a water for potential conthreat notification 	r ning the contained

AGENO- STANGENO	Water Utility Response, Recove	ry & Remediation Guid nnological Emergencies		ade and/or	April 15, 2002		
Office And Action	or Event						
RECOVERY ACTIONS	Recovery actions should begin once to	Recovery actions should begin once the contaminant is through the system.					
Recovery Notifications:	 Notify customers in the area of the facility of actions to take Notify customers in affected area once contaminant-free clean water is re-established Notify down-stream users such as water suppliers, irrigators, electric generating plants, etc. 						
Water Distribution / Storage	• Consider flushing system via hydrants in distribution systems						
	Water Distribution/Storage	• Assess need to deco	ontaminate/replace of	distribution system comp	ponents.		
REMEDIATION ACTIONS:	Wastewater Treatment Plant	 Based on sampling results assess need to remediate storage tanks, filters, sediment basins, solids handling. 	 Plan for appropriate disposition of PPE and other equipment 	• If waste water treat by-passed – sample monitoring regime s stream and potentia based on sampling	and establish for receiving I remediation		

Notes:



April 15, 2002

III. Notification from Health Officials of Potential Water Contamination

Event Description: This event is based on the water utility being notified by Public Health officials of potential contamination based on symptoms of patients.

Initial **Notifications:**

• Ask notifying official who else has been notified and request information on symptoms. potential contaminants and potential area affected

Source Water

- Notify local Law Enforcement
- Notify local FBI Field Office
- Notify National Response Center
- Notify local/state emergency management organization

Drinking Water

• Notify other associated system authorities (wastewater, water)

Water Distribution

• Increase sampling in

the area potentially

locations where the

have migrated to. It is

important to consider

exposure and onset of

symptoms to select

contaminant could

the time between

affected and at

- Notify local government official
- Notify Governor

/ Storage

- Notify local/state health and/or environmental department
- Notify critical care facilities

Wastewater

- Notify employees
- Consider when to notify customers and what notification to issue
- Notify ISAC

Wastewater

• Increase sampling at or near system intakes • Consider whether

- to isolate
- Preserve latest full battery background test result as baseline

Treatment Facility

- Increase sampling efforts
- Consider whether to continue normal operations (if determination is to reduce or stop water treatment – provide notification to customers/issue alerts)

alternative water supply (if needed)

Coordinate

- sampling sites isolate
- Consider whether to • Consider whether to increase residual disinfectant levels

Collection System Treatment Facility • Increase sampling at pumps stations and specifically in the area potentially affected

- Assess what to do with potentially contaminated water within the system based on contaminant, contaminant concentration. potential for system contamination, and ability to by-pass treatment plant
- If by-passed notify local & appropriate state authorities, downstream users (especially drinking water treatment facilities) & increase monitoring of receiving stream

RESPONSE ACTIONS

A SENCY ASENCY		al Emergencies	Арги 15, 2002			
RECOVERY ACTIONS	III. Notification from Health Officials of Potential Water Contamination Recovery actions should begin once the contaminant is through the system.					
Recovery Notifications:	• Assist health department with notifications to customers, media, downstream users and other organizations					
Appropriate Utility Elements:	• Sample appropriate system elements (storage tanks, filters, sediment basins, solids handling) to determine if residual contamination exists.	 Flush system based on results of sampling Monitor health of employees 	 Plan for appropriate disposition of personal protection equipment (PPE) and other equipment 			
REMEDIATION ACTIONS	Based on sampling results – assess need to remediate storage tanks, filters, sediment basins, solids handling and drinking water distribution system	 Plan for appropriate disposition of PPE and other equipment 	• If waste water treatment plant was by-passed – sample and establish monitoring regime for receiving stream and potential remediation based on sampling results.			

Notes: Patient symptoms should be used to narrow the list of potential contaminants.



April 15, 2002

IV. Intrusion through Supervisory Control and Data Acquisition (SCADA)

Event Description: This event is based on internal or external intrusion of the SCADA system to disrupt normal water system operations.

Initial Notifications:

- Notify local Law Enforcement
- Notify local FBI Field Office
- Notify National Infrastructure Protection Center (NIPC) at 1-888-585-9078 (or 202-323-3204/5/6)
- Notify other associated system authorities (wastewater, water)
- Notify employees
- If the water is assessed to be unfit for consumption, consider when to notify customers and what notification to issue

	Source Water	Drinking Water Treatment Facility	Water Distribution / Storage	Wastewater Collection System	Wastewater Treatment Facility
RESPONSE ACTIONS	 Increase sampling at or near system intakes Consider whether to isolate 	 Preserve latest full battery background test as baseline Increase sampling efforts Temporarily shut down SCADA system and go to manual operation using established protocol Consider whether to shut down system and provide alternate water 	Monitor unmanned components (storage tanks & pumping stations) Consider whether to isolate	Temporarily shut down go to manual operation protocol Monitor unmanned con stations) – required only SCADA system is come if SCADA intrusion can improperly treated water continue normal operations made to reduce or steprovide notification to one in the system.	nponents (pumping y if wastewater promised used release of er consider whether to ions (if determination op water treatment –

AGEN ON STATES	·	esponse, Recovery & Remediat Technological Eme sion through Supervisor	rgencies		April 15, 2002 SCADA)
RECOVERY ACTIONS	Recovery actions shoccurs) is through the	ould begin once the intrusion has be system.	peen eliminated an	d the contaminant/unsafe water	(if this
Recovery Notifications:	EmployeesLocal law enforcemNotify customers at notifications were n	nd media if the event resulted in co	ontamination and t	he full range (see scenario I) of	standard
Appropriate Utility Elements:	With FBI assistance, make an image copy of all system logs to preserve evidence.	With FBI assistance, check for in backdoors and other malicious c eliminate them before re-starting system	code and	 Install safeguards before re SCADA Bring SCADA system up an 	C
REMEDIATION ACTIONS	 Assess/implement additional protections for SCADA system. Check for an NIPC water sector warning based on the intrusion that may contain additional protective actions to be considered. NIPC warnings can be found at www.nIPC.gov or at https://www.infragard.org for secure access Infragard members. 				

Notes:



April 15, 2002

V. Significant Structural Damage Resulting from an Intentional Act

Event Description: The	nis event is based on intent	Event Description: This event is based on intentional structural damage to water system components to disrupt normal system operations.						
Initial Notifications:	 Notify local Law Enforcement Notify local FBI Field Office Notify National Response Center 	 Notify local/state emergency management organization Notify Governor Notify ISAC 	 Notify other associated system authorities (wastewater, water) Notify local government officials 	 Notify local/state health and/or environmental department Notify critical care facilities 	 Notify employees Consider when to notify customers and what notification to issue 			
	Source Water	Drinking Water Treatment System	Water Distribution / Storage	Wastewater Collection System	Wastewater Treatment Facility			
RESPONSE ACTIONS	 Deploy damage assessment teams, if damage appears to be intentional then treat as crime scene – Consult local/state law enforcement and FBI on evidence preservation Inform law enforcement and FBI of potential hazardous materials Coordinate alternative water supply, as needed Consider increasing security measures Based on extent of damage, consider alternate (interim) treatment schemes to maintain at least some level of treatment 							
RECOVERY ACTIONS	Recovery actions should begin as soon as practical after damaged facility is isolated from the rest of the utility facilities.							
Recovery Notifications:	 Employees Law enforcement Notify local FBI office 							
Appropriate Utility Elements:	• Dependent on the feedback from damage assessment teams • Implement damage recovery plan							
REMEDIATION ACTIONS	• Repair damage. • Assess need for additional protection/security measures for damaged facility, and other critical facilities within the utility.				="			

Notes: