

Truck Carrier Partner 2.0.14 Tool: Quick Start Guide 2014 Data Year - United States Version





Truck Carrier Partner 2.0.14 Tool: Quick Start Guide 2014 Data Year - United States Version

Transportation and Climate Division
Office of Transportation and Air Quality
U.S. Environmental Protection Agency



Office of Transportation and Air Quality
EPA-420-B-15-001
January 2015

Table of Contents

OVERVIEW	5
SECTION 1—BASIC INFORMATION FOR TRUCK CARRIERS	6
WHAT IS THE SMARTWAY TRANSPORT PARTNERSHIP?.....	6
WHY DO TRUCK CARRIERS JOIN THE SMARTWAY TRANSPORT PARTNERSHIP?.....	6
HOW DO TRUCK CARRIERS JOIN THE SMARTWAY TRANSPORT PARTNERSHIP?.....	7
HOW DO I JOIN IF MY PARENT COMPANY HAS MULTIPLE FLEETS?.....	7
WHAT DATA DO I NEED TO GATHER TO COMPLETE THE TRUCK CARRIER TOOL?.....	8
WHAT IS INCLUDED IN THE SMARTWAY TRUCK CARRIER PARTNERSHIP AGREEMENT?.....	9
WHAT SOFTWARE AND HARDWARE IS REQUIRED FOR COMPLETING THE SMARTWAY TRUCK CARRIER PARTNER TOOL?.....	10
SECTION 2— OVERVIEW OF DATA COLLECTION REQUIREMENTS	11
DATA REQUIREMENTS FOR INTRODUCTORY SCREENS.....	11
DATA REQUIREMENTS FOR PROVIDING US/CANADA OPERATIONS INFORMATION.....	11
DATA REQUIREMENTS FOR ESTABLISHING YOUR DATA COLLECTION YEAR.....	11
DATA REQUIREMENTS FOR SECTION 1: SPECIFY OFFICIAL PARTNER NAME.....	12
DATA REQUIREMENTS FOR SECTION 2: ENTER CONTACT INFORMATION.....	12
DATA REQUIREMENTS FOR SECTION 3: CHARACTERIZE YOUR FLEETS.....	13
DATA REQUIREMENTS FOR SECTION 4: FLEET DATA.....	14
SECTION 3—STEP BY STEP INSTRUCTIONS FOR DATA ENTRY	16
DOWNLOADING THE SMARTWAY TRUCK CARRIER TOOL.....	16
HOW TO SET SECURITY LEVELS FOR THE SMARTWAY TOOLS.....	16
STEPS FOR ENTERING PARTNER NAME.....	17
STEPS FOR ENTERING CONTACT INFORMATION:.....	17
STEPS FOR COMPLETING “IDENTIFY FLEETS” SCREEN:.....	18
STEPS FOR COMPLETING “FLEET DETAILS” SCREEN.....	19
STEPS FOR COMPLETING “OPERATION CATEGORIES” SCREEN:.....	19
STEPS FOR COMPLETING “BODY TYPES” SCREEN:.....	19
STEPS FOR SELECTING A FLEET TO REVIEW:.....	20
STEPS FOR COMPLETING “GENERAL INFORMATION” SCREEN.....	20
STEPS FOR COMPLETING THE “ENGINE MODEL YEAR & CLASS” SCREEN.....	21
STEPS FOR COMPLETING THE FUEL DATA POINTS ON “ACTIVITY INFORMATION” SCREEN.....	21
STEPS FOR COMPLETING THE “FUEL ALLOCATOR WORKSHEET”.....	22
STEPS FOR COMPLETING THE “BIODIESEL BLEND WORKSHEET ”.....	22
STEPS FOR COMPLETING THE “ETHANOL BLEND WORKSHEET ”.....	22
STEPS FOR COMPLETING THE PAYLOAD SECTION ON THE “ACTIVITY INFORMATION” SCREEN.....	23
STEPS FOR COMPLETING AVERAGE CAPACITY VOLUME (CUBIC FEET) SECTION ON THE “ACTIVITY INFORMATION” SCREEN.....	24
STEPS FOR COMPLETING THE % CAPACITY UTILIZATION SECTION ON THE “ACTIVITY INFORMATION” SCREEN.....	25
STEPS FOR COMPLETING THE ROAD TYPE / SPEED CATEGORY SECTION ON THE “ACTIVITY INFORMATION” SCREEN.....	25

STEPS FOR COMPLETING THE AVERAGE ANNUAL IDLE HOURS PER TRUCK SECTION ON THE “ACTIVITY INFORMATION” SCREEN.....	25
STEPS FOR COMPLETING THE “PM REDUCTION” SCREEN.....	27
OPTIONAL STEPS—YEAR TO YEAR COMPARISONS, VIEW REPORTS, AND PROVIDE ADDITIONAL INFORMATION.....	27
STEPS FOR SUBMITTING YOUR TOOL TO EPA.....	28
APPENDIX A: RECOMMENDED DATA SOURCES FOR ACTIVITY DATA	29
APPENDIX B: WORKSHEETS FOR DATA COLLECTION.....	33
WORKSHEET #1: US/CANADA OPERATION INFORMATION	34
WORKSHEET #2: CONTACT INFORMATION.....	35
WORKSHEET #3: FLEET CHARACTERIZATION	36
WORKSHEET #4: GENERAL FLEET INFORMATION (PAGE 1 OF 2)	37
WORKSHEET #4: GENERAL FLEET INFORMATION (PAGE 2 OF 2).....	38
WORKSHEET #5A MODEL YEAR/CLASS.....	40
WORKSHEET #5B: ACTIVITY DATA SOURCES AND INFORMATION (PAGE 1 OF 2).....	43
WORKSHEET #5B: ACTIVITY DATA SOURCES AND INFORMATION (PAGE 2 OF 2).....	44
WORKSHEET #5C: ACTIVITY - BIODIESEL AND ETHANOL BLENDS (IF APPLICABLE).....	45
WORKSHEET #5D: PAYLOAD AND VOLUME (PAGE 1 OF 12)	46
<i>Class 2b—Worksheet #5D: Payload and Volume (page 2 of 12).....</i>	<i>47</i>
<i>Class 3—Worksheet #5D: Payload and Volume (page 3 of 12).....</i>	<i>48</i>
<i>Class 4—Worksheet #5D: Payload and Volume (page 4 of 12).....</i>	<i>49</i>
<i>Class 5—Worksheet #5D: Payload and Volume (page 5 of 12).....</i>	<i>50</i>
<i>Class 6—Worksheet #5D: Payload and Volume (page 6 of 12).....</i>	<i>51</i>
<i>Class 7 Straight Trucks—Worksheet #5D: Payload and Volume (page 7 of 12).....</i>	<i>52</i>
<i>Class 7 Combination Trucks—Worksheet #5D: Payload and Volume (page 8 of 12).....</i>	<i>53</i>
<i>Class 8a Straight Trucks—Worksheet #5D: Payload and Volume (page 9 of 12).....</i>	<i>54</i>
<i>Class 8a Combination Trucks—Worksheet #5D: Payload and Volume (page 10 of 12).....</i>	<i>55</i>
<i>Class 8b Combination Trucks—Worksheet #5D: Payload and Volume (page 11 of 12).....</i>	<i>56</i>
<i>Volume—Worksheet #5D: Payload and Volume (page 12 of 12)</i>	<i>57</i>
<i>Worksheet #5E: Road Type/Speed Distribution and Idle Hours Worksheet.....</i>	<i>58</i>
<i>Worksheet #5F: Diesel PM Worksheet.....</i>	<i>59</i>
<i>Worksheet #5G: Port Drayage Program Data Requirements</i>	<i>60</i>

Overview


In this guide you will learn about:

- 1) SmartWay Basic Information
- 2) Joining SmartWay Transport Partnership as a truck carrier
- 3) Understanding the details of the SmartWay Partnership Agreement
- 4) Meeting software/hardware requirements for participating in the program
- 5) Gathering the data necessary for participation in SmartWay.

Please review this guide carefully **BEFORE** attempting to gather your company data, or enter data into the **Truck Carrier Tool**. Understanding the basics of the program will simplify your SmartWay experience.

WARNING:

*****Before beginning, use this chart to make sure you are choosing the right tool for your operations! *****



If none of the above statements is applicable, contact EPA SmartWay at 734-214-4647 for assistance.

Section 1—Basic Information for Truck Carriers

This section covers frequently asked questions and essential information about the SmartWay Transport Partnership and how truck carriers can participate.

WHAT IS THE SMARTWAY TRANSPORT PARTNERSHIP?

Launched in 2003, the SmartWay Transport Partnership is a public/private collaboration between the EPA and the freight industry to improve fuel efficiency, increase environmental performance, and encourage supply chain sustainability.

Five types of freight transport companies can join SmartWay.

- Freight shippers
- Logistics companies (including 3PLs/4PLs¹)
- Truck carriers
- Rail carriers
- Barge carriers
- Multi-modal carriers

Companies join the SmartWay Transport Partnership by submitting a Partner Tool to SmartWay. The SmartWay Tools (1) assess freight operations; (2) calculate fuel consumption and carbon footprints; and (3) track fuel-efficiency and emission reductions. SmartWay Tools must be submitted each year for the company to remain a Partner in good standing. Tools submitted and approved on time qualify partners to use the SmartWay Logo.

SmartWay ranks Partners' efficiency and environmental performance and recognizes superior performance through the SmartWay Excellence Awards.

WHY DO TRUCK CARRIERS JOIN THE SMARTWAY TRANSPORT PARTNERSHIP?

The SmartWay Transport Partnership provides truck carriers with ways to reduce the environmental impact of their freight operations and address costs. Designed with and for the freight sector, the SmartWay Transport Partnership delivers solutions to marketplace needs and challenges. With access to the latest in EPA-tested technologies and peer-provided success stories, carriers that join the SmartWay Transport Partnership can gain a better understanding of their environmental footprint and assert their corporate leadership.

Additionally, SmartWay Partners are associated with an internationally recognized and respected brand that symbolizes cleaner, more efficient transportation choices.

¹ 3PLs/4PLs Third party logistics/fourth-party logistics companies.

HOW DO TRUCK CARRIERS JOIN THE SMARTWAY TRANSPORT PARTNERSHIP?

Truck Carriers join SmartWay by submitting a SmartWay Truck Carrier Tool (hereafter known as the “Truck Carrier Tool.”)

Truck Carriers that submit tools that are approved by EPA are known as “SmartWay Truck Carrier Partners.”

When a truck carrier submits a Truck Carrier Tool to EPA, they agree to the requirements stipulated in the SmartWay Truck Carrier Partnership Agreement--notably, that they will measure and report the emissions performance of their company *annually* and provide supporting documentation to EPA upon request.

All SmartWay Truck Carrier Partners agree to complete and submit the SmartWay Truck Carrier Tool to:

- define company composition
- characterize company activity
- individually benchmark fleets
- track annual changes in performance.

Upon approval of a Truck Carrier Tool submission, truck carriers will be identified as SmartWay Truck Carriers Partners on EPA’s website on the SmartWay Partner List and in a database used to identify companies that meet SmartWay’s annual requirements.

HOW DO I JOIN IF MY PARENT COMPANY HAS MULTIPLE FLEETS?

Companies that join the SmartWay Partnership should include all of their fleets and trucks in their submission. If a company wishes to list multiple fleets in the Truck Carrier Tool, they should list these fleets as their customers can hire them. Internal fleets invisible to a customer should not be listed separately. Companies will be listed at the Company level in the SmartWay Partner list on the SmartWay website, and each individually defined fleet will appear as a separate entity in the SmartWay Carrier Data file that customers use to identify which fleets they do business with in the Shipper and/or Logistics Tools.

SmartWay highly recommends developing your list of fleets before beginning your data entry process. Any fleet that a shipper or logistics company could hire directly should be listed as a separate fleet in your Truck Carrier Tool submission.

The best strategy is to have a clear idea of how to define your companies before filling out the Tool.

WHAT DATA DO I NEED TO GATHER TO COMPLETE THE TRUCK CARRIER TOOL?

To participate in SmartWay, truck carriers need to gather the following essential information to complete the Truck Carrier Tool:

- The official company name EXACTLY as you would like it presented on the EPA website
- Company contact information
- Contact details for your Working Contact
- Contact details for an Executive and/or Other Contact(s) (cannot be the same as the Working Contact)
- Split between US/Canada operations
- Quarterly IFTA statements² (for activity data) for the reporting calendar year
- Fleet details for all fleets you control:
 - SCACs, MCNs, and/or DOT number information
 - Total inventory of vehicles in your fleet(s), sorted by vehicle class and engine model year, body type, and operational category for the reporting calendar year
 - Total miles, revenue miles and empty miles
 - Total diesel, biodiesel and/or other fuel use by class
 - Reefer fuel use by class (if applicable)
 - Average payload, average capacity volume, and percent capacity utilization by class
 - Average idle hours per truck
 - Use of particulate matter control equipment by truck class and engine model year (if applicable)
- Data sources for all data to be entered
- SmartWay ID number (if this is not your first tool submission)

This data must be provided for all of your company's fleets. This data reflects the amount of freight carried by each carrier, the distance that freight is carried, and the fuel consumed to carry the freight.

² If applicable – for Class 7, 8a and 8b trucks only.

WHAT IS INCLUDED IN THE SMARTWAY TRUCK CARRIER PARTNERSHIP AGREEMENT?

To join the SmartWay Transport Partnership as a truck carrier, you must agree to the language on the “Partnership Agreement for Truck Carriers.” When you begin working within the Tool, you will be asked to check a box stating that you agree to the terms of the Partnership Agreement. **This agreement must be renewed annually.**

Please review this language with the appropriate personnel within your organization before completing or submitting a Tool to EPA.

Partnership Agreement for Carriers

With this agreement, your company joins EPA’s SmartWay Transport Partnership and commits to:

1. Measure and report to EPA on an annual basis the environmental performance of your fleet(s) using EPA’s SmartWay Truck tool. (Existing fleets must report the 12 months of data for the prior year ending December 31. Newly formed companies require a minimum of 3 months of operational data.)
2. Have performance results posted on the EPA SmartWay website/database.
3. Agree to submit supporting documentation to EPA for any data used to complete this Tool and agree to EPA audit of this data upon request by EPA.

In return, EPA commits to:

1. Promote company participation in the Partnership by posting Partner names on the EPA SmartWay Website and in related educational, promotional, and media materials. EPA will obtain express written consent from the Partner before using the Partner’s name other than in the context of increasing public awareness of its participation as described here.
2. Provide companies with industry-wide performance benchmark data as this data becomes available to EPA.³
3. Assist Partners in achieving emission and fuel usage reduction goals (subject to Federal Government Appropriations).

General Terms

1. If the Partner or EPA defaults upon this agreement at any point, the agreement shall be considered null and void.
2. Either party can terminate the agreement at any time without prior notification or penalties or any further obligation.
3. EPA agrees not to comment publicly regarding the withdrawal of specific partners.
4. EPA reserves the right to suspend or revoke Partner status for any Partner that fails to accomplish the specific actions to which it committed in the SmartWay Transport Partnership Agreement and subsequent annual Agreements.
5. The Partner agrees that it will not claim or imply that its participation in the SmartWay Transport Partnership constitutes EPA approval or endorsement of anything other than the Partner’s commitment to the program. The Partner will not make statements or imply that EPA endorses the purchase or sale of the Partner’s products and services or the views of the organization.
6. Submittal of this SmartWay Truck Tool annually constitutes agreement to all terms in this Partnership Agreement. No separate agreement need be submitted.

³ Individual corporate data will be treated as sensitive business information.

WHAT SOFTWARE AND HARDWARE IS REQUIRED FOR COMPLETING THE SMARTWAY TRUCK CARRIER PARTNER TOOL?

The Truck Carrier Tool was designed in “Microsoft Excel Forms.” Completing the Truck Carrier Tool requires the following software and hardware:

- A 2003 or later version of Microsoft Excel
- Excel security level set at Medium or lower
- A PC running Windows XP or newer operating system, or a Mac that is running the Windows XP operating system (The Tool does not currently work using the Mac operating system)
- A minimum of 10 megabytes of free disk space. More disk space may be required based on the number of companies you define in your Tool
- Adequate memory (RAM) to run Microsoft Office
- A monitor resolution of at least 1,024 x 768

NOTE: The Excel web application in MS Office 365 (the cloud-based version of the Office operating system) does not currently support the macros used in the SmartWay tools. Therefore SmartWay tools do no function properly in Office 365 at this time.

Please check with the user guides for your computer, online support, or your company’s IT department to make sure your system is set up to use the Truck Carrier Tool.

We encourage you to make sure that you virus software is up to date, and scan your PC before putting data in the Truck Carrier Tool.

Section 2— Overview of Data Collection Requirements

This section will explore the data needed for completing the required sections of the Truck Carrier Tool. **The Truck Carrier Tool Data Entry and Troubleshooting Guide** explains more about the structure of the Tool and the data entry process; this guide will focus primarily on the essentials for completing the Tool.

DATA REQUIREMENTS FOR INTRODUCTORY SCREENS

There are five screens which orient you to the Tool, the Introduction, the Partnership Agreement, Tool selection guidance, data collection needs, and the SmartWay Partner Schedule for 2015. These are general information screens; however, note that you **MUST** click the box indicating that you agree to the terms of the Partnership Agreement before moving on to the next screen.

DATA REQUIREMENTS FOR PROVIDING US/CANADA OPERATIONS INFORMATION

To begin, you must indicate your company's percent operation in the U.S. and Canada. Acceptable metrics include miles, fuel consumption, or any reasonable quantitative means of allotting the approximate percentage of operations in the two countries.

DATA REQUIREMENTS FOR ESTABLISHING YOUR DATA COLLECTION YEAR

Before beginning your data collection, identify the last calendar year for which you have full annual (12 months) data. This means that you have data from January of the calendar year through December of the same year. If you are submitting for the first time and do not have a full year of operational data, please collect **a minimum of three months' data** for input into the SmartWay Tool. In your next update year, you will be required to submit a full year's data.

DATA REQUIREMENTS FOR SECTION 1: SPECIFY OFFICIAL PARTNER NAME

Your Partner Name is the official name that your customers would recognize for your company—in other words, the name someone hiring you would look for.

You must specify your company's official Partner Name, exactly as you want it to appear on the SmartWay website.

For example, if you enter:

- ABC Company
- ABC Company, Inc.
- ABC COMPANY LLC

Your company will be listed ***exactly*** as you've entered above. Therefore, it is important to pay special attention to proper capitalization, abbreviations, annotations, and punctuation.

DATA REQUIREMENTS FOR SECTION 2: ENTER CONTACT INFORMATION

The SmartWay Tool asks for:

- **General company information** such as location, web address, phone number, etc.
- **A Working Contact**⁴ for any questions about your company's participation and Tool submissions
- **An Executive Contact**⁵ for participation in awards and recognition events
- **Additional contacts (optional)**: Additional contacts may include anyone who is not the Working contact but may be involved with SmartWay (e.g., press/media contact, fleet manager, etc.).

Note that you **MUST** have at least two contacts listed in the contact information section of the Tool, and the Working and Executive Contacts must be different. SmartWay recommends developing an internal succession plan to make sure that your Truck Carrier Tool submission schedule is maintained, in the event that a Working Contact is reassigned, or leaves the company for any reason.

⁴ The Working Contact is the individual designated by the Executive Contact to directly interface with SmartWay regarding specific tasks involved in the timely submission of the Tool. The Working Contact is responsible for coordinating the assembly of information to complete/update company data; completing and updating the Tool itself; maintaining direct communication with SmartWay; and keeping interested parties within the company apprised of relevant developments with SmartWay.) NOTE: To ensure that emails from SmartWay/EPA are not blocked, new Working contacts may need to add SmartWay/EPA to their preferred list of trusted sources.)

⁵ The Executive Contact is the company executive who is responsible for agreeing to the requirements in the SmartWay Partnership Agreement, overseeing the Working Contact (as appropriate), and ensuring the timely submission of the Tool to SmartWay. The Executive Contact also represents the company at awards/recognition events. This person should be a Vice President or higher-level representative for the company.

DATA REQUIREMENTS FOR SECTION 3: CHARACTERIZE YOUR FLEETS

The Truck Carrier Tool tracks fleet-level operations. Most carriers should create one fleet i.e., one line.

However, if you have multiple fleets that can be hired by customers individually, you should create multiple fleet records in the Tool and characterize their operations individually. You should not include internal company fleet definitions or designations—only separate fleets as they would be identified and hired by your customers.

There are five screens in the **Fleet Characterization** section of the Tool:

- **Identify Fleets:** For each fleet that a customer can hire, you will be asked to establish names for each of your fleets. Each fleet name will begin with your Partner Name, and will include a fleet identifier. Use a fleet identifier that is recognizable by your customers.
- **Fleet Details:** You will need to confirm control of the fleet. **“Control” means that you operate/route the vehicles, regardless of ownership status, and you must confirm that you have at least 95% control of the fleet to include it in the SmartWay Truck Carrier Tool.** You will also be asked to provide SCACS, MCN, or DOT numbers (for fleet identification), define the fleet as “for-hire” or “private,” and identify a point of contact for the fleet.
- **Operation Categories:** You will need to provide a reasonable estimate of the fleet’s split between truckload, less-than-truckload, drayage, package delivery, and expedited operations.
- **Body Types:** You will need to provide a reasonable estimate of the fleet’s split between the following body types:
 - Dry van
 - Refrigerated (Reefer)⁶
 - Flatbed
 - Tanker
 - Intermodal chassis containers (pooled and owned)
 - Heavy/Bulk hauler
 - Auto carriers
 - Moving
 - Utility⁷
 - Special hauler (e.g., Hopper, Livestock, and other specialized carriers)
- **SmartWay Category:** The SmartWay Category designation for each of your fleets will be shown on the fifth screen, based on your selections on the **Operation** and **Body Type** screens. For example, SmartWay Categories include Truckload/Dry Van, LTL, Mixed, etc. Your fleet’s performance will be measured against other carriers with the same category designation, so please ensure you have characterized your fleet correctly before proceeding.

⁶ If you specify reefer body types in your fleet you must also provide your estimated reefer fuel use in the Activity section of the Tool.

⁷ The Utility category encompasses class 2b to 8b vehicles that do not carry typical commercial freight. Examples include garbage, recycle, service, work, dump, landscape, cement, bucket, boom, ambulance, armored, fire, farm, wrecker and other similar trucks. Because these trucks do not carry traditional freight payload, the user should self-define their payloads so as to make the emissions per payload efficiency useful to the user. SmartWay will not use the emissions per payload results for the utility category. Users may experience yellow or red warning labels on the Activity screen due to the unique nature of Utility “payload.” In the case of red alerts, simply input text defining your special conditions in the required text boxes that appear.

DATA REQUIREMENTS FOR SECTION 4: FLEET DATA

In Section 4 of the Truck Carrier Tool, you will enter **detailed activity and fuel consumption data** for each of the fleets you identified and characterized in Section 3.

General Information Screen Requirements

This screen asks you to provide information for six key indicators, including fuel types used.

The first section asks you to determine your short-haul split vs. long-haul split. This requires you to estimate the percentage of your fleet's operations that are short haul or long haul. A short haul is defined as any haul less than 200 miles; a long haul is defined as any haul in excess of 200 miles. Percentages should be reasonable estimates.

Next, you must select the fuel types found in this fleet. This requires you to define all fuels the fleet used from a list of:

- a. **Diesel/biodiesel:** petroleum diesel and/or biodiesel made from any renewable feedstock
- b. **Gasoline/Ethanol:** conventional and reformulated gasoline, including blends of 10% ethanol(E10) and 85% ethanol (E85)
- c. **Liquefied Petroleum Gas (LPG):** also know as LP Gas, Liquid Propane Gas, and propane
- d. **Liquefied Natural Gas (LNG)**
- e. **Compressed Natural Gas (CNG)**
- f. **Electric:** vehicles exclusively using battery electric power
- g. **Hybrid:** vehicles with hybrid electric or hydraulic hybrid powertrains, using either gasoline or diesel

NOTE: Once you check these boxes, the appropriate fuel type tab (along the top of the screen next to the **General Information** tab) will become active. **You will need to complete additional screens for each fuel type you select.**

You will be asked to determine whether you will need to enter data for Particulate Matter Reduction. Check the Particulate Matter Reduction box only if you have truck engines that are model year 2006 or earlier and are equipped with diesel retrofit particulate matter control devices (i.e., diesel oxidation catalysts (DOCs), particulate filters, or closed crankcase ventilation (CCV)).

Next you will be asked to determine what is known as your "Cube-Out" Percentage. Your "cube out" percentage is the percentage of truckloads using 100% of their available cargo capacity while remaining within allowable weight limits. **You must provide a reasonable estimate.**

Next you will go to the View/Select Commodities button to view a list of potential shipment types and select all of the ones that you move with this fleet.

You also have the option of choosing to participate in SmartWay's Port Dray Program. Appendix A to the Truck Carrier Tool Data Entry and Troubleshooting Guide provides the data entry requirements for participation in this program, as well as details regarding Dray Program Scoring.

Fuel-Specific Sections: Engine Model Year and Class, and Activity Information Screens

This section looks at truck classes and engine model years. Under each fuel-type tab (Diesel, Gasoline, LPG, LNG, CNG, Electric, and Hybrid) there are as many as four screens requiring data inputs:

1. the **Engine Model Year & Class**⁸ screen
2. the **Activity Information** screen
3. the **PM Reduction** screen will appear for diesel vehicles if you checked the **Particulate Matter Reduction** box on the **General Information** screen
4. the **Port Dray Program** screen will also appear for diesel vehicles if you checked the **Port Dray Program** box on the **General Information** screen.⁹

To complete these screens, you will need to know

- the number of trucks in each fleet split out by engine model year and truck class.
- total miles by vehicle class
- revenue miles by vehicle class
- empty miles by vehicle class
- gallons of fuel used by vehicle class (or kWhrs for electric trucks)
- payload information by class and body type (if available; if not, use the Payload Calculator defaults)
- average capacity volume by body type and truck class for straight trucks (if available; if not, use the Volume Calculator defaults) or by trailer/container type for combination trucks
- road type/speed category splits by truck class
- average idling hours (short duration and extended) per truck for all classes
- the number of trucks by class and engine model year for which you are using particulate matter retrofit control devices

⁸ For electric trucks, this screen is known as the “Motor Model Year and Class Screen”.

⁹ The Port Dray Program box will only appear if your fleet is predominantly defined as Dray – i.e., defined as greater than or equal to 75% Dray on the Operations Screen under Fleet Characterization.

Section 3—Step by Step Instructions for Data Entry

DOWNLOADING THE SMARTWAY TRUCK CARRIER TOOL

To download the Truck Carrier Tool, visit: <http://www.epa.gov/smartway/forcarriers/index.htm>. Save the Tool in a folder on your hard drive; this folder will house copies of your data and future updates.

HOW TO SET SECURITY LEVELS FOR THE SMARTWAY TOOLS








In some cases, Microsoft Excel will ask you to adjust your security settings before opening the Tool. Instructions should appear on your screen *if* you need to change your security settings before running the Tool. The instructions differ depending upon what version of Excel you use (Excel 2003, 2007, 2010, or 2013).

If you need additional assistance with your security settings, download the guidance document labeled “Truck Carrier Partner 2.0.14 Tool: Data Entry and Troubleshooting Guide.2014 Data Year—United States Version” from <http://www.epa.gov/smartway/forcarriers/index.htm> and review the screen-by-screen guidance in Part 1: Downloading and Setting Up the Tool.

STEPS FOR ENTERING PARTNER NAME


1. Type your Partner Name EXACTLY as you would like it to appear on the SmartWay website in the field as indicated.
2. Proceed to Section 2 to enter contact information.

STEPS FOR ENTERING CONTACT INFORMATION:

1. **Enter the Partner Information details** in Section 1 of the **Contact Information** screen.
2. **Enter Working Contact details** in Section 2. If the Working Contact's address is the same as the company, you can select the  button to automatically fill in the address section of this record.
3. **Enter the Executive Contact details** in Section #3 by selecting the  button to the right; enter the required data. Note that you MUST have at least two different contacts on the **Contact Information** screen and the Working and Executive Contacts must be different.
4. **Enter Other Contacts** (if applicable) in Section 4 by selecting the  button. A new contact field will appear, labeled **Other Contact Information**. Enter the first Other Contact then select **OK** when done. You can add more contacts by selecting "Add New Contact" again. If you wish to edit an existing contact's information, highlight the name you wish to edit and then select the  button. You can remove an existing contact by highlighting the contact and then selecting the  button.
5. Select  at the bottom of the screen. If any information is missing, a dialogue box will appear informing you what additional information is required.
6. When finished, select the  button to return to the **Home** screen and proceed to Section 3.


STEPS FOR COMPLETING “IDENTIFY FLEETS” SCREEN:

1. On the **Home** screen, select the **Characterize your Fleets** button to display the **Fleet Characterization** screens.
2. Confirm that the Fleet (Partner Name) that appears automatically is correct and appropriate for your fleets. If not, make changes in the field under the heading “Fleet (Partner Name).”
3. Enter the “Fleet Identifier” for your first (or only) fleet. This field may be left blank if you only have one fleet. In this case your final Fleet Name will simply be your Partner Name.
4. Enter additional fleets as needed:
 - a. To enter another fleet, select the **Add Another Fleet** button.
 - b. To delete a fleet, select the box next to the row you wish to delete, and then select the **Delete Checked Rows** button.
 - c. Once you have confirmed or modified the Partner Name and specified the Fleet Identifiers, the full Fleet Names will be displayed on the screen to the right, exactly how they will be displayed on the SmartWay website.
5. To proceed, select the **Fleet Details** tab at the top, or simply select the **NEXT** button at the bottom of the screen.
6. Before moving on, a popup screen will appear asking you to verify that you are satisfied with your fleet name(s).




7. **Verify that the fleet name(s) show exactly what you want customers to find in the SmartWay website and Carrier Data File.**
8. Select **OK** to proceed to the next screen. You may return to this screen later to revise your fleet name(s) if necessary.

STEPS FOR COMPLETING “FLEET DETAILS” SCREEN


1. For each fleet, if you control over 95% of the operation of the vehicles (weighted by miles) check the box labeled “95+% Control.”
2. Enter SCAC, MCN, and/or DOT identifiers (optional) for each fleet listed. If you have a single fleet that has multiple SCACs, enter all of them into the SCAC field, and separate them with commas.
 - While it is not required to enter SCAC, MCN, or DOT information for each fleet, it will help shippers and logistics companies searching by those parameters in the SmartWay database to easily find your fleet for inclusion in their Tool.
3. Select your Fleet Type (either “For-Hire,” “Private,” or “Dedicated”) for each fleet listed.
4. Select a Fleet Contact from the drop-down menu for each fleet listed. If the appropriate fleet contact is *not* listed, go back to the **Contact Information** screen (see Section 2), and enter that name under “Other Contacts.” Then return to this screen to add the name from the drop-down menu.
5. Click the  button or select the Operation Categories tab at the top to proceed to the next section.



STEPS FOR COMPLETING “OPERATION CATEGORIES” SCREEN:

1. For each fleet identified, estimate the percentage of mileage each fleet spends in the five defined operation categories and enter your estimates in the fields provided. Leave the field blank if no mileage is associated with that operation category for that fleet.
2. Click the  button or select the Body Types tab at the top to proceed to the next section.

STEPS FOR COMPLETING “BODY TYPES” SCREEN:

1. For each fleet, enter an estimate of the percentage of fleet mileage associated with each body type. The percentages specified can be approximate, based on vehicle populations. The percentages for each fleet must sum to 100%.





NOTE: If you specify activity for Special Haulers, a  button will appear next to the cell entry. You must select this button and provide a text description of your specialty haulers.

2. Once you are sure your information is input correctly, you may select the  button at the bottom of the page. You will be prompted then to confirm that you have identified all of your fleets. Return to the Identify Fleets screen if needed, otherwise select  and you will automatically be returned to the **Home** screen.

STEPS FOR SELECTING A FLEET TO REVIEW:

1. Using your mouse, on the **Home** screen select and highlight the name of the fleet for which you wish to enter data.
2. Double click the name; you will then be taken to the **General Information** data entry screen for that fleet.

STEPS FOR COMPLETING “GENERAL INFORMATION” SCREEN

1. Enter your percentage short-haul vs. long-haul operations.
 - Inputting a value in one cell automatically populates the other cell to add up to 100.
2. Check the boxes for the fuel types you use.
 - Once you check these boxes, the appropriate fuel type tab (along the top of the screen next to the **General Information** tab) will become active. If you select the **Diesel/Biodiesel** box, the greyed-out **Part 3: Particulate Matter Reduction** section will also become active.
3. Determine whether you will need to enter data for **Particulate Matter Reduction**; if yes, check the box.
 - Check the **Particulate Matter Reduction** box only if you have truck engines that are model year 2006 or earlier and are equipped with diesel retrofit particulate matter control devices (i.e., diesel oxidation catalysts (DOCs), particulate filters, or closed crankcase ventilation (CCV)).
4. Enter the percentage of trailers utilizing 100% of available cargo capacity while remaining within allowable weight limits.
5. Click the  button and select which commodity categories you typically carry. Select all categories that apply to your fleets.
6. **FOR FLEETS WITH 75% OR MORE OF TRUCKS IN THE DRAYAGE OPERATIONS CATEGORY:** Check the box and enter the additional requested information on APUs and SmartWay tire use if you wish to participate in the Port Dray Program.
7. Select the  button to make sure you have filled out everything on this screen properly. You can also select  to check your data entries across all screens for the given fleet.
8. Click  or select the next available fuel tab at the top to begin entering fuel and activity data for this fleet.

STEPS FOR COMPLETING THE “ENGINE MODEL YEAR & CLASS” SCREEN

*****NOTE: The following guidance will use the Diesel Fuel sections as an example. Similar procedures are followed for all other fuel types.*****

Select the boxes at the top (i.e., 2b, 3, 4, 5, 6, 7, 8a, 8b) for each of the truck classes you operate in this fleet.

Input the number of vehicles you have in each class, specifying the corresponding **engine** years (rather than the tractor model years).

- Use the scroll bar to the right if you need to enter information for older model years.



Check the box at the bottom of the screen to hide any unused truck classes if you wish.



Select  or select the **Activity Information** tab at top of the screen to proceed to the next section.




- Before leaving the **Engine Model Year & Class** screen, you will be prompted to confirm the accuracy of your model year and truck class selections. You may review previous years' selections by selecting the **Year-to-Year Comparison Report** on the **Home** screen.

STEPS FOR COMPLETING THE FUEL DATA POINTS ON “ACTIVITY INFORMATION” SCREEN


1. Select the  button under the **Overall Fleet & Data Source** section to specify where you obtained your data for each row. For each data type, specify the general type of data source and any additional data source detail information, as applicable.
2. Enter the exact value for total miles driven collectively by this fleet by vehicle class. Include all out-of-route, positioning, empty, and other miles driven.
3. Enter the exact value for the revenue miles—the number of miles your fleet drove that were charged to a customer account.
4. Enter the exact value for the total number of empty miles traveled by your fleet.
5. Enter the exact value for all the gallons of fuel used by your fleet in the **past 12-month reporting period**, including any gallons with biofuels (biodiesel for diesel vehicles, ethanol for gasoline vehicles).
6. If you specified any use of reefer body types under the Fleet Characterization section, the  button will appear. Select this button and provide your best estimate of your reefer fuel use in gallons for each truck class. Diesel, LPG, and electric trucks are assumed to use diesel reefers, gasoline trucks to use gasoline reefers, and CNG/LNG trucks to use CNG reefers. Enter zero for any truck classes/fuel types that do not utilize reefer units. If you do not know your reefer fuel use at the truck class level you may enter a total value which will be distributed across your truck classes proportional to your vehicle fuel consumption entries.

7. NOTE: On the **Electric Vehicle Activity** screen, “fuel inputs” are expressed in kWhrs rather than gallons.


STEPS FOR COMPLETING THE “FUEL ALLOCATOR WORKSHEET”

1. Select the  button on the **Activity Information** screen.
2. Enter total gallons of diesel for all truck classes.
3. Enter MPG estimates for each truck class.
4. If “Match” appears in blue next to the “Calculated Gallons Used” field, select .
5. If “No Match” appears in red next to the “Calculated Gallons Used” field, adjust the MPG values as necessary to get a match, and then select .







STEPS FOR COMPLETING THE “BIODIESEL BLEND WORKSHEET “

1. If this fleet has used biodiesel, select the  button and specify your biodiesel volumes by blend level in the **Biodiesel Blend Worksheet**.
2. For each of the blends used by your fleet, enter the appropriate number of gallons used.
3. Select **OK**.

STEPS FOR COMPLETING THE “ETHANOL BLEND WORKSHEET “




1. If this fleet has used ethanol, select the  button and specify your ethanol volumes by blend level (E10 or E85) in the **Ethanol Blend Worksheet**.
2. For each of the blends used by your fleet, enter the appropriate number of gallons used.
3. Select **OK**.

STEPS FOR COMPLETING THE PAYLOAD SECTION ON THE “ACTIVITY INFORMATION” SCREEN







1. Enter your average payloads into the Tool for each truck class by selecting the  button.
2. Under the “Step 1: Getting Started Tab,” select your activity Allocation Method.
3. Select your Units, from the drop-down.
4. Select the  button next the “Data Source.” A **Data Source Description** box will appear.
5. Using the drop-down menus, select your data source and details and enter any comments about your data source.
6. Select  .
7. Select the “Step 2: Body Types” tab or .
8. Check the box(es) next to the body types used in this Truck Class.
9. For each body type selected, enter the activity associated with this body type.
10. For each body type selected, use the drop-down to select a range OR enter the exact payload if available. Make sure to include any pallet and packaging weight in your payload estimates.
11. Validate the screen to determine if there are any errors to correct; if yes, correct the errors and/or enter comments using the  button to explain your data inputs.
12. Select  to perform a final validation check and return to the **Activity Information** screen.

STEPS FOR COMPLETING AVERAGE CAPACITY VOLUME (CUBIC FEET) SECTION ON THE “ACTIVITY INFORMATION” SCREEN



For truck classes 8a and 8b follow these steps:

1. Select the  button to open the **Volume Calculator** screen.
2. Select  to enter your data source for average capacity volume data.
3. Select one of the three reporting basis options using the radio check boxes.
4. Enter the requested metrics for the trailers, containers, tankers, bulk carrier, or other trailers used in this truck class.
5. Select  to return to the **Activity Information** Screen.





For truck classes 2b through 7, follow these steps:

1. Select  to open the **Volume Calculator** screen.
2. Under the “Step 1: Getting Started Tab,” select your activity Allocation Method.
3. Select your Units, from the drop-down.
4. Select  next the “Data Source.” A **Data Source Description** box will appear.
5. Using the drop-down menus, select your data source and details and enter any comments about your data source.
6. Select .
7. Select the “Step 2: Body Types” tab or .
8. Check the box(es) next to the body types used in this Truck Class.
9. For each body type selected, enter the activity associated with this body type.
10. For each body type selected, use the drop-down to select the default average volume OR enter the exact volume if available.
11. Validate the screen to determine if there are any errors to correct; if yes, correct the errors and/or enter comments using the  button to explain your data inputs.
12. Select  to perform a final validation check and return to the **Activity Information** screen.



STEPS FOR COMPLETING THE % CAPACITY UTILIZATION SECTION ON THE “ACTIVITY INFORMATION” SCREEN



1. Next to the % Capacity Utilization (excluding empty miles) data entry box, select the  button. A **Data Source Description** box will appear.
2. Using the drop-down menus, select your data source and details and enter any comments about your data source.
3. If you specified drayage activity under the **Operation Types** screen, you may select the data source "Unknown to dray carriers - use industry average" option, in which case the industry average capacity utilization value will be auto-populated for you.
4. Select  to return to the **Activity Information** screen.
5. Enter your % capacity utilization for each truck class.

STEPS FOR COMPLETING THE ROAD TYPE / SPEED CATEGORY SECTION ON THE “ACTIVITY INFORMATION” SCREEN

1. Select  next to the data entry box next to “Road Type/Speed Categories.” A **Data Source Description** box will appear.
2. Using the drop-down menus, select your data source and details and enter any comments about your data source.
3. Select  to return to the **Activity Information** screen.
4. For each truck class, select the  button to open the “Road Type/Speed Categories” box.
5. Enter the requested metrics for Highway or Rural Driving and Urban Driving for each of the speeds listed (if applicable). If you only know Highway or Rural driving, you can select the box next to “Populate the urban driving fields with default values” to complete the screen.
6. Select  to return to the **Activity Information** screen.


STEPS FOR COMPLETING THE AVERAGE ANNUAL IDLE HOURS PER TRUCK SECTION ON THE “ACTIVITY INFORMATION” SCREEN

1. Select  next to the data entry box next to “Average Annual Idle Hours per Truck.” A **Data Source Description** box will appear.
2. Using the drop-down menus, select your data source and details and enter any comments about your data source.
3. Select  to return to the **Activity Information** Screen.

4. Select the  button to open the **Idle Hours Calculator**.
5. Enter daily long-duration idling hours per truck, daily short-duration idle hours per truck, and average days in service per year for each vehicle class represented in this fleet.
6. Select  to return to the **Activity Information** Screen.


Next Steps

You have now completed the **Activity Information** Screen for this fuel type.

Select  to verify that you have completed the screen properly.

***** If you are using PM reduction equipment on model year 2006 or earlier trucks,** select the **PM Reduction** tab at the top of the screen to proceed to this section. Instructions for data entry are provided below this box. *******


If you have finished entering data for this fuel type, select the tab for the next fuel type and complete all screens as indicated above.

If you have finished inputting data for all of your fuel types, select  to return to the Home screen.



REMEMBER:

***** If additional fuel types are represented in this fleet, you must complete the Engine Model Year & Class and Activity Information screens for each of the fuel types you operate.**

Select the tab for the next fuel type and complete the *Engine Model Year & Class and Activity Information screens* as indicated above—the steps will be the same or similar to those for the Diesel Tab. **Do NOT move on if you have not completed the data input for each of your fuel types.*****

Once finished entering data for all of your fuel types, select  to return to the Home screen and follow the instructions to submit your Tool to EPA.

STEPS FOR COMPLETING THE “PM REDUCTION” SCREEN

1. Select the radio button next to a device (DOC, CCV, or PM trap) you have used for your fleet.
2. Enter the number of trucks equipped with the device by engine (not vehicle) model year.
3. If other devices have been used with this fleet, select the radio box(es) next to each device and enter the number of trucks equipped with the device by engine (not vehicle) model year.
4. When done, select  to make sure you have filled out everything properly on this screen.
5. Select  to return to the **Home** screen.


OPTIONAL STEPS—YEAR TO YEAR COMPARISONS, VIEW REPORTS, AND PROVIDE ADDITIONAL INFORMATION

After completing Steps 1 – 4 on the **Home** screen, you have access to three optional sections of the Tool.

The **Year-to-Year Comparison Report** allows the user to compare the fleet characteristics and activity values from your current reporting year, as well as CO₂ performance metrics, with your prior reporting year. This report is particularly helpful in identifying any changes that may have occurred since your last reporting period, determining trends in activity and performance, and performing general quality assurance of the inputs used for your current Tool. You can access this report by selecting



under item #5 on the **Home** screen.

The **Partner Profile/Logo Info/Suggestions** section allows you to provide EPA with additional information about your company, potential use of the SmartWay Logos, and general feedback regarding the SmartWay program. This information is optional and is not required in order to submit your Truck Carrier Tool data to EPA. Selecting the  button under item #6 on the **Home** screen will open the **Partner Information** forms.


The **View Your Data Reports** section gives you access to 13 reports to help you understand your data and use it to make better performance decisions. You can access these reports by selecting



under item #7 on the **Home** screen.

*****Once you've reviewed these sections, you will be ready to submit your Tool to EPA.*****

STEPS FOR SUBMITTING YOUR TOOL TO EPA

1. Select the  button, which will open a new screen.
2. Select the checkbox to indicate you understand the terms of the SmartWay Partnership Agreement once again.
3. Next, a question will appear asking if you are an existing SmartWay Partner (Y/N). If you are, a question will appear asking if you submitted your data the previous reporting year.
 - a. If so, you can then enter your Annual Submission ID, which has been sent to you by your SmartWay PAM via email. The SmartWay ID is 8 digits in length.
 - b. If you cannot locate your submission ID you can select the link “Email me my annual submission ID” to have your ID sent to you.
4. When ready, select NEXT to create a file with the following naming convention:

Truck_PartnerName_ Year_ V0.xml¹⁰

For example, Truck_ABCompany_ 2014 _V0.xml

where PartnerName is your company’s name as entered for Step 1 on the Home screen, and Year indicates the year for which you are submitting your data.

5. Next specify the folder where you would like to save the xml file, and a screen will appear.
6. Follow these instructions for submitting your xml and xls files to SmartWay. Note that the .xml file is approximately 10 times smaller than the .xls file.
7. Upon selecting NEXT, a screen will appear that allows you to close the Truck Carrier Tool or return to the **Home** screen.
 - **NOTE:** DO NOT ZIP the .xls and .xml files. Send them to EPA as normal files attached in an e-mail. EPA security will not allow zipped files through the EPA firewall.
 - **NOTE:** DO NOT CHANGE THE NAME OF THE XML OR XLS FILES.

Please visit <http://www.epa.gov/smartway/forcarriers/index.htm> for additional resources, including printable data collection worksheets, technical documentation, and the **Truck Carrier Tool Data Entry and Troubleshooting Guide** for more in depth exploration of each section of the Truck Carrier Tool.

¹⁰ If you create the XML file multiple times the file name will increment each time (e.g., Truck_ABCompany_2014_V1.XML for the second iteration, etc).

APPENDIX A: RECOMMENDED DATA SOURCES FOR ACTIVITY DATA

Table 1 summarizes the standard Data Source categories available for selection for each data type.

Table 1: Data Source Detail Selection Options

<u>Data Type</u>	<u>Data Source</u>	<u>Data Source Detail</u>
Total Miles Driven	As reported to IFTA Form 441 for tax reporting (interstate) – Class 7, 8a and 8b trucks only	Collected via fleet-wide GPS reporting software
		Collected via odometer readings
		Collected via maintenance records
		Collected via driver trip sheets
		Collected via standard mileage routes, e.g. PC Miler, Household Goods Guide
	As reported to individual states for tax reporting (intrastate)	Collected via fleet-wide GPS reporting software
		Collected via odometer readings
		Collected via maintenance records
		Collected via driver trip sheets
		Collected via standard mileage routes, e.g. PC Miler, Household Goods Guide
	Determined using software	Dispatching Software*
		Transportation Management System (TMS)*
	Vehicle-based data collection	Determined via Electronic Control Module (ECM) data recorder/logger*
	Revenue Miles Driven	As used in Federal tax reporting
Collected via GPS-enabled TMS		
Collected via manual input into company database with driver trip sheets		
Collected via non-electronic company records		
Financial data		Accounting/billing software*
		Tax reports/IRS and State*

<u>Data Type</u>	<u>Data Source</u>	<u>Data Source Detail</u>	
Revenue Miles Driven (cont'd)	Determined using software	Dispatching Software*	
		Transportation Management System (TMS)*	
	Based on total mileage	Equal to total miles	
		Total miles less empty miles	
		Calculated as a percentage of total miles*	
	Empty Miles Driven	Collected automatically / electronically / manually	Collected via electronic Transportation Management System (TMS)
Collected via GPS-enabled TMS			
Collected via manual input into company database			
Collected via non-electronic company records			
Collected via odometer readings			
Collected via driver trip sheets			
Financial Data		Accounting/billing software*	
		Tax reports/IRS and State*	
Determined using software		Dispatching Software*	
		Transportation Management System (TMS)*	
Based on total mileage		Total miles less revenue miles	
		Calculated as a percentage of total miles*	
Gallons of Fuel Used^		As reported to IFTA Form 441 for tax reporting (interstate) – Class 7, 8a and 8b trucks only	Collected via electronic fuel receipt
			Collected via paper fuel receipt
	Collected via driver trip sheets		
	Collected via electronic expenditure data		
	Collected via paper expenditure data		
	As reported to individual state for tax reporting (intrastate)	Collected via electronic fuel receipt	
		Collected via paper fuel receipt	
		Collected via driver trip sheets	
		Collected via electronic expenditure data	
		Collected via electronic expenditure data	

<u>Data Type</u>	<u>Data Source</u>	<u>Data Source Detail</u>
Gallons of Fuel Used (cont'd)		Collected via paper expenditure data
	Determined using software	Dispatching Software*
		Transportation Management System (TMS)*
	Vehicle-based data collection	Determined via Electronic Control Module (ECM) data recorder/logger*
Based on MPG estimates*	User-provided	
Average Payload	Bills of Lading – electronic records (preferred)	Based on actual miles traveled by specific payloads*
		Trip-weighted (total payload weights / total trips)*
	Bills of Lading – manual records	Based on actual miles traveled by specific payloads*
		Trip-weighted (total payload weights / total trips)*
Ranges provided by calculator	N/A (calculator)	
Average Volume	Determined using company records*	User-provided
	Defaults from calculator	N/A (calculator)
Capacity Utilization	Collected automatically / electronically / manually	Collected through load volume information
	Determined using software	Dispatching Software*
		Transportation Management System (TMS)*
Road Type / Speed Categories	Collected automatically / electronically	Driver trip sheets*
		Governed speed*
		Determined via GPS
		Determined via Electronic Control Module (ECM) data recorder/logger*
	Transportation Management System (TMS)	Driver trip sheets*
		Governed speed*
		Determined via GPS
		Determined via Electronic Control Module (ECM) data recorder/logger*

<u>Data Type</u>	<u>Data Source</u>	<u>Data Source Detail</u>
Average Annual Idle Hours per Truck	Vehicle-based data collection	Determined via Electronic Control Module (ECM) data recorder/logger*
	Driver trip reports*	User-provided
	Idle reduction strategy	Company “No Idle” policy in place*
		Local/State idle regulation in place*
	Determined using software	Dispatching Software*
		Transportation Management System (TMS)*

* User must provide additional description regarding data collection system and calculation method.

^ For electric vehicles, in lieu of gallons, use kWhrs. Common data sources for kWhrs include metering at charging dock, vehicle data acquisition units, and smart-meter applications.

APPENDIX B: WORKSHEETS FOR DATA COLLECTION

List of Worksheets

#1: US/Canada Operations Worksheet	34
#2: Contact Information Worksheet	35
#3: Fleet Characterization Worksheet	36
#4: General Fleet Information	37
#5A: Model Year/Class Worksheet	40
#5B: Activity Data Sources and Information	43
#5C: Biodiesel Blends and Ethanol Blends Worksheet	45
#5D: Payload and Volume Worksheets	46
#5E: Speed and Idle Hours Worksheet	58
#5F: Diesel PM Worksheet	59
#5G: Port Dray Program Data	60

WORKSHEET #1: US/CANADA OPERATION INFORMATION

% of fleet(s) operation in the United States: _____

% of fleet(s) operation in Canada: _____

WORKSHEET #2: CONTACT INFORMATION

#1. Enter your Contact Information:

General Company Contact Information

Company Name							
Headquarters Mailing Address							
City		State/Province		Zip		Country	
Main Phone Number		Toll-free Number		Cell number		Web Address	

Working Contact Information

Working Contact Name							
Working Contact Mailing Address							
City		State/Province		Zip		Country	
Working Contact Phone Number				Email Address			

Executive Contact Information

Executive Contact Name							
Executive Contact Mailing Address							
City		State/Province		Zip		Country	
Executive Contact Phone Number				Email Address			

Other Contact Information

Other Contact Name							
Other Contact Mailing Address							
City		State/Province		Zip		Country	
Other Contact Phone Number				Email Address			
Contact's role in program							

WORKSHEET #3: FLEET CHARACTERIZATION

Complete this worksheet for each fleet you will be submitting in the Truck Carrier Tool.

Specify Fleet Name: This will be a combination of your Partner Name and a Fleet Identifier you create. Use a Fleet Identifier that a company hiring your fleet would recognize. Enter it exactly as it should appear on the SmartWay website):

Partner Name _____

Fleet Identifier (suffix) _____

95% Control _____ SCAC: _____ MCN: _____ DOT #: _____

FLEET TYPE: _____ (for hire, private, dedicated)

Fleet Contact: _____

Operation Category Percentages:

Truckload _____ LTL _____ Drayage _____ Package Delivery _____ Expedited _____

Body Type Percentages:

Dry Van _____ Reefer _____ Flatbed _____ Tanker _____ Chassis _____
Heavy-Bulk _____ Auto Carrier _____ Moving _____ Utility _____ Special Hauler _____

If Special Hauler is selected, please describe type:

WORKSHEET #4: GENERAL FLEET INFORMATION (PAGE 1 OF 2)

Long- versus Short-haul split (%): _____ Short Haul _____ Long Haul

Types of Fuel Used:

_____ diesel/biodiesel _____ gasoline/ethanol _____ propane (LPG)
_____ liquefied natural gas (LNG) _____ compressed natural gas (CNG)
_____ electric _____ hybrid electric (diesel/gasoline)

Use of Particulate Matter (PM) Control Equipment:

_____ Diesel Oxidation Catalyst (DOC)
_____ Closed Crankcase Ventilation (CCV)
_____ Particulate Matter Filter (PM Trap)

Cube Out Percentage: _____

WORKSHEET #4: GENERAL FLEET INFORMATION (PAGE 2 OF 2)

Commodity Descriptions: Select all that apply to this fleet:	
	Animals and Fish (Live)
	Cereal Grains (including seed)
	Agricultural Products except for Animal Feed
	Animal Feed and Products of Animal Origin
	Meat, Fish, and Seafood, and their Preparations
	Milled Grain Products and Preparations, and Bakery Products
	Other Prepared Foodstuffs, and Fats and Oils
	Alcoholic Beverages and Tobacco Products
	Stone and Sands, Except Metal Bearing Sands
	Other Non-Metallic Minerals
	Metallic Ores and Concentrates
	Coal
	Crude Petroleum, Gasoline, Fuel Oils, and Aviation Turbine Fuel
	Other Coal and Petroleum Products
	Basic Chemicals
	Pharmaceutical Products
	Fertilizers
	Other Chemical Products and Preparations
	Plastics and Rubber
	Logs and Other Wood in the Rough
	Wood Products
	Pulp, Newsprint, Paper, and Paperboard
	Paper or Paperboard Articles
	Printed Products

	Textiles, Leather, and Articles of Textiles or Leather
	Non-Metallic Mineral Products
	Base Metal in Primary or Semi-Finished Forms and in Finished Basic Shapes
	Articles of Base Metal
	Machinery
	Electronic and Other Electrical Equipment and Components, and Office Equipment
	Motorized and Other Vehicles (including parts)
	Transportation Equipment
	Precision Instruments and Apparatus
	Furniture, Mattresses and Mattress Supports, Lamps, Lighting Fittings, and Illuminated Signs
	Miscellaneous Manufactured Products
	Waste and Scrap (except for agriculture or food)
	Mixed Freight









WORKSHEET #5A MODEL YEAR/CLASS









NOTE: Print multiple copies of this worksheet to gather data for each fuel type within each fleet.









Fleet Name: _____

Fuel Type: _____

Engine Model Year(s) and Class(es):

	Class 2b 8,501-10,000	Class 3 10,001-14,000	Class 4 14,001-16,000	Class 5 16,001-19,500	Class 6 19,501-26,000	Class 7 26,001-33,000	Class 8a 33,001-60,000	Class 8b 60,001 & above
								
ENGINE MODEL YEAR	2B	3	4	5	6	7	8A	8B
2015								
2014								
2013								
2012								
2011								
2010								

	Class 2b 8,501-10,000	Class 3 10,001-14,000	Class 4 14,001-16,000	Class 5 16,001-19,500	Class 6 19,501-26,000	Class 7 26,001-33,000	Class 8a 33,001-60,000	Class 8b 60,001 & above
								
ENGINE MODEL YEAR	2B	3	4	5	6	7	8A	8B
2009								
2008								
2007								
2006								
2005								
2004								
2003								
2002								
2001								
2000								
1999								
1998								

	Class 2b 8,501-10,000	Class 3 10,001-14,000	Class 4 14,001-16,000	Class 5 16,001-19,500	Class 6 19,501-26,000	Class 7 26,001-33,000	Class 8a 33,001-60,000	Class 8b 60,001 & above
								
ENGINE MODEL YEAR	2B	3	4	5	6	7	8A	8B
1997								
1996								
1995								
1994								
1993								
1992								
1991								
1990								
1989								
1988								
Pre-1988								

WORKSHEET #5B: ACTIVITY DATA SOURCES AND INFORMATION (PAGE 1 OF 2)

Fleet -Level Data Sources:

Total Miles Driven _____

Revenue Miles Driven _____

Empty Miles Driven _____

Gallons of Fuel Used (incl. Biofuel – biodiesel or ethanol) _____

Gallons of Reefer Fuel Used (diesel, gasoline, CNG - by vehicle class) _____

% Capacity Utilization (excluding empty miles) _____

Road Type / Speed Category _____

Average Idle Hours per Truck _____

Truck Class-Level Data Sources (payload and volume only)

	2B	3	4	5
Average Payload (tons or pounds – circle one) Cargo Weight Only				
Average Capacity Volume (cubic feet or TEUs – circle one)				

	6	7	8A	8B
Average Payload (tons or pounds – circle one) Cargo Weight Only				
Average Capacity Volume (cubic feet or TEUs – circle one)				

WORKSHEET #5B: ACTIVITY DATA SOURCES AND INFORMATION (PAGE 2 OF 2)

Activity Data by Truck Class

	2B	3	4	5	6	7	8A	8B
Total Miles Driven (exact values)								
Revenue Miles Driven (exact values)								
Empty Miles Driven (exact values)								
Gallons of Fuel used, including biofuels and Reefer used (exact values)								
% Capacity Utilization (excluding empty miles)								

WORKSHEET #5C: ACTIVITY - BIODIESEL AND ETHANOL BLENDS (IF APPLICABLE)

For each of the biodiesel blends used by your fleet, note the appropriate number of gallons used.

B1		B21		B41		B61		B81	
B2		B22		B42		B62		B82	
B3		B23		B43		B63		B83	
B4		B24		B44		B64		B84	
B5		B25		B45		B65		B85	
B6		B26		B46		B66		B86	
B7		B27		B47		B67		B87	
B8		B28		B48		B68		B88	
B9		B29		B49		B69		B89	
B10		B30		B50		B70		B90	
B11		B31		B51		B71		B91	
B12		B32		B52		B72		B92	
B13		B33		B53		B73		B93	
B14		B34		B54		B74		B94	
B15		B35		B55		B75		B95	
B16		B36		B56		B76		B96	
B17		B37		B57		B77		B97	
B18		B38		B58		B78		B98	
B19		B39		B59		B79		B99	
B20		B40		B60		B80		B100	

Actual ethanol usage figures:	Blend percentage:	Total Gallons Used
	E0	
	E10	
	E85	

WORKSHEET #5D: PAYLOAD AND VOLUME (PAGE 1 OF 12)





To determine average payload for the entire fleet you will need to select an allocation method to determine the amount each truck class/vehicle type contributes to the overall total. Four allocation methods are provided, listed from most preferred to least preferred. You will also need to specify the data source(s) used to develop your estimates, and select the units for Payload (short tons or pounds) and Volume (cubic feet or TEU).

CLASS 2B—WORKSHEET #5D: PAYLOAD AND VOLUME (PAGE 2 OF 12)

Select allocation method for this class (circle one):	# of miles	# of trips	% of operation	# of vehicles
---	------------	------------	----------------	---------------

Select payload unit (circle one): Tons Pounds

Select volume unit (circle one): Cubic Ft TEU




Vehicle Class	Vehicle Type	Allocation factor (#miles, trips, etc.)	Average Payload	Describe Payload Data Source/Calculation Method	Average Volume	Describe Volume Data Source/Calculation Method
2B	 Flatbed					
2B	 Step van					
2B	 Walk in					
2B	 Conventional van					
2B	? OTHER					

CLASS 3—WORKSHEET #5D: PAYLOAD AND VOLUME (PAGE 3 OF 12)

Select allocation method for this class (circle one):	# of miles	# of trips	% of operation	# of vehicles
---	------------	------------	----------------	---------------

Select payload unit (circle one): Tons Pounds

Select volume unit (circle one): Cubic Ft TEU





Vehicle Class	Vehicle Type	Allocation factor (#miles, trips, etc.)	Average Payload	Describe Payload Data Source/Calculation Method	Average Volume	Describe Volume Data Source/Calculation Method
3	 Step van					
3	 Walk in					
3	 Conventional van					
3	? OTHER					

CLASS 4—WORKSHEET #5D: PAYLOAD AND VOLUME (PAGE 4 OF 12)

Select allocation method for this class (circle one):	# of miles	# of trips	% of operation	# of vehicles
---	------------	------------	----------------	---------------

Select payload unit (circle one): Tons Pounds

Select volume unit (circle one): Cubic Ft TEU



Vehicle Class	Vehicle Type	Allocation factor (#miles, trips, etc.)	Average Payload	Describe Payload Data Source/Calculation Method	Average Volume	Describe Volume Data Source/Calculation Method
4	 Flatbed					
4	 Step van					
4	 Large walk-in					
4	 Conventional van					
4	? OTHER					

CLASS 5—WORKSHEET #5D: PAYLOAD AND VOLUME (PAGE 5 OF 12)

Select allocation method for this class (circle one):	# of miles	# of trips	% of operation	# of vehicles
--	------------	------------	----------------	---------------

Select payload unit (circle one): Tons Pounds

Select volume unit (circle one): Cubic Ft TEU





Vehicle Class	Vehicle Type	Allocation factor (#miles, trips, etc.)	Average Payload	Describe Payload Data Source/Calculation Method	Average Volume	Describe Volume Data Source/Calculation Method
5	 Large walk-in					
5	 Conventional van					
5	? OTHER					

CLASS 6—WORKSHEET #5D: PAYLOAD AND VOLUME (PAGE 6 OF 12)

Select allocation method for this class (circle one):	# of miles	# of trips	% of operation	# of vehicles
---	------------	------------	----------------	---------------

Select payload unit (circle one): Tons Pounds

Select volume unit (circle one): Cubic Ft TEU






Vehicle Class	Vehicle Type	Allocation factor (#miles, trips, etc.)	Average Payload	Describe Payload Data Source/Calculation Method	Average Volume	Describe Volume Data Source/Calculation Method
6	 Flatbed					
6	 Reefer					
6	 Large walk-in					
6	 Single axle van					
6	? OTHER					

CLASS 7 STRAIGHT TRUCKS—WORKSHEET #5D: PAYLOAD AND VOLUME (PAGE 7 OF 12)

Select allocation method for this class (circle one):	# of miles	# of trips	% of operation	# of vehicles
---	------------	------------	----------------	---------------

Select payload unit (circle one): Tons Pounds

Select volume unit (circle one): Cubic Ft TEU




Vehicle Class	Vehicle Type	Allocation factor (#miles, trips, etc.)	Average Payload	Describe Payload Data Source/Calculation Method	Average Volume	Describe Volume Data Source/Calculation Method
7	 Beverage					
7	 Flatbed					
7	 Reefer					
7	 Tanker					
7	 Single axle van					
7	? OTHER					

CLASS 7 COMBINATION TRUCKS—WORKSHEET #5D: PAYLOAD AND VOLUME (PAGE 8 OF 12)

Select allocation method for this class (circle one):	# of miles	# of trips	% of operation	# of vehicles
---	------------	------------	----------------	---------------

Select payload unit (circle one): **Tons** **Pounds**




Select volume unit (circle one): Cubic Ft TEU

Vehicle Class	Vehicle Type	Allocation factor (#miles, trips, etc.)	Average Payload	Describe Payload Data Source/Calculation Method	Average Volume	Describe Volume Data Source/Calculation Method
7	 Combination Flatbed					
7	 Combination Reefer					
7	 Dry Van - Single					
7	? OTHER					

CLASS 8A STRAIGHT TRUCKS—WORKSHEET #5D: PAYLOAD AND VOLUME (PAGE 9 OF 12)

Select allocation method for this class (circle one):	# of miles	# of trips	% of operation	# of vehicles
--	------------	------------	----------------	---------------

Select payload unit (circle one): Tons Pounds




Vehicle Class	Vehicle Type	Allocation factor (#miles, trips, etc.)	Average Payload	Describe Payload Data Source/Calculation Method
8A	 Flatbed			
8A	 Tanker			
8A	 Single axle van			
8A	? OTHER			

CLASS 8A COMBINATION TRUCKS—WORKSHEET #5D: PAYLOAD AND VOLUME

(PAGE 10 OF 12)

Select allocation method for this class (circle one):	# of miles	# of trips	% of operation	# of vehicles
--	------------	------------	----------------	---------------

Select payload unit (circle one): Tons Pounds










Vehicle Class	Vehicle Type	Allocation factor (#miles, trips, etc.)	Average Payload	Describe Payload Data Source/Calculation Method
8A	 Beverage			
8A	 Combination Flatbed			
8A	 Dry Van - Single			
8A	? OTHER			

CLASS 8B COMBINATION TRUCKS—WORKSHEET #5D: PAYLOAD AND VOLUME

(PAGE 11 OF 12)

Select allocation method for this class (circle one):	# of miles	# of trips	% of operation	# of vehicles
---	------------	------------	----------------	---------------

Select payload unit (circle one): Tons Pounds

Vehicle Class	Vehicle Type	Allocation factor (#miles, trips, etc.)	Average Payload	Describe Payload Data Source/Calculation Method
8B	 Dry Van - Single			
8B	 Dry Van - Double			
8B	 Dry Van - Triple			
8B	 Combination Reefer			
8B	 Combination Flatbed			
8B	 Combination Tanker			
8B	 Chassis			
8B	 Specialty			
8B	 OTHER			

VOLUME—WORKSHEET #5D: PAYLOAD AND VOLUME (PAGE 12 OF 12)

The volume worksheet for Class 8A/B reflects a range of standard trailer and container configurations. This worksheet will help you prepare for completing the worksheet in the Truck Carrier Tool.

Please specify your data source:

Please specify your reporting basis:

___ Percent Usage ___ Number of Truckloads/Year ___ Number of Trailers

Enter the numbers by type of trailer or container; the Tool will calculate an average capacity volume for your fleet:

Trailer Size – Box, Reefer, Std. Flatbed	Percentage/ # Truckloads/ # Trailers	Container Size	Percentage/ # Truckloads/ # Trailers	Other Trailers (e.g., low-boy, drop deck flatbed, etc.)	
20 ft		20 ft		Cubic Feet per Truck	
40 ft		40 ft		Number/Percent	
42 ft		45 ft			
45 ft		48 ft		Auto Carriers	
48 ft		53 ft		Number/Percent	
53 ft				Avg. # Vehicles/trailer	
57 ft		Bulk Carrier Size			
28 + 28		Large (42" X 8.5" X 11.5")		Liquid Tanker Size	
40 + 40		Medium (32" X 8" X 11")		Large (7,500+ gallons)	
48 + 28		Small (22" X 8" X 10.25")		Medium (3,001-7,499 gallons)	
48 + 48				Small (3,000 and under gallons)	
28 + 28 + 28					

WORKSHEET #5E: ROAD TYPE/SPEED DISTRIBUTION AND IDLE HOURS WORKSHEET

		2B	3	4	5	6	7	8B	8B
ROAD TYPE / SPEED DISTRIBUTION	% Highway vs. Rural Driving								
	% Urban Driving Under 25 mph								
	% Urban Driving 25 to 50 mph								
	% Urban Driving 50 mph+								
AVERAGE DAILY IDLE HOURS PER TRUCK	Daily Long Duration Idle Hours Per Truck								
	Daily Short Duration Idle Hours Per Truck								
	Average Days in Service Per Truck Per Year								

WORKSHEET #5F: DIESEL PM WORKSHEET

Trucks with PM Controls by truck class – Note # of trucks by control type (CCV, DOC, PM Trap, Flow-through Filter)

ENGINE MODEL YEAR	2B	3	4	5	6	7	8B	8B
2006								
2005								
2004								
2003								
2002								
2001								
2000								
1999								
1998								
1997								
1996								
1995								
1994								
1993								
1992								
1991								
1990								
1989								
1988								
Pre-1988								

WORKSHEET #5G: PORT DRAYAGE PROGRAM DATA REQUIREMENTS

Provide the following additional information for each fleet participating in the SmartWay Port Drayage Program.

of trucks equipped with auxiliary power units (APUs): _____

of trucks equipped with SmartWay tires: _____