

Radiation



Development and Application of a Risk Assessment Method for Radioactive Waste Management

**Volume III:
Economic Analysis;
Description
and Implementation
of AMRAW-B Model**



EPA REVIEW NOTICE

This report has been reviewed by the Office of Radiation Programs, U.S. Environmental Protection Agency (EPA) and approved for publication. Approval does not signify that the contents necessarily reflect the views and policies of the EPA. Neither the United States nor the EPA makes any warranty, expressed or implied, or assumes any legal liability or responsibility of any information, apparatus, product or process disclosed, or represents that its use would not infringe privately owned rights.

DEVELOPMENT AND APPLICATION OF A RISK
ASSESSMENT METHOD FOR RADIOACTIVE WASTE MANAGEMENT

Final Contract Report
Principal Investigator: Stanley E. Logan
Bureau of Engineering Research
The University of New Mexico
Albuquerque, New Mexico 87131

Volume IV: AMRAW Computer Code Users' Manual

S. E. Logan

July 1978

Prepared for
U. S. Environmental Protection Agency
Under Contract No. 68-01-3256

Project Officer
Bruce J. Mann
Office of Radiation Programs-LVF
P. O. Box 15027
Las Vegas, Nevada 89114

Page Intentionally Blank

FOREWORD


The EPA Office of Radiation Programs carries out a national program to evaluate human exposures to radioactivity, and to promote the development of controls to protect the environment and public health from such radioactivity. An important part of this program consists of the development of environmental protection criteria and standards for radioactive waste management and disposal.

To sustain this effort, studies have been supported by EPA to develop methods to evaluate the environmental adequacy of proposed waste management alternatives, and this report describes one of the first attempts to develop a comprehensive assessment model. It has been funded at a very modest level. Much interest has been expressed in this work, and through publication, EPA is making it available to those involved with the development and use of models as decision-making tools.

In order for models to be useful as tools for decision-making concerning radioactive waste management alternatives, their capabilities and limitations must be fully understood. It should be noted that assessment models in themselves will not identify optimum waste management choices. However, they can be used to compare well defined alternatives. One of the necessary steps in any model development and validation process is the comparison of results with results obtained from the application of alternate models to test cases. It is hoped that as other comprehensive assessment models become available, comparison studies can be performed.

The methodology described herein has been applied, for model illustration purposes, to a reference repository in a bedded salt formation located in the southwestern United States. Any results published in this report should not be interpreted as implying conclusions concerning the suitability of the reference site or any site-specific method/repository combination for the preparation and disposal of radioactive waste.

Comments on this analysis as well as any new information would be welcomed; they may be sent to the Director, Technology Assessment Division (AW-459) Office of Radiation Programs, U.S. Environmental Protection Agency, Washington, D.C. 20460.



W. D. Rowe, Ph.D.
Deputy Assistant Administrator
for Radiation Programs (AW-459)

Page Intentionally Blank

ABSTRACT

A Radioactive Waste Management Systems Model, developed and implemented by The University of New Mexico under contract with the U. S. Environmental Protection Agency, is presented. The systems model and associated computer code called AMRAW (Assessment Method for Radioactive Waste), has two parts. The first part, AMRAW-A, consists of the Source Term (radioactive inventory versus time), the Release Model, and the Environmental Model. The Release Model considers various geologic and man-caused events which are potential mechanisms for release of radioactive material beyond the immediate environs of a repository or other location; the risk analysis mode uses events distributed probabilistically over time, and the consequence analysis mode uses discrete events occurring at specified times. The Environmental Model includes: 1) the transport to and accumulations at various receptors in the biosphere, 2) pathways from these environmental concentrations, and 3) resulting radiation dose to man.

The second part of the systems model, AMRAW-B, is the Economic Model which calculates health effects corresponding to the various organ dose rates from AMRAW-A, collects these health effects in terms of economic costs and attributes these costs to radionuclides, decay groups, and elements initially in the waste inventory. Implementation, with calculated results, of AMRAW for Terminal Storage in a Bedded Salt Reference Repository are presented. Preliminary demonstrations for the repository operations phase of waste management and terminal storage in a shale formation are described; possible applications to other radioactive and nonradioactive hazardous materials are discussed. AMRAW uniquely links all steps together in a continuous calculation sequence.

ACKNOWLEDGEMENTS

Funding for this project was initially provided by the Energy/Environment Program, Office of Research and Development, and subsequent funding by the Office of Radiation Programs, EPA.

Persons at the EPA, other federal agencies, national laboratories, federal contractors, and foreign correspondents have provided helpful suggestions during progress of the work or through review of draft reports. These contributions are greatly appreciated though space does not permit acknowledgement of each individual contribution.

Assistance in planning the AMRAW users' guide was by K. E. Patterson and C. C. Herrmann. AMRAW-B information used for preparation of the guide was furnished by S. Ben-David and D. S. Brookshire; auxiliary program material was prepared by H. S. Ng. Others at UNM who participated in the project, including AMRAW programming, and other persons making direct contributions are named in the Acknowledgements section of Volume I.

DEVELOPMENT AND APPLICATION
OF A RISK ASSESSMENT METHOD
FOR RADIOACTIVE WASTE MANAGEMENT

VOLUME LISTING

VOLUME I	GENERIC DESCRIPTION OF AMRAW-A MODEL
VOLUME II	IMPLEMENTATION FOR TERMINAL STORAGE IN REFERENCE REPOSITORY AND OTHER APPLICATIONS
VOLUME III	ECONOMIC ANALYSIS; DESCRIPTION AND IMPLEMENTAT OF AMRAW-B MODEL
VOLUME IV	AMRAW COMPUTER CODE USERS' MANUAL

VOLUME IV

TABLE OF CONTENTS

	<u>PAGE</u>
Foreward.....	iii
Abstract.....	v
Acknowledgements.....	vi
List of Volumes.....	vii
List of Figures.....	x
List of Tables.....	x
List of Abbreviations, Symbols and Nomenclature.....	xii
 CHAPTER 1. INTRODUCTION.....	 1
<u>PART 1: AMRAW-A USERS' GUIDE</u>	
 CHAPTER 2. SUMMARY	 5
A. PROGRAM SUMMARY	5
B. PURPOSE	6
C. METHOD	7
CHAPTER 3. INPUT/OUTPUT DESCRIPTION.....	11
A. CARD INPUT SPECIFICATIONS.....	12
B. OUTPUT DESCRIPTION	23
CHAPTER 4. PROGRAM OPTIONS	27
CHAPTER 5. ERROR MESSAGES	31
 APPENDICES FOR PART 1	
A. BACKGROUND MATERIAL	33
B. SAMPLE RUN REQUEST	34
C. SAMPLE CODING FORM	35
D. JOB PROCESSING INSTRUCTIONS	41
E. OPERATING DECK SETUP	42
F. SAMPLE INPUT AND OUTPUT	43

TABLE OF CONTENTS (CONTINUED)

	<u>PAGE</u>
G. PROGRAMMER'S NOTES	67
H. AMRAW-A LISTING	70
I. FLOWCHART	89
J. AUXILIARY PROGRAMS	91
<u>PART 2: AMRAW-B USERS' GUIDE</u>	
CHAPTER 6. SUMMARY	109
A. PROGRAM SUMMARY	109
B. PURPOSE	110
C. METHOD	111
CHAPTER 7. INPUT/OUTPUT DESCRIPTION.....	113
A. CARD INPUT SPECIFICATIONS	115
B. OUTPUT DESCRIPTION	118
CHAPTER 8. PROGRAM OPTIONS	121
CHAPTER 9. ERROR MESSAGES	123
APPENDICES FOR PART 2	
K. BACKGROUND MATERIAL	125
L. SAMPLE RUN REQUEST	127
M. SAMPLE CODING FORM	129
N. JOB PROCESSING INSTRUCTIONS	131
O. OPERATING DECK SETUP	133
P. SAMPLE INPUT AND OUTPUT	135
Q. PROGRAMMER'S NOTES	151
R. AMRAW-B LISTING	155
S. FLOWCHART	163
T. AUXILIARY PROGRAM	165

VOLUME IV

LIST OF FIGURES

<u>FIGURE</u>		<u>PAGE</u>
1-1	Radioactive waste management systems model.....	2
1-2	One branch of systems model.....	3
I-1	AMRAW-A simplified flowchart.....	90
J-1	SENDY simplified flowchart.....	97
J-2	SENDY operating deck setup.....	98
S-1	AMRAW-B simplified flowchart.....	164

LIST OF TABLES

<u>TABLE</u>		<u>PAGE</u>
3-1	Directory of AMRAW-A Output Tables.....	24
4-1	Calculation and Output Options Controlled by NPRINT....	28
C-1	Sample Coding Form for One Nuclide, One Zone, and One Organ.....	36
F-1	Input Data.....	45
F-2	Output Data.....	49
H-1	Main Program.....	71
H-2	Subprograms.....	84
J-1	POLYEPA Program	93
J-2	SENDY Program	101
7-1	Arrangement of AMRAW-A Dose Rate Output; Local Dose Rate by Zone and Nonspecific Dose Rate	114
7-2	Directory of AMRAW-B Output Tables.....	119
M-1	Sample Coding Form with First Cards of Each Type Illustrated	130

LIST OF TABLES (CONTINUED)

		<u>PAGE</u>
P-1	Data File, AMB	136
P-2	Data File, AMLE	137
P-3	Data File, ECON48.....	138
P-4	Sample of AMRAW-A Output	139
P-5	Sample of AMRAW-A Output	140
P-6	Output Summary of Selected Input	142
P-7	AMRAW-B Output Table 1-1; Zonal and Total Damages for High Population Projection	143
P-8	AMRAW-B Output Table 1-2; Zonal and Total Damages for Low Population Projection	144
P-9	AMRAW-B Output Tables 2-9 and 2-14; Annual Damage Rates by Nuclide	145
P-10	AMRAW-B Output Table 3; Discounted Present Values	146
P-11	AMRAW-B Output Table 4-1; High Population Scenario, Number of Deaths per Time Interval	147
P-12	AMRAW-B Output Table 4-2; Low Population Scenario, Number of Deaths per Time Interval	148
P-13	AMRAW-B Output Table 5-1; Total Undiscounted Damages for Each Zone for Each Time Interval, High Population	149
P-14	AMRAW-B Output Table 5-2; Total Undiscounted Damages for Each Zone for Each Time Interval, Low Population	150
R-1	AMRAW-B Listing	156
T-1	COMPRESS Listing	166

VOLUME IV

LIST OF ABBREVIATIONS, SYMBOLS AND NOMENCLATURE

PART 1

A

AA1(JF, J)	Fraction of inventory transferred to receptor JF if a release via cutset J (i.e., JJ) occurs
ADJ	Fraction of inventory transferred from one environmental receptor pool to another pool per unit time; obtained from ADJ1 and ADJ2
ADJ1(JF,JFA,IZ)	Maximum fraction of a quantity dispersed to receptor JFA in Zone IZ which can be transferred to receptor JF in the same zone; paired with ADJ2 for inter-receptor adjustments over time following an initial dispersion.
ADJ2(JF,JFA,IZ)	Transfer rate constant associated with ADJ1, y^{-1}
AL	Axial dispersivity coefficient, m
AMRAW	(Assessment Method for Radioactive Waste) Assessment Model and associated computer code
AMRAW-A	That portion of AMRAW which includes Source Terms, Release Model, and Environmental Model
AMRAW-B	The economic part of AMRAW
AREAW (IZ)	Surface area of water by zone, cm^2
AREAG	Zone land surface area, cm^2 , over which nuclide is deposited
AT	Transverse dispersivity coefficient, m
A1	Transfer coefficient giving fraction of inventory transferred from inventory to receptor JF and due to release mechanism under consideration; obtained from subroutine FAULT and is equal to AA1(JF,J) except for leaching
A2	Time transfer coefficient accounting for radioactive and environmental decay occurring between release and population dose times; calculated within subroutine TRINP with help of function CRATIO for ground water transport calculations

A2MIN Truncation value (to 0.0) for A2 (accounts for decay and transport processes)

B

BIOFAC (K, JF, I) Concentration or integrated concentration in food or drink per unit receptor concentration, by subpath I, up to NS = NSP(JF); units are $(\mu\text{Ci-y/g})/(\mu\text{Ci}/\text{cm}^2)$ for terrestrial food, $(\mu\text{Ci/g})/(\mu\text{Ci}/\text{cm}^3)$ for aquatic food, and dimensionless for drinking water

BULKD Bulk solid density of aquifer, g/cm^3

C

C Transfer coefficient which transforms environmental concentration in a receptor to corresponding dose commitment rate to a specified organ; calculated in subroutine TRMAN

CINV Total number of canisters in inventory

CFAI Number of canisters exposed to leach incident

CHECK Flag for errors in data field; alphanumeric identification of checkpoint number (ICHEK)

COMPRESS An auxiliary program for preparing an AMRAW-B input file from AMRAW-A output

CP(JF,J,K) Function parameter: size of step function, slope of ramp function, exponential constant or set = 1.0 for delta function; K is component factor

CRATIO Subroutine in AMRAW-A for ground water transport calculations

CRMIN Cutoff value for CRATIO (ground water concentration)

D

DC1(K) Effective diffusivity for nuclide K leaching, cm^2/d

DELTE Time interval over which environmental decay constant is applied; also, time increment for which inter-receptor transfer is calculated

DELTL Time increment during release to environment period

DECFAC	Effective radioactive decay factor between two times
DEP	Deposition concentration for water and ground surface (Ci/cm ²) due to air deposition
DEPGND	Total deposition on land surface of zone
DEPWTR	Total deposition on water surface of zone
DFMIN	Cutoff value for DECFAC (decay factor)
DISPN (JF, IZ)	Area or volume over which, or in which, a release is dispersed in each receptor JF in each zone IZ, cm ² or cm ³
DOSFAC (K,JF,MODE,IH)	Dose commitment conversion factor for each organ IH of NIHT total; each card has conversion factors for specified nuclide and receptor/exposure mode combination, (mrem/y)/(μCi/cm ³), (mrem)/(μCi/cm ²) or mrem/μCi, as appropriate
DRC (K)	Dissolution rate constant for nuclide K leaching, d ⁻¹
<u>E</u>	
EDC(K, I, IZ)	Environmental decay constants for nuclides K, receptor JF (represented here by I) and Zones IZ; data sequence on cards is EDC by zone to MZ zones for first nuclide, repeated in turn for each subsequent nuclide to NK nuclides; if ISECT = 4, this group of cards is repeated in turn for JF = 2 and JF = 3
ELEM (ID)	Symbol for each of ND chemical elements
<u>F</u>	
FS	Exposed area of solidified waste specimen (canister as fractured), cm ²
FAULT	Subroutine in AMRAW-A which handles the Release Model and provides transfer coefficients used to accumulate releases to four preliminary input receptors
FUNCTION CRATIO	Determines concentration ratio in ground water at discharge point compared to release point; this ground water transport function is called by SUBROUTINE TRINP
FUNCTION RLEACH	Calculates amount of nuclide leached into the ground water preliminary environmental input receptor; the function is called by SUBROUTINE FAULT when a leach incident is involved

GNDDIS

Ground dispersion, related to ground water velocity and aquifer dimensions

GNDP

Non-accumulating matrix which retains integrated deposition for current time increment for use in calculating transfer to terrestrial food products

H I

HT

Height of aquifer, m

I

ICHCK

Flag for errors in data file--gives check point number

IFDIVW

Ground water time increment control; IFDIVW = 0 avoids subdivision of time increments and IFDIVW > 0 causes sub-division branch in subroutine TRINP to be executed

IFLAGE (JF,MODE,I)

Flag used in Environment-to-Man Pathways model designating whether output is accumulated as "local dose" (IFLAGE = 1) or "nonspecific dose" (IFLAGE = 2).

IFLAG (JF, J, K)

```

Probability function designation: 0 Constant
                                1 Step function
                                2 Ramp function
                                3 Exponential
                                  function
                                4 Delta function

```

K is component factor of cutset J releasing to receptor JF

IE

Output medium for error and data check point messages

IN

Input medium, normally card reader

IP

Output medium (line printer or tape)

ISTART

Starting zone number

ISTOP

Ending zone number

ISECT

Control flag for EDC data; ISECT = 1: internal EDC
default values used for JF = 2 & 3 ($= 2.30 \times 10^{-5}$),
type 36 cards omitted; ISECT = 2: EDC default values
used for JF = 3, type 36 cards read for JF = 2;

ISECT = 3: EDC default values used for JF = 2, type 36 cards read for JF = 3; ISECT = 4: type 36 cards read for JF = 2, followed by cards for JF = 3

ITE TIME subscript used for designation of time increment, Δt , within environmental time period of interest

ITR TIME subscript used for designation of time increments, Δt , within radionuclide release time period

ITRS TIME subscript for release start time; appears for end of time increment when release calculations start

ITRE TIME subscript for release end time; appears for end of time increment when release calculations cease (end)

ITSUMY TIME subscript for first table in Section 6 of output

ITSUMJ Increment on time subscript for successive tables

IW Model branch or waste management phase (IW = 1 is residuals treatment; = 2 is transportation; = 3 is repository operations, and = 4 is terminal storage)

IZ Subscript--geographic zone designation

IZONE(I) Identification number for each zone to be tabulated up to IZONM zones; note, IZONE(10) designates non-specific dose category

IZONM Number of zones to be tabulated

J

JF Subscript--Environmental Receptor designation (JF = 1 is air; = 2 is land surface; = 3 is surface water; = 4 is ground water)

JFA Environmental Receptor from which interreceptor transfer is made to receptor JF

JJ(JF, I) Cutset sequential identification number for cutset I, up to NJ

K

K Subscript--radionuclide designation, or in probability calculations K designates component factor of cutset J releasing to receptor JF

KSUB The nuclide K level for subtotal line in tables (as
for subtotal of fission products followed by actinides)

L

LPRINT Counter

M

MAN1L(ITE,IH) Average annual local dose to individual by nuclide,
organ, and zone, mrem/y

MAN1N(ITE,IH) Average annual nonspecific dose to population by
nuclide and organ, man-rem/y

MAN2L(ITE,IH,IZ) Average annual local dose to individual, total all
nuclides, total all receptors, by organ and zone,
mrem/y

MAN2LF(ITE,IH,IZ,JF) Average annual local dose to individual, total
all nuclides, by receptor, organ, and zones,
mrem/y

MAN2N(ITE,IH) Average annual nonspecific dose to individual, total
all nuclides, total all receptors, by organ, man-rem/y

MAN2NF(ITE,IH,JF) Average annual nonspecific dose to individual, total
all nuclides, for receptor JF = 1 to 4, by organ,
man-rem/y

MC Number of columns in output tables (FOR POLYEPA)

MODE A major grouping of environmental pathways under a
receptor; in general, MODE = 1 is external exposure
and MODE = 2 is internal

MS Number of time intervals corresponding to the reposi-
tory operations phase (for POLYEPA)

MT Number of time reporting points (each "time increment"
is between adjacent time reporting points)

MTADJ Number of interpolated output time points (for POLYEPA)

MW Maximum number of operation modes

MZ Number of geographic zones calculated

M1 Counter

M10 Counter

N

NCASE	Identification number of case or cases submitted
ND	Number of chemical elements in inventory
NIHT	Number of body organs being calculated
NJ (JF)	Number of cutsets (release scenarios) for each receptor JF
NJJ(JF, I)	Number of component factors for cutset I
NK	Number of isotopes in inventory
NPRINT	Output table specification
NSP (JF)	Number of subpaths for each receptor JF; the value of NSP for each JF applies to both modes 1 and 2 for each receptor
NUCNAM (K)	Symbol name for nuclide K, double precision, up to 8 characters each

O

ORGNAM (I)	Names of organs (body sites) for which dose rates are calculated, up to I = NIHT, double precision, up to 8 characters each
------------	---

P

POLYDATA	Data file for assembling POLYEPA input data
POLYEPA	An auxiliary program for preparing nuclide inventory data matrix by curve-fitting source data to prescribed times specified in AMRAW input
POLYDD	POLYEPA output data storage file
PORE	Aquifer porosity (as decimal)
PROBB(JF,J,K)	Initial probability of occurrence of component factor, y^{-1} ; K is component factor

R

RELOUT	Release fraction by each cut set for each nuclide, to each Environmental Input Receptor
--------	---

REMOV(JFA,IZ)	Used in accounting nuclide reduction in receptor JFA due to interreceptor transfer to receptor JF
RKD(K)	Distribution coefficient K_d , by nuclide K, cm^3/g
RKDMAX	Cutoff value for RKD (distribution coefficient K_d) above which ground water transport calculations may be bypassed
RLEACH	Subprogram in FAULT which handles leaching into ground water
RLJ(JF, ITR)	Release increment to each Preliminary Environment Input Receptor from all release events by nuclide, for different times, Curies
RLJMIN	Truncation value (to 0.0) for RLJ (Curies released to a given receptor)
R2(JF,ITE,IZ)	Adjusted concentration per release increment by receptor
R2CON	Intermediate unit conversion value of R2 used in accumulating R2TOT
R2MIN	Truncation value (to 0.0) for R2 (component of environmental concentration R2TOT)
R2TOT	Accumulated net total concentration in μCi per cm^2 or cm^3 by zone and Environment Input Receptor, for different times
 <u>S</u>	
SENDY	An auxiliary program for comparing results in tables from AMRAW run with corresponding tables from another run
SPACT (K)	Specific activity of nuclide K, Ci/g
SUBROUTINE FAULT	Determines release probability transfer coefficient; also, by use of time dependent component factors, the subroutine can modify the nuclide inventory at risk
SUBROUTINE TRINF	Determines transport-to-environment transfer coefficient, accounting for decay and other processes such as delay in ground water transport
SUBROUTINE TRMAN	Determines environment-to-man transfer coefficient for dose to man via all pathways from environmental concentrations

I

TFUEL Total inventory in repository, metric tons

TIME (I) The time in years at each of MT time reporting points

TIMEAD(I) Time in years at each of MTADJ output time points
 (for POLYEPA)

TITLE Title of run or case (1-10)

TP(JF,J,K) Time at which functional change in probability
 commences, y; K is component factor

V

VOLINT(JF,MODE,I,IZ) Consumption, exposure or food production rate, as
 appropriate, y/y, cm³/y, or g/y

VS Volume of solidified waste specimen (canister), cm³

VX Ground water seepage velocity, m/d

X

X(K, IT) Mass of nuclide K at TIME (IT), grams

XL(I) Distances from repository to average discharge point
 in each zone for I = 1 to MZ zones; XL = 0.0 indi-
 cates to code that contaminated plume does not dis-
 charge in zone

XX (ID) Total inventory of each element at end of repository
 operations, grams

Y

YW(I) Effective width of plume (width for concentration
 0.1% of center line value) in each zone (distance XL)
 where discharge occurs, for I = 1 to MZ zones, m;
 input as 0.0 for each zone where no discharge occurs
 (not used except in output display)

YY(I) Distance from plume centerline where concentration
 equals average across effective width YW, in each
 zone (distance XL) where discharge occurs, for I =
 1 to MZ zones; input as 0.0 for each zone where no
 discharge occurs (not used except in output display)

Z

ZAVG	Average quantity of nuclide in Curies during release time increment
ZONALO(JF,IZ)	Dispersion allocation factors by zone IZ for transport-to-environment receptor JF, Ci-y/cm ³ -Ci for JF = 1, Ci/Ci for JF = 2, 3; for JF = 4, ZONALO = 1.0 designates effected ground water in zone; 0.0 designates none
ZONDEP (IZ)	Surface deposition factor by zone IZ, Ci/cm ² -Ci

PART 2

AMB	One of three AMRAW-B input files; provides economic model control and conversion data
AMRAW	(Assessment Method for Radioactive Waste) Assessment Model and associated computer code
AMRAW-A	That portion of AMRAW which includes Source Term, Release Model, and Environmental Model
AMRAW-B	The economic part of AMRAW
AMLE	One of three AMRAW-B input files; provides time values, nuclide names and masses at each time
COMPRESS	An auxiliary program for preparing an AMRAW-B input file from AMRAW-A input
DAMAGE	An intermediate calculated value, damage per person (or nonspecific category), \$/y, during a given time increment, for a given zone and nuclide, summed for dose to all organs
DDP	Implied value of dose, \$/man-rem
DLD	An output parameter for Table 4, denoting deaths per time interval
DPY	Incidence rate for health effects, cases per 10 ⁶ man-rem (dose to organs)
DT	An output parameter for Table 1, denoting DTZ summed over all zones
DT9	An output parameter for Table 1, denoting DTZ summed over all zones and the nonspecific category

DTZ	An output parameter for Tables 1 and 2, denoting damage rate (given nuclide and time) by zone for Table 1, \$/y, and various summations for Table 2. For the latter, subscripts 1 through 5 represent, respectively: local damage summed over zones for high population, local damage summed over zones for low population, nonspecific damage, total of local and nonspecific damage for high population, and total for low population
DYRH	An output parameter for Table 5, denoting discounted damages per time interval, \$, for high population projection
DYRL	Same as DYRH except for low population projection
ECONxx	One of three AMRAW-B input files; provides restructured output matrix MAN1 of dose rates from AMRAW-A (xx is case no.)
IH	Organ identifier subscript
IKK	Subscript identity of each of K nuclides in group
IN	Number which specifies computer input medium
IP	Number which specifies computer output medium
IS	Number which specifies an input medium with large storage used for file ECONxx
IT	Time subscript used in matrices
ITB3	Number which specifies printing option for Table 2 (1 - requests printing; 0 - suppresses printing)
IZ	Subscript used for zone identification
K	Number of nuclides in group
MAN1	Refers to large dose rate output matrix from AMRAW-A
MAN1L	Average annual local dose to individual by nuclide, organ, and zone, mrem/y, comprising part of MAN1
MAN1N	Average annual nonspecific dose to population by nuclide and organ, man-rem/y, comprising part of MAN1
MZ	Number of geographic zones
NG	Number of nuclide decay groups
NIHT	Number of organs (body sites)
NK	Number of nuclides

NT	Number of times
NUCNAM, NUC2	Abbreviated nuclide name, e.g., AM 242M
POPH	Input high population projection by zone
POPL	Input low population projection by zone
PV2	An output parameter for Table 3, denoting disconnected present value of damages from a given nuclide over the full time range
REG	Name of zone
RATE	Discount rate expressed as decimal; input in file AMB
SPV	An output parameter for SS for all decay groups
SS	An output parameter for Table 3, denoting sum of PV2 for all nuclides in a given decay group, \$; also, used for marginal damages for a given decay group, \$/gm
TIME (I)	Time in years for each subscripted value of TIME
TTD	An output parameter for Table 4, denoting sum of DLD over all time increments
TUDH	An output parameter for Table 5, denoting sum of DYRH over all time increments
TUDL	An output parameter for Table 5, denoting sum of DYRL over all time increments
VOL	Cost of increased levels of risk; input in file AMB
X	Quantity of given nuclide in inventory at given time, gm

CHAPTER 1

INTRODUCTION

The Radioactive Waste Management Systems Model (Fig. 1-1) has several parallel paths, each representing a phase in the waste management sequence: residuals treatment (interim surface storage and solidification at a reprocessing plant site), waste transport, repository operations, and terminal storage. If other phases become applicable, such as interim surface storage away from a reprocessing plant site, interim storage as spent fuel, reprocessing of waste form, and other transportation steps, each of these simply becomes an additional parallel path in the model. One branch (parallel path) of the systems model is shown in greater detail in Fig. 1-2.

Implementation of the model is by the AMRAW computer code (Assessment Method for Radioactive Waste Management). The code runs calculations separately for each branch of the model. AMRAW is divided into two parts which are run separately: 1) AMRAW-A (see Figs. 1-1 and 1-2), described in Vols. I and II, begins with the inventory at risk and calculates population dose rates, and 2) AMRAW-B, described in Vol. III, uses the calculated population dose rates, applies incidence rates of health effects associated with radiation dose and calculates the economic costs of health effects in the population.

The model provides for technology assessment of radioactive waste management in two categories: 1) risk analysis, which considers the probabilities of occurrence of various radiation release scenarios and the consequence of such releases, and 2) consequence analysis, which considers only the consequences of the various low-probability potential release events assuming they do occur. The methodology permits evaluation of the various long-term waste disposal methods and management options, for protection of public health and safety and protection of resources.

A user's guide for AMRAW-A is presented in Part 1 and for AMRAW-B in Part 2 of this volume.




Figure 1-1. Radioactive waste management systems model.




Figure 1-2. One branch of systems model.

PART 1

AMRAW-A USERS' GUIDE

CHAPTER 2. SUMMARY

CHAPTER 3. INPUT/OUTPUT DESCRIPTION

CHAPTER 4. PROGRAM OPTIONS

CHAPTER 5. ERROR MESSAGES

APPENDICES: A THROUGH J

CHAPTER 2

SUMMARY

A. PROGRAM SUMMARY

Title: AMRAW-A; Assessment Method for Radioactive Waste (First Part).

Abstract: AMRAW performs a sequence of calculations for an inventory of radioactive wastes, evaluating release quantities, dispersion to the environment, and pathways for dose to man.

Effective Date: January, 1978.

Programmer: S. E. Logan

Computer: IBM 360/67

Language: Fortran IV

Core Memory Requirement: 256 k bytes

Execution Time (CP sec): < 1,300

Auxiliary Hardware Requirements: Disk, Tape, Line Printer

B. PURPOSE

AMRAW-A, the first part of the Radioactive Waste Management Systems Model, calculates population dose rates from postulated releases of radioactive material. Population dose rates are divided into local dose rates for populations within each of several geographic zones and nonspecific dose rates which are associated with largely exported agricultural products. Sub-models consider in series (see Fig. 1-2): the inventory at risk (Source Term), postulated release scenarios in the Release Model, dispersion from the locale of release to environmental receptors in each geographic zone (Transport to Environment) and the pathway analysis (Environment-to-Man Pathways).

C. METHOD

The AMRAW code is written in Fortran IV language. The AMRAW-A part of the AMRAW computer code may be run for one or more branches of the model, depending upon the number of sets of input data provided. The discussion which follows is based upon the terminal storage branch, in that the frame of reference refers to the inventory emplaced in a repository. However, the calculation flow of the model and code also applies to the other branches.

The code is structured with sequences of "receptors" separated by transfer coefficients. The receptors represent the progress of releases, environmental concentrations, concentrations in food and drink, radiation doses, health effects and associated economic damages. The transfer coefficients are evaluated in subroutines using externally-determined input data. The subroutines can be modified or replaced, providing a modular arrangement. Factors for dispersion, biological accumulation, dose, etc., used in the transfer coefficients, are evaluated externally by various existing transport and dose codes.

Each branch of the model (Fig. 1-2) is entered with the mass of each significant radionuclide in the inventory at risk. This is converted to Curies in the inventory by an activity transfer coefficient (specific activity). The Release Model evaluates the probability for release by each of numerous potential release mechanisms, and the fraction of the inventory released by each such occurrence, during each increment of time. AMRAW may be run for any of several release scenarios: 1) probabilistic distribution of events over time, 2) discrete event at specified time, 3) several events each at mean time of first occurrence, 4) dynamic repository simulation, or 5) combinations of these. Subroutine FAULT handles the Release Model and provides the transfer coefficients used to accumulate releases to four preliminary input receptors from all release events considered. This subroutine uses function RLEACH when an event involves leaching into ground water.

Releases as determined by the Release Model are not necessarily directly to the environment. This is particularly true for deep releases to ground water. The first portion of the Environmental Model is therefore the "Transport to Environment" section. This adjusts each release

increment, obtaining the contribution-to-concentrations in environmental input receptors at various times following release. These receptors are: air, ground surface, surface water, and ground water. The adjustment provides for dispersion into each of the several geographical zones comprising the study region, and then accounts for dispersion areas or volumes in each zone. The adjustment also accounts for decay from the time of release to the time being evaluated, transfer between receptors (such as deposition from air onto ground), retardation in ground water flow, and other environmental removal or fixation processes. Subroutine TRINP handles transport from the preliminary input receptors, providing transfer coefficients which account for physical and environmental decay and ground water transport delays. This subroutine uses function CRATIO for the ground water transport calculations. Use of the transfer coefficients from TRINP by the main program leads to net environmental concentrations for input to pathway analysis.

The last portion of the Environmental Model covers the pathways from environmental input concentrations to radiation dose to the population, with dose rate calculations for several organs of concern. Subroutine TRMAN handles evaluation of transfer coefficients between environmental concentrations and population dose rates for the various pathways. Pathways include immersion in air, inhalation, ingestion of ground water and contaminated food and drink (from contaminated ground surface and surface water), submersion in water, and direct surface exposure.

The present dimensioning of AMRAW-A is as follows:

- 1) Radionuclides: 25.
- 2) Environmental receptors: 4, designated by programming as Air, Land Surface, Surface Water, and Ground Water.
- 3) Release Model events: 9 events or event combinations under each of the 4 environmental receptors. Each may be input with up to 9 component factors. Each of these factors may be flagged for type of function (constant, step, ramp, exponential, or delta) and specified by three appropriate function parameters.
- 4) Environmental pathways: 2 main pathways (modes) are programmed

for each environmental receptor. Dimensioning provides for up to 6 subpaths for each receptor (each mode under a given receptor is divided into the same number of subpaths).

- 5) Geographic zones: 8.
- 6) Human organs: 8. Typically, one of these is total body, but there is no restriction.
- 7) Time increments: 50.

With this dimensioning, the code runs with 256 k bytes of core storage, 10 cylinders (1459 k bytes) of disc storage, and requires 21 minutes of CPU time in the UNM IBM 360/67 computer. The range of subscripts for variables is specified by input data and may be any value within the above dimensioning with the exception of environmental receptors which are fixed within the code at four. Dimensioning may be increased if necessary, limited only by available core storage or other system requirements.

Large output matrices for local and nonspecific dose rates are written onto disc to conserve core space. Complete output is then written onto magnetic tape for retention but output may be diverted directly to printer by job control statements if preferred. Printed output is subsequently obtained from the tape as needed. If AMRAW-B is to be coupled to AMRAW-A for a combined run, AMRAW-B may access the disc for dose rate input data. The operation demonstrated at UNM is separate running of AMRAW-B. For this purpose, the dose rate portion of the AMRAW-A output is obtained from tape.

Page Intentionally Blank

CHAPTER 3

INPUT/OUTPUT DESCRIPTION

Input for AMRAW-A is by an 80 column card data deck. There are 40 card types. As implemented at UNM, the input deck is read from two files in disk storage (file division made between card types 19 and 20), instead of from a card reader. No additional inputs are required. Card input is described in the following section.

Output is described in Section 3.B.

A. CARD INPUT SPECIFICATIONS

1. Data Deck Setup. Descriptions and number required of each card type are given in section 2 which follows. The sequence of the data deck, beginning with the first or front card is listed below:

<u>Card Type</u>	<u>Item</u>
1	NCASE
2	TITLE
3	ND, NK, MT, IW, ITRS, ITRE, MZ, NIHT, NPRINT, IFDIVW
4	R1JMIN, A2MIN, R2MIN, RKDMAX, CRMIN, DFMIN
5	TIME
6	ELEM
7	TFUEL
8	XX
9	NUCNAM, X
10	CHECK, ICHCK
11	SPACT
12	DC1
13	DRC
14	ADJ1, ADJ2
15	DISPN
16	ZONALO
17	ZONDEP
18	AREAW
19	RKD
20	CHECK, ICHCK
21	NSP
22	VOLINT
23	BIOFAC
24	CHECK, ICHCK
25	ORGNAM
26	DOSFAC
27	CHECK, ICHCK
28	NJ
29	JJ, NJJ

(There are 4 sets of card types 28 - 31)

<u>Card Type</u>	<u>Item</u>
30	AA1
31	PROBB, IFLAG, TP, CP
32	IFLAGE
33	VX, PORE, AL, AT, HT, BULKD, FS, VS, XL, YW, YY, CINV, CFAI
34	CHECK, ICHCK
35	ISECT
36	EDC (omitted if ISECT = 1)
37	CHECK, ICHCK
38	IZONM
39	IZONE
40	ITSUMY, ITSUMJ, KSUB

2. Description of Card Input. There are 3 subscripts prominently involved with input data: K, JF, and IZ. Subscript K designates the radionuclide, presently dimensioned to handle up to 25 nuclides. Subscript JF designates the 4 environmental receptor (shortened to "receptor" in descriptions which follow): JF = 1 is air, JF = 2 is land surface, JF = 3 is surface water, and JF = 4 is ground water. Subscript IZ designates geographic zones in the study region, presently dimensioned to handle up to 8 zones. Other subscripts are identified below as they occur.

The largest matrices of data are for X (card type 9), BIOFAC (card type 23), and DOSFAC (card type 26). The Release Model input (card types 28 to 31) can be as large as 400 cards if the full dimensioned capability is used. If EDC (card type 36) is read in instead of using internal default values, it is also a large input matrix. Because of the large amount of input data required, there are 6 check points provided; if any check point test is not satisfied, an error statement is output which identifies the block of data in which there are extra or omitted cards, and the run is terminated.

A list of each card type in input sequence, the necessary card format in each instance, the number of each card type required (one card unless stated otherwise), the data items and their descriptions, plus other explanatory notes are presented below.

<u>Card Type</u>	<u>Format and Item</u>	<u>Description</u>
1.	FORMAT (I5) NCASE	Number of cases submitted.
2.	FORMAT (10A8) TITLE	3 cards Title of case, double precision, up to 80 characters per card.
3.	FORMAT (16I5) ND NK MT IW	Number of chemical elements in inventory. Number of isotopes in inventory. Number of time reporting points (each "time increment" is between adjacent time reporting points). Model branch or waste management phase (IW = 1 is residuals treatment; IW = 2 is transportation; IW = 3 is repository)

<u>Card</u> <u>Type</u>	<u>Format and Item</u>	<u>Description</u>
	ITRS	operations and IW = 4 is terminal storage). TIME subscript for end of time increment when release calculations start.
	ITRE	TIME subscript for end of time increment when release calculations cease (end).
	MZ	Number of geographic zones calculated.
	NIHT	Number of body organs calculated.
	NPRINT	Output table specification (see Chap. 3).
	IFDIVW	Ground water time increment control; IFDIVW = 0 avoids subdivision of time increments and IFDIVW > 0 causes subdivision branch in subroutine TRINP to be executed.
4.	FORMAT (8E10.2)	
		This card specifies truncation or cutoff values to avoid overflow, underflow, or nonproductive calculations.
	RLJMIN	Truncation value (to 0.0) for RLJ (Curies released to a given receptor).
	A2MIN	Truncation value (to 0.0) for A2 (accounts for decay and transport processes).
	R2MIN	Truncation value (to 0.0) for R2 (component of environmental concentration R2TOT).
	RKDMAX	Cutoff value for RKD (distribution coefficient K_d) above which ground water transport calculations may be bypassed.
	CRMIN	Cutoff value for CRATIO (ground water concentration).
	DFMIN	Cutoff value for DECFAC (decay factor).
5.	FORMAT (8E10.2)	1 card for each 8 time points.
	TIME (I)	The time in years at each of MT time reporting points.
6.	FORMAT (20A4)	1 card if ND \leq 20.
	ELEM (ID)	Symbol for each of ND chemical elements.
7.	FORMAT (8E10.2)	
	TFUEL	Total inventory in repository, metric tons.
8.	FORMAT (8E10.2)	1 card for each 8 elements.
	XX (ID)	Total inventory of each element at end of repository operations, grams.
9.	FORMAT (A8, 2X, 7E10.2)	Minimum of 1 card for each of NK nuclides; add one card for each nuclide for each 7 time points beyond the first 7 points.

Card Type	Format and Item	Description
	NUCNAM (K)	Symbol name for nuclide K, double precision, up to 8 characters each.
	X(K, IT)	Mass of nuclide K at TIME (IT), grams.
	FORMAT (10X, 7E10.2)	Used for all cards after the first for each nuclide (bypasses rereading NUCNAM).
10.	FORMAT (19A4, I2)	This card provides a check field to provide error statement and terminate runs if incorrect number of cards read to this stage.
	CHECK	Alphanumeric identification of check-point no. 1, up to 76 columns.
	ICHCK	01 in columns 77 and 78.
11.	FORMAT (8E10.2) SPACT (K)	1 card for each 8 nuclides. Specific activity of nuclide K, ci/g.
12.	FORMAT (8E10.2) DC1(K)	1 card for each 8 nuclides. Effective diffusivity for nuclide K leaching, cm^2/d .
13.	FORMAT (8E10.2) DRC (K)	1 card for each 8 nuclides. Dissolution rate constant for nuclide K leaching, d^{-1} .
14.	FORMAT (8E10.2)	4 cards for each zone (1 card for each of 4 receptors in each zone). These cards provide pairs of adjustment parameters for inter-receptor adjustments over time following an initial dispersion.
	ADJ1(JF,JFA,IZ)	Maximum fraction of a quantity dispersed to receptor JFA in zone IZ which can be transferred to receptor JF in the same zone.
	ADJ2(JF,JFA,IZ)	Transfer rate constant associated with ADJ1, y^{-1} .
	Read as: $\left(\left(\left(\text{ADJ1}(\text{JF}, \text{JFA}, \text{IZ}), \text{ADJ2}(\text{JF}, \text{JFA}, \text{IZ}), \text{JFA} = 1, 4 \right), \right. \right. \\ \left. \left. \text{JF} = 1, 4 \right), \text{IZ} = 1, \text{MZ} \right)$	
15.	FORMAT (8E10.2) DISPN (JF, IZ)	4 cards (1 for each receptor) Area or volume over which, or in which, a release is dispersed in each receptor JF in each zone IZ, cm^2 or cm^3 .
	Read as: $\left(\left(\text{DISPN}(\text{JF}, \text{IZ}), \text{IZ} = 1, \text{MZ} \right), \text{JF} = 1, 4 \right)$	
16.	FORMAT (8E10.2)	4 cards (1 for each environmental receptor).

Card Type	Format and Item	Description
	ZONALO (JF, IZ)	Dispersion allocation factors by zone IZ for transport-to-environment receptor JF, $\text{Ci}^{-1}\text{Y}/\text{cm}^3\text{-Ci}$ for JF = 1, Ci/Ci for JF = 2, 3. For JF = 4, ZONALO = 1.0 designates effected ground water in zone; 0.0 designates none.
	Read as: $\left(\left(\text{ZONALO}(\text{JF}, \text{IZ}), \text{IZ} = 1, \text{MZ} \right), \text{JF} = 1, 4 \right)$	
17.	FORMAT (8E10.2) ZONDEP (IZ)	Surface deposition factor by zone IZ, $\text{Ci}/\text{cm}^2\text{-Ci}$.
18.	FORMAT (8E10.2) AREAW (IZ)	Surface area of water by zone, cm^2 .
	Note: Corresponding AREAG, land surface by zone, is set within code = DISPN (2, IZ).	
19.	FORMAT (8E10.2) RKD(K)	1 card for each 8 of NK nuclides. Distribution coefficient K_d , by nuclide K, cm^3/g .
20.	FORMAT (19A4, I2) CHECK ICHCK	This card provides the second data check point. Alphanumeric identification of check point no. 2, up to 76 columns. 02 in columns 77 and 78.
The following card types 21 to 23, and 25 and 26 provide data for the Environment-to-Man Pathways model (see Table 3-3 in Vol. I).		
21.	FORMAT (16I5) NSP (JF)	Number of subpaths for each receptor JF. The value of NSP for each JF applies to both modes 1 and 2 for each receptor.
22.	FORMAT (8E10.2) VOLINT(JF,MODE,I,IZ)	4 cards (1 for each receptor) for each zone. Consumption, exposure or food production rate, as appropriate, y/y , cm^3/y , or g/y .
	Read as: $\left(\left(\text{VOLINT}(\text{JF}, \text{MODE}, \text{I}, \text{IZ}), \text{I} = 1, \text{NS} \right), \text{MODE} = 1, 2 \right)$, where I is subpath under JF, up to $\text{NS} = \text{NSP}(\text{JF})$.	
23.	FORMAT (8E10.2)	3 cards (1 each for receptors JF = 2, 3, 4) for each of NK nuclides.

<u>Card Type</u>	<u>Format and Item</u>	<u>Description</u>
	BIOFAC (K, JF, I)	Concentration or integrated concentration in food or drink per unit receptor concentration, by subpath I, up to NS = NSP(JF). Units are ($\mu\text{Ci-y/g}$)/($\mu\text{Ci/cm}^2$) for terrestrial food, ($\mu\text{Ci/g}$)/($\mu\text{Ci/cm}^3$) for aquatic food, and dimensionless for drinking water.
	Note: BIOFAC for JF = 1 (air) is set = 1.0 in code.	
24.	FORMAT (19A4, I2) CHECK ICHCK	This card provides the third data check point. Alphanumeric identification of check point no. 3, up to 76 characters. 03 in columns 77 and 78.
25.	FORMAT (10A8) ORGNAM (I)	Names of organs (body sites) for which dose rates are calculated, up to I = NIHT, double precision, up to 8 characters each.
26.	FORMAT (8E10.2) DOSFAC(K,JF,MODE,IH)	8 cards for each of NK nuclides (2 for each of 4 receptors JF; first of each pair for MODE 1 and second for MODE 2). Dose commitment conversion factor for each organ IH of NIHT total. Each card has conversion factors for specified nuclide and receptor/exposure mode combination, (mrem/y)/($\mu\text{Ci/cm}^3$), ($\text{mrem}/\mu\text{Ci/cm}^2$), or $\text{mrem}/\mu\text{Ci}$, as appropriate.
27.	FORMAT (19A4, I2) CHECK ICHCK	This card provides the fourth data check point. Alphanumeric identification of check point no. 4, up to 76 characters. 04 in columns 77 and 78.

The following card types 28 to 31 provide data for the Release Model scenarios (see Table 6-4, Vol. II) calculated by subroutine FAULT. As presently dimensioned, each of 4 receptors JF may have up to 9 cutsets (release scenarios) NJ, and each cutset may have up to 9 component factors NJJ. This portion of the data deck can have from 4 cards (trivial case with zero release scenarios for each receptor) to 400 cards, as follows:

- 4 sets of cards, 1 set for each receptor JF:
 - Card type 28 1 card (if NJ = 0, subsequent cards for this JF are omitted).
 - 1 set of cards for each of NJ cutsets (9 maximum):

<u>Card Type</u>	<u>Formula and Item</u>	<u>Description</u>
	Card type 29 1 card	
	Card type 30 1 card	
	Card type 31 1 card for each of NJJ component factor (9 maximum).	
28.	FORMAT (16I5) NJ(JF)	4 cards, sequenced as stated above. Number of cutsets (release scenarios) for each receptor JF.
29.	FORMAT (16I5) JJ(JF, I) NJJ(JF, I)	Number of cards as stated above. Cutset sequential identification number for cutset I, up to NJ. Number of component factors for cutset I.
30.	FORMAT (8E10.2) AA1(JF, J)	Number of cards as stated above. Fraction of inventory transferred to receptor JF if a release via cutset J (i.e., JJ) occurs.
31.	FORMAT (E10.2, I10, 2E10.2) PROBB(JF,J,K) IFLAG(JF,J,K) TP(JF,J,K) CP(JF,J,K)	Number of cards as stated above. Subscripts on this card are: K designates component factor (not to be confused with nuclide K used elsewhere) of cutset J (i.e. JJ) releasing to receptor JF. Initial probability of occurrence of component factor, y^{-1} . Probability function designation: 0 Constant 1 Step function 2 Ramp function 3 Exponential function 4 Delta function. Time at which functional change in probability commences, y. Function parameter: size of step function, slope of ramp function, exponential constant, or set = 1.0 for delta function.
Note: For the constant function, TP and CP may have any value (not used) but 0.0 is suggested to avoid confusion in output display.		
32.	FORMAT (16I5) IFLAG(JF,MODE,I)	4 cards (1 for each receptor) Flag used in Environment-to-Man Pathways model designating whether output is accumulated as "local dose" (IFLAG = 1) or "nonspecific dose" (IFLAG = 2), (see Table 6-14, Vol. II). Values are sequenced on card for each of NSP subpaths under MODE = 1, followed by each of NSP subpaths under MODE = 2.

Card

<u>Type</u>	<u>Format and Item</u>	<u>Description</u>
The following series of 2 to 5 cards of type 33 provide data for the leach subprogram RLEACH and the ground water transport subprogram CRATIO.		
33.	FORMAT (8E10.2)	2 cards for 1 or 2 zones, 3 cards for 3 or 4 zones, 4 cards for 5 or 7 zones, and 5 cards for 8 zones.
	VX	Ground water seepage velocity, m/d.
	PORE	Aquifer porosity (as decimal).
	AL	Axial dispersivity coefficient, m.
	AT	Transverse dispersivity coefficient, m.
	HT	Height of aquifer, m.
	BULKD	Bulk solid density of aquifer, g/cm ³ .
	FS	Exposed area of solidified waste specimen (canister as fractured), cm ² .
	VS	Volume of solidified waste specimen (canister), cm ³ .
	XL(I)	Distances from repository to average discharge point in each zone for I = 1 to MZ zones. XL = 0.0 indicates to code that contaminated plume does not discharge in zone.
	YW(I)	Effective width of plume (width for concentration 0.1% of center line value) in each zone (distance XL) where discharge occurs, for I = 1 to MZ zones, m. Input as 0.0 for each zone where no discharge occurs (not used except in output display).
	YY(I)	Distance from plume centerline where concentration equals average across effective width YW, in each zone (distance XL) where discharge occurs, for I = 1 to MZ zones. Input as 0.0 for each zone where no discharge occurs (not used except in output display).
	CINV	Total number of canisters in inventory.
	CFAI	Number of canisters exposed to leach incident.
34.	FORMAT (19A4, I2)	This card provides the fifth data check point.
	CHECK	Alphanumeric identification of check point no. 5, up to 76 characters.
	ICHCK	05 in columns 77 and 78.

The following type 35 card controls data for the environmental decay constant $EDC(K, JF, IZ)$, y^{-1} , where subscripts denote nuclide, receptor, and zone, respectively. EDC for $JF = 1$ & 4 is set by statements in the code: $EDC(K, 1, IZ) = 50$, providing for rapid deposition

Card

Type	Format and Item	Description
------	-----------------	-------------

from air after dispersion, and EDC (K, 4, IZ) = 0.0, as EDC has no present application to ground water calculations.

- | | | |
|-----|---|---|
| 35. | FORMAT (16I5)
ISECT | Control flag for EDC data.
ISECT = 1: internal EDC default values used for JF = 2 & 3 ($= 2.30 \times 10^{-5}$).
Type 36 cards omitted.
ISECT = 2: EDC default values used for JF = 3; type 36 cards read for JF = 2.
ISECT = 3: EDC default values used for JF = 2; type 36 cards read for JF = 3.
ISECT = 4: type 36 cards read for JF = 2, followed by cards for JF = 3. |
| 36. | FORMAT (8E10.2)

EDC(K, I, IZ) | 0 cards if ISECT = 1; MZ x NK/8 cards if ISECT = 2 or 3; 2(MZ x NK)/8 cards if ISECT = 4.
Environmental decay constants for nuclides K, receptor JF (represented here by I) and zones IZ. Data sequence on cards is EDC by zone to MZ zones for first nuclide, repeated in turn for each subsequent nuclide to NK nuclides. If ISECT = 4, this group of cards is repeated in turn for JF = 2 and JF = 3. |
| 37. | FORMAT (19A4, IZ)

CHECK

ICHCK | This card provides the sixth (and last) data check point.
Alphanumeric identification of check point no. 6, up to 76 characters.
06 in columns 77 and 78. |

The following card types 38 to 40 control selection of output for dose summary tables in Section 6 of output. Each such table is for a specified time.

- | | | |
|-----|-----------------------------------|--|
| 38. | FORMAT (16I5)
IZONM | Number of zones to be tabulated. |
| 39. | FORMAT (16I5)
IZONE(I) | Identification number for each zone to be tabulated, up to IZONM zones.
Note: IZONE(10) designates nonspecific dose category. |
| 40. | FORMAT (16I5)
ITSUMY
ITSUMJ | Time subscript for first table.
Increment on time subscript for successive tables. |

<u>Card</u>		
<u>Type</u>	<u>Format and Item</u>	<u>Description</u>
	KSUB	The nuclide K level for subtotal line in tables (as for subtotal of fission products followed by actinides).

A sample coding form for 1 nuclide, 1 zone, and 1 organ is given in Appendix C. More complete sample input is given in Appendix F.

B. OUTPUT DESCRIPTION

AMRAW-A requires three output mediums: disk, tape file, and line printer.

1. Disk. Intermediate temporary storage of calculated values for each nuclide is on disk. The disk storage capacity required is up to 1459 k bytes of information. Information stored on disk is transferred to tape (or directly to line printer) at the end of each case.

2. Tape File. The tape file is used to store selected run output transferred from disk into several tabular configurations. The output stored on tape may subsequently be used in part as input to AMRAW-B (Economic Model), used as input to auxiliary codes for further analysis, or may be directed to a line printer for one or multiple printed copies. If preferred, and if further computer processing of output is not planned, output can be routed directly to the line printer instead of to tape.

3. Line Printer. The line printer must be capable of 132 characters per line. The preferred mode of operation is to direct output stored on the tape file to the line printer instead of routing output directly to line printer. In addition to the major output, error statements and data check point confirmations are output. Error and check point statements are routed to the output medium specified by the variable IE (see Chapter 4) and should always be set to the line printer.

4. Output Tables. Extensive output tabulations are produced by AMRAW-A, as directed by the output control parameter (see card type 3, and Chapter 4). These tables are divided into 6 sections, each set off by a divider page for clarity. Table 3-1 is a directory of output tables. The number of tables listed of each type is based upon 25 nuclides, 8 zones, and 8 organs, resulting in a total of 627 tables if all are requested by NPRINT. The number of tables is reduced appropriately for fewer nuclides, zones, or organs. Sample output is given in Appendix F.

Table 3-1. Directory of AMRAW-A Output Tables

Description	^a Number of Table Combinations				Total
	Nuclides	Zones	Organs	Environ. Receptors	
<u>SECTION 1. Data Input</u>					
1. Output listing of AMRAW input.	(20	pages)			
<u>SECTION 2. Release to Environment</u>					
1. Release Fractions by Each Cutset, RELOUT	25				25
2. Release Increments to Preliminary Environmental Input Receptors, RLJ, from All Release Events, Ci	25			(4 in each table)	25
3. Concentrations at Environment Input Receptor, R2TOT. Units: JF = 1 $\mu\text{Ci-y}/\text{cm}^3$, JF = 2 $\mu\text{Ci}/\text{cm}^2$, JF = 3 and 4 $\mu\text{Ci}/\text{cm}^3$.	25	8			200
<u>SECTION 3. Local Dose to Individual</u>					
1. Average Annual Local Dose to Individual, MANIL, mrem/y.	25	8	(8 in each table)		200
<u>SECTION 4. Nonspecific Dose to Population</u>					
1. Average Annual Nonspecific Dose to Population, MANIN, manrem/y.	25		(8 in each table)		25

Table 3-1. Directory of AMRAW Output Tables (continued)

				Total
SECTION 5. Total Dose by Receptors				
1. Average Annual Local Dose to Individual, MAN2LF for JF = 1 to 4, MAN2L for Total, mrem/y, Total for All Nuclides.		8	8 (4 in each table)	64
2. Average Annual Nonspecific Dose to Population, MAN2NF for JF = 1 to 4, MAN2N for Total, manrem/y, Total for All Nuclides.			8 (4 in each table)	8
SECTION 6. Dose Summary Tables				
1. Average Annual Local Dose to Individual, MAN1L, in Zone, mrem/y.	(25 in each table)	b up to 8	(8 in each table) ^c ₅	40
2. Average Annual Nonspecific Dose to Population, MAN1N, manrem/y.	(25 in each table)	b up to 8	(8 in each table) ^c ₅	40
Total Number of Tables				627
Note:				
a. All output tables, except Section 6 are for 50 time steps, 0 to 10 ⁶ years.				
b. Individual zones may be specified.				
c. Section 6 may call for a table for each of all times beginning with 100 y or skip some times; 5 tables result if call for every ninth time.				

Page Intentionally Blank

CHAPTER 4

PROGRAM OPTIONS

The first class of program options is concerned with design of the application. The number of nuclides, zones, organs, times, release scenarios, and environmental pathways may be varied within the range of dimensioning. The reader is referred to Vol. I for full discussion of these and other general input data options.

The input/output mediums are specified in statements in the main program which assign values for the variables IN, IE, and IP appropriate to the system being used (at UNM the values are 5, 6, and 2, respectively).

IN specifies the input medium, normally the card reader

IE specifies the output medium for error and data check point messages; this should always be set to the line printer

IP specifies the output medium for the code; this is normally tape file but it may be set to the line printer if preferred.

Calculation and output options are controlled by NPRINT (see card type 3, Chapter 3). This control variable has 3 digits, described in Table 3-1. The complete calculation and output capability is executed if NPRINT = 500. Options range down to setting the first digit to zero (such as NPRINT = 000 or simply = 0) resulting in reading in and outputting all data (in the Section 1 explanatory tabular arrangement) but performing no calculations. The latter is useful during setting up and checking a large data file.

EDC (environmental decay constant) values are internally set for the JF = 1 and 4 receptors. An option is provided for the values for JF = 2 and 3 receptors, controlled by ISECT (see card type 35 in Chapter 3). If ISECT = 1, internal EDC default values are used for both receptors. If EDC data is available for specific nuclides, receptors and zones, this may be read in by setting ISECT = 2 to 4. If ISECT = 2, EDC is read in for JF = 2; if ISECT = 3, EDC is read in for JF = 3; if ISECT = 4, EDC is read in for JF = 2 and 3.

Table 4-1. Calculation and Output Options Controlled by NPRINT

NPRINT = XYZ

Z controls organs calculated.

if Z = 0, all organs in input are calculated.

if $0 < Z \leq \text{NIHT}$, only 1 organ, the Zth organ, is calculated.

Z > NIHT is error.

Y controls zones calculated.

if Y = 0, all zones in input are calculated.

if $0 < Y \leq \text{MZ}$, only 1 zone, the Yth zone, is calculated.

Y > MZ is error.

X controls output as follows where an "X" denotes output:

Description ^a	X =	0 ^b	1	2	3	4	5	6	7-9
<u>SECTION 1. Data Input</u>									
1. Release Model data		X	X	X	X	X	X	X	X
Other input data		X					X		
<u>SECTION 2. Release to Environment</u>									
1. RELOUT							X		
2. RLJ			X		X	X	X		X
3. R2TOT				X	X	X	X		
<u>Section 3. Local Dose to Individual</u>									
1. MAN1L						X	X	X	X
<u>Section 4. Nonspecific Dose to Population</u>									
1. MAN1N						X	X	X	X
<u>Section 5. Total Dose by Receptors</u>									
1. MAN2LF, MAN2L; 2. MAN2NF, MAN2N						X	X	X	X
<u>Section 6. Dose Summary Tables</u>									
1. MAN1L; 2. MAN1N						X	X	X	X

^aSee Table 2-1 for further description.

^bFor X = 0, reads in and then outputs all data; no calculations are made.

Section 6 of the output consists of dose summary tables. Each table is a summary for a specific zone (or nonspecific dose) at a specific time. The option controlling the number of zones and times output in this section is controlled by card types 38 to 40 (see Chapter 3). IZONM specifies the number of zones to be tabulated, IZONE identifies the zone number of each zone to be tabulated, ITSUMY specifies the time subscript for the first table and ITSUMJ specifies a time subscript increment for successive tables.

Page Intentionally Blank

CHAPTER 5

ERROR MESSAGES

There are several error message provisions in AMRAW-A. Each message, its meaning, and corrective action required, is listed below.

Error Message:	"ERROR NEAR CHECK POINT (x) (y) "
Meaning:	Data which follows error before check point x is not in correct order.
Corrective Action:	Check for extra or missing cards and make sure data is in correct order; sort as necessary.
Error Message:	"ERROR: ATTEMPTED REPOSITORY OPERATION WITHOUT SUBSEQUENT ENVIRONMENT TIME INCREMENT"
Meaning:	Continued operating repository until end of time being studied with no subsequent time in the environment left to study.
Corrective Action:	Make ITRE < MT.
Error Message:	"ERROR: VALUE OF ZONE (x) OUTSIDE OF RANGE OF MAXIMUM ZONE (y) "
Meaning:	Attempted use of nonexistent zone.
Corrective Action:	Modify value of 2nd (middle) digit of control parameter NPRINT such that it is \leq MZ.
Error Message:	"ERROR: INVALID ORGAN NUMBER = (x) MAXIMUM NUMBER OF ORGANS = (y) "
Meaning:	Attempted to study nonexistent organ.
Corrective Action:	Modify right most digit of control parameter NPRINT such that it is \leq NIHT.

Page Intentionally Blank

APPENDIX A

BACKGROUND MATERIAL

The basic structure of the AMRAW model and computer code was developed at UNM between 1972 and 1974 as part of the S. Logan Ph.D. dissertation: "A Technology Assessment Methodology Applied to High-Level Radioactive Waste Management," The University of New Mexico, 1974. Additional development proceeded with support from the Sandia Laboratories University Research Program and from the Energy Resources Board of the State of New Mexico. Completion of the model and code was done under EPA Contract No. 68-01-3256 beginning in August, 1975.

APPENDIX B

SAMPLE RUN REQUEST

AMRAW-A RUN REQUEST	
Requested By: _____	
Phone: _____	Date: _____
Number of Seconds: _____	No. of Output Lines: _____
Number of Copies Requested: _____	
Special Form? _____	If so, form no. _____
Input Data On: Disk _____	Disk Name: _____
	DSN: _____
Card _____	Tape _____
	Tape Name: _____
	Label: _____
	DSN: _____

<u>OFFICE USE ONLY</u>	
Date Received: _____	
Date Submitted: _____	
Date Returned: _____	
Initials: _____	

APPENDIX C

SAMPLE CODING FORM

Table C-1 presents a sample coding form for AMRAW-A input data illustrating proper formats for the following conditions.

1 nuclide: C-14
1 zone: Zone 1
1 organ: Total Body
Model Branch: IW = 4, Terminal Storage (beginning at 30 y
reference time)
50 Times: Range from 0 to 10^6 y.

Card types, described in Section 2.A.2., are indicated.

This example is for Zone 1 for the base case described in Part 1 of Vol. II in which it is assumed there is no surface water and no discharge of ground water. If the example were for Zone 2, the value on card type 18 (AREAW) would change from 0.0 to 5.06E+11 and the first 3 values of the second card of type 33 (XL, YW, and YY) would change from 0.0 to 1.00E+04, 2.58E+03, and 5.20E+02, respectively.

The Release Model data (card types 28 to 31) represent 10 cutsets: 3 for each of the first 3 environmental receptors, and 1 for the fourth receptor.

It is assumed that EDC (Environmental Decay Constant) uses internal default values. Hence card type 35 has a value of 1 and card type 36 is omitted.

36

Card Type	Column Number	10	20	30	40	50	60	70	80																																																																							
1	1																																																																															
2	1	RUN FOR ONE NUCLIDE, ONE ZONE, ONE ORGAN																																																																														
2	1	TITLE MUST HAVE 3 LINES																																																																														
2	1	ALWAYS USE 3 EVEN IF 2 ARE BLANK																																																																														
3	1	1	50	4	8	50	1	1	500	1																																																																						
4	1	1.00E-22	1.00E-50	1.00E-35	5.00E+01	1.00E-50	1.00E-10																																																																									
5	1	0.00E+00	5.00E+00	1.00E+01	1.50E+01	2.00E+01	2.50E+01	3.00E+01	4.00E+01																																																																							
5	1	5.00E+01	6.00E+01	7.00E+01	8.00E+01	9.00E+01	1.00E+02	2.00E+02	3.00E+02																																																																							
5	1	4.00E+02	5.00E+02	6.00E+02	7.00E+02	8.00E+02	9.00E+02	1.00E+03	2.00E+03																																																																							
5	1	3.00E+03	4.00E+03	5.00E+03	6.00E+03	7.00E+03	8.00E+03	9.00E+03	1.00E+04																																																																							
5	1	2.00E+04	3.00E+04	4.00E+04	5.00E+04	6.00E+04	7.00E+04	8.00E+04	9.00E+04																																																																							
5	1	1.00E+05	2.00E+05	3.00E+05	4.00E+05	5.00E+05	6.00E+05	7.00E+05	8.00E+05																																																																							
5	1	9.00E+05	1.00E+06																																																																													
6	1	C																																																																														
7	1	1.87E+05																																																																														
8	1	4.04E+04																																																																														
9	1	C-14 1	0.0	6.14D+01	1.25D+03	4.07D+03	9.99D+03	2.17D+04	4.04D+04																																																																							
9	1	C-14 2	4.04D+04	4.04D+04	4.03D+04	4.02D+04	4.02D+04	4.01D+04	4.01D+04																																																																							
9	1	C-14 3	3.96D+04	3.91D+04	3.87D+04	3.82D+04	3.77D+04	3.73D+04	3.68D+04																																																																							
9	1	C-14 4	3.64D+04	3.59D+04	3.19D+04	2.82D+04	2.50D+04	2.21D+04	1.95D+04																																																																							
9	1	C-14 5	1.73D+04	1.54D+04	1.36D+04	1.21D+04	3.75D+03	1.07D+03	3.03D+02																																																																							
9	1	C-14 6	8.62D+01	2.49D+01	7.38D+00	2.24D+00	7.02D-01	2.26D-01	2.28D-06																																																																							
9	1	C-14 7	7.03D-12	1.50D-17	3.72D-23	0.0	0.0	0.0	0.0																																																																							
9	1	C-14 8	0.0																																																																													

Table C-1. (continued)

[illegible]

Table C-1. (continued)

[illegible]

Table C-1. (continued)

[illegible]

Table C-1. (concluded)

STATEMENT NUMBER	5	10	20	30	40	50	60	70	80	IDENTIFICATION SEQUENCE
31	1.00E-13		0	0.0	0.0					
29	3	2								
30	7.50E-02									
31	1.00E+00		0	0.0	0.0					
31	8.10E-12		0	0.0	0.0					
28	1									
29	1	4								
30	0.0									
31	1.00E+00		0	0.0	0.0					
31	1.00E+00		0	0.0	0.0					
31	1.00E+00		0	0.0	0.0					
31	1.40E-07		0	0.0	0.0					
32	1	1								
32	1	1	1	2	2	2	2			
32	1	1	1	1	2	2	2			
32	1	2								
33	4.00E-03	1.50E-01	5.00E+01	6.00E+00	5.00E+01	2.30E+00	4.38E+04	2.22E+05		
33	0.0	0.0	0.0	6.25E+04	2.50E+02					
34	***** CHECK POINT NUMBER FIVE (5) *****05									
35	1									
37	***** CHECK POINT NUMBER SIX (6) *****06									
38	1									
39	1									
40	14	9	1							
//										
/	*									

APPENDIX D

JOB PROCESSING INSTRUCTIONS

1. Prepare jobcard for run using run request as follows:

Job name - 8 characters alphanumeric serial number.

Time parameter - number of seconds estimated.

Lines parameter - number of lines (in thousands) estimated.

Forms parameter - form number from request.

Copies parameter - number of copies requested.

2. Input medium:

Card - keypunch as necessary and place in appropriate section of deck.

Disk - modify GO.SYSIN DD card to reflect parameters required by system.


Tape - modify GO.SYSIN DD card to reflect parameters required by system.

3. Submit job and note date submitted.

4. Return job to requester and note date returned.

APPENDIX E

OPERATING DECK SETUP



APPENDIX F

SAMPLE INPUT AND OUTPUT

Sample input and output is presented for a "short run" using only 3 radionuclides: Sr-90, I-129, and Pb-210. Other parameters are as in a typical "fuel run": 4 environmental receptors, 10 release scenarios (cutsets), 14 environmental pathways, 8 geographic zones, 8 human organs, and 50 time increments.

1. Input Data. Input data is listed according to card input specifications in Section 3.A. and the sample coding forms in Appendix C.

2. Output. Output is separated by partition pages into 6 sections:

(a) *Section 1 - Data Input*. This section, presented in full, is a descriptive output of input data, in the following sequence:

Definition of Environmental Inputs/Definition of Probability Inputs/Probability and Related Data.

Selected Residual Elements in Waste/Selected Radionuclides in Waste.

Ground Water Parameters

EDC

DISPN/ZONALO/ZONDEP

AREAW/ADJ1/ADJ2

VOLINT

BIOFAC

DOSFAC

(b) *Section 2 - Release to Environment*. Sample output is presented for one nuclide (I-129):

Release Fractions by Each Cutset

Release Increments to Preliminary Environment Input Receptors

Concentrations at Environment Input Receptors (Zones 1 and 2 of 8 zones shown)

(c) *Section 3 - Local Dose to Individual.* Sample output is presented for one nuclide (I-129) and one zone (Zone 1) of 8:

Average Annual Local Dose to Individual

(d) *Section 4 - Nonspecific Dose to Population.* Sample output is presented for one nuclide (I-129):

Average Annual Nonspecific Dose to Population

(e) *Section 5 - Total Dose by Receptors.* This section presents totals for all nuclides:

Average Annual Local Dose to Individual. Sample output is presented for 1 organ (Total Body) of 8 and 2 zones (1 and 2) of 8.

Average Annual Nonspecific Dose to Population. Sample output is presented for 1 organ (Total Body).

(f) *Section 6 - Dose Summary Tables.* These tables summarize dose rates by nuclide to each organ. Sample output is presented for 1 time (1000 y) and 1 zone:

Average Annual Local Dose to Individual, Zone 1

Average Annual Nonspecific Dose to Population

APPENDIX F 1. Input Data

```

SHORT RUN BASE CASE FOR TERMINAL STORAGE PHASE
ALL PROBABILISTIC RELEASES
APR. 16, 1978 DATA FILE USED: AMS1      NPRINT=500

03 03 50 4 5 50 8 8 500 1
1.00E-22 1.00E-50 1.00E-35 5.00E+01 1.00E-50 1.00E-10
0.00E+00 5.00E+00 1.00E+01 1.50E+01 2.00E+01 2.50E+01 3.00E+01 4.00E+01
5.00E+01 6.00E+01 7.00E+01 8.00E+01 9.00E+01 1.00E+02 2.00E+02 3.00E+02
4.00E+02 5.00E+02 6.00E+02 7.00E+02 8.00E+02 9.00E+02 1.00E+03 2.00E+03
3.00E+03 4.00E+03 5.00E+03 6.00E+03 7.00E+03 8.00E+03 9.00E+03 1.00E+04
2.00E+04 3.00E+04 4.00E+04 5.00E+04 6.00E+04 7.00E+04 8.00E+04 9.00E+04
1.00E+05 2.00E+05 3.00E+05 4.00E+05 5.00E+05 6.00E+05 7.00E+05 8.00E+05
9.00E+05 1.00E+06

SR 1 PB
1.87E+05
1.26E+08 1.84E+05 9.08E+02
SR-90 1 5.30D+05 3.89D+06 1.06D+07 2.24D+07 4.22D+07 7.11D+07 6.28D+07
SR-90 2 4.91D+07 3.90D+07 3.09D+07 2.43D+07 1.91D+07 1.48D+07 1.15D+07
SR-90 3 8.87D+05 7.72D+04 7.82D+03 7.85D+02 7.21D+01 6.10D+00 4.83D+01
SR-90 4 3.65D+02 2.68D+03 1.62D+14 8.95D+25 0.0 0.0 0.0 0.0
SR-90 5 0.0 0.0 0.0 0.0 0.0 0.0 0.0 0.0
SR-90 6 0.0 0.0 0.0 0.0 0.0 0.0 0.0 0.0
SR-90 7 0.0 0.0 0.0 0.0 0.0 0.0 0.0 0.0
SR-90 8 0.0
1-129 1 3.48D+02 2.66D+03 7.96D+03 1.77D+04 3.40D+04 5.84D+04 5.84D+04
1-129 2 5.84D+04 5.84D+04 5.84D+04 5.84D+04 5.84D+04 5.84D+04 5.84D+04
1-129 3 5.84D+04 5.84D+04 5.84D+04 5.84D+04 5.84D+04 5.84D+04 5.84D+04
1-129 4 5.84D+04 5.84D+04 5.84D+04 5.84D+04 5.84D+04 5.84D+04 5.84D+04
1-129 5 5.84D+04 5.84D+04 5.84D+04 5.84D+04 5.84D+04 5.84D+04 5.84D+04
1-129 6 5.83D+04 5.83D+04 5.82D+04 5.82D+04 5.82D+04 5.82D+04 5.82D+04
1-129 7 5.77D+04 5.74D+04 5.72D+04 5.69D+04 5.67D+04 5.65D+04 5.63D+04
1-129 8 5.61D+04
PB-210 1 2.12D+07 2.12D+06 9.10D+06 3.90D+05 1.32D+04 3.25D+04 4.51D+04
PB-210 2 7.00D+04 9.66D+04 1.26D+03 1.58D+03 1.94D+03 2.35D+03 2.82D+03
PB-210 3 1.28D+02 3.68D+02 7.85D+02 1.39D+01 2.20D+01 3.20D+01 4.39D+01
PB-210 4 5.75D+01 7.29D+01 2.96D+00 6.86D+00 9.69D+00 1.37D+01 1.79D+01
PB-210 5 2.23D+01 2.69D+01 3.15D+01 3.63D+01 4.40D+01 1.27D+02 1.63D+02
PB-210 6 1.93D+02 2.19D+02 2.46D+02 2.59D+02 2.74D+02 2.88D+02 3.40D+02
PB-210 7 3.08D+02 2.53D+02 1.99D+02 1.55D+02 1.19D+02 9.16D+01 7.07D+01
PB-210 8 5.47D+01

***** CHECK POINT NUMBER ONE (1) *****
1.42E+02 1.63E-04 8.12E+01
1.64E-08 9.82E-10 9.39E-10
2.90E-02 4.95E-03 2.75E-03
0.0 0.0 1.00E-09 2.00E+01 0.0 0.0 0.0 0.0
0.0 0.0 0.0 0.0 0.0 0.0 0.0 0.0
0.0 0.0 0.0 0.0 0.0 0.0 0.0 0.0
0.0 0.0 0.0 0.0 0.0 0.0 0.0 0.0
0.0 0.0 1.00E-09 2.00E+01 0.0 0.0 0.0 0.0
0.0 0.0 0.0 0.0 0.0 0.0 0.0 0.0
0.0 0.0 0.0 0.0 0.0 0.0 2.00E-01 2.00E+01
0.0 0.0 0.0 0.0 0.0 0.0 0.0 0.0
0.0 0.0 1.00E-09 2.00E+01 0.0 0.0 0.0 0.0
0.0 0.0 0.0 0.0 0.0 0.0 0.0 0.0
0.0 0.0 0.0 0.0 0.0 0.0 0.0 0.0

```

```

00000050
00000100
00000150
00000200
00000250
00000300
00000350
00000400
00000450
00000500
00000550
00000600
00000650
00000700
00000750
00000800
00000850
00000900
00000950
00001000
00001050
00001100
00001150
00001200
00001250
00001300
00001350
00001400
00001450
00001500
00001550
00001600
00001650
00001700
00001750
00001800
00001850
00001900
00001950
00002000
00002050
00002100
00002150
00002200
00002250
00002300
00002350
00002400
00002450
00002500
00002550
00002600
00002650
00002700
00002750

```

APPENDIX F

1. Input Data (continued)

0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	00002800
0.0	0.0	1.00E-09	2.00E+01	0.0	0.0	0.0	0.0	00002850
0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	00002900
0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	00002950
0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	00003000
0.0	0.0	1.00E-09	2.00E+01	0.0	0.0	0.0	0.0	00003050
0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	00003100
0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	00003150
0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	00003200
0.0	0.0	1.00E-09	2.00E+01	0.0	0.0	0.0	0.0	00003250
0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	00003300
0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	00003350
0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	00003400
0.0	0.0	1.00E-09	2.00E+01	0.0	0.0	0.0	0.0	00003450
0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	00003500
0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	00003550
0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	00003600
0.0	0.0	1.00E-09	2.00E+01	0.0	0.0	0.0	0.0	00003650
0.0	0.0	0.0	0.0	3.00E-01	2.00E+01	0.0	0.0	00003700
0.0	0.0	0.0	0.0	0.0	0.0	8.00E-01	2.00E+01	00003750
0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	00003800
1.00E+00	1.00E+00	1.00E+00	1.00E+00	1.00E+00	1.00E+00	1.00E+00	1.00E+00	00003850
7.99E+11	1.01E+14	2.27E+14	4.77E+13	1.22E+14	1.14E+14	1.57E+14	5.46E+12	00003900
0.0	5.06E+13	1.14E+14	1.12E+13	3.05E+13	2.85E+13	7.88E+13	2.60E+14	00003950
1.00E+00	1.00E+00	1.00E+00	1.00E+00	1.00E+00	1.00E+00	1.00E+00	1.00E+00	00004000
1.26E-20	5.31E-23	5.09E-24	2.12E-24	3.63E-24	3.03E-23	3.18E-24	3.12E-23	00004050
1.29E-01	4.41E-01	9.15E-02	8.68E-03	3.59E-02	2.42E-01	4.18E-02	1.46E-02	00004100
0.0	2.17E-03	4.60E-04	2.18E-05	9.00E-05	6.00E-04	2.18E-04	1.44E-03	00004150
0.0	1.00E+00	0.0	0.0	0.0	0.0	0.0	1.00E+00	00004200
4.04E-13	1.93E-15	1.94E-16	1.05E-16	1.79E-16	1.17E-15	1.50E-16	1.25E-15	00004250
0.0	5.06E+11	1.14E+12	1.12E+11	3.05E+11	2.85E+11	7.88E+11	5.40E+11	00004300
2.00E+01	0.0	4.00E+03						00004350
***** CHECK POINT NUMBER TWO (2) *****								00004400
1	4	4	1					00004450
1.00E+00	7.30E+09							00004500
4.00E-01	0.0	0.0	0.0	0.0	6.30E+07	0.0	0.0	00004550
0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	00004600
0.0	0.0							00004650
1.00E+00	7.30E+09							00004700
4.00E-01	0.0	0.0	0.0	0.0	1.18E+10	0.0	0.0	00004750
1.00E-03	0.0	0.0	0.0	4.00E+05	5.90E+09	0.0	0.0	00004800
4.80E+03	7.08E+07							00004850
1.00E+00	7.30E+09							00004900
4.00E-01	0.0	0.0	0.0	1.11E+10	1.81E+10	4.67E+08	4.05E+09	00004950
1.00E-03	0.0	0.0	0.0	2.00E+05	4.60E+09	4.05E+09	0.0	00005000
0.0	0.0							00005050
1.00E+00	7.30E+09							00005100
4.00E-01	0.0	0.0	0.0	3.95E+09	7.60E+09	8.32E+08	3.21E+09	00005150
1.00E-03	0.0	0.0	0.0	0.0	0.0	3.21E+09	0.0	00005200
0.0	0.0							00005250
1.00E+00	7.30E+09							00005300
4.00E-01	0.0	0.0	0.0	2.52E+11	1.02E+10	5.43E+09	1.58E+10	00005350
1.00E-03	0.0	0.0	0.0	0.0	0.0	1.58E+10	0.0	00005400
0.0	0.0							00005450
1.00E+00	7.30E+09							00005500

APPENDIX F

1. Input Data (continued)

4.00E-01	0.0	0.0	0.0	1.97E+13	1.38E+10	1.92E+09	1.50E+10	00005550
1.00E-03	0.0	0.0	0.0	0.0	0.0	1.50E+10	0.0	00005600
0.0	0.0							00005650
1.00E+00	7.30E+09							00005700
4.00E-01	0.0	0.0	0.0	5.82E+09	3.27E+10	7.88E+09	8.31E+10	00005750
1.00E-03	0.0	0.0	0.0	4.00E+05	1.67E+10	6.31E+10	0.0	00005800
0.0	0.0							00005850
1.00E+00	7.30E+09							00005900
4.00E-01	0.0	0.0	0.0	2.84E+09	0.0	6.23E+09	3.46E+10	00005950
1.00E-03	0.0	0.0	0.0	4.00E+05	9.60E+08	3.46E+10	0.0	00006000
2.00E+04	4.80E+07							00006050
5.26E-01	5.23E-03	3.56E-03	1.84E-02					00006100
1.00E+00	2.40E-01	8.12E-01	0.00					00006150
2.40E-01								00006200
8.26E-01	9.48E-01	2.59E-01	9.86E-02					00006250
1.00E+00	1.16E+00	3.84E+00	0.00					00006300
1.16E+00								00006350
8.26E-01	2.32E-03	1.71E-03	5.62E-03					00006400
1.00E+00	1.16E-01	3.97E-01	0.00					00006450
1.16E-01								00006500
***** CHECK POINT NUMBER THREE (3) *****								00006550
TOT BODYGI	TRACT GONADS	LIVER	LUNGS	MARROW	BONE	THYROID		00006600
0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	00006650
1.78E+03	3.56E+01	1.78E+03	0.0	9.71E+03	2.67E+04	2.67E+04	0.0	00006700
0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	00006750
1.69E+02	4.85E+01	1.69E+02	0.0	0.0	8.43E+03	8.43E+03	0.0	00006800
0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	00006850
1.69E+02	4.85E+01	1.69E+02	0.0	0.0	8.43E+03	8.43E+03	0.0	00006900
1.69E+02	4.85E+01	1.69E+02	0.0	0.0	8.43E+03	8.43E+03	0.0	00006950
1.69E+02	4.85E+01	1.69E+02	0.0	0.0	8.43E+03	8.43E+03	0.0	00007000
9.55E+07	1.98E+07	1.31E+08	3.60E+07	4.85E+07	1.56E+08	1.45E+08	1.01E+08	00007050
4.19E+00	5.34E+00	4.19E+00	2.11E+00	4.45E+02	2.48E+00	2.48E+00	5.55E+03	00007100
5.73E+04	1.19E+04	7.88E+04	2.16E+04	2.91E+04	9.38E+04	8.72E+04	6.04E+04	00007150
7.22E+00	9.70E+00	7.22E+00	2.81E+00	0.0	3.27E+00	3.27E+00	5.17E+03	00007200
2.01E+03	4.18E+02	2.74E+03	7.57E+02	1.02E+03	3.29E+03	3.06E+03	2.12E+03	00007250
7.22E+00	9.70E+00	7.22E+00	2.81E+00	0.0	3.27E+00	3.27E+00	5.17E+03	00007300
7.22E+00	9.70E+00	7.22E+00	2.81E+00	0.0	3.27E+00	3.27E+00	5.17E+03	00007350
7.22E+00	9.70E+00	7.22E+00	2.81E+00	0.0	3.27E+00	3.27E+00	5.17E+03	00007400
1.43E+07	5.75E+06	1.21E+07	7.27E+06	9.02E+06	2.65E+07	2.45E+07	1.20E+07	00007450
3.40E+03	7.12E+00	3.40E+03	3.10E+04	6.40E+05	3.30E+05	3.30E+05	0.0	00007500
2.27E+04	5.15E+03	1.92E+04	1.16E+04	1.44E+04	4.23E+04	3.90E+04	1.91E+04	00007550
5.10E+02	9.70E+00	5.10E+02	4.70E+03	0.0	5.00E+04	5.00E+04	0.0	00007600
3.00E+02	1.21E+02	2.54E+02	1.53E+02	1.60E+02	5.59E+02	5.15E+02	2.53E+02	00007650
5.10E+02	9.70E+00	5.10E+02	4.70E+03	0.0	5.00E+04	5.00E+04	0.0	00007700
5.10E+02	9.70E+00	5.10E+02	4.70E+03	0.0	5.00E+04	5.00E+04	0.0	00007750
5.10E+02	9.70E+00	5.10E+02	4.70E+03	0.0	5.00E+04	5.00E+04	0.0	00007800
***** CHECK POINT NUMBER FOUR (4) *****								00007850
3								00007900
1								00007950
5.00E-02								00008000
1.00E-13	0	0.0	0.0					00008050
2								00008100
7.50E-02								00008150
2.40E-12	0	0.0	0.0					00008200
3								00008250

APPENDIX F

1. Input Data (concluded)

6.00E-03										00008300
2.40E-12	0	0.0	0.0							00008350
3										00008400
1 2										00008450
3.33E-05										00008500
1.00E+00	0	0.0	0.0							00008550
0.0	2	1.60E+06	1.56E-07							00008600
2 1										00008650
5.00E-02										00008700
1.00E-13	0	0.0	0.0							00008750
3 1										00008800
7.50E-02										00008850
8.10E-12	0	0.0	0.0							00008900
3										00008950
1 3										00009000
3.33E-08										00009050
1.00E+00	0	0.0	0.0							00009100
1.00E+00	0	0.0	0.0							00009150
0.0	2	1.60E+06	1.56E-07							00009200
2 2										00009250
5.00E-02										00009300
1.00E+00	0	0.0	0.0							00009350
1.00E-13	0	0.0	0.0							00009400
3 2										00009450
7.50E-02										00009500
1.00E+00	0	0.0	0.0							00009550
8.10E-12	0	0.0	0.0							00009600
1										00009650
1 4										00009700
0.0										00009750
1.00E+00	0	0.0	0.0							00009800
1.00E+00	0	0.0	0.0							00009850
1.00E+00	0	0.0	0.0							00009900
1.40E-07	0	0.0	0.0							00009950
1 1										00010000
1 1	1	1	2	2	2	2				00010050
1 1	1	1	1	2	2	2				00010100
1 2										00010150
4.00E-03	1.50E-01	5.00E+01	6.00E+00	5.07E+01	2.30E+00	4.38E+04	2.22E+05			00010200
0.0	1.00E+04	0.0	0.0	0.0	0.0	0.0	2.00E+34			00010250
0.0	2.58E+03	0.0	0.0	0.0	0.0	0.0	3.64E+03			00010300
0.0	5.20E+02	0.0	0.0	0.0	0.0	0.0	7.30E+02			00010350
6.25E+04	2.50E+02									00010400
*****	CHECK POINT NUMBER FIVE (5)									00010450
1										00010500
*****	CHECK POINT NUMBER SIX (6)									00010550
3										00010600
1 8 10										00010650
14 9 2										00010700

APPENDIX F

2. Output (a)

** DEFINITION OF ENVIRONMENTAL INPUTS

JF	DEFINITION
1	AIR
2	GROUND SURFACE
3	SURFACE WATER
4	GROUND WATER

** DEFINITION OF PROBABILITY INPUTS

IFLAG	DEFINITION
0	PROBABILITY (PROB) CONSTANT
1	STEP FUNCTION AT TIME TP CHANGES PROB BY AMOUNT CP
2	RAMP FUNCTION AT TP CHANGES PROB BY SLOPE CP
3	EXPONENTIAL FUNCTION AT TP CHANGES PROB BY TIME CONSTANT CP
4	DELTA FUNCTION, AT TIME TP RELEASE TO ENVIRONMENT IS AA1

** PROBABILITY AND RELATED DATA

JF	NJF	J	NJJ	AA1	PROB	IFLAG	TP	CP
1	3	1	1	5.00E-02	1.00E-13	0	0.0	0.0
1	3	2	1	7.50E-02	2.40E-12	0	0.0	0.0
1	3	3	1	6.00E-03	2.40E-12	0	0.0	0.0
2	3	1	2	3.33E-05	1.00E 00	0	0.0	0.0
					0.0	2	1.60000E 05	1.56000E-07
2	3	2	1	5.00E-02	1.00E-13	0	0.0	0.0
2	3	3	1	7.50E-02	8.10E-12	0	0.0	0.0
3	3	1	3	3.33E-05	1.00E 00	0	0.0	0.0
					1.00E 00	0	0.0	0.0
					0.0	2	1.60000E 05	1.56000E-07
3	3	2	2	5.00E-02	1.00E 00	0	0.0	0.0
					1.00E-13	0	0.0	0.0
3	3	3	2	7.50E-02	1.00E 00	0	0.0	0.0
					8.10E-12	0	0.0	0.0
4	1	1	4	0.0	1.00E 00	0	0.0	0.0
					1.00E 00	0	0.0	0.0
					1.00E 00	0	0.0	0.0
					1.40E-07	0	0.0	0.0

***** CHECK POINT NUMBER FIVE (5) ***** 5
 ***** CHECK POINT NUMBER SIX (6) ***** 6

APPENDIX F

2. Output (a) continued

** SELECTED RESIDUAL ELEMENTS IN WASTE
GRAMS AT START OF TERMINAL STORAGE
FOR TOTAL FUEL = 187000. METRIC TONS

SR	1.26E 08
I	1.84E 05
PB	9.08E 02

** SELECTED RADIONUCLIDES IN WASTE
GRAMS IN WASTE VERSUS TIME IN YEARS

TIME	SR-90	I-129	PB-210
0.	5.30E 06	3.48E 02	2.12E-07
5.	3.89E 06	2.86E 03	2.12E-06
10.	1.06E 07	7.96E 03	9.10E-06
15.	2.24E 07	1.77E 04	3.90E-05
20.	4.22E 07	3.49E 04	1.32E-04
25.	7.11E 07	5.84E 04	3.25E-04
30.	6.28E 07	5.84E 04	4.51E-04
40.	4.91E 07	5.84E 04	7.00E-04
50.	3.90E 07	5.84E 04	9.66E-04
60.	3.09E 07	5.84E 04	1.26E-03
70.	2.43E 07	5.84E 04	1.58E-03
80.	1.91E 07	5.84E 04	1.94E-03
90.	1.48E 07	5.84E 04	2.35E-03
100.	1.15E 07	5.84E 04	2.82E-03
200.	8.87E 06	5.84E 04	1.28E-02
300.	7.72E 04	5.84E 04	3.68E-02
400.	7.82E 03	5.84E 04	7.85E-02
500.	7.85E 02	5.84E 04	1.39E-01
600.	7.21E 01	5.84E 04	2.20E-01
700.	6.10E 00	5.84E 04	3.20E-01
800.	4.83E-01	5.84E 04	4.39E-01
900.	3.65E-02	5.84E 04	5.75E-01
1000.	2.68E-03	5.84E 04	7.29E-01
2000.	1.62E-14	5.84E 04	2.96E 00
3000.	8.95E-25	5.84E 04	6.06E 00
4000.	0.0	5.84E 04	9.69E 00
5000.	0.0	5.84E 04	1.37E 01
6000.	0.0	5.84E 04	1.79E 01
7000.	0.0	5.84E 04	2.23E 01
8000.	0.0	5.84E 04	2.69E 01
9000.	0.0	5.84E 04	3.15E 01
10000.	0.0	5.84E 04	3.63E 01
20000.	0.0	5.83E 04	8.40E 01
30000.	0.0	5.83E 04	1.27E 02
40000.	0.0	5.83E 04	1.63E 02
50000.	0.0	5.83E 04	1.93E 02
60000.	0.0	5.83E 04	2.19E 02
70000.	0.0	5.82E 04	2.40E 02
80000.	0.0	5.82E 04	2.59E 02
90000.	0.0	5.82E 04	2.74E 02
100000.	0.0	5.82E 04	2.88E 02
200000.	0.0	5.80E 04	3.40E 02
300000.	0.0	5.77E 04	3.08E 02
400000.	0.0	5.74E 04	2.53E 02
500000.	0.0	5.72E 04	1.99E 02
600000.	0.0	5.69E 04	1.55E 02
700000.	0.0	5.67E 04	1.19E 02
800000.	0.0	5.65E 04	9.16E 01
900000.	0.0	5.63E 04	7.07E 01
1000000.	0.0	5.61E 04	5.47E 01

SPECIFIC ACTIVITY
CI/G 1.42E 02 1.63E-04 8.12E 01

APPENDIX F

2. Output (a) continued

RADIOISOTOPE	CC1 DATA	DRC DATA	RKD DATA
SR-90	1.64E-08	2.90E-02	2.00E 01
I-129	9.52E-10	4.95E-03	0.0
PB-210	5.39E-10	2.75E-03	4.00E 03

** GROUND WATER PARAMETERS

GROUND WATER SEEPAGE VELOCITY, V_K , IN METERS/DAY = 4.00E-03
 POROSITY OF SOLID MEDIUM, $PORE$ = 1.50E-01
 BULK SOLID DENSITY, $BULKD$, IN GRAMS/CUBIC CM = 2.30E 00
 DISPERSIVITY COEFFICIENTS, IN METERS: AXIAL, AL = 5.00E 01 TRANSVERSE, AT = 6.00E 00

AQUIFER VALUES, IN METERS: HEIGHT, HT = 5.00E 01
 DISTANCE FROM SOURCE TO EMERGENCE, $XL(IZ)$ EFFECTIVE WIDTH, $YW(IZ)$
 CONCENTRATION AT YY = AVERAGE CONCENTRATION IN YW

ZONE	IZ= 1	IZ= 2	IZ= 3	IZ= 4	IZ= 5	IZ= 6	IZ= 7	IZ= 8
$XL(IZ)$	0.0	1.00E 04	0.0	0.0	0.0	0.0	0.0	2.00E 04
$YW(IZ)$	0.0	2.56E 03	0.0	0.0	0.0	0.0	0.0	3.64E 03
$YY(IZ)$	0.0	5.20E 02	0.0	0.0	0.0	0.0	0.0	7.30E 02

EXPOSED AREA OF SOLIDIFIED WASTE SPECIMEN, FS , IN SQUARE CM = 4.38E 04
 VOLUME OF SOLIDIFIED WASTE SPECIMEN, VS , IN CUBIC CM = 2.22E 05
 TOTAL CANISTER INVENTORY, $CINV$ = 6.25E 04
 ASSUMED NUMBER OF CANISTER FAILURES, $CFAI$ = 2.50E 02

APPENDIX F

2. Output (a) continued

** EDC(K,JF,IZ) DATA, (JF=1,2,3,4), DEFAULT VALUES USED, EXCEPTING NONE READ IN

IZ= 1

SR-90	5.00E 01	2.30E-05	2.30E-05	0.0	5.00E 01	2.30E-05	2.30E-05	0.0
I-129	5.00E 01	2.30E-05	2.30E-05	0.0	5.00E 01	2.30E-05	2.30E-05	0.0
PB-210	5.00E 01	2.30E-05	2.30E-05	0.0	5.00E 01	2.30E-05	2.30E-05	0.0

IZ= 2

IZ= 3

SR-90	5.00E 01	2.30E-05	2.30E-05	0.0	5.00E 01	2.30E-05	2.30E-05	0.0
I-129	5.00E 01	2.30E-05	2.30E-05	0.0	5.00E 01	2.30E-05	2.30E-05	0.0
PB-210	5.00E 01	2.30E-05	2.30E-05	0.0	5.00E 01	2.30E-05	2.30E-05	0.0

IZ= 4

IZ= 5

SR-90	5.00E 01	2.30E-05	2.30E-05	0.0	5.00E 01	2.30E-05	2.30E-05	0.0
I-129	5.00E 01	2.30E-05	2.30E-05	0.0	5.00E 01	2.30E-05	2.30E-05	0.0
PB-210	5.00E 01	2.30E-05	2.30E-05	0.0	5.00E 01	2.30E-05	2.30E-05	0.0

IZ= 6

IZ= 7

SR-90	5.00E 01	2.30E-05	2.30E-05	0.0	5.00E 01	2.30E-05	2.30E-05	0.0
I-129	5.00E 01	2.30E-05	2.30E-05	0.0	5.00E 01	2.30E-05	2.30E-05	0.0
PB-210	5.00E 01	2.30E-05	2.30E-05	0.0	5.00E 01	2.30E-05	2.30E-05	0.0

IZ= 8

APPENDIX F

2. Output (a) continued

** DISPX(JF,IZ) DATA, (JF=1,2,3,4)

IZ= 1		IZ= 2
1.00E 00 7.90E 11 0.0 1.00E 00	1.00E 00 1.01E 14 5.06E 13 1.00E 00	
IZ= 3	IZ= 4	
1.00E 00 2.27E 14 1.14E 14 1.00E 00	1.00E 00 4.77E 13 1.12E 13 1.00E 00	
IZ= 5	IZ= 6	
1.00E 00 1.22E 14 3.06E 13 1.00E 00	1.00E 00 1.14E 14 2.85E 13 1.00E 00	
IZ= 7	IZ= 8	
1.00E 00 1.57E 14 7.68E 13 1.00E 00	1.00E 00 5.46E 12 2.60E 14 1.00E 00	

** ZONALO(JF,IZ) DATA, (JF=1,2,3,4)

IZ= 1		IZ= 2
1.26E-20 1.29E-01 0.0 0.0	5.31E-23 4.41E-01 2.17E-03 1.00E 00	
IZ= 3	IZ= 4	
5.09E-24 9.18E-02 4.60E-04 0.0	2.12E-24 9.68E-03 2.18E-05 0.0	
IZ= 5	IZ= 6	
3.83E-24 3.59E-02 9.00E-05 0.0	3.03E-23 2.42E-01 6.08E-04 0.0	
IZ= 7	IZ= 8	
3.18E-24 4.18E-02 2.10E-04 0.0	3.12E-23 1.46E-02 1.44E-03 1.00E 00	

** ZONDEP(IZ) DATA

IZ= 1	IZ= 2	IZ= 3	IZ= 4	IZ= 5	IZ= 6	IZ= 7	IZ= 8
4.04E-13	1.93E-15	1.94E-16	1.05E-16	1.79E-16	1.17E-15	1.50E-16	1.25E-15

APPENDIX F

2. Output (a) continued

** AREA(IZ) DATA

IZ= 1	IZ= 2	IZ= 3	IZ= 4	IZ= 5	IZ= 6	IZ= 7	IZ= 8
0.0	5.06E 11	1.14E 12	1.12E 11	3.06E 11	2.85E 11	7.88E 11	5.40E 11

** ADJ1(JF,JFA,IZ),ADJ2(JF,JFA,IZ) DATA, (JFA=1,2,3,4)

IZ= 1									
JF= 1	0.0	0.0	1.00E-09	2.00E 01	0.0	0.0	0.0	0.0	0.0
JF= 2	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
JF= 3	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
JF= 4	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
IZ= 2									
JF= 1	0.0	0.0	1.00E-09	2.00E 01	0.0	0.0	0.0	0.0	0.0
JF= 2	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
JF= 3	0.0	0.0	0.0	0.0	0.0	0.0	2.00E-01	2.00E 01	0.0
JF= 4	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
IZ= 3									
JF= 1	0.0	0.0	1.00E-09	2.00E 01	0.0	0.0	0.0	0.0	0.0
JF= 2	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
JF= 3	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
JF= 4	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
IZ= 4									
JF= 1	0.0	0.0	1.00E-09	2.00E 01	0.0	0.0	0.0	0.0	0.0
JF= 2	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
JF= 3	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
JF= 4	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
IZ= 5									
JF= 1	0.0	0.0	1.00E-09	2.00E 01	0.0	0.0	0.0	0.0	0.0
JF= 2	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
JF= 3	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
JF= 4	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
IZ= 6									
JF= 1	0.0	0.0	1.00E-09	2.00E 01	0.0	0.0	0.0	0.0	0.0
JF= 2	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
JF= 3	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
JF= 4	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
IZ= 7									
JF= 1	0.0	0.0	1.00E-09	2.00E 01	0.0	0.0	0.0	0.0	0.0
JF= 2	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
JF= 3	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
JF= 4	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
IZ= 8									
JF= 1	0.0	0.0	1.00E-09	2.00E 01	0.0	0.0	0.0	0.0	0.0
JF= 2	0.0	0.0	0.0	0.0	5.00E-01	2.00E 01	0.0	0.0	0.0
JF= 3	0.0	0.0	0.0	0.0	0.0	0.0	8.00E-01	2.00E 01	0.0
JF= 4	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0

APPENDIX F

2. Output (a) continued

** VOLINT(JF,MODE,NSP) DATA

IZ=	JF	MODE	NSP=1 THRU	VOLINT			
1	1	1	1	1.00E 00			
	1	2	1	7.30E 09			
	2	1	4	4.00E-01	0.0	0.0	0.0
	2	2	4	0.0	6.30E 07	0.0	0.0
	3	1	4	0.0	0.0	0.0	0.0
	3	2	4	0.0	0.0	0.0	0.0
	4	1	1	0.0			
	4	2	1	0.0			
2	1	1	1	1.00E 00			
	1	2	1	7.30E 09			
	2	1	4	4.00E-01	0.0	0.0	0.0
	2	2	4	0.0	1.18E 10	0.0	0.0
	3	1	4	1.00E-03	0.0	0.0	0.0
	3	2	4	4.00E 05	5.90E 09	0.0	0.0
	4	1	1	4.80E 03			
	4	2	1	7.08E 07			
3	1	1	1	1.00E 00			
	1	2	1	7.30E 09			
	2	1	4	4.00E-01	0.0	0.0	0.0
	2	2	4	1.11E 10	1.81E 10	4.67E 08	4.05E 09
	3	1	4	1.00E-03	0.0	0.0	0.0
	3	2	4	2.00E 05	4.60E 09	4.05E 09	0.0
	4	1	1	0.0			
	4	2	1	0.0			
4	1	1	1	1.00E 00			
	1	2	1	7.30E 09			
	2	1	4	4.00E-01	0.0	0.0	0.0
	2	2	4	3.95E 09	7.60E 09	8.32E 08	3.21E 09
	3	1	4	1.00E-03	0.0	0.0	0.0
	3	2	4	0.0	0.0	3.21E 09	0.0
	4	1	1	0.0			
	4	2	1	0.0			

APPENDIX F

2. Output (a) continued

```

IZ= 5
JF      MODE      NSP=1 THRU      VOL INT
1        1          1      1.00E 00
1        2          1      7.30E 09
2        1          4      4.00E-01      0.0      0.0      0.0
2        2          4      2.52E 11      1.02E 10      5.43E 09      1.58E 10
3        1          4      1.00E-03      0.0      0.0      0.0
3        2          4      0.0      0.0      1.58E 10      0.0
4        1          1      0.0
4        2          1      0.0

IZ= 6
JF      MODE      NSP=1 THRU      VOL INT
1        1          1      1.00E 00
1        2          1      7.30E 09
2        1          4      4.00E-01      0.0      0.0      0.0
2        2          4      1.97E 10      1.38E 10      1.92E 09      1.50E 10
3        1          4      1.00E-03      0.0      0.0      0.0
3        2          4      0.0      0.0      1.50E 10      0.0
4        1          1      0.0
4        2          1      0.0

IZ= 7
JF      MODE      NSP=1 THRU      VOL INT
1        1          1      1.00E 00
1        2          1      7.30E 09
2        1          4      4.00E-01      0.0      0.0      0.0
2        2          4      5.82E 09      3.27E 10      7.88E 09      6.31E 10
3        1          4      1.00E-03      0.0      0.0      0.0
3        2          4      4.00E 05      1.67E 10      6.31E 10      0.0
4        1          1      0.0
4        2          1      0.0

IZ= 8
JF      MODE      NSP=1 THRU      VOL INT
1        1          1      1.00E 00
1        2          1      7.30E 09
2        1          4      4.00E-01      0.0      0.0      0.0
2        2          4      2.84E 09      0.0      6.23E 09      3.46E 10
3        1          4      1.00E-03      0.0      0.0      0.0
3        2          4      4.00E 05      9.60E 08      3.46E 10      0.0
4        1          1      2.00E 04
4        2          1      4.80E 07

```

APPENDIX F

2. Output (a) continued

** BIOFAC(K,JF,NSP) DATA

RADIONUCLIDE= SR-90

JF NSP=1 THRU

BIOFAC

1	1	1.00E 00			
2	4	5.26E-01	5.23E-03	3.56E-03	1.84E-02
3	4	1.00E 00	2.40E-01	5.12E-01	0.0
4	1	2.40E-01			

RADIONUCLIDE= I-129

JF NSP=1 THRU

BIOFAC

1	1	1.00E 00			
2	4	5.26E-01	9.48E-01	2.59E-01	9.86E-02
3	4	1.00E 00	1.16E 00	3.84E 00	0.0
4	1	1.16E 00			

RADIONUCLIDE= PB-210

JF NSP=1 THRU

BIOFAC

1	1	1.00E 00			
2	4	5.26E-01	2.32E-03	1.71E-03	5.62E-03
3	4	1.00E 00	1.16E-01	3.97E-01	0.0
4	1	1.16E-01			

APPENDIX F

2. Output (a) continued

** DQSFAC(K,JF,MODE,IH) DATA

ORGAN = TOY BODY

	JF=1		JF=2		JF=3		JF=4	
	MODE=1	MODE=2	MODE=1	MODE=2	MODE=1	MODE=2	MODE=1	MODE=2
SR-90	0.0	1.78E 03	0.0	1.69E 02	0.0	1.69E 02	1.69E 02	1.69E 02
I-129	9.55E 07	4.19E 00	5.73E 04	7.22E 00	2.01E 03	7.22E 00	7.22E 00	7.22E 00
PB-210	1.43E 07	3.40E 03	2.27E 04	5.10E 02	3.00E 02	5.10E 02	5.10E 02	5.10E 02

ORGAN = GI TRACT

	JF=1		JF=2		JF=3		JF=4	
	MODE=1	MODE=2	MODE=1	MODE=2	MODE=1	MODE=2	MODE=1	MODE=2
SR-90	0.0	3.56E 01	0.0	4.85E 01	0.0	4.85E 01	4.85E 01	4.85E 01
I-129	1.98E 07	5.34E 00	1.19E 04	9.70E 00	4.18E 02	9.70E 00	9.70E 00	9.70E 00
PB-210	5.75E 06	7.12E 00	9.15E 03	9.70E 00	1.21E 02	9.70E 00	9.70E 00	9.70E 00

ORGAN = GONADS

	JF=1		JF=2		JF=3		JF=4	
	MODE=1	MODE=2	MODE=1	MODE=2	MODE=1	MODE=2	MODE=1	MODE=2
SR-90	0.0	1.78E 03	0.0	1.69E 02	0.0	1.69E 02	1.69E 02	1.69E 02
I-129	1.31E 08	4.19E 00	7.88E 04	7.22E 00	2.74E 03	7.22E 00	7.22E 00	7.22E 00
PB-210	1.21E 07	3.40E 03	1.92E 04	5.10E 02	2.54E 02	5.10E 02	5.10E 02	5.10E 02

ORGAN = LIVER

	JF=1		JF=2		JF=3		JF=4	
	MODE=1	MODE=2	MODE=1	MODE=2	MODE=1	MODE=2	MODE=1	MODE=2
SR-90	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
I-129	3.60E 07	2.11E 00	2.16E 04	2.81E 00	7.57E 02	2.81E 00	2.81E 00	2.81E 00
PB-210	7.27E 06	3.10E 04	1.16E 04	4.70E 03	1.53E 02	4.70E 03	4.70E 03	4.70E 03

APPENDIX F

2. Output (a) concluded

ORGAN = LUNGS

	JF=1		JF=2		JF=3		JF=4	
	MODE=1	MODE=2	MODE=1	MODE=2	MODE=1	MODE=2	MODE=1	MODE=2
SR-90	0.0	9.71E 03	0.0	0.0	0.0	0.0	0.0	0.0
I-129	4.85E 07	4.45E 02	2.51E 04	0.0	1.02E 03	0.0	0.0	0.0
PB-210	9.02E 06	5.40E 05	1.44E 04	0.0	1.90E 02	0.0	0.0	0.0

ORGAN = MARROW

	JF=1		JF=2		JF=3		JF=4	
	MODE=1	MODE=2	MODE=1	MODE=2	MODE=1	MODE=2	MODE=1	MODE=2
SR-90	0.0	2.67E 04	0.0	8.43E 03	0.0	8.43E 03	8.43E 03	8.43E 03
I-129	1.56E 08	2.48E 00	9.38E 04	3.27E 00	3.29E 03	3.27E 00	3.27E 00	3.27E 00
PB-210	2.65E 07	3.30E 05	4.22E 04	5.00E 04	5.59E 02	5.00E 04	5.00E 04	5.00E 04

ORGAN = BONE

	JF=1		JF=2		JF=3		JF=4	
	MODE=1	MODE=2	MODE=1	MODE=2	MODE=1	MODE=2	MODE=1	MODE=2
SR-90	0.0	2.67E 04	0.0	8.43E 03	0.0	8.43E 03	8.43E 03	8.43E 03
I-129	1.45E 08	2.48E 00	8.72E 04	3.27E 00	3.06E 03	3.27E 00	3.27E 00	3.27E 00
PB-210	2.45E 07	3.30E 05	3.90E 04	5.00E 04	5.15E 02	5.00E 04	5.00E 04	5.00E 04

ORGAN = THYROID

	JF=1		JF=2		JF=3		JF=4	
	MODE=1	MODE=2	MODE=1	MODE=2	MODE=1	MODE=2	MODE=1	MODE=2
SR-90	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
I-129	1.01E 08	5.55E 03	6.04E 04	5.17E 03	2.12E 03	5.17E 03	5.17E 03	5.17E 03
PB-210	1.20E 07	0.0	1.91E 04	0.0	2.53E 02	0.0	0.0	0.0

APPENDIX F 2. Output (b)

RADIONUCLIDE: I-129 (K = 2)

RELEASE FRACTIONS BY EACH CUTSET, RELOUT

TIME	JF	INITIAL RELEASE FRACTIONS		
40.	1	5.00E-14	1.80E-12	1.44E-13
40.	2	0.0	5.00E-14	6.07E-12
40.	3	0.0	5.00E-14	6.07E-12
40.	4	9.97E-12		
50.	1	5.00E-14	1.80E-12	1.44E-13
50.	2	0.0	5.00E-14	6.07E-12
50.	3	0.0	5.00E-14	6.07E-12
50.	4	9.97E-12		
60.	1	5.00E-14	1.80E-12	1.44E-13
60.	2	0.0	5.00E-14	6.07E-12
60.	3	0.0	5.00E-14	6.07E-12
60.	4	9.97E-12		
70.	1	5.00E-14	1.80E-12	1.44E-13
70.	2	0.0	5.00E-14	6.07E-12
70.	3	0.0	5.00E-14	6.07E-12
70.	4	9.97E-12		
80.	1	5.00E-14	1.80E-12	1.44E-13
80.	2	0.0	5.00E-14	6.07E-12
80.	3	0.0	5.00E-14	6.07E-12
80.	4	9.97E-12		
90.	1	5.00E-14	1.80E-12	1.44E-13
90.	2	0.0	5.00E-14	6.07E-12
90.	3	0.0	5.00E-14	6.07E-12
90.	4	9.97E-12		
100.	1	5.00E-14	1.80E-12	1.44E-13
100.	2	0.0	5.00E-14	6.07E-12
100.	3	0.0	5.00E-14	6.07E-12
100.	4	9.97E-12		
200.	1	5.00E-13	1.80E-11	1.44E-12
200.	2	0.0	5.00E-13	6.07E-11
200.	3	0.0	5.00E-13	6.07E-11
200.	4	9.00E-10		
300.	1	5.00E-13	1.80E-11	1.44E-12
300.	2	0.0	5.00E-13	6.07E-11
300.	3	0.0	5.00E-13	6.07E-11
300.	4	9.00E-10		
400.	1	5.00E-13	1.80E-11	1.44E-12
400.	2	0.0	5.00E-13	6.07E-11
400.	3	0.0	5.00E-13	6.07E-11
400.	4	9.00E-10		
500.	1	5.00E-13	1.80E-11	1.44E-12
500.	2	0.0	5.00E-13	6.07E-11
500.	3	0.0	5.00E-13	6.07E-11
500.	4	9.00E-10		
600.	1	5.00E-13	1.80E-11	1.44E-12
600.	2	0.0	5.00E-13	6.07E-11
600.	3	0.0	5.00E-13	6.07E-11
600.	4	9.00E-10		
700.	1	5.00E-13	1.80E-11	1.44E-12
700.	2	0.0	5.00E-13	6.07E-11
700.	3	0.0	5.00E-13	6.07E-11
700.	4	9.00E-10		
800.	1	5.00E-13	1.80E-11	1.44E-12
800.	2	0.0	5.00E-13	6.07E-11
800.	3	0.0	5.00E-13	6.07E-11
800.	4	9.00E-10		

This table continues through 1,000,000 years.

APPENDIX F

2. Output (b) continued

RADIONUCLIDE: I-129 (K= 2)

RELEASE INCREMENTS TO PRELIMINARY ENVIRONMENT INPUT
RECEPTORS, RIJ, FROM ALL RELEASE EVENTS, IN CURIES

TIME	JF=1 AIR	JF=2 GROUND SURFACE	JF=3 SURFACE WATER	JF=4 GROUND WATER
0.	0.0	0.0	0.0	0.0
5.	0.0	0.0	0.0	0.0
10.	0.0	0.0	0.0	0.0
15.	0.0	0.0	0.0	0.0
20.	0.0	0.0	0.0	0.0
25.	0.0	0.0	0.0	0.0
30.	0.0	0.0	0.0	0.0
40.	1.90E-11	5.83E-11	5.83E-11	9.49E-11
50.	1.90E-11	5.83E-11	5.83E-11	9.49E-11
60.	1.90E-11	5.83E-11	5.83E-11	9.49E-11
70.	1.90E-11	5.83E-11	5.83E-11	9.49E-11
80.	1.90E-11	5.83E-11	5.83E-11	9.49E-11
90.	1.90E-11	5.83E-11	5.83E-11	9.49E-11
100.	1.90E-11	5.83E-11	5.83E-11	9.49E-11
200.	1.90E-10	5.83E-10	5.83E-10	8.56E-09
300.	1.90E-10	5.83E-10	5.83E-10	8.56E-09
400.	1.90E-10	5.83E-10	5.83E-10	8.56E-09
500.	1.90E-10	5.83E-10	5.83E-10	8.56E-09
600.	1.90E-10	5.83E-10	5.83E-10	8.56E-09
700.	1.90E-10	5.83E-10	5.83E-10	8.56E-09
800.	1.90E-10	5.83E-10	5.83E-10	8.56E-09
900.	1.90E-10	5.83E-10	5.83E-10	8.56E-09
1000.	1.90E-10	5.83E-10	5.83E-10	8.56E-09
2000.	1.90E-09	5.83E-09	5.83E-09	8.36E-07
3000.	1.90E-09	5.83E-09	5.83E-09	8.36E-07
4000.	1.90E-09	5.83E-09	5.83E-09	8.36E-07
5000.	1.90E-09	5.83E-09	5.83E-09	8.36E-07
6000.	1.90E-09	5.83E-09	5.83E-09	8.36E-07
7000.	1.90E-09	5.83E-09	5.83E-09	8.36E-07
8000.	1.90E-09	5.83E-09	5.83E-09	8.36E-07
9000.	1.90E-09	5.83E-09	5.83E-09	8.36E-07
10000.	1.90E-09	5.83E-09	5.83E-09	8.36E-07
20000.	1.90E-08	5.83E-08	5.83E-08	8.33E-05
30000.	1.89E-08	5.82E-08	5.82E-08	8.32E-05
40000.	1.89E-08	5.82E-08	5.82E-08	8.32E-05
50000.	1.89E-08	5.82E-08	5.82E-08	8.32E-05
60000.	1.89E-08	5.82E-08	5.82E-08	8.32E-05
70000.	1.89E-08	5.82E-08	5.82E-08	8.31E-05
80000.	1.89E-08	5.81E-08	5.81E-08	8.31E-05
90000.	1.89E-08	5.81E-08	5.81E-08	8.31E-05
100000.	1.89E-08	5.81E-08	5.81E-08	8.31E-05
200000.	1.89E-07	5.80E-07	5.80E-07	8.29E-03
300000.	1.88E-07	5.78E-07	5.78E-07	8.26E-03
400000.	1.87E-07	5.78E-07	5.78E-07	8.21E-03
500000.	1.86E-07	5.72E-07	5.72E-07	8.18E-03
600000.	1.85E-07	5.70E-07	5.70E-07	8.14E-03
700000.	1.85E-07	5.67E-07	5.67E-07	8.11E-03
800000.	1.84E-07	5.65E-07	5.65E-07	8.08E-03
900000.	1.83E-07	5.63E-07	5.63E-07	8.05E-03
1000000.	1.83E-07	5.61E-07	5.61E-07	8.02E-03

APPENDIX F

2. Output (b) continued

RADIOISOTOPE: I-129 (K= 2)

CONCENTRATIONS AT ENVIRONMENT INPUT RECEPTOR, R2TUT UNITS: JF=1 MICROCURIE*YEARS/CUBIC CM
JF=2 MICROCURIES/SQUARE CM. JF=3 AND 4 MICROCURIES/CUBIC CM

ZONE= 1

TIME	JF=1 AIR	JF=2 GROUND SURFACE	JF=3 SURFACE WATER	JF=4 GROUND WATER
0.	0.0	0.0	0.0	0.0
5.	0.0	0.0	0.0	0.0
10.	0.0	0.0	0.0	0.0
15.	0.0	0.0	0.0	0.0
20.	0.0	0.0	0.0	0.0
25.	0.0	0.0	0.0	0.0
30.	0.0	0.0	0.0	0.0
40.	4.11E-25	1.72E-17	0.0	0.0
50.	5.83E-25	3.44E-17	0.0	0.0
60.	7.55E-25	5.16E-17	0.0	0.0
70.	9.26E-25	6.87E-17	0.0	0.0
80.	1.10E-24	8.59E-17	0.0	0.0
90.	1.27E-24	1.03E-16	0.0	0.0
100.	1.44E-24	1.20E-16	0.0	0.0
200.	3.16E-23	2.92E-16	0.0	0.0
300.	4.87E-23	4.63E-16	0.0	0.0
400.	6.58E-23	6.34E-16	0.0	0.0
500.	8.28E-23	8.04E-16	0.0	0.0
600.	9.98E-23	9.75E-16	0.0	0.0
700.	1.17E-22	1.14E-15	0.0	0.0
800.	1.34E-22	1.31E-15	0.0	0.0
900.	1.51E-22	1.48E-15	0.0	0.0
1000.	1.67E-22	1.65E-15	0.0	0.0
2000.	3.37E-21	3.35E-15	0.0	0.0
3000.	5.02E-21	4.99E-15	0.0	0.0
4000.	6.62E-21	6.60E-15	0.0	0.0
5000.	8.19E-21	8.17E-15	0.0	0.0
6000.	9.72E-21	9.70E-15	0.0	0.0
7000.	1.12E-20	1.12E-14	0.0	0.0
8000.	1.27E-20	1.27E-14	0.0	0.0
9000.	1.41E-20	1.41E-14	0.0	0.0
10000.	1.55E-20	1.55E-14	0.0	0.0
20000.	3.08E-19	3.08E-14	0.0	0.0
30000.	4.16E-19	4.16E-14	0.0	0.0
40000.	5.03E-19	5.02E-14	0.0	0.0
50000.	5.71E-19	5.71E-14	0.0	0.0
60000.	6.25E-19	6.25E-14	0.0	0.0
70000.	6.68E-19	6.68E-14	0.0	0.0
80000.	7.02E-19	7.02E-14	0.0	0.0
90000.	7.29E-19	7.29E-14	0.0	0.0
100000.	7.50E-19	7.50E-14	0.0	0.0
200000.	1.92E-17	1.92E-13	0.0	0.0
300000.	1.89E-17	1.89E-13	0.0	0.0
400000.	1.88E-17	1.88E-13	0.0	0.0
500000.	1.87E-17	1.87E-13	0.0	0.0
600000.	1.87E-17	1.87E-13	0.0	0.0
700000.	1.86E-17	1.86E-13	0.0	0.0
800000.	1.85E-17	1.85E-13	0.0	0.0
900000.	1.85E-17	1.85E-13	0.0	0.0
1000000.	1.84E-17	1.84E-13	0.0	0.0

ZONE= 2

TIME	JF=1 AIR	JF=2 GROUND SURFACE	JF=3 SURFACE WATER	JF=4 GROUND WATER
0.	0.0	0.0	0.0	0.0
5.	0.0	0.0	0.0	0.0
10.	0.0	0.0	0.0	0.0
15.	0.0	0.0	0.0	0.0
20.	0.0	0.0	0.0	0.0
25.	0.0	0.0	0.0	0.0
30.	0.0	0.0	0.0	0.0
40.	3.92E-27	2.91E-19	2.87E-21	0.0
50.	6.83E-27	5.82E-19	5.73E-21	0.0
60.	9.74E-27	8.73E-19	8.60E-21	0.0
70.	1.27E-26	1.16E-18	1.15E-20	0.0
80.	1.56E-26	1.45E-18	1.43E-20	0.0
90.	1.85E-26	1.75E-18	1.72E-20	0.0
100.	2.14E-26	2.04E-18	2.01E-20	0.0
200.	5.05E-25	4.95E-18	4.87E-20	0.0
300.	7.95E-25	7.85E-18	7.73E-20	0.0
400.	1.08E-24	1.07E-17	1.06E-19	0.0
500.	1.37E-24	1.36E-17	1.34E-19	0.0
600.	1.66E-24	1.65E-17	1.63E-19	0.0
700.	1.95E-24	1.94E-17	1.91E-19	0.0
800.	2.24E-24	2.23E-17	2.19E-19	0.0
900.	2.52E-24	2.51E-17	2.47E-19	0.0
1000.	2.81E-24	2.80E-17	2.75E-19	0.0
2000.	5.68E-23	5.67E-17	5.59E-19	0.0
3000.	8.47E-23	8.46E-17	8.33E-19	1.67E-35
4000.	1.12E-22	1.12E-16	1.10E-18	3.00E-25
5000.	1.38E-22	1.38E-16	1.37E-18	3.70E-20
6000.	1.64E-22	1.64E-16	2.74E-18	9.97E-18
7000.	1.90E-22	1.90E-16	1.46E-17	1.05E-16
8000.	2.15E-22	2.15E-16	9.16E-17	6.90E-16
9000.	2.39E-22	2.39E-16	3.51E-16	2.34E-15
10000.	2.63E-22	2.62E-16	7.74E-16	3.85E-15
20000.	5.22E-21	5.22E-16	1.03E-15	3.08E-16
30000.	7.05E-21	7.05E-16	5.14E-15	3.87E-15
40000.	8.51E-21	8.51E-16	8.40E-15	3.86E-15
50000.	9.67E-21	9.67E-16	1.10E-14	3.86E-15
60000.	1.08E-20	1.06E-15	1.31E-14	3.86E-15
70000.	1.13E-20	1.13E-15	1.47E-14	3.86E-15
80000.	1.19E-20	1.19E-15	1.60E-14	3.86E-15
90000.	1.23E-20	1.23E-15	1.70E-14	3.86E-15
100000.	1.27E-20	1.27E-15	1.78E-14	3.86E-15
200000.	3.26E-19	3.26E-15	5.52E-15	4.20E-17
300000.	3.21E-19	3.21E-15	4.74E-14	4.19E-15
400000.	3.19E-19	3.19E-15	5.13E-14	4.17E-15
500000.	3.18E-19	3.18E-15	5.15E-14	4.15E-15
600000.	3.16E-19	3.16E-15	5.13E-14	4.13E-15
700000.	3.15E-19	3.15E-15	5.11E-14	4.12E-15
800000.	3.14E-19	3.14E-15	5.09E-14	4.10E-15
900000.	3.13E-19	3.13E-15	5.07E-14	4.08E-15
1000000.	3.11E-19	3.11E-15	5.05E-14	4.07E-15

APPENDIX F

2. Output (c)

** AVERAGE ANNUAL LOCAL DOSE TO INDIVIDUAL, NANIL, IN MILLIREMS/YEAR

ZONE= 1... NUCLEIDE= 1-129 K= 2

TIME	TOT BODY	GI TRACT	GONADS	LIVER	LUNGS	MARROW	BONE	THYROID
0.	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
5.	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
10.	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
15.	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
20.	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
25.	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
30.	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
40.	3.95E-13	6.34E-14	5.43E-13	1.49E-13	3.34E-13	6.46E-13	6.00E-13	2.08E-12
50.	7.90E-13	1.66E-13	1.09E-12	2.98E-13	5.89E-13	1.29E-12	1.20E-12	3.19E-12
60.	1.18E-12	2.48E-13	1.63E-12	4.47E-13	8.45E-13	1.94E-12	1.80E-12	4.30E-12
70.	1.58E-12	3.31E-13	2.17E-12	5.95E-13	1.10E-12	2.58E-12	2.40E-12	5.41E-12
80.	1.97E-12	4.13E-13	2.71E-12	7.44E-13	1.36E-12	3.23E-12	3.00E-12	6.52E-12
90.	2.37E-12	4.96E-13	3.25E-12	8.93E-13	1.61E-12	3.87E-12	3.60E-12	7.64E-12
100.	2.76E-12	5.78E-13	3.79E-12	1.04E-12	1.87E-12	4.51E-12	4.20E-12	8.75E-12
200.	6.70E-12	1.40E-12	9.21E-12	2.53E-12	4.42E-12	1.10E-11	1.02E-11	1.99E-11
300.	1.06E-11	2.22E-12	1.46E-11	4.01E-12	6.97E-12	1.74E-11	1.62E-11	3.09E-11
400.	1.46E-11	3.04E-12	2.00E-11	5.49E-12	9.52E-12	2.38E-11	2.21E-11	4.20E-11
500.	1.85E-11	3.86E-12	2.54E-11	6.96E-12	1.21E-11	3.02E-11	2.81E-11	5.30E-11
600.	2.24E-11	4.68E-12	3.07E-11	8.44E-12	1.46E-11	3.66E-11	3.40E-11	6.40E-11
700.	2.63E-11	5.49E-12	3.61E-11	9.90E-12	1.71E-11	4.30E-11	3.99E-11	7.50E-11
800.	3.01E-11	6.30E-12	4.14E-11	1.14E-11	1.96E-11	4.93E-11	4.58E-11	8.59E-11
900.	3.40E-11	7.11E-12	4.68E-11	1.29E-11	2.21E-11	5.56E-11	5.17E-11	9.68E-11
1000.	3.79E-11	7.92E-12	5.21E-11	1.43E-11	2.47E-11	6.20E-11	5.76E-11	1.08E-10
2000.	7.69E-11	1.61E-11	1.06E-10	2.90E-11	4.99E-11	1.26E-10	1.17E-10	2.18E-10
3000.	1.15E-10	2.40E-11	1.57E-10	4.32E-11	7.44E-11	1.87E-10	1.74E-10	3.24E-10
4000.	1.51E-10	3.17E-11	2.08E-10	5.71E-11	9.83E-11	2.48E-10	2.30E-10	4.28E-10
5000.	1.87E-10	3.92E-11	2.59E-10	7.07E-11	1.22E-10	3.07E-10	2.85E-10	5.29E-10
6000.	2.23E-10	4.65E-11	3.06E-10	8.40E-11	1.44E-10	3.64E-10	3.38E-10	6.28E-10
7000.	2.57E-10	5.37E-11	3.53E-10	9.69E-11	1.67E-10	4.20E-10	3.91E-10	7.25E-10
8000.	2.91E-10	6.08E-11	3.99E-10	1.10E-10	1.89E-10	4.75E-10	4.42E-10	8.20E-10
9000.	3.23E-10	6.76E-11	4.45E-10	1.22E-10	2.10E-10	5.29E-10	4.92E-10	9.12E-10
10000.	3.56E-10	7.43E-11	4.89E-10	1.34E-10	2.31E-10	5.82E-10	5.41E-10	1.00E-09
20000.	7.07E-10	1.48E-10	9.72E-10	2.67E-10	4.59E-10	1.16E-09	1.08E-09	1.99E-09
30000.	9.55E-10	2.00E-10	1.31E-09	3.60E-10	6.20E-10	1.56E-09	1.45E-09	2.69E-09
40000.	1.15E-09	2.41E-10	1.58E-09	4.35E-10	7.48E-10	1.89E-09	1.75E-09	3.25E-09
50000.	1.31E-09	2.74E-10	1.80E-09	4.94E-10	8.50E-10	2.14E-09	1.99E-09	3.69E-09
60000.	1.43E-09	3.00E-10	1.97E-09	5.41E-10	9.31E-10	2.35E-09	2.18E-09	4.04E-09
70000.	1.53E-09	3.20E-10	2.11E-09	5.78E-10	9.94E-10	2.51E-09	2.33E-09	4.32E-09
80000.	1.61E-09	3.37E-10	2.21E-09	6.07E-10	1.04E-09	2.63E-09	2.45E-09	4.54E-09
90000.	1.67E-09	3.50E-10	2.30E-09	6.31E-10	1.08E-09	2.73E-09	2.54E-09	4.71E-09
100000.	1.72E-09	3.60E-10	2.37E-09	6.49E-10	1.12E-09	2.82E-09	2.62E-09	4.85E-09
200000.	4.41E-09	9.22E-10	6.06E-09	1.66E-09	2.86E-09	7.21E-09	6.71E-09	1.24E-08
300000.	4.35E-09	9.09E-10	5.98E-09	1.64E-09	2.82E-09	7.11E-09	6.61E-09	1.23E-08
400000.	4.32E-09	9.04E-10	5.94E-09	1.63E-09	2.80E-09	7.07E-09	6.57E-09	1.22E-08
500000.	4.30E-09	9.00E-10	5.91E-09	1.62E-09	2.79E-09	7.04E-09	6.54E-09	1.21E-08
600000.	4.28E-09	8.96E-10	5.89E-09	1.62E-09	2.78E-09	7.01E-09	6.51E-09	1.21E-08
700000.	4.26E-09	8.92E-10	5.86E-09	1.61E-09	2.77E-09	6.98E-09	6.48E-09	1.20E-08
800000.	4.25E-09	8.89E-10	5.84E-09	1.60E-09	2.76E-09	6.95E-09	6.46E-09	1.20E-08
900000.	4.23E-09	8.85E-10	5.82E-09	1.60E-09	2.75E-09	6.93E-09	6.44E-09	1.19E-08
1000000.	4.22E-09	8.82E-10	5.80E-09	1.59E-09	2.74E-09	6.90E-09	6.42E-09	1.19E-08

APPENDIX F

2. Output (d)

** AVERAGE ANNUAL NONSPECIFIC DOSE TO POPULATION. MANIN. IN MANREMS/YEAR

NONSPECIFIC ... NUCLIDE= I-129 K= 2

TIME	TOT BODY	GI TRACT	GONADS	LIVER	LUNGS	MARROW	BONE	THYROID
0.	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
5.	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
10.	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
15.	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
20.	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
25.	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
30.	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
40.	1.15E-11	1.55E-11	1.15E-11	4.49E-12	0.0	5.22E-12	5.22E-12	8.25E-09
50.	1.29E-11	1.74E-11	1.29E-11	5.04E-12	0.0	5.86E-12	5.86E-12	9.27E-09
60.	1.43E-11	1.92E-11	1.43E-11	5.56E-12	0.0	6.47E-12	6.47E-12	1.02E-08
70.	1.56E-11	2.09E-11	1.56E-11	6.06E-12	0.0	7.05E-12	7.05E-12	1.11E-08
80.	1.68E-11	2.26E-11	1.68E-11	6.55E-12	0.0	7.62E-12	7.62E-12	1.21E-08
90.	1.81E-11	2.43E-11	1.81E-11	7.04E-12	0.0	8.19E-12	8.19E-12	1.29E-08
100.	1.93E-11	2.60E-11	1.93E-11	7.52E-12	0.0	8.75E-12	8.75E-12	1.38E-08
200.	3.50E-11	4.70E-11	3.50E-11	1.36E-11	0.0	1.58E-11	1.58E-11	2.50E-08
300.	4.90E-11	6.58E-11	4.90E-11	1.91E-11	0.0	2.22E-11	2.22E-11	3.51E-08
400.	6.21E-11	8.34E-11	6.21E-11	2.42E-11	0.0	2.81E-11	2.81E-11	4.45E-08
500.	7.48E-11	1.01E-10	7.48E-11	2.91E-11	0.0	3.39E-11	3.39E-11	5.36E-08
600.	8.73E-11	1.17E-10	8.73E-11	3.40E-11	0.0	3.95E-11	3.95E-11	6.25E-08
700.	9.97E-11	1.34E-10	9.97E-11	3.88E-11	0.0	4.51E-11	4.51E-11	7.14E-08
800.	1.12E-10	1.50E-10	1.12E-10	4.36E-11	0.0	5.07E-11	5.07E-11	8.01E-08
900.	1.24E-10	1.67E-10	1.24E-10	4.83E-11	0.0	5.62E-11	5.62E-11	8.89E-08
1000.	1.36E-10	1.83E-10	1.36E-10	5.31E-11	0.0	6.17E-11	6.17E-11	9.76E-08
2000.	2.91E-10	3.91E-10	2.91E-10	1.13E-10	0.0	1.32E-10	1.32E-10	2.09E-07
3000.	4.26E-10	5.72E-10	4.26E-10	1.66E-10	0.0	1.93E-10	1.93E-10	3.05E-07
4000.	5.49E-10	7.38E-10	5.49E-10	2.14E-10	0.0	2.49E-10	2.49E-10	3.93E-07
5000.	6.67E-10	8.96E-10	6.67E-10	2.60E-10	0.0	3.02E-10	3.02E-10	4.77E-07
6000.	8.40E-10	1.13E-09	8.40E-10	3.27E-10	0.0	3.81E-10	3.81E-10	6.02E-07
7000.	1.58E-09	2.12E-09	1.58E-09	6.15E-10	0.0	7.16E-10	7.16E-10	1.13E-06
8000.	5.83E-09	7.83E-09	5.83E-09	2.27E-09	0.0	2.64E-09	2.64E-09	4.17E-06
9000.	1.97E-08	2.65E-08	1.97E-08	7.68E-09	0.0	8.93E-09	8.93E-09	1.41E-05
10000.	4.16E-08	5.59E-08	4.16E-08	1.62E-08	0.0	1.88E-08	1.88E-08	2.98E-05
20000.	2.28E-07	3.06E-07	2.28E-07	8.88E-08	0.0	1.03E-07	1.03E-07	1.63E-04
30000.	5.57E-07	7.48E-07	5.57E-07	2.17E-07	0.0	2.52E-07	2.52E-07	3.99E-04
40000.	3.90E-06	5.25E-06	3.90E-06	1.52E-06	0.0	1.77E-06	1.77E-06	2.80E-03
50000.	6.54E-06	8.79E-06	6.54E-06	2.55E-06	0.0	2.96E-06	2.96E-06	4.69E-03
60000.	7.64E-06	1.03E-05	7.64E-06	2.97E-06	0.0	3.46E-06	3.46E-06	5.47E-03
70000.	8.11E-06	1.09E-05	8.11E-06	3.16E-06	0.0	3.67E-06	3.67E-06	5.81E-03
80000.	8.32E-06	1.12E-05	8.32E-06	3.24E-06	0.0	3.77E-06	3.77E-06	5.96E-03
90000.	8.44E-06	1.13E-05	8.44E-06	3.29E-06	0.0	3.82E-06	3.82E-06	6.04E-03
100000.	8.51E-06	1.14E-05	8.51E-06	3.31E-06	0.0	3.85E-06	3.85E-06	6.09E-03
200000.	2.54E-06	3.41E-06	2.54E-06	9.89E-07	0.0	1.15E-06	1.15E-06	1.82E-03
300000.	3.81E-05	5.12E-05	3.81E-05	1.48E-05	0.0	1.73E-05	1.73E-05	2.73E-02
400000.	4.16E-05	5.58E-05	4.16E-05	1.62E-05	0.0	1.88E-05	1.88E-05	2.98E-02
500000.	4.16E-05	5.59E-05	4.16E-05	1.62E-05	0.0	1.88E-05	1.88E-05	2.98E-02
600000.	4.14E-05	5.56E-05	4.14E-05	1.61E-05	0.0	1.87E-05	1.87E-05	2.96E-02
700000.	4.12E-05	5.54E-05	4.12E-05	1.61E-05	0.0	1.87E-05	1.87E-05	2.95E-02
800000.	4.11E-05	5.52E-05	4.11E-05	1.60E-05	0.0	1.86E-05	1.86E-05	2.94E-02
900000.	4.09E-05	5.50E-05	4.09E-05	1.59E-05	0.0	1.85E-05	1.85E-05	2.93E-02
1000000.	4.08E-05	5.48E-05	4.08E-05	1.59E-05	0.0	1.85E-05	1.85E-05	2.92E-02

APPENDIX F

2. Output (e)

♦♦ AVERAGE ANNUAL LOCAL DOSE TO INDIVIDUAL, MAN2LF FOR JF=1 TO 4. MAN2L FOR TOTAL. IN MILLIREMS/YEAR

TOTAL FOR ALL NUCLIDES

TOT BODY

ZONE= 1

ZONE= 2

TIME	JF=1 AIR	JF=2 GROUND SURFACE	JF=3 SURFACE WATER	JF=4 GROUND WATER	TOTAL	TIME	JF=1 AIR	JF=2 GROUND SURFACE	JF=3 SURFACE WATER	JF=4 GROUND WATER	TOTAL
0.	0.0	0.0	0.0	0.0	0.0	0.	0.0	0.0	0.0	0.0	0.0
5.	0.0	0.0	0.0	0.0	0.0	5.	0.0	0.0	0.0	0.0	0.0
10.	0.0	0.0	0.0	0.0	0.0	10.	0.0	0.0	0.0	0.0	0.0
15.	0.0	0.0	0.0	0.0	0.0	15.	0.0	0.0	0.0	0.0	0.0
20.	0.0	0.0	0.0	0.0	0.0	20.	0.0	0.0	0.0	0.0	0.0
25.	0.0	0.0	0.0	0.0	0.0	25.	0.0	0.0	0.0	0.0	0.0
30.	0.0	0.0	0.0	0.0	0.0	30.	0.0	0.0	0.0	0.0	0.0
40.	4.46E-04	3.95E-13	0.0	0.0	4.46E-04	40.	4.25E-06	6.69E-15	1.62E-04	0.0	1.66E-04
50.	4.98E-04	7.90E-13	0.0	0.0	4.98E-04	50.	5.83E-06	1.34E-14	2.55E-04	0.0	2.60E-04
60.	5.11E-04	1.19E-12	0.0	0.0	5.11E-04	60.	6.60E-06	2.01E-14	3.03E-04	0.0	3.10E-04
70.	4.96E-04	1.58E-12	0.0	0.0	4.96E-04	70.	6.77E-06	2.68E-14	3.19E-04	0.0	3.26E-04
80.	4.62E-04	1.98E-12	0.0	0.0	4.62E-04	80.	6.55E-06	3.38E-14	3.14E-04	0.0	3.20E-04
90.	4.17E-04	2.38E-12	0.0	0.0	4.17E-04	90.	6.07E-06	4.03E-14	2.94E-04	0.0	3.00E-04
100.	3.67E-04	2.78E-12	0.0	0.0	3.67E-04	100.	5.45E-06	4.71E-14	2.66E-04	0.0	2.71E-04
200.	3.79E-04	6.87E-12	0.0	0.0	3.79E-04	200.	6.06E-06	1.16E-13	3.04E-04	0.0	3.10E-04
300.	4.55E-05	1.15E-11	0.0	0.0	4.55E-05	300.	7.43E-07	1.95E-13	3.76E-05	0.0	3.83E-05
400.	5.42E-06	1.74E-11	0.0	0.0	5.42E-06	400.	8.93E-08	2.94E-13	4.53E-06	0.0	4.62E-06
500.	6.91E-07	2.52E-11	0.0	0.0	6.91E-07	500.	1.15E-08	4.27E-13	5.82E-07	0.0	5.94E-07
600.	8.30E-08	3.59E-11	0.0	0.0	8.30E-08	600.	1.38E-09	6.08E-13	7.03E-08	0.0	7.17E-08
700.	8.92E-09	5.02E-11	0.0	0.0	8.92E-09	700.	1.49E-10	8.50E-13	7.81E-09	0.0	7.76E-09
800.	9.61E-10	6.87E-11	0.0	0.0	1.03E-09	800.	1.61E-11	1.16E-12	8.72E-10	0.0	8.90E-10
900.	2.38E-10	9.22E-11	0.0	0.0	3.30E-10	900.	3.98E-12	1.56E-12	2.84E-10	0.0	2.89E-10
1000.	2.38E-10	1.21E-10	0.0	0.0	3.59E-10	1000.	3.98E-12	2.05E-12	3.19E-10	0.0	3.25E-10
2000.	1.22E-09	5.55E-10	0.0	0.0	1.87E-09	2000.	2.22E-11	9.41E-12	1.80E-09	0.0	1.83E-09
3000.	4.79E-09	1.86E-09	0.0	0.0	6.65E-09	3000.	8.08E-11	3.15E-11	6.54E-09	5.80E-31	6.65E-09
4000.	1.10E-08	4.18E-09	0.0	0.0	1.52E-08	4000.	1.87E-10	7.07E-11	1.51E-08	1.04E-20	1.53E-08
5000.	2.03E-08	7.58E-09	0.0	0.0	2.79E-08	5000.	3.43E-10	1.28E-10	2.77E-08	1.28E-15	2.82E-08
6000.	3.25E-08	1.21E-08	0.0	0.0	4.46E-08	6000.	5.50E-10	2.05E-10	4.45E-08	3.46E-13	4.52E-08
7000.	4.76E-08	1.77E-08	0.0	0.0	6.54E-08	7000.	8.08E-10	3.00E-10	6.54E-08	3.62E-12	6.65E-08
8000.	6.61E-08	2.44E-08	0.0	0.0	9.05E-08	8000.	1.12E-09	4.14E-10	9.07E-08	2.39E-11	9.22E-08
9000.	8.73E-08	3.22E-08	0.0	0.0	1.19E-07	9000.	1.48E-09	5.48E-10	1.20E-07	8.11E-11	1.23E-07
10000.	1.11E-07	4.10E-08	0.0	0.0	1.52E-07	10000.	1.88E-09	6.95E-10	1.55E-07	1.33E-10	1.57E-07
20000.	3.53E-07	1.44E-07	0.0	0.0	5.37E-07	20000.	6.65E-09	2.45E-09	5.41E-07	1.07E-11	5.50E-07
30000.	9.32E-07	3.42E-07	0.0	0.0	1.27E-06	30000.	1.58E-08	5.79E-09	1.29E-06	2.34E-10	1.31E-06
40000.	1.55E-06	5.66E-07	0.0	0.0	2.11E-06	40000.	2.62E-08	9.59E-09	2.14E-06	1.34E-10	2.18E-06
50000.	2.16E-06	7.89E-07	0.0	0.0	2.99E-06	50000.	3.65E-08	1.34E-08	2.98E-05	1.34E-10	3.03E-06
60000.	2.73E-06	1.00E-06	0.0	0.0	3.73E-06	60000.	4.63E-08	1.69E-08	3.78E-06	1.34E-10	3.84E-06
70000.	3.25E-06	1.19E-06	0.0	0.0	4.44E-06	70000.	5.51E-08	2.02E-08	4.50E-06	1.34E-10	4.58E-06
80000.	3.72E-06	1.36E-06	0.0	0.0	5.08E-06	80000.	6.30E-08	2.31E-08	5.14E-06	1.34E-10	5.23E-06
90000.	4.13E-06	1.51E-06	0.0	0.0	5.64E-06	90000.	6.99E-08	2.56E-08	5.70E-06	1.34E-10	5.80E-06
100000.	4.48E-06	1.64E-06	0.0	0.0	6.12E-06	100000.	7.59E-08	2.70E-08	6.19E-06	1.34E-10	6.29E-06
200000.	1.28E-05	4.70E-06	0.0	0.0	1.75E-05	200000.	2.18E-07	7.97E-08	1.76E-05	1.46E-12	1.79E-05
300000.	1.31E-05	4.80E-06	0.0	0.0	1.79E-05	300000.	2.22E-07	8.14E-08	1.81E-05	1.45E-10	1.84E-05
400000.	1.13E-05	4.16E-06	0.0	0.0	1.55E-05	400000.	1.92E-07	7.04E-08	1.57E-05	1.45E-10	1.60E-05
500000.	9.14E-06	3.35E-06	0.0	0.0	1.25E-05	500000.	1.55E-07	5.67E-08	1.27E-05	1.44E-10	1.29E-05
600000.	7.16E-06	2.62E-06	0.0	0.0	9.78E-06	600000.	1.21E-07	4.44E-08	9.96E-06	1.43E-10	1.01E-05
700000.	5.54E-06	2.03E-06	0.0	0.0	7.57E-06	700000.	9.39E-08	3.44E-08	7.74E-06	1.43E-10	7.87E-06
800000.	4.26E-06	1.56E-06	0.0	0.0	5.82E-06	800000.	7.22E-08	2.65E-08	5.99E-06	1.42E-10	6.08E-06
900000.	3.28E-06	1.21E-06	0.0	0.0	4.49E-06	900000.	5.56E-08	2.04E-08	4.65E-06	1.41E-10	4.72E-06
1000000.	2.54E-06	9.32E-07	0.0	0.0	3.47E-06	1000000.	4.30E-08	1.58E-08	3.62E-06	1.41E-10	3.68E-06

APPENDIX F

2. Output (f)

AVERAGE ANNUAL LOCAL DOSE TO INDIVIDUAL, MANILA, IN ZONE 1, IN MILLIREMS/YEAR

1000. YEARS#									
K	NUCLIDE	TOT BODY	GI TRACT	GONADS	LIVER	LUNGS	MARROW	BONE	THYROID
1	SR-90	6.36E-12	1.27E-13	6.36E-12	0.0	3.47E-11	9.54E-11	9.54E-11	0.0
2	I-129	3.79E-11	7.92E-12	5.21E-11	1.43E-11	2.47E-11	6.20E-11	5.76E-11	1.08E-10
SUB TOTAL		4.42E-11	8.05E-12	5.84E-11	1.43E-11	5.93E-11	1.57E-10	1.53E-10	1.08E-10
3	PB-210	3.15E-10	3.41E-11	3.02E-10	2.15E-09	4.36E-08	2.26E-08	2.26E-08	7.01E-11
SUB TOTAL		3.15E-10	3.41E-11	3.02E-10	2.15E-09	4.36E-08	2.26E-08	2.26E-08	7.01E-11
TOTAL		3.59E-10	4.21E-11	3.60E-10	2.16E-09	4.36E-08	2.28E-08	2.27E-08	1.78E-10

#TIME SINCE START OF REPOSITORY OPERATIONS.

AVERAGE ANNUAL NONSPECIFIC DOSE TO POPULATION, MANILA, IN MANREMS/YEAR

1000. YEARS#									
K	NUCLIDE	TOT BODY	GI TRACT	GONADS	LIVER	LUNGS	MARROW	BONE	THYROID
1	SR-90	5.74E-11	1.65E-11	5.74E-11	0.0	0.0	2.87E-09	2.87E-09	0.0
2	I-129	1.36E-10	1.83E-10	1.36E-10	5.31E-11	0.0	6.17E-11	6.17E-11	9.76E-08
SUB TOTAL		1.94E-10	2.00E-10	1.94E-10	5.31E-11	0.0	2.93E-09	2.93E-09	9.76E-08
3	PB-210	6.48E-09	1.23E-10	6.48E-09	5.98E-08	0.0	6.36E-07	6.36E-07	0.0
SUB TOTAL		6.48E-09	1.23E-10	6.48E-09	5.98E-08	0.0	6.36E-07	6.36E-07	0.0
TOTAL		6.68E-09	3.23E-10	6.68E-09	5.98E-08	0.0	6.39E-07	6.39E-07	9.76E-08

#TIME SINCE START OF REPOSITORY OPERATIONS.

APPENDIX G

PROGRAMMER'S NOTES

Variables

The variables used and their definitions are presented in the list of nomenclature in the front pages of this volume.

"Index" File Structure

"Index" is an unformatted temporary file allocated to logical unit 1. Index holds a maximum of 260 records, each 400 bytes in length. Index is calculated for each nuclide and zone.

Subprogram Usage

- SUBROUTINE FAULT - determines release probability transfer coefficient. Also, by use of time dependent component factors, the subroutine can modify the nuclide inventory at risk.
- FUNCTION RLEACH - calculates amount of nuclide leached into the ground water preliminary environmental input receptor. The function is called by SUBROUTINE FAULT when a leach incident is involved.
- SUBROUTINE TRINP - determines transport-to-environment transfer coefficient, accounting for decay and other processes such as delay in ground water transport.
- FUNCTION CRATIO - determines concentration ratio in ground water at discharge point compared to release point. This ground water transport function is called by SUBROUTINE TRINP.
- SUBROUTINE TRMAN - determines environment-to-man transfer coefficient for dose to man via all pathways from environmental concentrations.

Dimensioning

Some exchanges of dimensioning can be used for special cases without increasing storage requirements. For example, 9 Release Model events, each with 9 component factors represent 81 storage combinations

(= 9 x 9). If release is described by an involved function representing dynamic repository simulation, AMRAW can be dimensioned by other combinations such as one release event with up to 81 component factors if needed. The number of geographic zones, presently dimensioned at 8 is limited to 9 because of programming for the variable "NPRINT" which controls output options.

Multiple Cases

AMRAW-A has provisions for running more than one case, per submission. This can be: 1) more than one set of conditions for a waste management phase such as terminal storage, or 2) more than one phase, such as repository operations and terminal storage. A full set of input data is read in for each case.

Modification for Running on CDC System

AMRAW, written in FORTRAN IV, was developed with implementation on an IBM 360 system. Some changes are necessary for operation on a CDC system. The following programming features in AMRAW-A, used successfully on the IBM system, produce problems on a CDC 6400:

1. Three quadruply dimensioned arrays are used: DOSFAC, MAN2LF, and VOLINT. ANSI Fortran permits up to 3 subscripts.
2. DO loop control indices are passed through common, e.g., IZ in /BTRINP/, JF and IH in /BTRMAN/, etc.
3. "Computed GOTO" drops to the next statement when out of range in FORTRAN G on the IBM, but causes a fatal error on the CDC.
4. Integers are declared as INTEGERS*2 and INTEGER*4 variables, not necessary on the CDC. The use of INTEGER*4 in AMRAW is for storing 8 characters per variable; the CDC will store 10 characters when declared as INTEGER.
5. "Direct access" read and write, used in AMRAW do not exist directly on the CDC.

EPA personnel at the Las Vegas, Nevada facility identified the above problems, incorporated changes to respond to the problems, and have run the modified version on a CDC 6400 computer. The changes, listed in

correspondence with the problems, are as follows:

1. Change the 3 quadruply dimensioned arrays into triply dimensioned arrays through the addition of new variables.
2. Change the way the control indices are passed through common.
3. Introduce an extra IF test before the computed GOTO to achieve the same effect as in FORTRAN G.
4. Change INTERGER*2 and INTEGER*4 to INTEGER.
5. Replace the IBM direct access file writes and reads by calls to subroutines which manage ACTUAL KEY files.

Also, to reduce the large memory requirements, put the arrays resulting from MAN2LF into blank common. The way blank common is allocated on the available CDC 6400 system allows the LOADER to use the region which will become blank common during the loading process.

APPENDIX H

AMRAW-A LISTING

1. Main Program

MAIN

2. Sub-programs

FAULT - Release Model

RLEACH - Leach rate calculations

TRINP - Transport-to-Environment part of Environmental Model

CRATIO - Ground water transport calculations

TRMAN - Environment-to-Man part of Environmental Model

Discussion of changes needed for running on a CDC 6400 computer instead of IBM is presented in Appendix G (Programmer's Notes).

Main Program

22/35/04

C AMRAW: ASSESSMENT METHOD FOR RADIOACTIVE WASTE,
C A CODE DEVELOPED BY UNIVERSITY OF NEW MEXICO UNDER EPA CONTRACT #68-01-3256
C THIS LISTING IS AMRAW-A, CALCULATION THROUGH DOSE RATE.
C PRINCIPLE INVESTIGATOR: S.E.LOGAN, DECEMBER, 1977.

```

0001      IMPLICIT INTEGER*2 (I-N)
0002      DOUBLE PRECISION NUCNAM(25),ORGNAM(8),TITLE(10,3),
      *HEAD(4,6),HEAD1(4),AIZ
0003      REAL AA1(4,9),ADJ1(4,4,8),ADJ2(4,4,8),BIOFAC(25,4,6),CP(4,9,4)
0004      REAL DC1,DISPEN(4,8),DRC,DOSFAC(25,4,2,8),EDC(25,4,8)
0005      REAL MAN2LF(50,8,8,4),MAN2L(50,8,8),MAN2NF(50,8,4),MAN2N(50,8)
0006      REAL ELEM(15),MAN1L(50,8),MAN1N(50,8),PROBB(4,9,4),R1J(4,50)
0007      REAL R2(4,50,8),R2TOT(4,50,8),REMOV(4,8),RKD(25)
0008      REAL SPACT,TIME(50),TP(4,9,4),VOLINT(4,2,6,8),X,XX(15)
0009      REAL ZONALO(4,8),RELOUT(9),XL(8),YW(8),YY(8)
0010      REAL ZONDEP(8),GNDEP(50,8),AREAW(8)
0011      INTEGER*2 IFLAG(4,9,4),IFLAGE(4,2,6)
0012      INTEGER*2 JIJ(4,9),NJI(4),NJJ(4,9),NSP(6),IZONE(10)
0013      INTEGER*4 NPRINT,CHECK(19),JN(9),VAR(5),IN,IP,IE
0014      DATA VAR/'F10','0.0','5.1P','5E1','2.2'/'
0015      DATA HEAD1/' NONE',' JF= 2',' JF= 3',' JF= 263'/'
0016      DATA AIZ/' IZ='/'
0017      DATA JN/'1E1','2E1','3E1','4E1','5E1','6E1','7E1','8E1','9E1'/'
0018      DATA HEAD/' ', ' DATA ', ' INPUT ', ' ', ' '

```

```

2' REL', 'EASE TO ', 'ENVIRONM', 'ENT '
3' LOCA', 'L DOSE T', 'O INDIVI', 'DUAL '
4' NONSPEC', 'IFIC DOS', 'E TO POP', 'ULATION '
5' TOTA', 'L DOSE B', 'Y RECEPT', 'ORS '
6' DO', 'SE SUMMA', 'RY TABLE', 'S '/'

0019 COMMON/BFAULT/ PROBB,AA1,TP,CP,IFLAG
0020 COMMON/BLEACH/ DC1(25),DRC(25),X(25,50),F5,VS,SPACT(25),CINV
0021 COMMON/FDLEA/ CFA1,XR,DELTIM,I1
0022 COMMON/BTRINP/ Y2,Y3,I2,IFDIW
0023 COMMON/CTRINP/ CRMIN,DFMIN
0024 COMMON/BTRMAN/ BIOFAC,VOLINT,DOSFAC,NSP,IFLAG,JF,IH,DELTE
0025 COMMON/BCRATO/ RKD,CONCI,TIME,VX,PORE,AL,AT,HT,BULKD,YW,ITR,NT,

```

```

0026      1ITE,K,GNDIS,YY
0027      COMMON/FCRATO/DEL TL
0028      DEFINE FILE 1(260,400,U,INDEX)
0029      IN=5
0030      IE=6
0031      IP=4
0032      READ(IN,801)NCASE
0033      DO 9999 KASE=1,NCASE
           WRITE(IP,802)KASE
C*****
C***** READ IN DATA AND INITIALIZE CASE **
C***** THE TITLE MUST HAVE THREE LINES *****
0034      READ(IN,803)TITLE
0035      IF(IP.NE.IE)WRITE(IE,836)TITLE,NCASE,(HEAD(I,1),I=1,4)
0036      READ(IN,801)ND,NK,MT,IW,ITRS,ITRE,MZ,NIHT,NPRINT,IFDIVW
0037      IF(IW.EQ.3.AND.ITRE.GE.MT)GO TO 9995
C***** SET ORGAN, ZONE, AND NPRINT VALUES *****
0038      IORGS=IABS(MOD(NPRINT,10))
0039      IORGE=IORGS-1

```


FORTRAN IV G LEVEL 21

MAIN

DATE = 78096

22/35/04

```

0040      IF(IORGS.EQ.0) IORGE=NIHT
0041      IF(IORGS.EQ.0) IORGS=1
0042      IF(IORGS.GT.NIHT) GO TO 9997
0043      NPRINT=NPRINT/10
0044      ISTART=ABS(MOD(NPRINT,10))
0045      ISTOP=ISTART-1
0046      IF(ISTART.EQ.0) ISTOP=MZ
0047      IF(ISTART.EQ.0) ISTART=1
0048      IF(ISTART.GT.MZ) GO TO 9996
0049      NPRINT=NPRINT/10
0050      IF(KASE.GT.1) GO TO 5
0051      C***** READ IN CUTOFF VALUES *****
0052      READ(IN,806) R1JMIN,A2MIN,R2MIN,RKDMAX,CRMIN,DFMIN
0053      READ(IN,806) (TIME(I),I=1,MT)
0054      READ(IN,806) (ELEM(ID),ID=1,ND)
0055      READ(IN,806) TFUEL
0056      READ(IN,806) (XX(ID),ID=1,ND)
0057      DO 20 K=1,NK
0058      READ(IN,808) NUCNAM(K), (X(K,IT),IT=1,7)
0059      IF(MT.GE.8) READ(IN,809) (X(K,IT),IT=8,MT)
0060      20 CONTINUE
0061      READ(IN,845,ERR=9998,END=9998) CHECK,ICHCK
0062      IF(ICHCK.NE.1) GO TO 9998
0063      WRITE(IE,848) CHECK,ICHCK
0064      READ(IN,806) (SPACT(K),K=1,NK)
0065      READ(IN,806) (DC1(K),K=1,NK)
0066      READ(IN,806) (DRC(K),K=1,NK)
0067      READ(IN,806) ((ADJ1(JF,JFA,IZ),ADJ2(JF,JFA,IZ),JFA=1,4),JF=1,4),
0068      *IZ=1,MZ)
0069      READ(IN,806) ((DISP(IZ),IZ=1,MZ),JF=1,4)
0070      READ(IN,806) ((ZONALD(JF,IZ),IZ=1,MZ),JF=1,4)
0071      READ(IN,806) (ZONDEP(IZ),IZ=1,MZ)
0072      READ(IN,806) (AREAW(IZ),IZ=1,MZ)
0073      READ(IN,806) (RKD(K),K=1,NK)
0074      READ(IN,845,ERR=9998,END=9998) CHECK,ICHCK
0075      IF(ICHCK.NE.2) GO TO 9998
0076      WRITE(IE,848) CHECK,ICHCK
0077      READ(IN,801) (NSP(JF),JF=1,4)
0078      DO 30 IZ=1,MZ
0079      DO 30 JF=1,4
0080      NS=NSP(JF)
0081      30 READ(IN,806) ((VOLINT(JF,MODE,I,IZ),I=1,NS),MODE=1,2)
0082      DO 40 K=1,NK
0083      DO 40 NS=1,6
0084      40 BIOFAC(K,1,NS)=1.
0085      DO 50 K=1,NK
0086      DO 50 JF=2,4
0087      NS=NSP(JF)
0088      50 READ(IN,806) (BIOFAC(K,JF,I),I=1,NS)
0089      READ(IN,845,ERR=9998,END=9998) CHECK,ICHCK
0090      IF(ICHCK.NE.3) GO TO 9998
0091      WRITE(IE,848) CHECK,ICHCK
0092      READ(IN,803) (ORGNAM(I),I=1,NIHT)

```

```

FORTRAN IV G LEVEL 21          MAIN          DATE = 78096          22/35/04

0091      READ(IN,806)({({DOSFAC(K,JF,MODE,IH),IH=1,NINT},MODE=1,2),JF=1,4),
          *K=1,NK)
0092      5 CONTINUE
0093      READ(IN,845,ERR=9998,END=9998)CHECK,ICHCK
0094      IF(ICHCK.NE.4)GO TO 9998
0095      WRITE(IE,848)CHECK,ICHCK
C***** JJ(JF,I) SPECIFIES A PARTICULAR RELEASE EVENT CUTSET. **
C***** NJ(JF) =# OF RELEASE CUTSETS ASSOCIATED WITH JF. **
C***** NJJ(JF,I) =# OF PROBABILITIES ASSOCIATED WITH EACH CUTSET. **
0096      1000 ISECT=1
0097      WRITE(IP,836)TITLE,ISECT,(HEAD(I,ISECT),I=1,4)
0098      WRITE(IP,805)
0099      DO 1030 JF=1,4
0100      READ(IN,801)NJ(JF)
0101      NJF=NJ(JF)
0102      IF(NJF.EQ.0)GO TO 1030
0103      DO 1020 I=1,NJF
0104      READ(IN,801)JJ(JF,I),NJJ(JF,I)
0105      J=JJ(JF,I)
0106      NJJJ=NJJ(JF,I)
0107      READ(IN,806)AA1(JF,J)
0108      DO 1020 K=1,NJJJ
0109      READ(IN,810)PROBB(JF,J,K),IFLAG(JF,J,K),TP(JF,J,K),CP(JF,J,K)
0110      IF(K.EQ.1)WRITE(IP,811)JF,NJF,J,NJJJ,AA1(JF,J),PROBB(JF,J,1),
          *IFLAG(JF,J,1),TP(JF,J,1),CP(JF,J,1)
0111      IF(K.GT.1)WRITE(IP,812)PROBB(JF,J,K),IFLAG(JF,J,K),TP(JF,J,K),
          *CP(JF,J,K)
0112      1020 CONTINUE
0113      1030 CONTINUE
0114      IF(KASE.GT.1)GO TO 6
0115      DO 1060 JF=1,4
0116      J=NSP(JF)
0117      1060 READ(IN,801)({IFLAGE(JF,MODE,I),I=1,J},MODE=1,2)
0118      READ(IN,806)VX,PORE,AL,AT,HT,BULKD,FS,VS,(XL(I),I=1,MZ),
          1(YW(I),I=1,MZ),(YY(I),I=1,MZ),
          2CINV,CFAI
0119      READ(IN,845,ERR=9998,END=9998)CHECK,ICHCK
0120      IF(ICHCK.NE.5) GO TO 9998
0121      WRITE(IE,848)CHECK,ICHCK
C***** READ EDC FLAG 1=DEFAULT,2=JF READ,3=JF READ,4=READ JF=263 ****
0122      READ(IN,801)ISECT
0123      I=ISECT
0124      DO 1130 K=1,NK
0125      DO 1130 IZ=1,MZ
0126      EDC(K,1,IZ)=50.0
0127      EDC(K,4,IZ)=0.0
0128      GO TO(1110,1120,1110,1130),I
0129      1110 EDC(K,2,IZ)=2.30*10.0**(-5)
0130      GO TO(1120,1130,1130,1130),I
0131      1120 EDC(K,3,IZ)=2.30*10.0**(-5)
0132      1130 CONTINUE
0133      GO TO(1210,1160,1160,1140),I
0134      1140 DO 1150 I=2,3

```

FORTRAN IV G LEVEL 21

MAIN

DATE = 78096

22/35/04

```

0135      1150 READ(IN,806)((EDC(K,I,IZ),IZ=1,MZ),K=1,NK)
0136      GO TO 1210
0137      1160 READ(IN,806)((EDC(K,I,IZ),IZ=1,MZ),K=1,NK)
0138      1210 READ(IN,845,ERR=9998,END=9998)CHECK,ICHCK
0139      IF(ICHCK.NE.6) GO TO 9998
0140      WRITE(IE,848)CHECK,ICHCK
C***** READ SECTION 6 INPUT TO STMT 1310 *****
C***** IZONM = # OF TABLES WANTED **
0141      READ(IN,801)IZONM
0142      IF(IZONM.EQ.0)GO TO 1310
C***** IZONE = ZONES TO DO, IZONE = 10 MEANS NONSPECIFIC *****
0143      READ(IN,801)(IZONE(I),I=1,IZONM)
C*** ITSUMY=INITIAL TIME, ITSUMJ=TIME CHANGE, KSUB=K FOR SUBTOTAL **
0144      READ(IN,801)ITSUMY,ITSUMJ,KSUB
0145      1310 LPRINT=NK/10+1
0146      IF(NK.EQ.NK/10*10)LPRINT=LPRINT-1
0147      6 CONTINUE
0148      IF(NPRINT.EQ.0.OR.NPRINT.EQ.5)GO TO 1500
0149      GO TO 2000
C***** OUTPUT SELECTED INPUT DATA **
0150      1500 WRITE(IP,813)TFUEL
0151      WRITE(IP,814)(ELEM(ID),XX(ID),ID=1,ND)
0152      M1=1
0153      M10=10
0154      WRITE(IP,815)
0155      DO 1550 I=1,LPRINT
0156      IF(M10.GT.NK)M10=NK
0157      WRITE(IP,816)(NUCNAM(K),K=M1,M10)
0158      DO 1540 IT=1,MT
0159      1540 WRITE(IP,817)TIME(IT),(X(K,IT),K=M1,M10)
0160      WRITE(IP,818)(SPACT(K),K=M1,M10)
0161      M1=M10+1
0162      M10=M10+10
0163      1550 CONTINUE
0164      WRITE(IP,819)
0165      DO 1580 K=1,NK
0166      1580 WRITE(IP,820)NUCNAM(K),DCI(K),DRC(K),RKD(K)
0167      WRITE(IP,859) VX,PORE,BULKD,AL,AT,HT,(AIZ,I,I=1,MZ)
0168      WRITE(IP,870) (XL(I),I=1,MZ)
0169      WRITE(IP,871) (YW(I),I=1,MZ)
0170      WRITE(IP,872) (YY(I),I=1,MZ)
0171      WRITE(IP,873) FS,VS,CINV,CFAI
0172      WRITE(IP,821)HEAD1(ISECT)
0173      DO 1620 IZ=1,MZ,2
0174      IZP1=IZ+1
0175      IF (IZ.EQ.5)WRITE(IP,844)
0176      WRITE(IP,822)IZ,IZP1
0177      DO 1620 K=1,NK
0178      1620 WRITE(IP,823)NUCNAM(K),((EDC(K,JF,I),JF=1,4),I=IZ,IZP1)
0179      WRITE(IP,824)
0180      DO 1660 IZ=1,MZ,2
0181      IZP1=IZ+1
0182      1660 WRITE(IP,822)IZ,IZP1,((DISPN(JF,I),JF=1,4),I=IZ,IZP1)

```

APPENDIX H Main Program continued

FORTRAN IV G LEVEL 21

MAIN

DATE = 78096

22/35/04

```

0183      WRITE(IP,849)
0184      DO 1700 IZ=1,MZ,2
0185          IZP1=IZ+1
0186      1700 WRITE(IP,822) IZ, IZP1, ((ZONALO(JF,I), JF=1,4), I=IZ, IZP1)
0187          WRITE(IP,850) (AIZ,I, I=1,MZ)
0188          WRITE(IP,880) (ZONDEP(I), I=1,MZ)
0189          WRITE(IP,851) (AIZ,I, I=1,MZ)
0190          WRITE(IP,880) (AREAW(I), I=1,MZ)
0191          WRITE(IP,825)
0192          DO 1740 IZ=1,MZ
0193              WRITE(IP,826) IZ
0194              DO 1740 JF=1,4
0195                  WRITE(IP,827) JF, (ADJ1(JF, JFA, IZ), ADJ2(JF, JFA, IZ), JFA=1,4)
0196      1740 CONTINUE
0197          WRITE(IP,826)
0198          DO 1780 IZ=1,MZ
0199              IF((IZ/5)*5.EQ. IZ) WRITE(IP,844)
0200          WRITE(IP,829) IZ
0201          DO 1780 JF=1,4
0202              NS=NSP(JF)
0203              DO 1780 MODE=1,2
0204      1780 WRITE(IP,830) JF, MODE, NS, (VOLINT(JF, MODE, I, IZ), I=1, NS)
0205          WRITE(IP,831)
0206          DO 1830 K=1, NK
0207              WRITE(IP,832) NUCNAM(K)
0208              DO 1820 JF=1,4
0209                  NS=NSP(JF)
0210      1820 WRITE(IP,843) JF, NS, (BIOFAC(K, JF, I), I=1, NS)
0211              IF((K/9)*9.EQ. K) WRITE(IP,844)
0212      1830 CONTINUE
0213          WRITE(IP,833)
0214          DO 1870 IH=1, ORGS, IORGE
0215              WRITE(IP,834) ORGNAM(IH)
0216              DO 1860 K=1, NK
0217      1860 WRITE(IP,835) NUCNAM(K), ((DOSFAC(K, JF, MODE, IH), MODE=1,2),
0218              1 JF=1,4)
0219              IF((IH/2)*2.EQ. IH) WRITE(IP,844)
0219      1870 CONTINUE
0220          IF(NPRINT.EQ.0) GO TO 9999
C*****TO STMT 2999 CONSIDER EACH BRANCH SEPARATELY **
0221      2000 ISECT=2
0222          WRITE(IP,836) TITLE, ISECT, (HEAD(I, ISECT), I=1,4)
0223          IF(IW.EQ.3) DTIME=TIME(ITRE+1)-TIME(ITRE)
0224          DO 2020 IT=1, MT
0225              DO 2020 IH=1, NIHT
0226                  MAN2N(IT, IH)=0.0
0227                  DO 2020 JF=1,4
0228                      MAN2NF(IT, IH, JF)=0.0
0229                  DO 2020 IZ=ISTART, ISTOP
0230                      MAN2LF(IT, IH, IZ, JF)=0.0
0231      2020 MAN2L(IT, IH, IZ)=0.0
0232          GNDDIS=1.0
C*****TO STMT 2999 CONSIDER EACH RADIONUCLIDE *****

```

APPENDIX H Main Program continued

FORTRAN IV G LEVEL 21

MAIN

DATE = 78096

22/35/04

```

0233      DO 2999 K=1,NK
0234      IF(1W.EQ.3)DFAC=(1.0-{X(K,ITRE+1)/X(K,ITRE)})/DTIME
0235      CTR1=0.
0236      LINEP=4
0237      DO 2050 IT=1,MT
0238      DO 2040 IH=1,NIHT
0239      2040  MAN1N(IT,IH)=0.0
0240      DO 2050 JF=1,4
0241      RIJ(JF,IT)=0.
0242      DO 2050 IZ=1,ISTART,ISTOP
0243      R2(JF,IT,IZ)=0.
0244      R2TOT(JF,IT,IZ)=0.
0245      2050  GNDP(IH,IZ)=0.0
C***** TO STMT 2500 CALCULATE ENVIRONMENTAL CONCENTRATIONS **
C***** CALCULATE RELEASE DURING EACH TIME INTERVAL *****
C***** TO PRELIMINARY ENVIRONMENT INPUT RECEPTORS TO STMT 2140 **
0246      IF(NPRINT.EQ.5)WRITE(IP,847)NUCNA(K),K
0247      DO 2500 ITR=ITR5,ITRE
0248      DELTL=TIME(ITR)-TIME(ITR-1)
0249      XR=X(K,ITR)
0250      ZAVG=((XR+X(K,ITR-1))*SPACT(K))/2.0
0251      DO 2120 I=1,9
0252      2120  RELOUT(I)=0.0
0253      DO 2160 JF=1,4
0254      NJF=NJ(JF)
0255      IF(NJF.EQ.0)GO TO 2160
0256      DO 2140 I=1,NJF
0257      J=JJ(JF,I)
0258      NJJJ=NJJ(JF,I)
0259      IF(CTR1.GE.1.)GO TO 2140
C***** DETERMINE RELEASE FAULT PROB AND TRANSFER COEFF **
0260      CALL FAULT(TIME,PROB,A1,JF,J,NJJJ,ITR,K,CONCI)
0261      PRBDEL=PROB*DELT
0262      IF(PRBDEL.GT.1.0) PRBDEL=1.0
0263      REL=PRBDEL*A1
0264      REL=ABS(REL)
0265      CTR1=CTR1+REL
0266      IF(REL.GT.1.)REL=1.
0267      RELOUT(I)=REL
0268      RIJ(JF,ITR)=RIJ(JF,ITR)+ZAVG*REL
0269      2140  CONTINUE
C***** TO STMT 2160 OUTPUT RELEASE FRACTIONS BY CUTSET **
0270      VAR(4)=JN(NJF)
0271      LINEP= LINEP+1
0272      IF(LINEP.GT.60.AND.NPRINT.EQ.5)WRITE(IP,852)
0273      IF(LINEP.GT.60)LINEP=1
0274      IF(NPRINT.EQ.5)WRITE(IP,VAR)TIME(ITR),JF,(RELOUT(I),I=1,NJF)
0275      2160  CONTINUE
C***** TO STMT 2499 FOLLOW EACH RELEASE INCREMENT THROUGH ENVIRONMENT **
C***** DURING SUBSEQUENT TIME INTERVALS **
0276      DO 2499 ITE=ITR,MT
0277      DELT2=TIME(ITE)-TIME(ITR)
0278      DELT3=TIME(ITE)-TIME(ITR)

```

APPENDIX H Main Program continued

```

FORTRAN IV G LEVEL 21                MAIN                DATE = 78096                22/35/04

0279      DO 2210 IZ=ISTART,ISTOP
0280      DO 2210 JF=1,4
0281      2210 REMOV(JF,IZ)=0.
C***** TO STMT 2220 DETERMINE TRANSFER COEFF TO ENVIRONMENT INPUT **
0282      XEM1=X(K,ITE-1)
0283      XE=X(K,ITE)
0284      DO 2390 IZ=ISTART,ISTOP
0285      DO 2280 JF=1,4
C***** SET TEMPORARY VALUES FOR DELT4 AND XEM2. **
0286      DELT4=0.
0287      XEM2=XEM1
0288      TRL=EOC(K,JF,IZ)
0289      IF(JF.EQ.4.OR.ITE.EQ.ITR)GO TO 2220
0290      XEM2=X(K,ITE-2)
0291      DELT4=(TIME(ITE)-TIME(ITE-2))/2.
0292      2220 CALL TRINP(DELT2,DELT3,DELT4,XR,XE,XEM1,XEM2,TRL,DECFAA,A2,
        *XL(IZ),X(K,ITRE),OFAC,
        *ITE,ITRE,IW,JF,RKD,RKDMAX,K)
0293      IF(R1J(JF,ITR).LE.R1JMIN)R1J(JF,ITR)=0.0
0294      IF(A2.LE.A2MIN)A2=0.0
0295      IF(JF.EQ.4)GO TO 2260
0296      IF(ITE.NE.ITR)GO TO 2270
0297      GO TO (2230,2240,2250),JF
0298      2230 R2(JF,ITE,IZ)=R1J(JF,ITR)*A2*ZONALO(JF,IZ)
0299      DEP=R1J(JF,ITR)*A2*ZONDEP(IZ)
0300      AREAG=DISPN(2,IZ)
0301      DEPGND=DEP*AREAG
0302      DEPWTR=DEP*AREAW(IZ)
0303      GO TO 2280
0304      2240 R2(JF,ITE,IZ)=R1J(JF,ITR)*A2*ZONALO(JF,IZ)+DEPGND
0305      GO TO 2280
0306      2250 R2(JF,ITE,IZ)=R1J(JF,ITR)*A2*ZONALO(JF,IZ)+DEPWTR
0307      GO TO 2280
0308      2260 R2(JF,ITE,IZ)=R1J(JF,ITR)*A2*ZONALO(JF,IZ)
0309      GO TO 2280
0310      2270 R2(JF,ITE,IZ)=R2(JF,ITE-1,IZ)*A2
0311      2280 IF(R2(JF,ITE,IZ).LE.R2MIN)R2(JF,ITE,IZ)=0.0
C*** TO STMT 2499 ADJUST ENVIRON RECEPTOR; TRANSFER FROM OTHER RECEPTORS **
0312      DO 2330 JF=1,4
0313      DO 2330 JFA=1,4
0314      IF(JFA.EQ.JF.OR.ADJ1(JF,JFA,IZ).EQ.0.)GO TO 2330
0315      DELTE=TIME(ITE)-TIME(ITE-1)
0316      AMD=ADJ2(JF,JFA,IZ)*0.8*DELTE
0317      IF(AMD.GT.15.)GO TO 2300
0318      ADJ=ADJ1(JF,JFA,IZ)*(1.-EXP(-AMD))
0319      GO TO 2310
0320      2300 ADJ=ADJ1(JF,JFA,IZ)
0321      IF(JF.NE.1)GO TO 2310
C***** FOLLOWING STATEMENT IS INTEGRATED CONCENTRATION FOR RESUSPENSION **
0322      ADJR2=ADJ*R2(JFA,ITE,IZ)*(DELTE/DISP(N(JFA,IZ))
0323      GO TO 2320
0324      2310 ADJR2=ADJ*R2(JFA,ITE,IZ)
0325      2320 R2(JF,ITE,IZ)=R2(JF,ITE,IZ)+ADJR2

```

APPENDIX H Main Program continued

```

FORTRAN IV G LEVEL 21          MAIN          DATE = 78096          22/35/04

0326      IF(JF.EQ.1)GO TO 2330
0327      REMOV(JFA,IZ)=REMOV(JFA,IZ)+ADJR2
0328      2330 CONTINUE
0329      DO 2390 JF=1,4
0330      IF(DISP(JF,IZ).EQ.0.)GO TO 2390
0331      GO TO (2340,2350,2360,2370),JF
0332      2340 R2CON=10.**6*R2(JF,ITE,IZ)
0333      GO TO 2380
0334      2350 R2CON=10.**6*R2(JF,ITE,IZ)/DISP(JF,IZ)
0335      IF(ITE.NE.ITR)GO TO 2380
0336      GNDEP(ITE,IZ)=R2CON
0337      GO TO 2380
0338      2360 R2CON=10.**6*R2(JF,ITE,IZ)/DISP(JF,IZ)
0339      GO TO 2380
0340      2370 DISP(JF,IZ)=GNDDIS
0341      IF(GNDDIS.EQ.0.)R2CON=0.
0342      IF(GNDDIS.EQ.0.)GO TO 2380
0343      R2CON=R2(JF,ITE,IZ)/DISP(JF,IZ)
0344      2380 R2TOT(JF,ITE,IZ)=R2TOT(JF,ITE,IZ)+R2CON
0345      2390 CONTINUE
0346      DO 2499 JF=1,4
0347      DO 2499 IZ=ISTART,ISTOP
0348      R2(JF,ITE,IZ)=R2(JF,ITE,IZ)-REMOV(JF,IZ)
0349      2499 IF(R2(JF,ITE,IZ).LT.0.)R2(JF,ITE,IZ)=0.
0350      2500 CONTINUE
***** TO STMT 2730 CALCULATE EACH CATAGORY OF MAN DOSE **
0351      DO 2780 IZ=ISTART,ISTOP
0352      DO 2700 IH=1,NIHT
0353      DO 2700 ITE=1,MT
0354      2700 MAN1L(ITE,IH)=0.0
0355      DO 2730 ITE=ITRS,MT
0356      DELTE=TIME(ITE)-TIME(ITE-1)
0357      DO 2720 IH=IORGS,IORGE
0358      DO 2720 JF=1,4
***** TRMAN, DETERMINE TRANSFER COEFF TO MAN DOSE **
0359      NSS=1
0360      CALL TRMAN(K,ITE,IZ,NSS,C)
0361      MAN1L(ITE,IH)=MAN1L(ITE,IH)+C*R2TOT(JF,ITE,IZ)
0362      MAN2LF(ITE,IH,IZ,JF)=MAN2LF(ITE,IH,IZ,JF)+C*R2TOT(JF,ITE,IZ)
0363      MAN2L(ITE,IH,IZ)=MAN2L(ITE,IH,IZ)+C*R2TOT(JF,ITE,IZ)
0364      NSS=2
0365      CALL TRMAN(K,ITE,IZ,NSS,C)
*****APPLYING .001 FACTOR TO STMTS 2720: CONVERTS MILLIMANREM TO MANREM*****
0366      IF(JF.NE.2)GO TO 2710
0367      MAN2NF(ITE,IH,JF)=MAN2NF(ITE,IH,JF)+C*GNDEP(ITE,IZ)*0.001
0368      MAN2N(ITE,IH)=MAN2N(ITE,IH)+C*GNDEP(ITE,IZ)*0.001
0369      MAN1N(ITE,IH)=MAN1N(ITE,IH)+C*GNDEP(ITE,IZ)*0.001
0370      GO TO 2720
0371      2710 MAN2NF(ITE,IH,JF)=MAN2NF(ITE,IH,JF)+C*R2TOT(JF,ITE,IZ)*0.001
0372      MAN2N(ITE,IH)=MAN2N(ITE,IH)+C*R2TOT(JF,ITE,IZ)*0.001
0373      MAN1N(ITE,IH)=MAN1N(ITE,IH)+C*R2TOT(JF,ITE,IZ)*0.001
0374      2720 CONTINUE
0375      2730 CONTINUE

```

FORTRAN IV G LEVEL 21

MAIN

DATE = 78096

22/35/04

```

0376      INDEX=10*(K-1)+IZ
0377      2780 WRITE(1,INDEX)((MAN1L(ITE,IH),ITE=1,MT),IH=IORGS,IORGE)
0378      INDEX=10*(K-1)+10
0379      WRITE(1,INDEX)((MAN1N(ITE,IH),ITE=1,MT),IH=IORGS,IORGE)
C***** TO STMT 2870 OUTPUT ENVIRONMENT INPUT CONCENTRATIONS **
0380      IF(NPRINT.EQ.6)GO TO 2999
0381      IF(NPRINT.EQ.2)GO TO 2840
0382      WRITE(IP,839)NUCNAM(K),K
0383      DO 2820 IT=1,MT
0384      2820 WRITE(IP,838)TIME(IT),(R1J(JF,IT),JF=1,4)
0385      2840 IF(NPRINT.EQ.1.OR.NPRINT.GT.5)GO TO 2999
0386      DO 2870 IZ=ISTART,ISTOP,2
0387      IF(ISTOP.LE.ISTART)GO TO 2850
0388      IZP1=IZ+1
0389      WRITE(IP,837)NUCNAM(K),K,IZ,IZP1
0390      WRITE(IP,838)TIME(IT),(R2TOT(JF,IT,IZ),JF=1,4),TIME(IT),
1(R2TOT(JF,IT,IZP1),JF=1,4),IT=1,MT)
0391      GO TO 2870
0392      2850 WRITE(IP,862)NUCNAM(K),K,IZ
0393      DO 2860 IT=1,MT
0394      2860 WRITE(IP,838)TIME(IT),(R2TOT(JF,IT,IZ),JF=1,4)
0395      2870 CONTINUE
0396      2999 CONTINUE
C***** OUTPUT DOSE RATE RESULTS **
C***** FOR LOCAL DOSE STMTS 3000 TO 3100 ***
C***** FOR NONSPECIFIC DOSE STMTS 4000 TO 4100 ***
C***** FOR TOTAL ALL NUCLIDES STMTS 5000 TO 5400 ***
0397      IF(NPRINT.LT.4)GO TO 9999
0398      3000 ISECT=3
0399      WRITE(IP,836)TITLE,ISECT,(HEAD(1,ISECT),I=1,4)
0400      DO 3100 IZ=ISTART,ISTOP
0401      DO 3100 K=1,NK
0402      WRITE(IP,840)IZ,NUCNAM(K),K
0403      INDEX=10*(K-1)+IZ
0404      READ(1,INDEX)((MAN1L(ITE,IH),ITE=1,MT),IH=IORGS,IORGE)
0405      WRITE(IP,816)(ORGNAM(N),N=IORGS,IORGE)
0406      DO 3100 IT=1,MT
0407      3100 WRITE(IP,817)TIME(IT),(MAN1L(IT,IH),IH=IORGS,IORGE)
0408      4000 ISECT=4
0409      WRITE(IP,836)TITLE,ISECT,(HEAD(1,ISECT),I=1,4)
0410      DO 4100 K=1,NK
0411      WRITE(IP,841)NUCNAM(K),K
0412      INDEX=10*(K-1)+10
0413      READ(1,INDEX)((MAN1N(ITE,IH),ITE=1,MT),IH=IORGS,IORGE)
0414      WRITE(IP,816)(ORGNAM(N),N=IORGS,IORGE)
0415      DO 4100 IT=1,MT
0416      4100 WRITE(IP,817)TIME(IT),(MAN1N(IT,IH),IH=IORGS,IORGE)
0417      5000 ISECT=5
0418      WRITE(IP,836)TITLE,ISECT,(HEAD(1,ISECT),I=1,4)
0419      DO 5200 IH=IORGS,IORGE
0420      DO 5200 IZ=ISTART,ISTOP,2
0421      IF(ISTOP.LE.ISTART)GO TO 5110
0422      IZP1=IZ+1

```


APPENDIX H Main Program continued

```

FORTRAN IV G LEVEL 21          MAIN          DATE = 78096          22/35/0

0423      WRITE(IP,900)ORGNAM(IH),IZ,IZP1
0424      DO 5100 IT=1,MT
0425      WRITE(IP,901)TIME(IT),(MAN2LF(IT,IH,IZ,JF),JF=1,4),
      1MAN2L(IT,IH,IZ),
      2TIME(IT),(MAN2LF(IT,IH,IZP1,JF),JF=1,4),MAN2L(IT,IH,IZP1)
0426      5100 CONTINUE
0427      GO TO 5200
0428      5110 WRITE(IP,902) ORGNAM(IH),IZ
0429      DO 5120 IT=1,MT
0430      WRITE(IP,901)TIME(IT),(MAN2LF(IT,IH,IZ,JF),JF=1,4),
      1MAN2L(IT,IH,IZ)
0431      5120 CONTINUE
0432      5200 CONTINUE
0433      DO 5400 IH=IORGS,IORGE
0434      WRITE(IP,950)ORGNAM(IH)
0435      DO 5300 IT=1,MT
0436      WRITE(IP,951)TIME(IT),(MAN2NF(IT,IH,JF),JF=1,4),MAN2N(IT,IH)
0437      5300 CONTINUE
0438      5400 CONTINUE
C***** TO STMT 6500 OUTPUT DOSE SUMMARY TABLES *****
0439      6000 ISECT=6
0440      IF(IZONH.EQ.0)GO TO 9999
0441      WRITE(IP,836)TITLE,ISECT,(HEAD(I,ISECT),I=1,4)
C***** SET ZONE FOR TABLE *****
0442      DO 6500 IZP1=1,IZONH
0443      IZ=IZONE(IZP1)
C***** IZ=10 MEANS NONSPECIFIC DOSE RATES *****
C***** SET TIME FOR TABLE *****
0444      DO 6500 ITR=ITSUMY,MT,ITSUNJ
0445      IF(IZ.NE.10)WRITE(IP,853)IZ
0446      IF(IZ.EQ.10)WRITE(IP,854)
0447      WRITE(IP,855)TIME(ITR),(ORGNAM(N),N=IORGS,IORGE)
C***** INITIALIZE SUBTOTAL SETTING *****
0448      M1=1
0449      M10=KSUB
C***** ZERO REMOV=SUBTOTAL *****
0450      6100 DO 6200 I=IORGS,IORGE
0451      6200 REMOV(1,I)=0.0
0452      DO 6300 K=M1,M10
0453      INDEX=10*(K-1)+IZ
0454      READ(1,INDEX)((MAN1L(ITE,IH),ITE=1,MT),IH=IORGS,IORGE)
C***** WRITE TABLE *****
0455      WRITE(IP,856)K,NUCNAM(K),(MAN1L(ITR,IH),IH=IORGS,IORGE)
0456      DO 6300 I=IORGS,IORGE
0457      6300 REMOV(1,I)=REMOV(1,I)+MAN1L(ITR,I)
C***** WRITE SUBTOTAL *****
0458      WRITE(IP,857)(REMOV(1,I),I=IORGS,IORGE)
0459      IF(M10.EQ.NK)GO TO 6400
0460      M1=KSUB+1
0461      M10=NK
0462      GO TO 6100
C***** WRITE TOTAL IF IZ= 10 MAN2N OR ELSE MAN2L *****
0463      6400 IF(IZ.NE.10)WRITE(IP,858)(MAN2L(ITR,I,IZ),I=IORGS,IORGE)

```

Main Program continued

81

APPENDIX H Main Program continued

```

FORTRAN IV G LEVEL 21          MAIN          DATE = 78096          22/35/04

0500      828 FORMAT('1# VOLINT(JF,MODE,NSP) DATA'//)
0501      829 FORMAT('  IZ=',I2/5X,'JF      MODE      NSP=1 THRU',I0X,'VOLINT')
0502      830 FORMAT(5X,I2,6X,I2,I2X,I2,6(3X,1PE10.2))
0503      831 FORMAT('1# BIOFAC(K,JF,NSP) DATA'//)
0504      832 FORMAT('  RADIONUCLIDE=',A8/5X,'JF      NSP=1 THRU',I0X,'BIOFAC')
0505      833 FORMAT('1# DOSFAC(K,JF,MODE,1H) DATA'//)
0506      834 FORMAT('  ORGAN = ',A6/T25,'JF=1',T61,'JF=2',T77,'JF=3',
      1T103,'JF=4',/16X,4('MODE=1',7X,'MODE=2',7X))
0507      835 FORMAT(3X,A8,8(3X,1PE10.2))
      C*** TO HAVE N LINES IN TITLE MUST CHANGE 3(T27,10A8/) IN 1 BELOW ***
      C***** TO N(T27,10A8/) AND REMOVE CORRESPONDING # OF / *****
0508      836 FORMAT(/,'1'/9(1X,132('0')/),10(/),T37,'AMRAW: ASSESSMENT METHOD',
      1' FOR RADIOACTIVE WASTE MANAGEMENT',4(/),3(T27,10A8/),///,T61,
      2'SECTION',I3/,5(/),T51,4A8,15(/),9(1X,132('0')/))
0509      837 FORMAT('1RADIONUCLIDE: ',A8,' (K=',I2,')'/1X,29('0')/' CONCENTRATI
      IONS AT ENVIRONMENT INPUT RECEPTOR. R2TOT      UNITS: JF=1 MICROCURI
      2E0YEARS/CUBIC CM'/' JF=2 MICROCURIES/SQUARE CM, JF=3 AND 4 MICROCU
      3RIES/CUBIC CM'/' ZONE=',I2,T71,'ZONE=',I2,/'
      42(14X,'JF=1      JF=2      JF=3      JF=4',18X)/
      82(6X,'TIME      AIR      GROUND      SURFACE      GROUND',17X)/
      62(23X,'SURFACE      WATER      WATER',18X))
0510      838 FORMAT(OPF10.0,1P4E10.2,18X,OPF8.0,1P4E10.2)
0511      839 FORMAT('1RADIONUCLIDE: ',A8,' (K=',I2,')'/1X,29('0')/' RELEASE INC
      1REMENTS TO PRELIMINARY ENVIRONMENT INPUT'/' RECEPTORS. R1J, FROM A
      2LL RELEASE EVENTS, IN CURIES'/'14X,'JF=1      JF=2      JF=3
      3JF=4',/5X,'TIME      AIR      GROUND      SURFACE      GROUND',/23X,'SURFA
      4CE      WATER      WATER')
0512      840 FORMAT('1# AVERAGE ANNUAL LOCAL DOSE TO INDIVIDUAL, MAN1L, IN MIL
      1LIREMS/YEAR'/' ZONE=',I2,'... NUCLIDE=',A8,' K=',I3/)
0513      841 FORMAT('1# AVERAGE ANNUAL NONSPECIFIC DOSE TO POPULATION, MANIN,
      2IN MANREMS/YEAR'/' NONSPECIFIC ... NUCLIDE=',A8,' K=',I3/)
0514      842 FORMAT(1X,132('0')/' ERROR: VALUE OF ZONE',I5/' OUTSIDE OF RANGE
      1 OF MAXIMUM ZONE ('I2,')'/1X,132('0')/))
0515      843 FORMAT(5X,I2,I2X,I2,6(3X,1PE10.2))
0516      844 FORMAT('1')
0517      845 FORMAT(19A4,I2)
0518      846 FORMAT(9(1X,132('0')/))//T54,'ERROR NEAR CHECK POINT ',
      *12//1X,19A4//9(1X,132('0')/))
0519      847 FORMAT('1RADIONUCLIDE: ',A8,' (K = ',I2,')'/1X,31('0')/' RELEASE
      *FRACTIONS BY EACH CUTSET, RELOUT'/' TIME',T14,'JF',T20,
      *INITIAL RELEASE FRACTIONS')
0520      848 FORMAT(1X,19A4,I2)
0521      849 FORMAT(/////,'** ZONALO(JF,I2) DATA, (JF=1,2,3,4)'//)
0522      850 FORMAT(/////,'** ZONDEP(I2) DATA'////,4X,9(A3,I2,5X))
0523      851 FORMAT('1# AREAW(I2) DATA'////,4X,9(A3,I2,5X))
0524      850 FORMAT(2X,9(1PE10.2))
0525      852 FORMAT('1TIME',T14,'JF',T20,33HINITIAL RELEASE FRACTIONS, CONT'D)
0526      853 FORMAT('1',T15,' AVERAGE ANNUAL LOCAL DOSE TO INDIVIDU',
      1'AL, MAN1L, IN ZONE',I2,'% IN MILLIREMS/YEAR',//)
0527      854 FORMAT('1',T15,' AVERAGE ANNUAL NONSPECIFIC DOSE TO PO',
      1'PULATION, MANIN, IN MANREMS/YEAR',//)
0528      855 FORMAT(T38,OPF9.0,' YEARS',/,1X,94('0')/,/, ' K NUCLIDE',1X,
      18(2X,A8),/,1X,94('0'))

```

APPENDIX H Main Program concluded

FORTRAN IV G LEVEL 21

MAIN

DATE = 78096

22/35/04

```

0529      856 FORMAT(2X,I2,2X,A2,8(1PE10.2))
0530      857 FORMAT(1X,94(' '),/5X,'SUB TOTAL',8(1PE10.2),/1X,94(' '))
0531      858 FORMAT(7X,'TOTAL',2X,8(1PE10.2),/1X,94(' '),
1/,' #TIME SINCE START OF REPOSITORY OPERATIONS.')
0532      859 FORMAT(////,' ** GROUND WATER PARAMETERS',///,3X,
1'GROUND WATER SEEPAGE VELOCITY, VX, IN METERS/DAY =',1PE10.2,/,
23X,'POROSITY OF SOLID MEDIUM, PORE =',1PE10.2,/,3X,
3'BULK SOLID DENSITY, BULKD, IN GRAMS/CUBIC CM =',1PE10.2,/,3X,
4'DISPERSIVITY COEFFICIENTS, IN METERS: AXIAL, AL =',1PE10.2,
52X,'TRANSVERSE, AT =',1PE10.2,/,3X,
6'AQUIFER VALUES, IN METERS: HEIGHT, HT=',1PE10.2,
7/,3X,'DISTANCE FROM SOURCE TO EMERGENCE, XL(I2)',
8' EFFECTIVE WIDTH, YW(I2)',/3X,
9'CONCENTRATION AT YV = AVERAGE CONCENTRATION IN YW',/,
104X,'ZONE',5X,9(A3,I2,5X))
0533      870 FORMAT(3X,'XL(I2)',2X,9(1PE10.2))
0534      871 FORMAT(3X,'YW(I2)',2X,9(1PE10.2))
0535      872 FORMAT(3X,'YV(I2)',2X,9(1PE10.2))
0536      873 FORMAT(/,3X,
6'EXPOSED AREA OF SOLIDIFIED WASTE SPECIMEN, FS, IN SQUARE CM =',
1PE10.2,/,3X,
7'VOLUME OF SOLIDIFIED WASTE SPECIMEN, VS, IN CUBIC CM =',1PE10.2,/,
83X,'TOTAL CANISTER INVENTORY, CINV =',1PE10.2,/,3X,
9'ASSUMED NUMBER OF CANISTER FAILURES, CFAI =',1PE10.2)
0537      860 FORMAT(1X,132('*'))' ERROR: INVALID ORGAN NUMBER =',I5,5X,
1'MAXIMUM NUMBER OF ORGANS =',I2,/,1X,132('*'))
0538      861 FORMAT(1X,132('*'))' ERROR: ATTEMPTED REPOSITORY OPERATION ',
1'WITHOUT SUBSEQUENT ENVIRONMENT TIME INCREMENT',/1X,132('*'))
0539      862 FORMAT('IRADIONUCLIDE: ',A8,' (K=',I2,')',/1X,29(' '),/CONCENTRATI
1ONS AT ENVIRONMENT INPUT RECEPTOR, R2TOT UNITS: JF=1 MICROCURI
2E*YEARS/CUBIC CM',/JF=2 MICROCURIES/SQUARE CM, JF=3 AND 4 MICROCU
3RIES/CUBIC CM',/ZONE=',I2,/,
41(14X,'JF=1 JF=2 JF=3 JF=4',18X)/
51(5X,'TIME AIR GROUND SURFACE GROUND',17X)/
61(23X,'SURFACE WATER WATER',18X))
0540      900 FORMAT('*** AVERAGE ANNUAL LOCAL DOSE TO INDIVIDUAL, MAN2LF FOR JF
1=1 TO 4, MAN2L FOR TOTAL, IN MILLIREMS/YEAR',/4X,
2'TOTAL FOR ALL NUCLIDES',T63,A8,/,
3' ZONE=',I2,T71,'ZONE=',I2,/,2(13X,'JF=1 JF=2 JF=3
4 JF=4',13X),/2(4X,'TIME AIR GROUND SURFACE GROUND
5 TOTAL',3X),/2(22X,'SURFACE WATER WATER',13X))
0541      901 FORMAT(F9.0,1PSE10.2,1X,0P1F9.0,1PSE10.2)
0542      902 FORMAT('*** AVERAGE ANNUAL LOCAL DOSE TO INDIVIDUAL, MAN2LF FOR JF
1=1 TO 4, MAN2L FOR TOTAL, IN MILLIREMS/YEAR',/4X,
2'TOTAL FOR ALL NUCLIDES',T63,A8,/,
3' ZONE=',I2,/,1(13X,'JF=1 JF=2 JF=3 JF=4',
4 13X),/1(4X,'TIME AIR GROUND SURFACE GROUND ',
5 'TOTAL',3X),/1(22X,'SURFACE WATER WATER',13X))
0543      950 FORMAT('*** AVERAGE ANNUAL NONSPECIFIC DOSE TO POPULATION, MAN2NF
1FOR JF=1 TO 4, MAN2N FOR TOTAL, IN MANREMS/YEAR',/4X,
2'TOTAL FOR ALL NUCLIDES',T63,A8,/,16X,'JF=1 JF=2 JF=3',
3' JF=4',7X,'TIME AIR GROUND SURFACE GROUND',
4' TOTAL',/25X,'SURFACE WATER WATER')
0544      951 FORMAT(F12.0,1PSE10.2)
0545      STOP
0546      END

```

APPENDIX H Subprograms

```

FORTRAN IV G LEVEL 21          FAULT          DATE = 78096          22/35/04

0001      SUBROUTINE FAULT(TIME,PROB,A1,JF,J,NJJJ,ITR,K,CONCI)
0002      IMPLICIT INTEGER*2 (I-N)
0003      COMMON/BFAULT/ PROBB,AA1,TP,CP,IFLAG
0004      COMMON/FDLEA/ CFAI,XR,DELTIM,I1
0005      COMMON/FCRATO/DELT
0006      DIMENSION PROBB(4,9,4),AA1(4,9),TIME(50),TP(4,9,4),CP(4,9,4)
0007      INTEGER*2 IFLAG(4,9,4)
0008      PROB=1.
0009      C***** NJJJ=# OF PROB ASSOCIATED WITH EACH CUTSET. **
0010      DO 100 I=1,NJJJ
0011      CPROB=PROBB(JF,J,I)
0012      IF(TIME(ITR).LT.TP(JF,J,I))GO TO 50
0013      DELTIM=TIME(ITR)-TP(JF,J,I)
0014      I1=IFLAG(JF,J,I)+1
0015      GO TO(50,40,30,20),I1
0016      C***** PROB IS DELTA FUNCTION **
0017      IF(DELTIM.EQ.0.)GO TO 10
0018      GO TO 50
0019      10 CPROB=1./DELT
0020      GO TO 50
0021      C***** PROB CHANGES EXPONENTIALLY **
0022      20 CPROB=CPROB+EXP(CP(JF,J,I)*DELTIM)
0023      GO TO 50
0024      C***** PROB CHANGES BY RAMP FUNCTION. **
0025      30 CPROB=CPROB + CP(JF,J,I)*DELTIM
0026      GO TO 50
0027      C***** PROB CHANGES BY STEP FUNCTION. **
0028      40 CPROB=CPROB+CP(JF,J,I)
0029      C***** PROB IS CONSTANT *****
0030      50 PROB=PROB*CPROB
0031      100 CONTINUE
0032      A1=AA1(JF,J)
0033      IF(PROB.EQ.0.0)GO TO 155
0034      IF(JF.EQ.4)GO TO 156
0035      RETURN
0036      155 CONCI=0.0
0037      RETURN
0038      156 A1=RLEACH(K,ITR,CONCI,X2)*CFAI*X2*365.
0039      IF(XR.EQ.0.0)A1=0.0
0040      IF(XR.EQ.0.0)RETURN
0041      A1=A1/XR.
0042      RETURN
0043      END

```

APPENDIX H Sub-programs

<p>FORTTRAN IV G LEVEL 21</p>	<p>RLEACH</p>	<p>DATE = 78096</p>	<p>22/35/04</p>
-------------------------------	---------------	---------------------	-----------------

```

0001      FUNCTION RLEACH(K, ITR, CONC1, X2)
0002      IMPLICIT INTEGER*2 (I-N)
0003      COMMON/BLEACH/ DC1(25), DRC(25), X(25,50), FS, VS, SPACT(25), CINV
0004      COMMON/FDLEA/ CFAI, XR, DELTIM, I1
0005      COMMON/FCRATO/DETL
0006      JM=5
0007      DTIME=DETL
0008      IF(I1.EQ.2) DTIME=DELTIM
0009      IF(DTIME.GE.100.) JM=10
0010      AJM=JM
0011      DELTLD=DTIME*365./AJM
0012      CONC1=0.
0013      CONC2=0.
0014      STER=SQRT(DC1(K)/3.1416)
0015      CC1=(2.*FS*X(K, ITR)*CFAI)/(VS*CINV)
0016      TERM=STER*SQRT(DELTLD)
0017      DO 85 I=1, JM
0018      IF(DTIME.GE.10.) GO TO 65
0019      CC2=1.+5*DRC(K)*DELTLD
0020      CONC2=CONC2+CC1*CC2*TERM
0021      CONC1=CONC1+CC1*CC2*TERM*SPACT(K)
0022      GO TO 75
0023  65  CC3=CC1/2.
0024      CC4=SQRT(DC1(K)*DRC(K))
0025      CC5=DELTLD+.5/DRC(K)
0026      CONC2=CONC2+CC3*CC4*CC5
0027      CONC1=CONC1+CC3*CC4*CC5*SPACT(K)
0028  75  RLEACH=CONC2
0029      IF(RLEACH .GT. 3.2E+07) RLEACH=3.2E+07
0030  85  CONTINUE
0031      RLEACH=RLEACH/(CFAI*FS*CTIME*365.)
0032      X2=FS*DETL
0033      RETURN
0034      END

```

APPENDIX H Sub-programs continued

```

FORTRAN IV G LEVEL  21              TRINP              DATE = 78096      22/35/04

0001      SUBROUTINE TRINP(DELTA,DELTA3,DELTA4,XR,XE,XEM1,XEM2,TRL,
0002      1DECFA, A2,XL,XE3,DFAC,ITE,ITRE,IW,JF,RKD,RKDMAX,K)
0003      IMPLICIT INTEGER*2 (I-N)
0004      DIMENSION RKD(25)
0005      COMMON/BTRINP/ Y2,Y3,IZ,IFDIW
0006      COMMON/CTRINP/ CRMIN,DFMIN
0007      DECFAC=1.
0008      GO TO(1,1,1,30),JF
0009      1 IF(DELTA.EQ.0.)GO TO 5
0010      Y=1.
0011      GO TO 62
0012      5 A2=1.
0013      GO TO 70
0014      30 IF(XL.LT.1.0) GO TO 68
0015      IF(RKD(K).GT.RKDMAX) GO TO 68
0016      DELTIM=DELTA*365.
0017      DELTA=DELTA3-DELTA2
0018      IIN=2
0019      IF(IFDIW.EQ.0)GO TO 50
0020      IF(DELTA.GE.5000..AND.RKD(K).LT.1.)IIN=11
0021      IF(DELTA.GE.50000.)IIN=6
0022      IF(DELTA.GE.50000..AND.RKD(K).LT.1.)IIN=101
0023      50 RIN=IIN
0024      DELINC=DELTA*365./(RIN-1.)
0025      XINC=(XE-XEM1)/(RIN-1.)
0026      A2=0.0
0027      DO 400 I=1,IIN
0028      Y=CRATIO(DELTIM,XL,DELTA,DELINC,IZ)
0029      IF(Y.LE.1.) GO TO 100
0030      Y=1.
0031      100 IF(XR.LE.1.0E-40)GO TO 300
0032      IF(IW.EQ.3) GO TO 200
0033      DECFAC=XEM1/XR
0034      GO TO 250
0035      200 IF(ITE.LE.ITRE) DECFAC=1.0
0036      IF(ITE.GT.ITRE) DECFAC=XEM1/XE3
0037      250 IF(Y.LT.CRMIN.OR.DECFAC.EQ.0.) GO TO 300
0038      IF(DECFAC.LT.DFMIN) DECFAC=DFMIN
0039      A2=A2+Y*DECFAC
0040      300 DELTIM=DELTIM+DELINC
0041      XEM1=XEM1+XINC
0042      400 CONTINUE
0043      A2=A2/RIN
0044      GO TO 70
0045      62 IF((XEM1+XEM2).LE.10.E-40.OR.ABS(TRL*DELTA).GE.50.)GO TO 68
0046      IF(IW.EQ.3.AND.ITE.LE.ITRE)GO TO 64
0047      DECFAC=(XE+XEM1)/(XEM1+XEM2)
0048      GO TO 66
0049      64 DECFAC=1.0-((DELTA3-DELTA2)*DFAC)
0050      66 TRR1=TRL*DELTA4
0051      IF(TRR1.GT.180.) GO TO 68
0052      A2=DECFAC*Y*EXP(-TRR1)
0053      GO TO 70
0054      68 A2=0.
0055      70 RETURN
0056      END

```

APPENDIX H Sub-programs continued

```

FORTRAN IV G LEVEL 21                      CRATIO                      DATE = 78096                      22/35/04

0001                      FUNCTION CRATIO(DELTIM,XL,DELTA,DELINC,IZ)
0002                      IMPLICIT INTEGER*2 (I-N)
0003                      DIMENSION RKD(25),TIME(50),YY(8),YW(8)
0004                      COMMON/BCRATO/ RKD,CONCI,TIME,VX,PORE,AL,AT,HT,BULKD,YW,ITR,MT,
                         IITE,K,GNDDIS,YY
0005                      COMMON/FCRATO/DETL
0006                      IF(CONCI.EQ.0..OR.CONCI.LE.1.E-60)CRATIO=0.
0007                      IF(CONCI.EQ.0..OR.CONCI.LE.1.E-60)RETURN
0008                      VPORE=VX
0009                      DXX=AL*VPORE
0010                      DYY=AT*VPORE
0011                      IF(CONCI.LE.1.E-70)CONCI=0.
0012                      SSAM=CONCI/HT
0013                      DR1=BULKD*RKD(K)/PORE
0014                      RD=1. + DR1
0015                      EX=DXX/RD
0016                      EY=DYY/RD
0017                      EE=(EX*EY)**0.5
0018                      U=VPORE/RD
0019                      IF(DELTIM.LE.0.)CRATIO=0.
0020                      IF(DELTIM.LE.0.)RETURN
0021                      6 TEE=EE*DELTIM
0022                      TEX=4.*3.14159*TEE
0023                      IF(SSAM.GT.1.E+30.OR.TEX.LT.1.E-45)TER=1./(HT*TEX)
0024                      IF(SSAM.GT.1.E+30.OR.TEX.LT.1.E-45)GO TO 31
0025                      TER=SSAM/TEX
0026                      31 TT1=ABS(XL-U*DELTIM)**2/(4.*EX*DELTIM)
0027                      TT3=(YY(IZ)**2)/(4.*EY*DELTIM)
0028                      TT4=ABS(TT1+TT3)
0029                      IF(TT4.GE.90.)GO TO 10
0030                      TT4=EXP(-TT4)
0031                      GO TO 34
0032                      10 TT4=0.
0033                      34 IF(SSAM.GT.1.E+30.OR.TEX.LT.1.E-45)GO TO 33
0034                      TER=TER/CONCI
0035                      33 CONC=TER*TT4
0036                      GNDDIS=YW(IZ)*HT*VPORE*PORE*DELTA*365.
0037                      GNDINC=YW(IZ)*HT*VPORE*PORE*DELINC
0038                      CONC=CONC*GNDINC
0039                      CRATIO=CONC
0040                      IF(CRATIO.GT.1.)CRATIO=1.
0041                      RETURN
0042                      END

```


APPENDIX H Sub-programs concluded

FORTRAN IV G LEVEL 21 TRMAN DATE = 78096 22/35/04

```

0001      SUBROUTINE TRMAN(K,ITE,IZ,NSS,C)
0002      IMPLICIT INTEGER*2 (I-N)
0003      DIMENSION BIOFAC(25,4,6),VOLINT(4,2,6,8),DOSFAC(25,4,2,8)
0004      COMMON/BTRMAN/ BIOFAC,VOLINT,DOSFAC,NSP,IFLAGE,JF,IH,DELTE
0005      INTEGER*2 NSP(6),IFLAGE(4,2,6)
0006      NS=NSP(JF)
0007      C=0.
0008      DO 20 MODE=1,2
0009      CSUM=0.
0010      IF(DOSFAC(K,JF,MODE,IH).EQ.0.)GO TO 20
0011      C*****SUM ALL SUBPATHWAYS TO DOSE TO MAN. **
0012      DO 10 I=1,NS
0013      IF(IFLAGE(JF,MODE,I).NE.NSS)GO TO 10
0014      FACT=BIOFAC(K,JF,I)
0015      IF(MODE.EQ.1)FACT=1.
0016      GO TO(4,2,6,6),JF
0017      2 IF(MODE.EQ.1)GO TO 6
0018      4 CSUM=CSUM+FACT*VOLINT(JF,MODE,I,IZ)/DELTE
0019      GO TO 10
0020      6 CSUM=CSUM+FACT*VOLINT(JF,MODE,I,IZ)
0021      10 CONTINUE
0022      C*****DETERMINE TRANSFER COEFFICIENT FOR DOSE TO MAN. **
0023      C=C+CSUM*DOSFAC(K,JF,MODE,IH)
0024      20 CONTINUE
0025      RETURN
0026      END

```

APPENDIX I

FLOWCHART

Figure I-1 shows a simplified flowchart for AMRAW-A. The chart represents flow through the code for a specified waste management phase, such as repository operations or terminal storage. The reader is referred to Vol. I, Generic Description of AMRAW-A, for detailed description of each step through the model.




Figure I-1. AMRAW-A simplified flowchart.

APPENDIX J

AUXILIARY PROGRAMS

Auxiliary programs for use with AMRAW are described in this appendix.

- 1) COMPRESS - a program for preparing an AMRAW-B input file from AMRAW-A output.
- 2) POLYEPA - a program for preparing inventory data matrix by curve fitting source data to prescribed time specified in AMRAW input.
- 3) SENDY - a program for comparing results in tables from AMRAW run with corresponding tables from another run.

1. COMPRESS. All of the AMRAW-A output tables in Section 3 (Local Dose to Individual) and Section 4 (Nonspecific Dose to Population) comprise the major input to AMRAW-B (Economic Model). COMPRESS is an auxiliary program, written in PL-1 and Fortran IV language, which finds these tables in the full output stored on tape, strips off the headings and left hand column of time, and outputs a continuous "compressed" file in a form ready to be read by AMRAW-B. The program may be used separately to produce AMRAW-B input files from AMRAW-A output, or it may be joined to AMRAW-B to process data directly. Appendix T in Part 2 describes and presents a listing of COMPRESS, including JCL, as run on the IBM 360/67 computer at UNM.

2. POLYEPA. The repository inventory matrix input to AMRAW consists of quantities of each radionuclide at each time specified for calculation, over the total time range considered. However, source data are generally available listed for time which do not match the intended calculation times and also are usually not subdivided into sufficiently short time increments. POLYEPA is a program written in CALL-OS FORTRAN which uses a cubic spline curve-fitting technique for interpolation to adjust quantities to the required times and furnish the required intermediate values. POLYEPA reads in the name of NK isotopes K together with inventories $X(I, K)$ at various time points I. For each isotope, there are a total of MT input time points for use in interpolating MTADJ output

data points. The output results can be written either on the terminal or stored in a data file "POLYDD" in the user's CALL-OS user library, for subsequent use as a portion of the AMRAW input data file. Before running POLYEPA, its input is assembled in a data file named "POLYDATA," stored in the user's CALL-OS user library.

Description of Card Input. One card of each type is required except as noted for card types 4 and 5.

<u>Card Type</u>	<u>Format and Item</u>	<u>Description</u>
1	Free format	
	MT	Number of input data time
	MS	Number of time intervals corresponding to the repository operations phase.
	MTADJ	Number of interpolated output time points.
	NK	Number of radioisotopes.
	MC	Number of columns in output tables.
2	Free format	
	TIME (I)	Time in years at each of MT input time points.
3	Free format	
	TIMEAD (I)	Time in years at each of MTADJ output time points.
	NK sets of card types 4 and 5 are required:	
4	FORMAT (A8)	
	NUCNAM (K)	Name of radioisotope (e.g., Sr-90, NB-93m, or PU-239).
5	Free format	
	X (I, K)	MT values of masses of isotope K at time points I.

Listing. Table J-1 is a listing of POLYEPA.

Table J-1.

```

REAL*8 TIME(17),TIMLG(17),TIMEAD(55),XS(50),U,SEVAL,X
X(17,25),XLG(17,25),B(17,25),C(17,25),D(17,25),NUCNAM(25)
INTEGER MTSAB(26),MTA,MK,ISAV,MT,M1,M7,M10,MTADJ
WRITE(6,500)
CALL OPEN(1,'DATAPOLY','INPUT')
CALL OPEN(9,'DDPOLY','OUTPUT')
READ(1,*)MT,MS,MTADJ,MK,MC
READ(1,*)(TIME(I),I=1,MT)
READ(1,*)(TIMEAD(I),I=1,MTADJ)
MSM1=MS-1
MP=MTADJ+MSM1
DO 10 I=MS,MT
    IMM=I-MSM1
10  TIMLG(IMM)=DLOG10(TIME(I))
DO 50 K=1,MK
    READ(1,910)NUCNAM(K)
    READ(1,*)(X(I,K),I=1,MT)
    DO 20 I=MS,MT
        IMM=I-MSM1
        IF(X(I,K).GT.0.000)GO TO 20
        ISAV=I-1-MSM1
        GO TO 40
20  XLG(IMM,K)=DLOG10(X(I,K))
    ISAV=MT-MSM1
40  MTSAB(K)=ISAV
50  CONTINUE
    DO 60 K=1,MK
        MTA=MTSAB(K)
60  CALL SPLINE(MTA,MK,K,TIMLG,XLG,8,C,D)
1  WRITE(6,501)
    READ(5,*)IANS
    IF(IANS.EQ.1)GO TO 3
    IF(IANS.GT.3)GO TO 1
    PAUSE 'ROLL PAPER TO BEGINNING OF CLEAN SHEET AND HIT RETURN'
3  GO TO(2,2,4),IANS
2  DO 90 I1=1,MK
    DO 61 I=1,MSM1
61  XS(I)=X(I,I1)
    MTA=MTSAB(I1)
    L=1
    M1=1
    M7=7
    DO 80 I=1,MTADJ,7
        DO 70 K=1,7
            IF(I+K-1.GT.MTADJ)GOTO70
            IF=DLOG10(TIMEAD(I+K-1))
            XS(I+K+5)=SEVAL(MTA,MK,I1,U,TIMLG,XLG,8,C,D)
            XS(I+K+5)=10.000**XS(I+K+5)
70  CONTINUE
80  CONTINUE
    DO 81 I=1,MP,7
        IF(IANS.EQ.1)WRITE(9,930)NUCNAM(I1),L,(XS(K),K=M1,M7)
        IF(IANS.EQ.2)WRITE(6,930)NUCNAM(I1),L,(XS(K),K=M1,M7)
        L=L+1
    IF(M7.GE.MP)GO TO 90

```

Table J-1. (continued)

```

      M1=M7+1
      M7=M7+7
      IF (M7.GT.MP) M7=MP
81  CONTINUE
90  CONTINUE
      GO TO 1
      4  WRITE(6,900)
      M1=1
      M10=MC
51  WRITE(6,925)(NUCNAM(K),K=M1,M10)
      DO 53 I=1,MT
53  WRITE(6,940)TIME(I),(X(I,K),K=M1,M10)
      IF (M10.GE.MK) GO TO 55
      M1=M10+1
      M10=M10+MC
      IF (M10.GT.MK) M10=MK
      GO TO 51
55  WRITE(6,920)
      M1=1
      M10=MC
65  WRITE(6,925)(NUCNAM(K),K=M1,M10)
      DO 67 I=1,MSM1
67  WRITE(6,940)TIMEAD(I),(X(I,K),K=M1,M10)
      DO 82 I=1,MTADJ
      U=DLOG10(TIMEAD(I))
      DO 71 K=M1,M10
      MTA=MTSAV(K)
      XS(K)=SEVAL(MTA,MK,K,U,TIMLG,XLG,B,C,D)
71  XS(K)=10.000**XS(K)
      IF (XS(K).LT.1.0E-25) XS(K)=0.00
82  WRITE(6,940)TIMEAD(I),(XS(K),K=M1,M10)
      IF (M10.GE.MK) GO TO 999
      M1=M10+1
      M10=M10+MC
      IF (M10.GT.MK) M10=MK
      GO TO 65
      GO TO 1
999  STOP
500  FORMAT(' 1=WRITE TO DATA FILE'//%
           ' 2=WRITE DATA FILE FORMATTED OUTPUT ON TERMINAL'//%
           ' 3=WRITE FORMATTED FOR EPA REPORT')
501  FORMAT(' ENTER REQUEST')
900  FORMAT('///' ** INPUT DATA'//4X,'PROPERTIES OF ACCUMULATED 10 YEAR%
OLD WASTE AS A FUNCTION OF AGE.'//T51,'CONCENTRATION, GRAMS')
910  FORMAT(A8)
920  FORMAT('///' *** OUTPUT RESULTS'//T51,%
'CONCENTRATIONS, GRAMS')
925  FORMAT('OTIME(YRS)',10(2X,A8))
930  FORMAT(A8,I2,7(1PE10.2))
940  FORMAT(F10.0,10(1PE10.2))
      END
      SUBROUTINE SPLINE(N,MK,K,X,Y,B,C,D)
      INTEGER N,MK,K
      REAL*8 X(17),Y(17,25),B(17,25),C(17,25),D(17,25),T
      INTEGER NM1,IB,I

```

Table J-1. (concluded)

```

      NM1 = N-1
      IF ( N .LT. 3 ) GO TO 50
      D(1,K) = X(2) - X(1)
      C(2,K) = (Y(2,K) - Y(1,K))/D(1,K)
      DO 10 I = 2, NM1
        D(I,K) = X(I+1) - X(I)
        B(I,K) = 2.*(D(I-1,K) + D(I,K))
        C(I+1,K) = (Y(I+1,K) - Y(I,K))/D(I,K)
        C(I,K) = C(I+1,K) - C(I,K)
10    CONTINUE
      B(1,K) = -D(1,K)
      B(N,K) = -D(N-1,K)
      C(1,K) = 0.
      C(N,K) = 0.
      IF ( N .EQ. 3 ) GO TO 15
      C(1,K) = C(3,K)/(X(4)-X(2)) - C(2,K)/(X(3)-X(1))
      C(N,K) = C(N-1,K)/(X(N)-X(N-2)) - C(N-2,K)/(X(N-1)-X(N-3))
      C(1,K) = C(1,K)*D(1,K)**2/(X(4)-X(1))
      C(N,K) = -C(N,K)*D(N-1,K)**2/(X(N)-X(N-3))
15    DO 20 I = 2, N
      T = D(I-1,K)/B(I-1,K)
      B(I,K) = B(I,K) - T*D(I-1,K)
      C(I,K) = C(I,K) - T*C(I-1,K)
20    CONTINUE
      C(N,K) = C(N,K)/B(N,K)
      DO 30 IB = 1, NM1
      I = N-IB
      C(I,K) = (C(I,K) - D(I,K)*C(I+1,K))/B(I,K)
30    CONTINUE
      B(N,K) = (Y(N,K) - Y(NM1,K))/D(NM1,K) + D(NM1,K)*(C(NM1,K) + 2.*C(N,K))
      DO 40 I = 1, NM1
      B(I,K) = (Y(I+1,K) - Y(I,K))/D(I,K) - D(I,K)*(C(I+1,K) + 2.*C(I,K))
      D(I,K) = (C(I+1,K) - C(I,K))/D(I,K)
      C(I,K) = 3.*C(I,K)
40    CONTINUE
      C(N,K) = 3.*C(N,K)
      D(N,K) = D(N-1,K)
      RETURN
50    IF ( N .LT. 2 ) RETURN
      B(1,K) = (Y(2,K)-Y(1,K))/(X(2)-X(1))
      C(1,K) = 0.
      D(1,K) = 0.
      RETURN
      END
      REAL FUNCTION SEVAL*8 (N,MK,KK,U,X,Y,B,C,D)
      INTEGER N,MK,KK
      REAL*8 U,X(17),Y(17,25),B(17,25),C(17,25),D(17,25),DX
      INTEGER I, J, K
      DATA I/1/
      IF ( I.GE.N ) I = 1
      IF ( U .LT. X(I) ) GO TO 10
      IF ( U .LE. X(I+1) ) GO TO 30
10    I = 1
      J = N + 1
      DO K = (I+J)/2
      IF ( U .LT. X(K) ) J = K
      IF ( U .GE. X(K) ) I = K
      IF ( J .GT. I+1 ) GO TO 20
30    DX = U - X(I)
      SEVAL = Y(I,KK) + DX*(B(I,KK) + DX*(C(I,KK) + DX*D(I,KK)))
      RETURN
      END

```


3. SENDY. This is an auxiliary program developed to help compare results from different computer runs of AMRAW-A. It handles two cases at a time. AMRAW-A stores output results on magnetic tape; SENDY reads corresponding matrices of two different cases from the tape. It can compare results from two cases by finding the ratio of elements of the two matrices, or calculate the normalized values in each matrix (e.g., metric tons of initial waste stored). There are provisions in SENDY for users to modify the program to perform other mathematical manipulations on the two matrices.

SENDY identifies the particular matrix by the unique headings of the matrix. It compares the matrix heading it reads on the tape with that of the input heading read from a card. Once the matrix heading on the tape matches that on the card, it reads and stores the entire matrix in the core. Input to SENDY consists of identification of magnetic tape volumes which store the two cases to be compared, headings identifying the matrix in each of the cases to be compared, and commands the comparison or normalizing operation to be performed.

AMRAW-A points out 9 variables in its output: 3 in section 2, one in sections 3 and 4, and 4 in section 5. In order to simplify the modification of SENDY to suit different users, the program is partitioned into 7 parts; namely, JCLSENDY, SENDYGEN, SENDY3A, SENDY4A, SENDY5A, SENDY5B and DDSENDY. A complete SENDY run consists of these 7 parts, plus input cards with commands and headings (see Figures J-1 and J-2).

SENDY first reads in commands (compare case n_1 with case n_2) and headings. Then it searches through the tape and locates the matrix whose headings match the one desired. After reading from tape, storing and printing out the matrix from each of the two cases, the arithmetical calculation on the two matrices is performed. After these calculations, the whole loop is repeated if requested (see Figure J-1).

DDSENDY is an integral part of SENDY consisting of the data set definition statements and the statements STOP/END. The data set reference number in the DD statement is made to be identical with the case number which was stored on the tape volume as addressed in the DD statement.




Figure J-1. SENDY simplified flowchart.




Figure J-2. SENDY operating deck setup.

Description of Card Input. One card of each type is required.

<u>Card Type</u>	<u>Format and Item</u>	<u>Description</u>															
1	FORMAT (10A4, I2, 2A4, A3, I2, T79, I2) Commands EXPLAN(I) IP1 IP2 IMATH	Compare case n_1 with n_2 . In column 41; first case number to compare (n_1). In column 54; second case number to compare (n_2). Column 80, flags that control calculations options: IMATH Operation: 1 Normalized for case n_1 . 2 Normalized for case n_2 . 3 Normalized for case n_1 and n_2 . 4 Dummy (for modification). 5 Dummy (for modification). 6 Dummy (for modification). 7 Ratio: first case, n_1 , divided by second case, n_2 .															
2	FORMAT (17A4, A2, T77, A2, I1, A1) Heading TITLE(I) ISECT(3) ISECT3 CODE	Store the heading of the desired matrix from card; column 1 to column 70. Section of output; column 77, 78. A code to aid in locating the matrix on tape: column 79, for ISECT3 (integer 3, 4, or 5 for AMRAW-A output section). Flag A or B in column 80. ISECT(3), ISECT3, and CODE appear on card as follows: <table> <tr> <th><u>Section</u></th><th><u>AMRAW-A Item</u></th><th></th></tr> <tr> <td>3</td><td>Local Dose, MAN1L</td><td>b33A</td></tr> <tr> <td>4</td><td>Nonspecific Dose, MAN1N</td><td>b44A</td></tr> <tr> <td>5</td><td>Local Dose, MAN2L</td><td>b55A</td></tr> <tr> <td>5</td><td>Nonspecific Dose, MAN2NF</td><td>b55B</td></tr> </table>	<u>Section</u>	<u>AMRAW-A Item</u>		3	Local Dose, MAN1L	b33A	4	Nonspecific Dose, MAN1N	b44A	5	Local Dose, MAN2L	b55A	5	Nonspecific Dose, MAN2NF	b55B
<u>Section</u>	<u>AMRAW-A Item</u>																
3	Local Dose, MAN1L	b33A															
4	Nonspecific Dose, MAN1N	b44A															
5	Local Dose, MAN2L	b55A															
5	Nonspecific Dose, MAN2NF	b55B															
3	FORMAT (T6, IZ) IZ	Zone heading Additional table identifier where needed. Zone number as appeared on the left hand side of output pages: 1, 3, 5, or 7. Card required only for MAN2L from AMRAW-A with present output format.															

Modification of SENDY. Calculation options may be added. Replace a CONTINUE statement by the mathematical routine desired. The matrix of the first case read in is stored in the variable that begins with an X in front of the original variable name. The second case is stored as the original variable name. The original variable with a Y in front can be used to store intermediate results. For example, SENDY4A deals with the variable MAN1N. The matrix from the first case is stored in XMAN1N, and from the second case as MAN1N. Variable YMAN1N is used to store intermediate results.

Statement numbers in each section of SENDY containing dummy "CONTINUE" statements and the corresponding IMATH flag are as follows:

IMATH	SENDY SECTION			
	3A	4A	5A	5B
4	2431	2535	2632	2732
5	2441	2545	2642	2742
6	2451	2555	2652	2752

Listing. Table J-2 presents the SENDY listing.

Sample Input. Sample input for a simple application of SENDY for comparison of nonspecific dose rates (AMRAW-A Section 3) from C-14. is presented. The comparison requested is to divide each value in the table from Case 55 by the corresponding value in the table from Case 48 (IMATH = 7) and output the resulting table of quotients. The input required is as follows:

```

** SENSITIVITY ANALYSIS : COMPARE CASE 55 WITH CASE 48.
NONSPECIFIC ... NUCLIDE= C-14 K= 1

```

Column 80

7
44A

Table J-2 (a). File SENDYGEN

```

1000 REAL X(3,4,50),XR1J(4,50),XR2TOT(4,50,8)
1010 REAL Y(3,4,50),YR1J(4,50),YR2TOT(4,50,8)
1020 REAL R(3,4,50),R1J(4,50),R2TOT(4,50,8)
1030 REAL XMAN1L(50,8),YMAN1L(50,8),MAN1L(50,8)
1040 REAL TIME(50)
1050 REAL XMAN1N(50,8),XAN2LF(50,8,4),XMAN2L(50,8),XAN2NF(50,4),
1060 CXMAN2N(50)
1070 REAL YMAN1N(50,8),YAN2LF(50,8,4),YMAN2L(50,8),YAN2NF(50,4),
1080 CYMAN2N(50)
1090 REAL MAN1N(50,8),MAN2LF(50,8,4),MAN2L(50,8),MAN2NF(50,4),MAN2N(50)
1100 EQUIVALENCE (X(1),XR1J(1),XR2TOT(1),XMAN1L(1),XMAN1N(1),XAN2LF(1),
1110 CXAN2NF(1)),(XMAN2L(1),XMAN2N(1))
1120 EQUIVALENCE (Y(1),YR1J(1),YR2TOT(1),YMAN1L(1),YMAN1N(1),YAN2LF(1),
1130 CYAN2NF(1)),(YMAN2L(1),YMAN2N(1))
1140 EQUIVALENCE (R(1),R1J(1),R2TOT(1),MAN1L(1),MAN1N(1),MAN2LF(1),MAN2
1150 CNF(1)),(MAN2L(1),MAN2N(1))
1160 INTEGER*4 JN(9),VAR(5),TITLE(17),CHECK(33),SECT(3),EXPLAN(15),IY,
1170 CIP1,IP2,IP1F,MT,IP,IN,NJ(4)
1180 DATA VAR/'9F10','0.1','5.1P','9E1','2.2'/
1190 DATA JN/'1E1','2E1','3E1','4E1','5E1','6E1','7E1','8E1','9E1'/
1200 DATA NJ/3,3,3,1/
1210 DATA A,B,C/'A','B','C'/
1212 DATA SECT(1),SECT(2)/'SECT','ION '/
1220 IN=5
1230 IP=6
1240 MT=50
1250 MJF=4
1260 MIH=8
1270 TWASTE=187000.00
1280 C UNM COMPUTER SYSTEM ASSIGN DATA SET REFERENCE NUMBER:
1290 C 5 FOR CARD READER,6 FOR PRINTER.
1300 C*****READ INPUT COMMAND : DETERMINE CASES TO COMPARE WITH. *****
1310 1 READ(IN,1100,ERR=9990,END=9990)(EXPLAN(I),I=1,10),IP1,(EXPLAN(I),I
1320 C=11,13),IP2,IMATH
1330 IP1F=IP1
1340 WRITE(IP,1101)(EXPLAN(I),I=1,10),IP1,(EXPLAN(I),I=11,13),IP2
1350 IY=0
1360 READ(IN,1102)(TITLE(I),I=1,18),SECT(3),ISECT3,CODE
1370 2 IY=IY+1
1380 IF(IY.EQ.2) IP1=IP2
1390 GO TO (20,20,30,40,50),ISECT3
1400 20 READ(IP1,1103)
1410 DO 11 J=1,900
1420 READ(IP1,1104)(CHECK(I),I=16,18)
1425 WRITE(IP,1104)(CHECK(I),I=16,18)
1430 IF(CHECK(16).EQ.SECT(1).AND.CHECK(17).EQ.SECT(2).AND.CHECK(18).EQ.
1440 CSECT(3)) GO TO 2050
1450 11 CONTINUE
1460 WRITE(IP,1105)(TITLE(I),I=1,18)
1470 IF(ISECT3.EQ.2.AND.CODE.EQ.C) READ(IN,1100) DUMMY
1480 IF(ISECT3.EQ.5.AND.CODE.EQ.A) READ(IN,1100) DUMMY
1490 GO TO 1
1500 30 READ(IP1,1106)
1510 GO TO 80
1520 40 READ(IP1,1107)
1530 GO TO 80
1532 50 READ(IP1,1113)
1534 GO TO 80
1540 2050 READ(IP1,1108)
1550 IF(ISECT3.EQ.2.AND.CODE.EQ.A) GO TO 2100
1560 IF(ISECT3.EQ.2.AND.CODE.EQ.B) GO TO 2200
1570 IF(ISECT3.EQ.2.AND.CODE.EQ.C) GO TO 2300
1580 IF(ISECT3.EQ.3.AND.CODE.EQ.A) GO TO 2400
1590 IF(ISECT3.EQ.4.AND.CODE.EQ.A) GO TO 2500
1600 IF(ISECT3.EQ.5.AND.CODE.EQ.A) GO TO 2600
1610 IF(ISECT3.EQ.5.AND.CODE.EQ.B) GO TO 2700
1620 1100 FORMAT(10A4,12,2A4,A3,12,Y79,I2)
1630 1101 FORMAT(11H1,10A4,12,2A4,A3,I2)
1640 1102 FORMAT(17A4,A2,177,A2,I1,A1)
1650 1103 FORMAT(4(255(/)),27(/))
1660 1104 FORMAT(1X,T61,2A4,A2)
1670 1105 FORMAT(1H1,'** OUTPUT MATRIX OF :',18A4,' CANNOT BE FOUND.'/'/' CHE
1680 CCK STATEMENT NUMBER 10,20 CR 30,1/)
1690 1106 FORMAT(51(255(/)),54(/))
1700 1107 FORMAT(95(255(/)),95(/))
1710 1108 FORMAT(29(/))
1720 1109 FORMAT(1H1,'RATIO OF TWO OUTPUT MATRIXES',/'/' CASE',14,' DIVIDED BY
1730 C CASE',14/1X,'*IN THIS MATRIX, THE ELEMENTS ARE RATIO OF CORR'
1740 C SPONDING ELEMENTS IN THE PRECEDING TWO MATRIXES',/' -1.00 STANDS
1750 C FOR ZERO DIVIDED BY ZERO. -X STANDS FOR X DIVIDED BY ZERO')
1760 C/2HO(,17A4,A2,1H1)
1770 1110 FORMAT(1X,33A4)
1780 1111 FORMAT(33A4)
1790 1112 FORMAT(1H1,'INITIAL TOTAL INVENTORY OF WASTE=',F12.2,' METRIC TON'
1800 C/1X,17A4,A2,4X,'CASE',14,'/' NORMALIZED DOSE .',/'/'
1810 1113 FORMAT(101(255(/)),29(/))

```

Table J-2 (b). File SENDY3A

```

1000 C*****3A*****
1010 C    READ MATRIX HEADINGS FROM TAPE.
1020   2400 DO 2406 K=1,2
1030       READ(IP1,1111)(CHECK(I),I=1,33)
1040   2406 WRITE(IP,1111)(CHECK(I),I=1,33)
1050   2410 READ(IP1,1110)(CHECK(I),I=1,7)
1060       DO 2420 I=1,7
1070       IF(CHECK(I).NE.TITLE(I)) GO TO 2430
1080   2420 CONTINUE
1090       WRITE(IP,1241)(TITLE(I),I=1,7),IP1
1100       DO 2407 K=1,3
1110       READ(IP1,1110)(CHECK(I),I=1,33)
1120   2407 WRITE(IP,1110)(CHECK(I),I=1,33)
1130       IF(IY.EQ.2) GO TO 2440
1140 C    OUTPUT THE MATRIX FROM FIRST CASE FOR COMPARISON.
1150       DO 2450 IT=1,MT
1160   2450 READ(IP1,1242) TIME(IT),(XMAN1L(IT,IH),IH=1,MIH)
1170       REWIND IP1
1180       DO 2460 IT=1,MT
1190   2460 WRITE(IP,1242) TIME(IT),(XMAN1L(IT,IH),IH=1,MIH)
1200       GO TO 2
1210 C    OUTPUT MATRIX FROM SECOND CASE FOR COMPARISON.
1220   2440 DO 2470 IT=1,MT
1230       READ(IP1,1242) TIME(IT),(MAN1L(IT,IH),IH=1,MIH)
1240   2470 WRITE(IP,1242) TIME(IT),(MAN1L(IT,IH),IH=1,MIH)
1250       REWIND IP1
1260       GO TO (2411,2421,2411,2431,2441,2451,2461),IMATH
1270   2411 IF(IMATH.NE.1.AND.IMATH.NE.3) GO TO 2421
1280       WRITE(IP,1112) TWASTE,(TITLE(I),I=1,17),IP1F
1290       DO 2412 IT=1,MT
1300       DO 2413 IH=1,MIH
1310   2413 YMAN1L(IT,IH)=XMAN1L(IT,IH)/TWASTE
1320   2412 WRITE(IP,1242) TIME(IT),(YMAN1L(IT,IH),IH=1,MIH)
1330   2421 IF(IMATH.NE.2.AND.IMATH.NE.3) GO TO 2431
1340       WRITE(IP,1112) TWASTE,(TITLE(I),I=1,17),IP2
1350       DO 2422 IT=1,MT
1360       DO 2423 IH=1,MIH
1370   2423 YMAN1L(IT,IH)=MAN1L(IT,IH)/TWASTE
1380   2422 WRITE(IP,1242) TIME(IT),(YMAN1L(IT,IH),IH=1,MIH)
1390   2431 CONTINUE
1400   2441 CONTINUE
1410   2451 CONTINUE
1420 C    CALCULATE THE RATIO OF TWO MATRIXES.
1430   2461 DO 2480 IT=1,MT
1440       DO 2490 IH=1,MIH
1450       IF(MAN1L(IT,IH).NE.0.0) GO TO 2490
1460       IF(XMAN1L(IT,IH).NE.0.0) XMAN1L(IT,IH)=1.0
1470       MAN1L(IT,IH)=-1.0
1480   2490 MAN1L(IT,IH)=XMAN1L(IT,IH)/MAN1L(IT,IH)
1490   2480 CONTINUE
1500 C    PRINT THE RATIO MATRIX.
1510       WRITE(IP,1109) IP1F,IP2,(TITLE(I),I=1,17)
1520       DO 2491 IT=1,MT
1530   2491 WRITE(IP,1242) TIME(IT),(MAN1L(IT,IH),IH=1,MIH)
1540       GO TO 1
1550   2430 READ(IP1,1243)
1560       GO TO 2410
1570   1241 FORMAT(1X,7A4,T62,'CASE',I4)
1580   1242 FORMAT(0FF11.0,1P10E10,2)
1590   1243 FORMAT(54(/))

```

Table J-2 (c). File SENDY4A

```

1000 C*****4A*****
1010 C READ MATRIX HEADINGS FROM TAPE.
1020   2500 DO 2506 K=1,2
1030     READ(IP1,1111)(CHECK(I),I=1,33)
1040   2506 WRITE(IP,1111)(CHECK(I),I=1,33)
1050   2530 READ(IP1,1110)(CHECK(I),I=1,33)
1060     DO 2510 I=1,10
1070       IF(CHECK(I).NE.TITLE(I)) GO TO 2520
1080   2510 CONTINUE
1090 C PRINT OUT HEADINGS
1100   WRITE(IP,1250)(CHECK(I),I=1,10),IP1
1110     DO 2521 J=1,3
1120       READ(IP1,1110)(CHECK(I),I=1,33)
1130   2521 WRITE(IP,1110)(CHECK(I),I=1,33)
1140     IF(IY.EQ.2) GO TO 2540
1150 C OUTPUT THE MATRIX FROM FIRST CASE FOR COMPARISON.
1160   DO 2550 IT=1,MT
1170   2550 READ(IP1,1251) TIME(IT),(XMANIN(IT,IH),IH=1,MIH)
1180     REWIND IP1
1190     DO 2551 IT=1,MT
1200   2551 WRITE(IP,1251) TIME(IT),(XMANIN(IT,IH),IH=1,MIH)
1210     GO TO 2
1220 C OUTPUT THE MATRIX FROM SECOND CASE FOR COMPARISON.
1230   2540 DO 2560 IT=1,MT
1240     READ(IP1,1251) TIME(IT),(MANIN(IT,IH),IH=1,MIH)
1250   2560 WRITE(IP,1251) TIME(IT),(MANIN(IT,IH),IH=1,MIH)
1260     REWIND IP1
1270     GO TO (2515,2525,2515,2535,2545,2555,2565),IMATH
1280   2515 IF(IMATH.NE.1.AND.IMATH.NE.3) GO TO 2525
1290     WRITE(IP,1112) TWASTE,(TITLE(I),I=1,18),IP1F
1300     DO 2516 IT=1,MT
1310     DO 2517 IH=1,MIH
1320   2517 YMANIN(IT,IH)=XMANIN(IT,IH)/TWASTE
1330   2516 WRITE(IP,1251) TIME(IT),(YMANIN(IT,IH),IH=1,MIH)
1340   2525 IF(IMATH.NE.2.AND.IMATH.NE.3) GO TO 2535
1350     WRITE(IP,1112) TWASTE,(TITLE(I),I=1,18),IP2
1360     DO 2526 IT=1,MT
1370     DO 2527 IH=1,MIH
1380   2527 YMANIN(IT,IH)=MANIN(IT,IH)/TWASTE
1390   2526 WRITE(IP,1251) TIME(IT),(YMANIN(IT,IH),IH=1,MIH)
1400   2535 CONTINUE
1410   2545 CONTINUE
1420   2555 CONTINUE
1430 C CALCULATE THE RATIO OF TWO MATRIXES.
1440   2565 DO 2570 IT=1,MT
1450     DO 2580 IH=1,MIH
1460       IF(MANIN(IT,IH).NE.0.0) GO TO 2580
1470       IF(XMANIN(IT,IH).EQ.0.0) XMANIN(IT,IH)=1.0
1480       MANIN(IT,IH)=-1.0
1490   2580 MANIN(IT,IH)=XMANIN(IT,IH)/MANIN(IT,IH)
1500   2570 CONTINUE

1510 C PRINT THE RATIO MATRIX.
1520   WRITE(IP,1109) IP1F,IP2,(TITLE(I),I=1,18)
1530   DO 2590 IT=1,MT
1540   2590 WRITE(IP,1251) TIME(IT),(MANIN(IT,IH),IH=1,MIH)
1550     GO TO 1
1560   2520 READ(IP1,1252)
1570     GO TO 2530
1580   1250 FORMAT(1X,10A4,T62,'CASE',I4)
1590   1251 FORMAT(F11.0,1P10E10.2)
1600   1252 FORMAT(54(/))

```


Table J-2 (d). File SENDY5A

```

1000 C*****5A*****
1030 2600 IF(IY.EQ.1) READ(IN,1261) IZA,IZB
1032 DO 2625 J=1,2
1034 READ(IP1,1111)(CHECK(I),I=1,33)
1036 2625 WRITE(IP,1111)(CHECK(I),I=1,33)
1040 2630 READ(IP1,1110)(CHECK(I),I=1,33)
1050 2610 DO 2620 I=1,17
1060 IF(CHECK(I).NE.TITLE(I)) GO TO 2640
1070 2620 CONTINUE
1080 WRITE(IP,1263)(CHECK(I),I=1,18),IP1
1100 READ(IP1,1110)(CHECK(I),I=1,33)
1110 WRITE(IP,1110)(CHECK(I),I=1,33)
1120 2631 READ(IP1,1262) IZ,IZP1
1130 IF(IZ.NE.IZA) GO TO 2650
1140 WRITE(IP,1264) IZ,IZP1
1150 C PRINT HEADINGS.
1160 DO 2660 J=1,4
1170 READ(IP1,1110)(CHECK(I),I=1,33)
1180 2660 WRITE(IP,1110)(CHECK(I),I=1,33)
1190 IF(IY.EQ.2) GO TO 2690
1200 C OUTPUT THE MATRIX FROM FIRST CASE FOR COMPARISON.
1210 DO 2670 IT=1,MT
1220 2670 READ(IP1,1265) TIME(IT),(XAN2LF(IT,IZ,JF),JF=1,MJF),XMAN2L(IT,IZ),
1230 CTIME(IT),(XAN2LF(IT,IZP1,JF),JF=1,MJF),XMAN2L(IT,IZP1)
1240 REWIND IP1
1250 DO 2680 IT=1,MT
1260 2680 WRITE(IP,1265) TIME(IT),(XAN2LF(IT,IZ,JF),JF=1,MJF),XMAN2L(IT,IZ),
1270 CTIME(IT),(XAN2LF(IT,IZP1,JF),JF=1,MJF),XMAN2L(IT,IZP1)
1280 GO TO 2
1290 C OUTPUT THE MATRIX FROM SECOND CASE FOR COMPARISON.
1300 2690 DO 2691 IT=1,MT
1310 2691 READ(IP1,1265) TIME(IT),(MAN2LF(IT,IZ,JF),JF=1,MJF),MAN2L(IT,IZ),
1320 CTIME(IT),(MAN2LF(IT,IZP1,JF),JF=1,MJF),MAN2L(IT,IZP1)
1330 WRITE(IP,1265)(TIME(IT),(MAN2LF(IT,IZ,JF),JF=1,MJF),MAN2L(IT,IZ),
1340 CTIME(IT),(MAN2LF(IT,IZP1,JF),JF=1,MJF),MAN2L(IT,IZP1),IT=1,MT)
1350 REWIND IP1
1360 GO TO (2612,2622,2612,2632,2642,2652,2662),IMATH
1370 2612 IF(IMATH.NE.1.AND.IMATH.NE.3) GO TO 2622
1380 WRITE(IP,1112) TWASTE,(TITLE(I),I=1,18),IP1F
1390 DO 2613 IT=1,MT
1400 DO 2614 JF=1,MJF
1410 YAN2LF(IT,IZ,JF)=XAN2LF(IT,IZ,JF)/TWASTE
1420 2614 YAN2LF(IT,IZP1,JF)=XAN2LF(IT,IZP1,JF)/TWASTE
1430 YMAN2L(IT,IZ)=XMAN2L(IT,IZ)/TWASTE
1440 YMAN2L(IT,IZP1)=XMAN2L(IT,IZP1)/TWASTE
1450 2613 WRITE(IP,1265) TIME(IT),(YAN2LF(IT,IZ,JF),JF=1,MJF),YMAN2L(IT,IZ),
1460 CTIME(IT),(YAN2LF(IT,IZP1,JF),JF=1,MJF),YMAN2L(IT,IZP1)
1470 2622 IF(IMATH.NE.2.AND.IMATH.NE.3) GO TO 2632
1480 WRITE(IP,1112) TWASTE,(TITLE(I),I=1,18),IP2
1490 DO 2623 IT=1,MT
1500 DO 2624 JF=1,MJF
1510 YAN2LF(IT,IZ,JF)=MAN2LF(IT,IZ,JF)/TWASTE
1520 2624 YAN2LF(IT,IZP1,JF)=MAN2LF(IT,IZP1,JF)/TWASTE
1530 YMAN2L(IT,IZ)=MAN2L(IT,IZ)/TWASTE
1540 YMAN2L(IT,IZP1)=MAN2L(IT,IZP1)/TWASTE
1550 2623 WRITE(IP,1265) TIME(IT),(YAN2LF(IT,IZ,JF),JF=1,MJF),YMAN2L(IT,IZ),
1560 CTIME(IT),(YAN2LF(IT,IZP1,JF),JF=1,MJF),YMAN2L(IT,IZP1)
1570 2632 CONTINUE
1580 2642 CONTINUE
1590 2652 CONTINUE
1600 C CALCULATE THE RATIO OF TWO MATRIXES.
1610 2662 DO 2695 IT=1,MT
1620 DO 2697 JF=1,MJF
1630 IF(MAN2LF(IT,IZ,JF).NE.0.0) GO TO 269
1640 IF(XAN2LF(IT,IZ,JF).EQ.0.0) XAN2LF(IT,IZ,JF)=1.0
1650 MAN2LF(IT,IZ,JF)=-1.0
1660 269 MAN2LF(IT,IZ,JF)=XAN2LF(IT,IZ,JF)/MAN2LF(IT,IZ,JF)
1670 IF(MAN2LF(IT,IZP1,JF).NE.0.0) GO TO 2696
1680 IF(XAN2LF(IT,IZP1,JF).EQ.0.0) XAN2LF(IT,IZP1,JF)=1.0
1690 MAN2LF(IT,IZP1,JF)=-1.0
1700 2696 MAN2LF(IT,IZP1,JF)=XAN2LF(IT,IZP1,JF)/MAN2LF(IT,IZP1,JF)
1710 2697 CONTINUE
1720 IF(MAN2L(IT,IZ).NE.0.0) GO TO 270
1730 IF(XMAN2L(IT,IZ).EQ.0.0) XMAN2L(IT,IZ)=1.0
1740 MAN2L(IT,IZ)=-1.0
1750 270 MAN2L(IT,IZ)=XMAN2L(IT,IZ)/MAN2L(IT,IZ)
1760 IF(MAN2L(IT,IZP1).NE.0.0) GO TO 271
1770 IF(XMAN2L(IT,IZP1).EQ.0.0) XMAN2L(IT,IZP1)=1.0
1780 MAN2L(IT,IZP1)=-1.0
1790 271 MAN2L(IT,IZP1)=XMAN2L(IT,IZP1)/MAN2L(IT,IZP1)
1800 2695 CONTINUE
1810 C PRINT THE RATIO MATRIX
1820 WRITE(IP,1109) IP1F,IP2,(TITLE(I),I=1,18)
1830 DO 2698 IT=1,MT
1840 2698 WRITE(IP,1265) TIME(IT),(MAN2LF(IT,IZ,JF),JF=1,MJF),MAN2L(IT,IZ),
1850 CTIME(IT),(MAN2LF(IT,IZP1,JF),JF=1,MJF),MAN2L(IT,IZP1)
1860 GO TO 1
1870 2640 READ(IP1,1266)
1880 GO TO 2630
1890 2650 READ(IP1,1267)
1900 GO TO 2631
1920 1261 FORMAT(16,12,T7S,12)
1930 1262 FORMAT(16,12,T7S,12)
1940 1263 FORMAT(1X,18A4,T7S,'CASE',14)
1950 1264 FORMAT(2X,'ZONE=',12,T71,'ZONE=',12)
1960 1265 FORMAT(0PF9.0,1PSE10.2,1X,0PF9.0,1PSE10.2)
1970 1266 FORMAT(234(/))
1980 1267 FORMAT(57(/))

```

Table J-2 (e). File SENDY5B

```

1000 C*****5B*****
1010 C SKIP 1887 RECORDS AND READ HEADINGS OF MATRIX FROM TAPE.
1020 2700 READ(IP1,1270)
1022 DO 2725 J=1,2
1024 READ(IP1,1111)(CHECK(I),I=1,33)
1026 2725 WRITE(IP,1111)(CHECK(I),I=1,33)
1030 2730 READ(IP1,1110)(CHECK(I),I=1,33)
1040 DO 2710 I=1,17
1050 IF (CHECK(I).NE.TITLE(I)) GO TO 2720
1060 2710 CONTINUE
1070 C PRINT HEADINGS.
1080 WRITE(IP,1271)(CHECK(I),I=1,18),IP1
1090 DO 2711 K=1,4
1100 READ(IP1,1110)(CHECK(I),I=1,33)
1110 2711 WRITE(IP,1110)(CHECK(I),I=1,33)
1120 IF(IY.EQ.2) GO TO 2740
1130 C OUTPUT THE MATRIX FROM FIRST CASE FOR COMPARISON.
1140 DO 2750 IT=1,MT
1150 2750 READ(IP1,1272) TIME(IT),(XAN2NF(IT,JF),JF=1,MJF),XMAN2N(IT)
1160 REWIND IP1
1170 DO 2760 IT=1,MT
1180 2760 WRITE(IP,1272) TIME(IT),(XAN2NF(IT,JF),JF=1,MJF),XMAN2N(IT)
1190 GO TO 2
1200 C OUTPUT THE MATRIX FROM SECOND CASE FOR COMPARISON.
1210 2740 DO 2770 IT=1,MT
1220 READ(IP1,1272) TIME(IT),(MAN2NF(IT,JF),JF=1,MJF),MAN2N(IT)
1230 2770 WRITE(IP,1272) TIME(IT),(MAN2NF(IT,JF),JF=1,MJF),MAN2N(IT)
1240 REWIND IP1
1250 GO TO (2712,2722,2712,2732,2742,2752,2762),IMATH
1260 2712 IF (IMATH.NE.1.AND.IMATH.NE.3) GO TO 2722
1270 WRITE(IP,1112) TWASTE,(TITLE(I),I=1,18),IP1F
1280 DO 2713 IT=1,MT
1290 DO 2714 JF=1,MJF
1300 2714 YAN2NF(IT,JF)=XAN2NF(IT,JF)/TWASTE
1310 YMAN2N(IT)=XMAN2N(IT)/TWASTE
1320 2713 WRITE(IP,1272) TIME(IT),(YAN2NF(IT,JF),JF=1,MJF),YMAN2N(IT)
1330 2722 IF (IMATH.NE.2.AND.IMATH.NE.3) GO TO 2732
1340 WRITE(IP,1112) TWASTE,(TITLE(I),I=1,18),IP2
1350 DO 2723 IT=1,MT
1360 DO 2724 JF=1,MJF
1370 2724 YAN2NF(IT,JF)=MAN2NF(IT,JF)/TWASTE
1380 YMAN2N(IT)=MAN2N(IT)/TWASTE
1390 2723 WRITE(IP,1272) TIME(IT),(YAN2NF(IT,JF),JF=1,MJF),YMAN2N(IT)
1400 2732 CONTINUE
1410 2742 CONTINUE
1420 2752 CONTINUE
1430 C CALCULATE THE RATIO OF TWO MATRIXES.
1440 2762 DO 2780 IT=1,MT
1450 DO 2790 JF=1,MJF
1460 IF (MAN2NF(IT,JF).NE.0.0) GO TO 2790
1470 IF (XAN2NF(IT,JF).EQ.0.0) XAN2NF(IT,JF)=1.0
1480 MAN2NF(IT,JF)=-1.0
1490 2790 MAN2NF(IT,JF)=XAN2NF(IT,JF)/MAN2NF(IT,JF)
1500 IF (MAN2N(IT).NE.0.0) GO TO 279
1510 IF (XMAN2N(IT).EQ.0.0) XMAN2N(IT)=1.0
1520 MAN2N(IT)=-1.0
1530 279 MAN2N(IT)=XMAN2N(IT)/MAN2N(IT)
1540 2780 CONTINUE
1550 C PRINT OUT THE RATIO MATRIX.
1560 WRITE(IP,1105) IP1F,IP2,(TITLE(I),I=1,18)
1570 DO 2791 IT=1,MT
1580 2791 WRITE(IP,1272) TIME(IT),(MAN2NF(IT,JF),JF=1,MJF),MAN2N(IT)
1590 GO TO 1
1600 2720 READ(IP1,1273)
1610 GO TO 2730
1620 1270 FORMAT(7(255(/)),102(/))
1630 1271 FORMAT(1X,18A4,176,'CASE',I4)
1640 1272 FORMAT(F12.0,1P5E10.2)
1650 1273 FORMAT(55(/))

```

Table J-2 (f). File DDSENDY (i.e., JCL)

```
1000 9990 STOP
1010      END
1020 //GO.FT48F001 DD UNIT=TAPE9,DSN=EPAJOB,VOL=SER=PE1737,
1030 // LABEL=(1,SL),DCB=(RECFM=FBA,LRECL=133,BLKSIZE=1330),
1040 // DISP=(OLD,PASS)
1080 //GO.FT55F001 DD UNIT=TAPE9,DSN=EPAJOB,VOL=SER=PE1737,
1090 // LABEL=(3,SL),DCB=(RECFM=FBA,LRECL=133,BLKSIZE=1330),
1100 // DISP=(OLD,PASS)
1110 //GO.SYSIN DD *
```

PART 2

AMRAW-B USERS' GUIDE

CHAPTER 6. SUMMARY

CHAPTER 7. INPUT/OUTPUT DESCRIPTION

CHAPTER 8. PROGRAM OPTIONS

CHAPTER 9. ERROR MESSAGES

APPENDICES: K THROUGH T

Page Intentionally Blank

CHAPTER 6

SUMMARY

A. PROGRAM SUMMARY

Title: AMRAW-B; Assessment Method for Radioactive Waste (Second Part).

Abstract: AMRAW-B performs a sequence of calculations for an inventory of radioactive wastes, evaluating health effects and economic costs resulting from dose to man calculated by AMRAW-A.

Effective Date: May, 1978.

Programmer: The University of New Mexico staff.

Computer: IBM 360/67.

Language: Fortran IV.

Core Memory Requirement: 124 k bytes.

Execution Time (CP sec): 270.

Auxiliary Hardware Requirements: Disk, Tape, Line Printer.

B. PURPOSE

AMRAW-B, the second part of the Radioactive Waste Management Systems Model, picks up the population dose rates calculated in AMRAW-A and calculates corresponding estimates of health effects and economic costs of these health effects (see Fig. 1-2). These calculations consider the populations in each geographic zone, incidence rates of health effects per unit of radiation dose to a given body organ, and costs based upon the value of small changes in risk.

C. METHOD

The AMRAW Code is written in Fortran IV language. The two parts of the code are: 1) AMRAW-A which contains the Source Term, the Release Model, and the Environmental Model, and 2) AMRAW-B which contains the Economics Model. They are being run separately but may be joined if desired. There is an advantage to running the first part independently to determine sensitivity of environmental concentrations and dose rates to variations in input. Similarly, there is an advantage to running the economic model independently to study the response to varied economic parameters.

The flow of AMRAW-B calculations is best described first using the sequence indicated by Fig. 1-2: 1) determine rate of occurrence of health effects, and 2) perform corresponding damage calculations in economic units. An altered sequence of the actual calculations within AMRAW-B is then described. The matrix of local dose rates from AMRAW-A, to individuals in each zone from each radionuclide to each body site (organ) during each time increment, multiplied by the population of each zone and then multiplied by the set of health effect incidence rates for each body site, obtains the health effect incidence rates in each zone. Similarly, nonspecific dose rates from AMRAW-A (dose to a nonspecific population) multiplied by health effect incidence rates obtains health effect incidence rates corresponding to nonspecific dose. As actually calculated within AMRAW-B, the input incidence rates of health effects, deaths/ 10^6 man-rem, are first converted to \$/man-rem by multiplying by $\$260,000/10^6$ (the value $\$260,000$ is the present input for cost of increased level of risk, VOL). Damage rates, \$/y, in each zone (and the nonspecific category), are calculated by multiplying together: dose rates, populations, and \$/man-rem. The damage rates, \$/y, are accumulated over nuclides and organs in each zone (and nonspecific) versus time. Total damage rates are also accumulated over zones, organs, and times for each nuclide. Damages during each time increment, \$, are then obtained by multiplying rates by the length of each time increment and accumulated over the total time range. Finally, the number of deaths (health effects) during each time increment are obtained by dividing the damages in dollars by $\$260,000$. Results are obtained for both high

and low population projections.

The present dimensioning of AMRAW-B is as follows:

- 1) Radionuclides: 25.
- 2) Geographic Zones: 8 (the nonspecific category is treated as a ninth zone in calculations).
- 3) Human Organs: 8; typically, one of these is total body.
- 4) Time Increments: 50.

AMRAW-B runs with 124 k bytes of core storage, 125 tracks (900 k bytes) of disk storage for input data, 10 cylinders (200 tracks or 1440 bytes) of disk storage for intermediate storage, and requires 270 seconds of CPU time in the UNM IBM 360/67 computer. Input data from the major data matrices can be furnished from tape instead of from disk if preferred.

CHAPTER 7

INPUT/OUTPUT DESCRIPTION

Input for AMRAW-B is by an 80 column card data deck. There are 15 card types. As implemented at UNM, the input deck is read from 3 files in disk and/or tape storage. No additional inputs are required. The 3 input data files are as follows:

- 1) AMB. This file provides economic model control and conversion data, including discount rate (zero presently used), cost assigned to a death, the numbers of times, zones, radionuclides, and organs involved, incidence rates of health effects by body site or organ, high and low population projections by zone, and designation of nuclide decay group.
- 2) AMLE. This file provides values of time at the end of each time increment, names of each radionuclide, and the mass of each radionuclide (in grams) in the repository inventory at each time.
- 3) ECONxx (xx is case number). This is the large output matrix, MAN1, of dose rates from AMRAW-A, restructured for AMRAW-B input.

Radionuclide mass versus time is used within AMRAW-B at this time only for calculation of marginal damages (\$/gram) by decay group, based upon the accumulated inventory at the time repository operations cease. The full nuclide matrix provides for possible additions to AMRAW-B for allocation of damages to elements in the waste. The dose rate matrix, MAN1, from AMRAW-A is arranged as shown in Table 7-1. With the present dimensioning used, the dose rates are presented in 225 separate tables (9 zones x 25 nuclides). For input to AMRAW-B, this is processed through an auxiliary program, COMPRESS, to strip away headings and the time column, producing a data file with 11,250 lines (from 225 tables x 50 lines each). Each line has dose rate values for 8 organs resulting in 90,000 data items.

Card input is described in the following section. Output is described in Section 7.B.

Table 7-1. Arrangement of AMRAW-A Dose Rate Output:
Local Dose Rate by Zone and Nonspecific
Dose Rate

Zone 1^a

Nuclide 1

Time Increment 1: Organ 1, Organ 2, ... Organ 8.^b

2: Organ 1, Organ 2, ... Organ 8.

(repeat for other time increments)

⋮

50: Organ 1, Organ 2, ... Organ 8.

Nuclide 2

(repeat for other nuclides)

⋮

Nuclide 25

Zone 2

(repeat for other zones)

⋮

Zone 8

Nonspecific (handled as Zone 9).^c

^aLocal dose rates are mrem/y.

^bOrgan refers to each body site for which dose rate is calculated.

^cNonspecific dose rates are man-rem/y.

A. CARD INPUT SPECIFICATIONS

1. Data Deck Setup. Descriptions and number required of each card type are given in section 2 which follows. The sequence of the data deck, beginning with the first or front card is listed below:

<u>File</u>	<u>Card Type</u>	<u>Items</u>
AMB	1	TITLE
	2	RATE
	3	VOL
	4	NT
	5	MZ
	6	NK
	7	NIHT
	8	SITE, DPY
	9	REG, POPH, POPL
	10	NG
	11	K, IKK
AM1E	12	TIME
ECONxx	13	NUCNAM, X
	14	X
	15	MAN1

2. Description of Card Input. Input data is grouped into 3 sequentially read data files: AMB, AM1E, and ECONxx (where xx denotes the case number from which this file is extracted).

The largest matrix of data is for MAN1 (card type 12). This is the dose rate output from AMRAW-A as selected and restructured by auxiliary program COMPRESS for use as AMRAW-B input. As presently dimensioned, this file can consist of as many as 11,250 cards. Because of its size, this file is handled via tape and/or disk storage.

A list of each card type in input sequence, the necessary card format in each instance, the number of each card type required (one card unless stated otherwise), the data items and their descriptions, plus

other explanatory notes are presented below.

Card

<u>Type</u>	<u>Format and Items</u>	<u>Description</u>
The following card types 1 through 11 comprise data file AMB, economic model control and conversion data.		
1.	FORMAT (10A4) TITLE	Title of case, up to 40 characters.
2.	FORMAT (15X, F10.0) RATE	Discount rate, expressed as decimal.
3.	FORMAT (15X, F10.0) VOL	Cost of increased level of risk.
4.	FORMAT (20X, I5) NT	Number of times.
5.	FORMAT (20X, I5) MZ	Number of geographic zones.
6.	FORMAT (20X, I5) NK	Number of nuclides.
7.	FORMAT (20X, I5) NIHT	Number of organs (body sites).
8.	FORMAT (5A4, F5.0) SITE DPY	1 card for each of NIHT organs. Name of organ (body site), up to 20 characters. Health effect incidence rate, cases per 10^6 man-rem.
9.	FORMAT (A4, 1X, 2F10.0) REG POPH POPL	1 card for each of MZ zones. Name of zone up to 4 characters High population projection. Low population projection.
10.	FORMAT (3X, 25I3) NG	Number of nuclide decay groups.
11.	FORMAT (3X, 25I3) K IKK(J)	1 card for each of NG groups. Number of nuclides in group. Subscript identity of each of K nuclides in group.

The following card types 12 through 14 comprise data file AMLE which furnishes values of time to be calculated and the nuclide inventory versus time.

<u>Card Type</u>	<u>Format and Items</u>	<u>Description</u>
12.	FORMAT (1P8E10.2) TIME(I)	1 card for each 8 times of NT total. Time in years for each subscripted value of TIME.

One set of the following card types 10 and 11 is required for nuclide K of NK total (e.g., for 25 nuclides and 50 time, $25 \times 8 = 200$ cards, are required).

13.	FORMAT (A8, 2X, 7E10.2) NUCNAM (K) X(K, IT)	1 card in each nuclide set. Abbreviated name of nuclide (e.g., SR 90 or AM 241M). Inventory quantities for first 7 times IT.
14.	FORMAT (10X, 7E10.2) X(K, IT)	1 card for each 7 times, 8 through NT, in each nuclide group. Inventory quantities for times 8 through NT. This card bypasses rereading NUCNAM, which may be placed on each card along with card sequence number in the 10X field.

The following card type 15 comprises data file ECONxx (xx represents the case number from which the file is extracted). This file is the large matrix which is a portion of AMRAW-A output, providing calculated dose rates.

15.	FORMAT (1P8E10.2) MAN1 (IT, IH)	One set of cards for each Zone IZ of MZ + 1 total (the last "zone" is reserved for "nonspecific dose") (maximum MZ + 1 is 9) within each set is a subset of cards for each nuclide K of NK total (25 maximum), one card for each time 1 of NT total (50 maximum), (e.g., for 9 zones, including the nonspecific category, 25 nuclides, and 50 times, 9×25 $\times 50 = 11,250$ cards, are required). Dose rate to each organ IH of NIHT total (8 maximum), at time IT (in Zone IZ via nuclide K).
-----	--	---

A sample coding form illustrating the first card of each type is given in Appendix M. More complete sample input is given in Appendix P.

B. OUTPUT DESCRIPTION

AMRAW-B requires two output mediums: disk and line printer.

1. Disk. Intermediate temporary storage of calculated values for each nuclide is on disk. Output can be to disk and/or line printer.

2. Line Printer. The line printer must be capable of 132 characters per line.

3. Output Tables. Output from AMRAW-B is the series of tables listed in the directory in Table 7-2. Table 1 as numbered by AMRAW-B provides average damage rates in each zone, for nonspecific, and the total, versus time. Subtables are for high and low population projections, respectively. Table 2 is a series of tables, one for each time increment giving average damage rates: total for zones, nonspecific, and total by nuclide, for high and low population. Table 3 presents the total discounted present value of damages over the entire time range for each nuclide, subtotals for each decay group and the overall total, for high and low populations. This table also includes marginal damages, by decay group and total, based upon masses in repository inventory at the beginning of the terminal storage phase. Table 4 presents total expected deaths per time interval in each zone, for nonspecific, and the total, versus time. Similarly, Table 5 presents total damages in dollars per time interval. Subtables of Tables 4 and 5 are for high and low populations. Sample output is given in Appendix P.

Table 7-2. Directory of AMRAW-B Output Tables

Table No.	Title or Description	Nuclides	Units				Components				Population	
			\$/y	\$/ Δt^a	\$/ 10^6 y	Deaths/ Δt^a	Each Zone	Total of zones	Non-specific	Total	High	Low
	Output listing of selected AMRAW-B input											
1-1	Zonal and Total Damages for High Population Projection, \$/y.	Total	X				X	X	X	X	X	
1-2	Zonal and Total Damages for Low Population Projection, \$/y.	Total	X				X	X	X	X		X
2	One table for each time interval calculated: damages by nuclide, \$/y.	25 (1 table for each time interval-43)	X					X	X	X	X	X
3	Discounted Present Values, \$, and \$/g.	25			X					X	X	X
4-1	High Population Scenario: Number of Deaths Per Time Interval.	Total				X	X	X	X	X	X	
4-2	Low Population Scenario: Number of Deaths Per Time Interval.	Total				X	X	X	X	X		X
5-1	Total Undiscounted Damages for Each Zone for Each Time Interval-High Population, \$.	Total		X			X	X	X	X	X	
5-2	Total Undiscounted Damages for Each Zone for Each Time Interval-Low Population, \$.	Total		X			X	X	X	X		X

^a Δt represents the length of time interval calculated.

Page Intentionally Blank

CHAPTER 8

PROGRAM OPTIONS

The major class of options is concerned with design of the application. The number of nuclides, geographic zones, times, release scenarios, and environmental pathways may be varied in AMRAW-A within the range of dimensioning and carry over into the AMRAW-B calculations.

There are no options built into AMRAW-B for alternate calculation sequences. There is an option to print or suppress printing of output Table 2. This table consists of 1 page for each time calculated (see Table 2-2 for description). Setting ITB3 = 1 requests printing of output Table 2; setting ITB3 = 0 suppresses printing. Write statements are provided (before and after Format statement 3806) for outputting the large MAN1 input matrix from file ECONxx. The write statements are suppressed by labeling as comment statements. Removal of the "C" from the two lines results in output.

The input/output mediums are specified in statements in the main program which assign values for the variables IN, IP, and IS appropriate to the system being used:

- IN specifies an input medium, normally the card reader (at UNM, this is 5).
- IP specifies the output medium for the code; this is normally the line printer but it may be set to disk or tape file if preferred, along with appropriate JCL (at UNM, line printer is 6).
- IS specifies an input medium with large storage, used for file ECONxx. This can be disk or tape files; the value of IS can be any allowable and free integer as supported by appropriate JCL (at UNM, this may be 1, 3, or 4; 2 is used in AMRAW-B for system disk storage of intermediate calculations).

Page Intentionally Blank

CHAPTER 9

ERROR MESSAGES

AMRAW-B in the present version does not generate error messages. No such addition is planned at this point in time. If the computer code fails in a run, it is suggested that the input data formats be checked. Extensive comment statements have been placed in the program for assisting the user to isolate any problems.

Page Intentionally Blank

APPENDIX K

BACKGROUND MATERIAL

The basic structure of the AMRAW model and computer code was developed at UNM between 1972 and 1974 as part of the S. Logan Ph.D. dissertation: "A Technology Assessment Methodology Applied to High-Level Radioactive Waste Management," The University of New Mexico, 1974. Additional development proceeded with support from the Sandia Laboratories University Research Program and from the Energy Resources Board of the State of New Mexico. Completion of the model and code was done under EPA Contract No. 68-01-3256 beginning in August, 1975.

Page Intentionally Blank

APPENDIX L

SAMPLE RUN REQUEST

AMRAW-B RUN REQUEST	
Requested By:	_____
Phone: _____	Date: _____
Number of Seconds: _____	No. of Output Lines: _____
Number of Copies Requested: _____	
Special Form? _____	If so, form no. _____
Input Data On: Disk _____	Disk Name: _____
	DSN: _____
Card _____	Tape _____
	Tape Name: _____
Label: _____	DSN: _____

<u>O F F I C E U S E O N L Y</u>	
Date Received:	_____
Date Submitted:	_____
Date Returned:	_____
Initials:	_____

Page Intentionally Blank

APPENDIX M

SAMPLE CODING FORM

Table M-1 presents a sample coding form for AMRAW-B input data illustrating proper formats for each of the 15 card types. The data shown is from the base case for terminal storage, reported elsewhere. Only the first card of each card type is illustrated. Card types 1 through 11 comprise data file AMB, card types 12 through 14 comprise data file AM1E and card type 15 represents the large dose rate output file from AMRAW-A: ECONxx. For 9 zones, including one "zone" allocated to non-specific dose rates, 25 nuclides, and 50 times, 11,250 cards of card type 15 are required. Because of the large size of the last file, it is obtained from AMRAW-A and placed on tape or disk by machine processing. File AM1E is obtained from an AMRAW-A input data file via machine processing. Normally, only file AMB requires key punching or typing on a terminal.

130

[illegible]

APPENDIX N

JOB PROCESSING INSTRUCTIONS

1. Prepare jobcard for computer run using run request as follows:

Job name - 8 alphanumeric characters.

Time parameter - number of seconds estimated.

Lines parameter - number of lines (in thousands) estimated.

Forms parameter - form number from request.

Copies parameter - number of copies requested.

2. Input medium:

Card - keypunch as necessary and place in appropriate section of deck.

Disk - modify the data definition statement GO.FT01F001 DD card to reflect parameters required by the system.


Tape - modify the data definition statement GO.FT02F001 DD card to reflect parameters required by the system.

3. Submit job and note date submitted.
4. Return job to requester and note date returned.

Page Intentionally Blank

APPENDIX 0

OPERATING DECK SETUP



Page Intentionally Blank

APPENDIX P

SAMPLE INPUT AND OUTPUT

AMRAW-B Sample Input

Sample input data for the base case for terminal storage phase, Case No. 48, are presented.

1. Table P-1. Data file AMB.^a

2. Table P-2. Data file AMLE.^a

The full file for 50 times and 25 nuclides is 207 lines long; the beginning and end of the file is shown here.

3. Table P-3. Data file ECON48.

This is the file with designation of form ECONxx for Case No. 48. The full file for 50 times, 25 nuclides, and 8 zones is 11,250 lines long; the beginning and end of the file is shown here, as obtained by processing AMRAW-A output through the auxiliary program, COMPRESS.

4. Tables P-4 and P-5. Sample of AMRAW-A output.

These tables are a sample of AMRAW-A output prior to processing by COMPRESS to obtain the AMRAW-B input file illustrated in Table P-3.

Table P-4. Average Annual Local Dose to Individual in Zone 1, from Ra-226, in Millirems/Year.

Table P-5. Average Annual Nonspecific Dose to Population from Ra-226, in Man-rems/Year.

^aThe left hand line number column in these tables is computer-furnished for these listings and is not part of the data files.

Table P-1. Data File AMB

1234567890123456789012345678901234567890

3980	ECON48 - 50 PERIODS - NEW BODY COEFF.	
3990	RATE	0.0
4000	VOL	260000.0
4010	NT	50
4020	MZ	8
4030	NK	25
4040	NIHT	8
4050	TOTAL BODY (REMAIN.)	85
4060	GI TRACT	34
4070	GONAD(GENETIC)	200
4080	LIVER	0
4090	LUNG	44
4100	MARROW(LUKEMIA)	32
4110	BONE	7
4120	THYROID	0
4130	REPO	101 101
4140	EDDY	17200 6100
4150	REDB	213000 53600
4160	MIDO	784000 224000
4170	WTEX	217000 57900
4180	LEA	245000 74000
4190	CHAV	253000 67800
4200	REGB	155000 54900
4210	NG	11
4220	G01	2 19 25
4230	G02	5 11 13 15 20 21
4240	G03	6 10 12 14 17 22 24
4250	G04	3 16 18 23
4260	G05	1 1
4270	G06	2 2 3
4280	G07	2 4 5
4290	G08	1 6
4300	G09	1 7
4310	G10	1 8
4320	G11	1 9

Table P-2. Data File AMLE

1050		0.00E+00	5.00E+00	1.00E+01	1.50E+01	2.00E+01	2.50E+01	3.00E+01	4.00E+01
1060		5.00E+01	6.00E+01	7.00E+01	8.00E+01	9.00E+01	1.00E+02	2.00E+02	3.00E+02
1070		4.00E+02	5.00E+02	6.00E+02	7.00E+02	8.00E+02	9.00E+02	1.00E+03	2.00E+03
1080		3.00E+03	4.00E+03	5.00E+03	6.00E+03	7.00E+03	8.00E+03	9.00E+03	1.00E+04
1090		2.00E+04	3.00E+04	4.00E+04	5.00E+04	6.00E+04	7.00E+04	8.00E+04	9.00E+04
1100		1.00E+05	2.00E+05	3.00E+05	4.00E+05	5.00E+05	6.00E+05	7.00E+05	8.00E+05
1110		9.00E+05	1.00E+06						
1170	C-14 1	0.0		6.14D+01	1.28D+03	4.07D+03	9.99D+03	2.17D+04	4.04D+04
1180	C-14 2	4.04D+04	4.04D+04	4.03D+04	4.02D+04	4.02D+04	4.02D+04	4.01D+04	4.01D+04
1190	C-14 3	3.96D+04	3.91D+04	3.87D+04	3.82D+04	3.77D+04	3.73D+04	3.68D+04	
1200	C-14 4	3.64D+04	3.59D+04	3.19D+04	2.82D+04	2.50D+04	2.21D+04	1.95D+04	
1210	C-14 5	1.73D+04	1.54D+04	1.36D+04	1.21D+04	3.75D+03	1.07D+03	3.03D+02	
1220	C-14 6	8.62D+01	2.49D+01	7.38D+00	2.24D+00	7.02D-01	2.26D-01	2.28D-06	
1230	C-14 7	7.03D-12	1.50D-17	3.72D-23	0.0	0.0	0.0	0.0	
1240	C-14 8	0.0							
1250	SR-90 1	5.30D+05	3.89D+06	1.06D+07	2.24D+07	4.22D+07	7.11D+07	6.28D+07	
1260	SR-90 2	4.91D+07	3.90D+07	3.09D+07	2.43D+07	1.91D+07	1.48D+07	1.15D+07	
1270	SR-90 3	8.87D+05	7.72D+04	7.82D+03	7.85D+02	7.21D+01	6.10D+00	4.83D-01	
1280	SR-90 4	3.65D-02	2.68D-03	1.62D-14	8.95D-25	0.0	0.0	0.0	
1290	SR-90 5	0.0	0.0	0.0	0.0	0.0	0.0	0.0	
1300	SR-90 6	0.0	0.0	0.0	0.0	0.0	0.0	0.0	
1310	SR-90 7	0.0	0.0	0.0	0.0	0.0	0.0	0.0	
1320	SR-90 8	0.0							
1330	Y-90 1	1.38D+02	1.01D+03	2.75D+03	5.82D+03	1.10D+04	1.85D+04	1.63D+04	
1340	Y-90 2	1.28D+04	1.02D+04	8.06D+03	6.34D+03	4.95D+03	3.86D+03	2.99D+03	
1350	Y-90 3	2.30D+02	2.00D+01	2.03D+00	2.04D-01	1.87D-02	1.58D-03	1.25D-04	
1360	Y-90 4	9.48D-06	6.96D-07	4.20D-18	0.0	0.0	0.0	0.0	
1370	Y-90 5	0.0	0.0	0.0	0.0	0.0	0.0	0.0	
1380	Y-90 6	0.0	0.0	0.0	0.0	0.0	0.0	0.0	
1390	Y-90 7	0.0	0.0	0.0	0.0	0.0	0.0	0.0	
1400	Y-90 8	0.0							
1410	ZR-93 1	8.44D+05	6.38D+06	1.82D+07	4.00D+07	7.72D+07	1.33D+08	1.33D+08	
1420	ZR-93 2	1.33D+08	1.33D+08	1.33D+08	1.33D+08	1.33D+08	1.33D+08	1.33D+08	
1430	ZR-93 3	1.33D+08	1.33D+08	1.33D+08	1.33D+08	1.33D+08	1.33D+08	1.33D+08	
1440	ZR-93 4	1.33D+08	1.33D+08	1.33D+08	1.33D+08	1.33D+08	1.33D+08	1.33D+08	
1450	ZR-93 5	1.32D+08	1.32D+08	1.32D+08	1.32D+08	1.31D+08	1.31D+08	1.30D+08	
1460	ZR-93 6	1.30D+08	1.29D+08	1.29D+08	1.28D+08	1.28D+08	1.27D+08	1.22D+08	
<hr/>									
2870	AM-242M 3	5.95D+05	5.69D+05	5.43D+05	5.19D+05	4.95D+05	4.73D+05	4.52D+05	
2880	AM-242M 4	2.90D+05	1.83D+05	1.14D+05	7.10D+04	4.44D+04	2.80D+04	1.78D+04	
2890	AM-242M 5	1.14D+04	7.40D+03	9.66D+01	8.24D-01	6.08D-03	4.71D-05	4.14D-07	
2900	AM-242M 6	4.22D-09	5.02D-11	6.92D-13	1.10D-14	0.0	0.0	0.0	
2910	AM-242M 7	0.0	0.0	0.0	0.0	0.0	0.0	0.0	
2920	AM-242M 8	0.0							
2930	AM-243 1	1.08D+05	1.17D+06	9.45D+06	2.55D+07	4.98D+07	7.25D+07	7.25D+07	
2940	AM-243 2	7.24D+07	7.23D+07	7.23D+07	7.22D+07	7.21D+07	7.21D+07	7.20D+07	
2950	AM-243 3	7.14D+07	7.07D+07	7.00D+07	6.94D+07	6.87D+07	6.81D+07	6.75D+07	
2960	AM-243 4	6.69D+07	6.64D+07	6.10D+07	5.54D+07	5.01D+07	4.54D+07	4.13D+07	
2970	AM-243 5	3.77D+07	3.45D+07	3.18D+07	2.94D+07	1.29D+07	4.80D+06	1.66D+06	
2980	AM-243 6	5.92D+05	2.25D+05	9.11D+04	3.93D+04	1.79D+04	8.56D+03	4.87D+01	
2990	AM-243 7	3.75D+00	1.08D+00	6.45D-01	5.98D-01	7.39D-01	1.11D+00	1.91D+00	
3000	AM-243 8	3.64D+00							
3010	CM-242 1	3.05D+00	3.09D+01	2.16D+02	5.61D+02	1.07D+03	1.58D+03	1.50D+03	
3020	CM-242 2	1.43D+03	1.37D+03	1.31D+03	1.25D+03	1.19D+03	1.14D+03	1.09D+03	
3030	CM-242 3	6.98D+02	4.40D+02	2.74D+02	1.71D+02	1.07D+02	6.73D+01	4.28D+01	
3040	CM-242 4	2.75D+01	1.78D+01	2.33D-01	1.99D-03	1.47D-05	1.14D-07	1.00D-09	
3050	CM-242 5	1.02D-11	1.21D-13	1.67D-15	2.66D-17	1.16D-32	0.0	0.0	
3060	CM-242 6	0.0	0.0	0.0	0.0	0.0	0.0	0.0	
3070	CM-242 7	0.0	0.0	0.0	0.0	0.0	0.0	0.0	
3080	CM-242 8	0.0							
3090	CM-244 1	2.66D+04	3.76D+05	3.92D+06	1.03D+07	1.91D+07	2.47D+07	2.04D+07	
3100	CM-244 2	1.39D+07	9.73D+06	6.79D+06	4.69D+06	3.21D+06	2.18D+06	1.47D+06	
3110	CM-244 3	2.75D+04	6.19D+02	1.76D+01	4.97D-01	1.22D-02	2.63D-04	5.14D-06	
3120	CM-244 4	9.33D-08	1.62D-09	0.0	0.0	0.0	0.0	0.0	
3130	CM-244 5	0.0	0.0	0.0	0.0	0.0	0.0	0.0	
3140	CM-244 6	0.0	0.0	0.0	0.0	0.0	0.0	0.0	
3150	CM-244 7	0.0	0.0	0.0	0.0	0.0	0.0	0.0	
3160	CM-244 8	0.0							

0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
2.40E-12	3.03E-11	8.05E-13	0.0	3.37E-10	1.28E-11	1.28E-11	0.0
3.41E-12	4.29E-11	1.14E-12	0.0	4.77E-10	1.82E-11	1.82E-11	0.0
4.41E-12	5.55E-11	1.48E-12	0.0	6.17E-10	2.35E-11	2.35E-11	0.0
5.40E-12	6.80E-11	1.81E-12	0.0	7.56E-10	2.88E-11	2.88E-11	0.0
6.39E-12	8.05E-11	2.14E-12	0.0	8.95E-10	3.40E-11	3.40E-11	0.0
7.38E-12	9.29E-11	2.47E-12	0.0	1.03E-09	3.93E-11	3.93E-11	0.0
8.36E-12	1.05E-10	2.80E-12	0.0	1.17E-09	4.46E-11	4.46E-11	0.0
1.82E-11	2.29E-10	6.10E-12	0.0	2.55E-09	9.71E-11	9.71E-11	0.0
2.77E-11	3.49E-10	9.29E-12	0.0	3.89E-09	1.48E-10	1.48E-10	0.0
3.70E-11	4.66E-10	1.24E-11	0.0	5.19E-09	1.97E-10	1.97E-10	0.0
4.61E-11	5.80E-10	1.54E-11	0.0	6.46E-09	2.46E-10	2.46E-10	0.0
5.48E-11	6.90E-10	1.84E-11	0.0	7.68E-09	2.92E-10	2.92E-10	0.0
6.34E-11	7.98E-10	2.12E-11	0.0	8.85E-09	3.38E-10	3.38E-10	0.0
7.17E-11	9.03E-10	2.40E-11	0.0	1.00E-08	3.82E-10	3.82E-10	0.0
7.98E-11	1.00E-09	2.67E-11	0.0	1.12E-08	4.25E-10	4.25E-10	0.0
8.76E-11	1.10E-09	2.93E-11	0.0	1.23E-08	4.67E-10	4.67E-10	0.0
1.65E-10	2.08E-09	5.54E-11	0.0	2.32E-08	8.82E-10	8.82E-10	0.0
2.18E-10	2.75E-09	7.30E-11	0.0	3.06E-08	1.16E-09	1.16E-09	0.0
2.55E-10	3.21E-09	8.53E-11	0.0	3.57E-08	1.36E-09	1.36E-09	0.0
2.79E-10	3.51E-09	9.35E-11	0.0	3.91E-08	1.49E-09	1.49E-09	0.0
2.93E-10	3.69E-09	9.80E-11	0.0	4.10E-08	1.56E-09	1.56E-09	0.0
2.99E-10	3.76E-09	1.00E-10	0.0	4.19E-08	1.59E-09	1.59E-09	0.0
3.00E-10	3.78E-09	1.01E-10	0.0	4.20E-08	1.60E-09	1.60E-09	0.0
2.96E-10	3.73E-09	9.92E-11	0.0	4.15E-08	1.58E-09	1.58E-09	0.0
2.88E-10	3.63E-09	9.66E-11	0.0	4.04E-08	1.54E-09	1.54E-09	0.0
1.54E-10	4.46E-09	1.19E-10	0.0	4.96E-08	1.89E-09	1.89E-09	0.0
1.35E-10	1.83E-09	4.87E-11	0.0	2.04E-08	7.75E-10	7.75E-10	0.0
5.00E-11	6.30E-10	1.67E-11	0.0	7.01E-09	2.67E-10	2.67E-10	0.0
1.61E-11	2.03E-10	5.39E-12	0.0	2.26E-09	8.58E-11	8.58E-11	0.0
5.03E-12	6.34E-11	1.69E-12	0.0	7.05E-10	2.68E-11	2.68E-11	0.0
1.56E-12	1.97E-11	5.24E-13	0.0	2.19E-10	8.33E-12	8.33E-12	0.0
4.90E-13	6.17E-12	1.64E-13	0.0	6.86E-11	2.61E-12	2.61E-12	0.0
1.56E-13	1.96E-12	5.21E-14	0.0	2.18E-11	8.30E-13	8.30E-13	0.0
5.06E-14	6.37E-13	1.69E-14	0.0	7.08E-12	2.69E-13	2.69E-13	0.0
3.16E-14	3.98E-13	1.06E-14	0.0	4.42E-12	1.68E-13	1.68E-13	0.0
3.16E-14	3.97E-13	1.06E-14	0.0	4.42E-12	1.68E-13	1.68E-13	0.0
9.72E-25	1.22E-23	3.25E-25	0.0	1.36E-22	5.18E-24	5.18E-24	

138

Table P-4. Sample of AMRAW-A Output

** AVERAGE ANNUAL LOCAL DOSE TO INDIVIDUAL, MANIL, IN MILLIREMS/YEAR

ZONE= 1... NUCLIDE= RA-226 K= 12

TIME	TOT BODY	GI TRACT	GONADS	LIVER	LUNGS	MARROW	BONE	THYROID
0.	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
5.	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
10.	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
15.	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
20.	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
25.	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
30.	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
40.	1.42E-13	6.24E-16	1.42E-13	5.72E-16	4.13E-13	1.68E-12	1.68E-12	7.25E-16
50.	2.43E-13	1.42E-15	2.44E-13	1.37E-15	7.05E-13	2.87E-12	2.87E-12	1.75E-15
60.	3.82E-13	2.53E-15	3.83E-13	2.49E-15	1.11E-12	4.51E-12	4.51E-12	3.17E-15
70.	5.68E-13	4.04E-15	5.69E-13	4.02E-15	1.65E-12	6.69E-12	6.69E-12	5.12E-15
80.	8.12E-13	6.04E-15	8.14E-13	6.05E-15	2.35E-12	9.56E-12	9.56E-12	7.71E-15
90.	1.12E-12	8.63E-15	1.13E-12	8.67E-15	3.25E-12	1.32E-11	1.32E-11	1.11E-14
100.	1.52E-12	1.19E-14	1.52E-12	1.20E-14	4.39E-12	1.78E-11	1.78E-11	1.53E-14
200.	9.15E-12	7.89E-14	9.18E-12	8.03E-14	2.65E-11	1.08E-10	1.08E-10	1.03E-13
300.	4.10E-11	3.63E-13	4.12E-11	3.70E-13	1.19E-10	4.82E-10	4.82E-10	4.73E-13
400.	1.20E-10	1.07E-12	1.20E-10	1.10E-12	3.46E-10	1.41E-09	1.41E-09	1.40E-12
500.	2.69E-10	2.43E-12	2.70E-10	2.48E-12	7.78E-10	3.16E-09	3.16E-09	3.17E-12
600.	5.14E-10	4.65E-12	5.15E-10	4.76E-12	1.49E-09	6.04E-09	6.04E-09	6.08E-12
700.	8.76E-10	7.97E-12	8.79E-10	8.15E-12	2.53E-09	1.03E-08	1.03E-08	1.04E-11
800.	1.38E-09	1.25E-11	1.38E-09	1.28E-11	3.98E-09	1.62E-08	1.62E-08	1.64E-11
900.	2.03E-09	1.86E-11	2.04E-09	1.90E-11	5.88E-09	2.39E-08	2.39E-08	2.43E-11
1000.	2.87E-09	2.63E-11	2.88E-09	2.69E-11	8.31E-09	3.38E-08	3.38E-08	3.43E-11
2000.	1.61E-08	1.48E-10	1.62E-08	1.52E-10	4.66E-08	1.89E-07	1.89E-07	1.94E-10
3000.	5.88E-08	5.42E-10	5.90E-08	5.55E-10	1.70E-07	6.91E-07	6.91E-07	7.09E-10
4000.	1.37E-07	1.26E-09	1.37E-07	1.29E-09	3.95E-07	1.60E-06	1.60E-06	1.65E-09
5000.	2.52E-07	2.32E-09	2.52E-07	2.38E-09	7.27E-07	2.96E-06	2.96E-06	3.04E-09
6000.	4.04E-07	3.74E-09	4.06E-07	3.83E-09	1.17E-06	4.75E-06	4.75E-06	4.89E-09
7000.	5.94E-07	5.49E-09	5.96E-07	5.62E-09	1.72E-06	6.98E-06	6.98E-06	7.18E-09
8000.	8.19E-07	7.57E-09	8.21E-07	7.75E-09	2.37E-06	9.62E-06	9.62E-06	9.90E-09
9000.	1.08E-06	9.98E-09	1.08E-06	1.02E-08	3.12E-06	1.27E-05	1.27E-05	1.31E-08
10000.	1.38E-06	1.27E-08	1.38E-06	1.30E-08	3.98E-06	1.62E-05	1.62E-05	1.67E-08
20000.	4.85E-06	4.49E-08	4.87E-06	4.60E-08	1.40E-05	5.70E-05	5.70E-05	5.87E-08
30000.	1.15E-05	1.06E-07	1.15E-05	1.09E-07	3.32E-05	1.35E-04	1.35E-04	1.39E-07
40000.	1.91E-05	1.77E-07	1.92E-05	1.81E-07	5.52E-05	2.24E-04	2.24E-04	2.31E-07
50000.	2.66E-05	2.46E-07	2.67E-05	2.52E-07	7.69E-05	3.13E-04	3.13E-04	3.22E-07
60000.	3.36E-05	3.11E-07	3.37E-05	3.19E-07	9.72E-05	3.95E-04	3.95E-04	4.07E-07
70000.	4.01E-05	3.71E-07	4.03E-05	3.80E-07	1.16E-04	4.71E-04	4.71E-04	4.86E-07
80000.	4.59E-05	4.25E-07	4.60E-05	4.35E-07	1.33E-04	5.39E-04	5.39E-04	5.56E-07
90000.	5.09E-05	4.71E-07	5.11E-05	4.83E-07	1.47E-04	5.98E-04	5.98E-04	6.17E-07
100000.	5.53E-05	5.12E-07	5.55E-05	5.24E-07	1.60E-04	6.50E-04	6.50E-04	6.70E-07
200000.	1.59E-04	1.47E-06	1.59E-04	1.50E-06	4.58E-04	1.86E-03	1.86E-03	1.92E-06
300000.	1.62E-04	1.50E-06	1.62E-04	1.53E-06	4.68E-04	1.90E-03	1.90E-03	1.96E-06
400000.	1.40E-04	1.29E-06	1.40E-04	1.33E-06	4.04E-04	1.64E-03	1.64E-03	1.69E-06
500000.	1.13E-04	1.04E-06	1.13E-04	1.07E-06	3.26E-04	1.32E-03	1.32E-03	1.36E-06
600000.	8.80E-05	8.15E-07	8.83E-05	8.34E-07	2.54E-04	1.03E-03	1.03E-03	1.07E-06
700000.	6.80E-05	6.30E-07	6.82E-05	6.45E-07	1.97E-04	7.99E-04	7.99E-04	8.24E-07
800000.	5.25E-05	4.86E-07	5.27E-05	4.98E-07	1.52E-04	6.17E-04	6.17E-04	6.36E-07
900000.	4.05E-05	3.75E-07	4.06E-05	3.84E-07	1.17E-04	4.75E-04	4.75E-04	4.90E-07
1000000.	3.13E-05	2.89E-07	3.14E-05	2.97E-07	9.04E-05	3.67E-04	3.67E-04	3.79E-07

Table P-5. Sample of AMRAW-A Output

** AVERAGE ANNUAL NONSPECIFIC DOSE TO POPULATION, MAXIN, IN MANREMS/YEAR

NONSPECIFIC *** NUCLIDE= RA-226 K= 12

TIME	TET BODY	GI TRACT	GONADS	LIVER	LUNGS	MARPCW	BONE	THYROID
0.	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
5.	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
10.	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
15.	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
20.	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
25.	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
30.	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
40.	6.48E-10	1.35E-12	6.48E-10	1.20E-13	0.0	7.71E-09	7.71E-09	0.0
50.	1.00E-09	2.08E-12	1.00E-09	1.85E-13	0.0	1.19E-08	1.19E-08	0.0
60.	1.47E-09	3.07E-12	1.47E-09	2.73E-13	0.0	1.75E-08	1.75E-08	0.0
70.	2.09E-09	4.35E-12	2.09E-09	3.87E-13	0.0	2.49E-08	2.49E-08	0.0
80.	2.89E-09	6.01E-12	2.89E-09	5.34E-13	0.0	3.43E-08	3.43E-08	0.0
90.	3.89E-09	8.09E-12	3.89E-09	7.19E-13	0.0	4.63E-08	4.63E-08	0.0
100.	5.14E-09	1.07E-11	5.14E-09	9.51E-13	0.0	6.12E-08	6.12E-08	0.0
200.	3.03E-08	6.30E-11	3.03E-08	5.60E-12	0.0	3.60E-07	3.60E-07	0.0
300.	1.32E-07	2.75E-10	1.32E-07	2.44E-11	0.0	1.57E-06	1.57E-06	0.0
400.	3.77E-07	7.85E-10	3.77E-07	6.98E-11	0.0	4.49E-06	4.49E-06	0.0
500.	8.35E-07	1.74E-09	8.35E-07	1.54E-10	0.0	9.93E-06	9.93E-06	0.0
600.	1.57E-06	3.27E-09	1.57E-06	2.61E-10	0.0	1.87E-05	1.87E-05	0.0
700.	2.66E-06	5.54E-09	2.66E-06	4.92E-10	0.0	3.17E-05	3.17E-05	0.0
800.	4.15E-06	8.63E-09	4.15E-06	7.67E-10	0.0	4.94E-05	4.94E-05	0.0
900.	6.10E-06	1.27E-08	6.10E-06	1.13E-09	0.0	7.26E-05	7.26E-05	0.0
1000.	8.58E-06	1.78E-08	8.58E-06	1.59E-09	0.0	1.02E-04	1.02E-04	0.0
2000.	5.02E-05	1.04E-07	5.02E-05	9.28E-09	0.0	5.97E-04	5.97E-04	0.0
3000.	1.82E-04	3.79E-07	1.82E-04	3.37E-08	0.0	2.17E-03	2.17E-03	0.0
4000.	4.18E-04	8.69E-07	4.18E-04	7.73E-08	0.0	4.97E-03	4.97E-03	0.0
5000.	7.63E-04	1.59E-06	7.63E-04	1.41E-07	0.0	9.08E-03	9.08E-03	0.0
6000.	1.22E-03	2.53E-06	1.22E-03	2.25E-07	0.0	1.45E-02	1.45E-02	0.0
7000.	1.78E-03	3.69E-06	1.78E-03	3.23E-07	0.0	2.11E-02	2.11E-02	0.0
8000.	2.44E-03	5.07E-06	2.44E-03	4.51E-07	0.0	2.90E-02	2.90E-02	0.0
9000.	3.20E-03	6.66E-06	3.20E-03	5.92E-07	0.0	3.81E-02	3.81E-02	0.0
10000.	4.07E-03	8.47E-06	4.07E-03	7.53E-07	0.0	4.84E-02	4.84E-02	0.0
20000.	1.51E-02	3.14E-05	1.51E-02	2.79E-06	0.0	1.80E-01	1.80E-01	0.0
30000.	3.57E-02	7.43E-05	3.57E-02	6.60E-06	0.0	4.25E-01	4.25E-01	0.0
40000.	5.89E-02	1.23E-04	5.89E-02	1.09E-05	0.0	7.01E-01	7.01E-01	0.0
50000.	8.16E-02	1.70E-04	8.16E-02	1.51E-05	0.0	9.71E-01	9.71E-01	0.0
60000.	1.03E-01	2.14E-04	1.03E-01	1.90E-05	0.0	1.22E 00	1.22E 00	0.0
70000.	1.22E-01	2.54E-04	1.22E-01	2.26E-05	0.0	1.45E 00	1.45E 00	0.0
80000.	1.39E-01	2.89E-04	1.39E-01	2.57E-05	0.0	1.65E 00	1.65E 00	0.0
90000.	1.54E-01	3.21E-04	1.54E-01	2.85E-05	0.0	1.83E 00	1.83E 00	0.0
100000.	1.67E-01	3.48E-04	1.67E-01	3.09E-05	0.0	1.99E 00	1.99E 00	0.0
200000.	5.14E-01	1.07E-03	5.14E-01	9.50E-05	0.0	6.12E 00	6.12E 00	0.0
300000.	5.27E-01	1.10E-03	5.27E-01	9.75E-05	0.0	6.27E 00	6.27E 00	0.0
400000.	4.55E-01	9.47E-04	4.55E-01	8.42E-05	0.0	5.42E 00	5.42E 00	0.0
500000.	3.67E-01	7.64E-04	3.67E-01	6.79E-05	0.0	4.37E 00	4.37E 00	0.0
600000.	2.87E-01	5.96E-04	2.87E-01	5.39E-05	0.0	3.41E 00	3.41E 00	0.0
700000.	2.22E-01	4.61E-04	2.22E-01	4.19E-05	0.0	2.64E 00	2.64E 00	0.0
800000.	1.71E-01	3.56E-04	1.71E-01	3.16E-05	0.0	2.03E 00	2.03E 00	0.0
900000.	1.32E-01	2.74E-04	1.32E-01	2.44E-05	0.0	1.57E 00	1.57E 00	0.0
1000000.	1.02E-01	2.12E-04	1.02E-01	1.88E-05	0.0	1.21E 00	1.21E 00	0.0

AMRAW-B Sample Output

This section of Appendix P contains output for the full run base case for terminal storage phase, Case No. 48, and is based on the total of cancers and genetic effects.

1. Output Summary of Selected Input: Table P-6.
2. Annual Damage Rates, by Zone, Nonspecific and Total
 - a. Table P-7 (Output Table 1-1). Zonal and Total Damages for High Population Projection (\$/y).
 - b. Table P-8 (Output Table 1-2). Zonal and Total Damages for Low Population Projection (\$/y).
3. Annual Damage Rates, by Nuclide, Total All Zones, and Nonspecific
Table P-9. (Output Tables 2-9 (50 y), 2-14 (100 y)).
The full output of this type is a table for all times calculated after 30 y.
4. Discounted Present Values of Damage Costs by Nuclide, and Total, Integrated Over 10^6 Years
Table P-10 (Output Table F-10). Discounted Present Values (\$), Discount Rate = 0.00%.
5. Number of Deaths per Time Interval
 - a. Table P-11 (Output Table 4-1). High Population Scenario: Number of Deaths per Time Interval (#/Δy).
 - b. Table P-12 (Output Table 4-2). Low Population Scenario: Number of Deaths per Time Interval (#/Δy).
6. Total Undiscounted Damages per Time Interval, by Zone
 - a. Table P-13 (Output Table 5-1). Total Undiscounted Damages for Each Zone for Each Time Interval - High Population (\$/Δy).
 - b. Table P-14 (Output Table 5-2). Total Undiscounted Damages for Each Zone for Each Time Interval - Low Population (\$/Δy).

Appendix P

Table P-6. Output Summary of Selected Input

ECON43 - 50 PERIODS - NEW BODY CDEFF.

DISCOUNT RATE = 0.00 %

COST OF INCREASED LEVEL OF RISK OF DEATH = \$ 260000.

SITE OR TYPE	COST OF EXCESS RISK OF DEATH	
	DEATH /MIL. MAN-REM	\$/MAN-REM
TOTAL BODY (REMAIN.)	85.0	22.1
GI TRACT	34.0	8.8
GONAD(GENETIC)	200.0	52.0
LIVER	0.0	0.0
LUNG	44.0	11.4
MARROW(LUKEMIA)	32.0	8.3
BONE	7.0	1.8
THYROID	0.0	0.0

POPULATION PROJECTIONS		
ZONE	HIGH	LOW
1 REPO	101.	101.
2 EDDY	17200.	6100.
3 REDB	213000.	53600.
4 MIDJ	784000.	224000.
5 WTEX	217000.	57900.
6 LEA	245000.	74000.
7 CHAV	253000.	67800.
8 REG3	155000.	54900.

Appendix P

Table P-7. AMRAW-B Output Table 1-1

TABLE 1 - 1 : ZONAL AND TOTAL DAMAGES FOR HIGH POP. PROJECTION (\$/YR)

TIME	REPO	EDDY	REDB	MIDD	WTEX	LWA	CHAV	REGB	TOT.ZONE	NON-SPEC	TOTAL
0.	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
5.	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
10.	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
15.	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
20.	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
25.	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
30.	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
40.	1.61E-01	2.42E 00	1.58E 00	5.06E-01	2.34E-01	1.93E 00	2.28E 00	3.97E 00	1.31E 01	6.00E 01	7.30E 01
50.	1.70E-01	3.70E 00	2.32E 00	6.62E-01	3.03E-01	2.47E 00	3.41E 00	4.82E 00	1.79E 01	5.02E 01	6.80E 01
60.	1.69E-01	4.33E 00	2.65E 00	7.25E-01	3.31E-01	2.68E 00	3.91E 00	4.76E 00	1.96E 01	4.22E 01	6.17E 01
70.	1.62E-01	4.52E 00	2.71E 00	7.34E-01	3.34E-01	2.70E 00	4.00E 00	4.37E 00	1.95E 01	3.51E 01	5.46E 01
80.	1.52E-01	4.43E 00	2.60E 00	7.15E-01	3.25E-01	2.63E 00	3.83E 00	3.91E 00	1.86E 01	2.91E 01	4.77E 01
90.	1.43E-01	4.18E 00	2.40E 00	6.86E-01	3.12E-01	2.51E 00	3.53E 00	3.47E 00	1.72E 01	2.40E 01	4.12E 01
100.	1.35E-01	3.84E 00	2.17E 00	6.59E-01	2.99E-01	2.42E 00	3.17E 00	3.10E 00	1.58E 01	1.96E 01	3.54E 01
200.	1.98E-01	4.89E 00	2.43E 00	1.04E 00	4.71E-01	3.78E 00	3.41E 00	6.11E 00	2.23E 01	1.45E 01	3.68E 01
300.	1.74E-01	1.95E 00	1.28E 00	9.46E-01	4.28E-01	3.43E 00	1.61E 00	3.57E 00	1.35E 01	2.40E 00	1.59E 01
400.	1.89E-01	1.84E 00	1.36E 00	1.04E 00	4.71E-01	3.78E 00	1.70E 00	3.81E 00	1.42E 01	1.11E 00	1.53E 01
500.	2.04E-01	2.02E 00	1.51E 00	1.14E 00	5.14E-01	4.12E 00	1.89E 00	4.07E 00	1.55E 01	9.03E-01	1.64E 01
600.	2.19E-01	2.18E 00	1.63E 00	1.22E 00	5.52E-01	4.43E 00	2.05E 00	4.29E 00	1.66E 01	8.25E-01	1.74E 01
700.	2.31E-01	2.31E 00	1.73E 00	1.29E 00	5.84E-01	4.68E 00	2.16E 00	4.46E 00	1.74E 01	7.64E-01	1.82E 01
800.	2.40E-01	2.38E 00	1.79E 00	1.34E 00	6.07E-01	4.87E 00	2.23E 00	4.59E 00	1.81E 01	7.06E-01	1.88E 01
900.	2.46E-01	2.42E 00	1.82E 00	1.38E 00	6.25E-01	5.01E 00	2.27E 00	4.66E 00	1.84E 01	6.54E-01	1.91E 01
1000.	2.51E-01	2.44E 00	1.84E 00	1.41E 00	6.38E-01	5.12E 00	2.29E 00	4.71E 00	1.87E 01	6.07E-01	1.93E 01
2000.	3.95E-01	3.67E 00	2.80E 00	2.24E 00	1.01E 00	8.09E 00	3.44E 00	8.25E 00	2.99E 01	5.86E-01	3.05E 01
3000.	4.22E-01	3.60E 00	2.80E 00	2.40E 00	1.08E 00	8.66E 00	3.37E 00	8.53E 00	3.08E 01	4.89E-01	3.13E 01
4000.	4.91E-01	4.05E 00	3.18E 00	2.78E 00	1.26E 00	1.01E 01	3.80E 00	9.68E 00	3.51E 01	5.39E-01	3.59E 01
5000.	5.54E-01	4.51E 00	3.55E 00	3.15E 00	1.42E 00	1.14E 01	4.23E 00	1.07E 01	3.95E 01	6.23E-01	4.02E 01
6000.	6.07E-01	4.86E 00	3.86E 00	3.45E 00	1.56E 00	1.25E 01	4.57E 00	1.16E 01	4.30E 01	7.65E-01	4.37E 01
7000.	6.50E-01	5.17E 00	4.10E 00	3.69E 00	1.67E 00	1.34E 01	4.85E 00	1.23E 01	4.58E 01	1.25E 00	4.70E 01
8000.	6.85E-01	5.40E 00	4.29E 00	3.89E 00	1.76E 00	1.41E 01	5.05E 00	1.28E 01	4.80E 01	3.78E 00	5.18E 01
9000.	7.13E-01	5.62E 00	4.43E 00	4.05E 00	1.83E 00	1.47E 01	5.19E 00	1.33E 01	4.98E 01	1.18E 01	6.16E 01
10000.	7.36E-01	5.84E 00	4.55E 00	4.18E 00	1.89E 00	1.52E 01	5.31E 00	1.36E 01	5.13E 01	2.44E 01	7.57E 01
20000.	1.11E 00	6.41E 00	6.62E 00	6.27E 00	2.83E 00	2.27E 01	7.67E 00	2.22E 01	7.78E 01	3.61E 01	1.14E 02
30000.	8.54E-01	6.68E 00	4.71E 00	4.84E 00	2.19E 00	1.75E 01	5.29E 00	1.69E 01	5.90E 01	1.54E 02	2.13E 02
40000.	6.54E-01	5.44E 00	3.32E 00	3.71E 00	1.67E 00	1.34E 01	3.58E 00	1.85E 01	5.03E 01	3.03E 02	3.54E 02
50000.	5.34E-01	5.02E 00	2.63E 00	3.03E 00	1.37E 00	1.10E 01	2.80E 00	2.02E 01	4.66E 01	4.13E 02	4.60E 02
60000.	4.30E-01	4.98E 00	2.29E 00	2.55E 00	1.15E 00	9.25E 00	2.47E 00	2.01E 01	4.32E 01	4.74E 02	5.18E 02
70000.	3.78E-01	5.04E 00	2.08E 00	2.15E 00	9.71E-01	7.79E 00	2.33E 00	1.91E 01	3.99E 01	5.10E 02	5.50E 02
80000.	3.18E-01	5.10E 00	1.94E 00	1.80E 00	8.14E-01	6.53E 00	2.26E 00	1.80E 01	3.67E 01	5.30E 02	5.67E 02
90000.	2.66E-01	5.14E 00	1.83E 00	1.51E 00	6.84E-01	5.48E 00	2.22E 00	1.69E 01	3.40E 01	5.41E 02	5.75E 02
100000.	2.27E-01	5.18E 00	1.76E 00	1.29E 00	5.83E-01	4.67E 00	2.21E 00	1.59E 01	3.19E 01	5.47E 02	5.78E 02
200000.	4.47E-01	6.84E 00	4.32E 00	2.54E 00	1.15E 00	9.20E 00	5.73E 00	1.50E 01	4.52E 01	2.38E 02	2.83E 02
300000.	3.80E-01	1.23E 01	4.18E 00	2.16E 00	9.78E-01	7.82E 00	5.70E 00	4.33E 01	7.68E 01	1.32E 03	1.39E 03
400000.	4.14E-01	1.05E 01	4.01E 00	2.36E 00	1.06E 00	8.53E 00	5.34E 00	3.63E 01	6.86E 01	1.04E 03	1.11E 03
500000.	4.30E-01	8.55E 00	3.69E 00	2.45E 00	1.10E 00	8.87E 00	4.77E 00	2.88E 01	5.86E 01	7.57E 02	8.16E 02
600000.	4.34E-01	6.93E 00	3.35E 00	2.46E 00	1.11E 00	8.92E 00	4.21E 00	2.31E 01	5.05E 01	5.43E 02	5.93E 02
700000.	4.29E-01	5.72E 00	3.03E 00	2.44E 00	1.10E 00	8.84E 00	3.72E 00	1.89E 01	4.42E 01	3.92E 02	4.37E 02
800000.	4.20E-01	1.06E 01	2.76E 00	2.39E 00	1.08E 00	8.63E 00	3.32E 00	1.59E 01	4.50E 01	2.87E 02	3.32E 02
900000.	4.07E-01	3.94E 02	2.53E 00	2.31E 00	1.05E 00	8.38E 00	2.97E 00	1.35E 01	4.25E 02	2.38E 02	6.64E 02
1000000.	3.92E-01	5.95E 03	2.33E 00	2.23E 00	1.01E 00	8.09E 00	2.70E 00	1.18E 01	5.98E 03	5.66E 02	6.55E 03

Appendix P. Table P-8. AMRAW-B Output Table 1-2

TABLE 1 - 2 : ZONAL AND TOTAL DAMAGES FOR LOW POP. PROJECTION (\$/YR)

TIME	REPO	EDDY	FEDB	MIDO	WTEX	LEA	CHAV	REGS	TOT.ZONE	NON-SPEC	TTOTAL
0.	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
5.	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
10.	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
15.	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
20.	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
25.	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
30.	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
40.	1.61E-01	8.59E-01	3.97E-01	1.44E-01	6.25E-02	5.84E-01	6.10E-01	1.41E 00	4.23E 00	6.00E 01	6.42E 01
50.	1.70E-01	1.31E 00	5.84E-01	1.89E-01	8.09E-02	7.47E-01	9.14E-01	1.71E 00	5.71E 00	5.02E 01	5.59E 01
60.	1.69E-01	1.54E 00	6.68E-01	2.07E-01	8.82E-02	8.11E-01	1.05E 00	1.69E 00	6.21E 00	4.22E 01	4.84E 01
70.	1.62E-01	1.60E 00	6.81E-01	2.10E-01	8.91E-02	8.16E-01	1.07E 00	1.55E 00	6.18E 00	3.51E 01	4.13E 01
80.	1.52E-01	1.57E 00	6.54E-01	2.04E-01	8.66E-02	7.93E-01	1.03E 00	1.38E 00	5.87E 00	2.91E 01	3.50E 01
90.	1.43E-01	1.48E 00	6.04E-01	1.96E-01	8.32E-02	7.60E-01	9.45E-01	1.23E 00	5.44E 00	2.40E 01	2.94E 01
100.	1.35E-01	1.36E 00	5.46E-01	1.83E-01	7.98E-02	7.30E-01	8.50E-01	1.10E 00	4.99E 00	1.96E 01	2.46E 01
200.	1.98E-01	1.74E 00	6.11E-01	2.57E-01	1.26E-01	1.14E 00	9.13E-01	2.16E 00	7.19E 00	1.45E 01	2.17E 01
300.	1.74E-01	6.91E-01	3.22E-01	2.70E-01	1.14E-01	1.04E 00	4.31E-01	1.30E 00	4.34E 00	2.40E 00	6.74E 00
400.	1.89E-01	6.53E-01	3.43E-01	2.98E-01	1.26E-01	1.14E 00	4.55E-01	1.35E 00	4.56E 00	1.11E 00	5.66E 00
500.	2.04E-01	7.16E-01	3.80E-01	3.25E-01	1.37E-01	1.25E 00	5.06E-01	1.44E 00	4.96E 00	9.03E-01	5.86E 00
600.	2.19E-01	7.75E-01	4.11E-01	3.49E-01	1.47E-01	1.34E 00	5.49E-01	1.52E 00	5.31E 00	8.25E-01	6.13E 00
700.	2.31E-01	8.18E-01	4.34E-01	3.69E-01	1.56E-01	1.41E 00	5.80E-01	1.58E 00	5.58E 00	7.64E-01	6.35E 00
800.	2.40E-01	8.44E-01	4.50E-01	3.84E-01	1.62E-01	1.47E 00	5.99E-01	1.62E 00	5.77E 00	7.06E-01	6.48E 00
900.	2.46E-01	8.58E-01	4.58E-01	3.95E-01	1.67E-01	1.51E 00	6.09E-01	1.65E 00	5.90E 00	6.54E-01	6.55E 00
1000.	2.51E-01	8.64E-01	4.63E-01	4.04E-01	1.70E-01	1.55E 00	6.13E-01	1.67E 00	5.98E 00	6.07E-01	6.59E 00
2000.	3.95E-01	1.30E 00	7.05E-01	6.39E-01	2.70E-01	2.44E 00	9.23E-01	2.92E 00	9.60E 00	5.86E-01	1.02E 01
3000.	4.22E-01	1.28E 00	7.05E-01	6.84E-01	2.88E-01	2.61E 00	9.02E-01	3.02E 00	9.91E 00	4.89E-01	1.04E 01
4000.	4.91E-01	1.44E 00	8.01E-01	7.94E-01	3.36E-01	3.04E 00	1.02E 00	3.43E 00	1.13E 01	5.39E-01	1.19E 01
5000.	5.54E-01	1.60E 00	8.94E-01	9.00E-01	3.79E-01	3.44E 00	1.13E 00	3.80E 00	1.27E 01	6.23E-01	1.33E 01
6000.	6.07E-01	1.72E 00	9.70E-01	9.86E-01	4.15E-01	3.77E 00	1.23E 00	4.10E 00	1.38E 01	7.65E-01	1.46E 01
7000.	6.50E-01	1.83E 00	1.03E 00	1.05E 00	4.45E-01	4.04E 00	1.30E 00	4.34E 00	1.47E 01	1.25E 00	1.59E 01
8000.	6.85E-01	1.92E 00	1.08E 00	1.11E 00	4.69E-01	4.25E 00	1.35E 00	4.54E 00	1.54E 01	3.78E 00	1.92E 01
9000.	7.13E-01	1.99E 00	1.11E 00	1.16E 00	4.88E-01	4.43E 00	1.39E 00	4.69E 00	1.60E 01	1.18E 01	2.78E 01
10000.	7.36E-01	2.07E 00	1.14E 00	1.20E 00	5.04E-01	4.58E 00	1.42E 00	4.81E 00	1.65E 01	2.44E 01	4.09E 01
20000.	1.11E 00	2.98E 00	1.67E 00	1.79E 00	7.54E-01	6.85E 00	2.06E 00	7.88E 00	2.51E 01	3.61E 01	6.12E 01
30000.	8.54E-01	2.37E 00	1.19E 00	1.38E 00	5.63E-01	5.29E 00	1.42E 00	6.00E 00	1.91E 01	1.54E 02	1.73E 02
40000.	6.54E-01	1.93E 00	8.35E-01	1.06E 00	4.46E-01	4.05E 00	9.59E-01	6.54E 00	1.65E 01	3.03E 02	3.20E 02
50000.	5.34E-01	1.78E 00	6.62E-01	8.66E-01	3.65E-01	3.32E 00	7.49E-01	7.16E 00	1.54E 01	4.13E 02	4.28E 02
60000.	4.50E-01	1.77E 00	5.75E-01	7.30E-01	3.08E-01	2.79E 00	6.63E-01	7.11E 00	1.44E 01	4.74E 02	4.89E 02
70000.	3.78E-01	1.79E 00	5.24E-01	6.14E-01	2.59E-01	2.35E 00	6.25E-01	6.78E 00	1.33E 01	5.10E 02	5.23E 02
80000.	3.18E-01	1.81E 00	4.87E-01	5.15E-01	2.17E-01	1.97E 00	6.05E-01	6.37E 00	1.23E 01	5.30E 02	5.43E 02
90000.	2.66E-01	1.82E 00	4.60E-01	4.33E-01	1.83E-01	1.65E 00	5.95E-01	5.97E 00	1.14E 01	5.41E 02	5.52E 02
100000.	2.27E-01	1.84E 00	4.42E-01	3.69E-01	1.55E-01	1.41E 00	5.93E-01	5.65E 00	1.07E 01	5.47E 02	5.57E 02
200000.	4.47E-01	2.43E 00	1.09E 00	7.27E-01	3.06E-01	2.78E 00	1.54E 00	5.31E 00	1.46E 01	2.38E 02	2.53E 02
300000.	3.80E-01	4.35E 00	1.05E 00	6.18E-01	2.61E-01	2.36E 00	1.53E 00	1.53E 01	2.59E 01	1.32E 03	1.34E 03
400000.	4.14E-01	3.74E 00	1.01E 00	6.74E-01	2.84E-01	2.58E 00	1.43E 00	1.29E 01	2.30E 01	1.04E 03	1.07E 03
500000.	4.30E-01	3.03E 00	9.29E-01	6.99E-01	2.95E-01	2.68E 00	1.28E 00	1.02E 01	1.95E 01	7.57E 02	7.77E 02
600000.	4.34E-01	2.46E 00	8.42E-01	7.03E-01	2.97E-01	2.69E 00	1.13E 00	8.19E 00	1.67E 01	5.43E 02	5.60E 02
700000.	4.29E-01	2.03E 00	7.64E-01	6.98E-01	2.94E-01	2.67E 00	9.98E-01	6.71E 00	1.46E 01	3.92E 02	4.07E 02
800000.	4.20E-01	3.74E 00	6.96E-01	6.83E-01	2.88E-01	2.61E 00	8.90E-01	5.62E 00	1.49E 01	2.87E 02	3.02E 02
900000.	4.07E-01	1.40E 02	6.37E-01	6.61E-01	2.79E-01	2.53E 00	7.97E-01	4.79E 00	1.50E 02	2.38E 02	3.88E 02
1000000.	3.92E-01	2.11E 03	5.87E-01	6.33E-01	2.69E-01	2.44E 00	7.23E-01	4.17E 00	2.12E 03	5.66E 02	2.69E 03

Appendix P

Table P-9. Output Tables 2-9 and 2-14: AMRAW-B
Annual Damage Rates by Nuclide

TABLE 2 - 9 : TIME PERIOD= 50.

NUCLIDE	HIGH POP	LOW POP	NON-SPEC	TOT-HIGH	TOT-LOW
C-14	3.88E-07	1.22E-07	3.46E-06	3.85E-06	3.58E-06
SR-90	9.09E-00	2.86E-00	3.61E-01	4.52E-01	3.89E-01
Y-90	7.76E-02	2.43E-02	9.02E-02	1.68E-01	1.14E-01
ZR-93	1.59E-07	5.06E-08	1.38E-06	1.53E-06	1.43E-06
NB-93M	2.13E-07	6.74E-08	9.28E-06	9.49E-06	9.35E-06
TC-99	3.92E-06	1.24E-06	2.30E-04	2.34E-04	2.31E-04
I-129	6.19E-10	2.00E-10	1.17E-09	1.79E-09	1.37E-09
CS-135	7.71E-07	2.41E-07	8.55E-06	9.32E-06	8.79E-06
CS-137	6.92E-01	2.18E-01	6.64E-00	7.33E-00	6.86E-00
PB-210	6.32E-10	2.00E-10	2.04E-09	2.67E-09	2.24E-09
RA-225	3.70E-08	1.16E-08	3.76E-07	4.13E-07	3.88E-07
RA-226	1.13E-08	3.54E-09	1.95E-07	2.06E-07	1.98E-07
TH-229	9.73E-07	3.20E-07	1.80E-07	1.15E-06	5.00E-07
TH-230	9.50E-08	3.13E-08	9.85E-09	1.05E-07	4.11E-08
NP-237	6.89E-04	2.24E-04	8.05E-04	1.46E-03	1.03E-03
NP-239	3.26E-03	1.06E-03	1.88E-05	3.26E-03	1.08E-03
PU-238	6.59E-01	2.17E-01	3.43E-02	6.93E-01	2.52E-01
PU-239	3.76E-03	1.24E-03	2.05E-04	3.97E-03	1.45E-03
PU-240	5.92E-02	1.95E-02	3.23E-03	6.24E-02	2.28E-02
PU-241	4.59E-03	1.51E-03	3.35E-04	4.92E-03	1.85E-03
AM-241	8.27E-01	2.68E-01	9.58E-01	1.78E-00	1.23E-00
AM-242M	6.34E-02	2.05E-02	8.09E-02	1.44E-01	1.01E-01
AM-243	1.75E-01	5.67E-02	2.04E-01	3.79E-01	2.61E-01
CM-242	3.33E-03	1.09E-03	1.33E-03	4.67E-03	2.43E-03
CM-244	6.20E-00	2.02E-00	6.09E-00	1.23E-01	8.10E-00

TABLE 2 - 14 : TIME PERIOD= 100.

NUCLIDE	HIGH POP	LOW POP	NON-SPEC	TOT-HIGH	TOT-LOW
C-14	1.14E-06	3.48E-07	1.11E-05	1.22E-05	1.14E-05
SR-90	7.28E-00	2.26E-00	1.27E-01	2.00E-01	1.50E-01
Y-90	6.80E-02	2.08E-02	5.99E-02	1.28E-01	8.07E-02
ZR-93	4.77E-07	1.49E-07	2.52E-06	2.96E-06	2.66E-06
NB-93M	7.58E-07	2.35E-07	2.95E-05	3.03E-05	2.92E-05
TC-99	1.16E-05	3.58E-06	7.34E-04	7.45E-04	7.37E-04
I-129	2.12E-09	6.86E-10	1.75E-09	3.87E-09	2.43E-09
CS-135	2.27E-06	6.91E-07	1.81E-05	2.04E-05	1.88E-05
CS-137	6.61E-01	2.03E-01	4.64E-00	5.30E-00	4.85E-00
PB-210	6.00E-09	1.86E-09	7.42E-09	1.34E-08	9.28E-09
RA-225	2.65E-07	8.09E-08	2.52E-06	2.78E-06	2.60E-06
RA-226	8.38E-08	2.56E-08	1.00E-06	1.06E-06	1.03E-06
TH-229	7.39E-06	2.41E-06	4.44E-07	7.84E-06	2.85E-06
TH-230	7.07E-07	2.31E-07	2.38E-08	7.30E-07	2.54E-07
NP-237	2.16E-03	6.92E-04	8.35E-04	3.00E-03	1.53E-03
NP-239	1.14E-02	3.71E-03	2.10E-03	1.14E-02	3.73E-03
PU-238	1.43E-00	4.67E-01	2.37E-02	1.45E-00	4.90E-01
PU-239	1.24E-02	4.03E-03	2.15E-04	1.26E-02	4.75E-03
PU-240	2.42E-01	7.90E-02	4.21E-03	2.46E-01	8.32E-02
PU-241	1.25E-03	4.07E-04	2.90E-05	1.27E-03	4.36E-04
AM-241	2.41E-00	7.72E-01	9.26E-01	3.34E-00	1.70E-00
AM-242M	1.55E-01	4.94E-02	6.55E-02	2.20E-01	1.15E-01
AM-243	5.36E-01	1.72E-01	2.07E-01	7.44E-01	3.79E-01
CM-242	8.28E-03	2.69E-03	1.08E-03	9.37E-03	3.77E-03
CM-244	2.96E-00	9.51E-01	9.57E-01	3.92E-00	1.91E-00

Appendix P

Table P-10. AMRAW-B Output Table 3

TABLE 3 : DISCOUNTED PRESENT VALUES (\$)
DISCOUNT RATE = 0.00 %

NUCLIDE	HIGH POPULATION DISCOUNTED	PV \$/GM	LOW POPULATION DISCOUNTED	PV \$/GM
PU-240	0.37E 06		0.12E 06	
CM-244	0.96E 03		0.52E 03	
SUB TOT	3.72E 05	8.51E-03	1.21E 05	2.77E-03
RA-225	0.72E 07		0.66E 07	
TH-229	0.18E 08		0.57E 07	
NP-237	0.68E 09		0.27E 09	
PU-241	0.58E 03		0.19E 03	
AM-241	0.90E 05		0.30E 05	
SUB TOT	7.06E 08	6.82E 00	2.82E 08	2.72E 00
PB-210	0.99E 06		0.45E 06	
RA-226	0.63E 08		0.58E 08	
TH-230	0.11E 07		0.37E 06	
PU-238	0.88E 03		0.29E 03	
AM-242M	0.22E 03		0.84E 02	
CM-242	0.11E 02		0.36E 01	
SUB TOT	6.52E 07	1.00E 01	5.89E 07	9.06E 00
NP-239	0.15E 05		0.51E 04	
PU-239	0.25E 07		0.80E 06	
AM-243	0.10E 07		0.34E 06	
SUB TOT	3.51E 06	4.41E-02	1.15E 06	1.44E-02
C-14	0.32E 02		0.30E 02	
SUB TOT	3.16E 01	7.83E-04	2.98E 01	7.37E-04
SR-90	0.42E 04		0.31E 04	
Y-90	0.28E 02		0.17E 02	
SUB TOT	4.21E 03	6.70E-05	3.16E 03	5.03E-05
ZR-93	0.25E 04		0.21E 04	
NB-93M	0.32E 05		0.31E 05	
SUB TOT	3.46E 04	2.60E-04	3.35E 04	2.52E-04
TC-99	0.48E 09		0.47E 09	
SUB TOT	4.82E 08	3.13E 00	4.73E 08	3.07E 00
I-129	0.46E 04		0.36E 04	
SUB TOT	4.58E 03	7.85E-02	3.58E 03	6.13E-02
CS-135	0.26E 05		0.23E 05	
SUB TOT	2.56E 04	3.76E-04	2.30E 04	3.38E-04
CS-137	0.12E 04		0.11E 04	
SUB TOT	1.17E 03	7.69E-06	1.07E 03	7.01E-06
TOTAL	1.26E 09	1.57E 00	8.15E 08	1.01E 00

Appendix P

Table P-11 AMRAW-B Output Table 4-1

TABLE 4 - 1 : HIGH POPULATION SCENARIO
NUMBER OF DEATHS PER TIME INTERVAL.(5260000.)

TIME	REPO	EDDY	REBD	MIDG	WTC	LEA	CHAV	REGB	TOT.ZONE	NON-SPEC	TOTAL
0.	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
5.	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
10.	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
15.	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
20.	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
25.	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
30.	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
40.	6.19E-06	9.32E-05	6.06E-05	1.94E-05	9.01E-06	7.44E-05	8.76E-05	1.53E-04	5.03E-04	2.31E-03	2.81E-03
50.	6.55E-06	1.42E-04	8.93E-05	2.55E-05	1.17E-05	9.51E-05	1.31E-04	1.85E-04	6.87E-04	1.93E-03	2.62E-03
60.	6.51E-06	1.67E-04	1.02E-04	2.79E-05	1.27E-05	1.03E-04	1.50E-04	1.83E-04	7.53E-04	1.62E-03	2.37E-03
70.	6.23E-06	1.74E-04	1.04E-04	2.82E-05	1.28E-05	1.04E-04	1.54E-04	1.69E-04	7.51E-04	1.35E-03	2.10E-03
80.	5.85E-06	1.70E-04	1.00E-04	2.75E-05	1.25E-05	1.01E-04	1.47E-04	1.50E-04	7.15E-04	1.12E-03	1.83E-03
90.	5.49E-06	1.61E-04	9.24E-05	2.64E-05	1.20E-05	9.67E-05	1.36E-04	1.33E-04	6.63E-04	9.22E-04	1.58E-03
100.	5.17E-06	1.48E-04	8.35E-05	2.54E-05	1.15E-05	9.29E-05	1.22E-04	1.19E-04	6.07E-04	7.55E-04	1.36E-03
200.	7.63E-05	1.88E-03	9.34E-04	4.00E-04	1.81E-04	1.45E-03	1.31E-03	2.35E-03	8.59E-03	5.58E-03	1.42E-02
300.	6.67E-05	7.49E-04	4.92E-04	3.64E-04	1.64E-04	1.32E-03	6.18E-04	1.41E-03	5.19E-03	9.23E-04	6.11E-03
400.	7.25E-05	7.08E-04	5.24E-04	4.01E-04	1.81E-04	1.45E-03	6.52E-04	1.47E-03	5.46E-03	4.26E-04	5.89E-03
500.	7.86E-05	7.76E-04	5.80E-04	4.37E-04	1.98E-04	1.59E-03	7.27E-04	1.57E-03	5.95E-03	3.47E-04	6.30E-03
600.	8.41E-05	8.40E-04	6.29E-04	4.70E-04	2.12E-04	1.70E-03	7.89E-04	1.65E-03	6.38E-03	3.17E-04	6.70E-03
700.	8.87E-05	8.87E-04	6.64E-04	4.97E-04	2.24E-04	1.80E-03	8.33E-04	1.72E-03	6.71E-03	2.94E-04	7.00E-03
800.	9.22E-05	9.16E-04	6.87E-04	5.17E-04	2.34E-04	1.87E-03	8.59E-04	1.76E-03	6.94E-03	2.72E-04	7.21E-03
900.	9.46E-05	9.31E-04	7.00E-04	5.32E-04	2.40E-04	1.93E-03	8.74E-04	1.79E-03	7.09E-03	2.52E-04	7.34E-03
1000.	9.65E-05	9.38E-04	7.07E-04	5.43E-04	2.45E-04	1.97E-03	8.80E-04	1.81E-03	7.19E-03	2.34E-04	7.42E-03
2000.	1.52E-03	1.41E-02	1.08E-02	8.60E-03	3.89E-03	3.11E-02	1.32E-02	3.17E-02	1.15E-01	2.25E-03	1.17E-01
3000.	1.62E-03	1.38E-02	1.08E-02	9.21E-03	4.15E-03	3.33E-02	1.30E-02	3.28E-02	1.19E-01	1.88E-03	1.21E-01
4000.	1.89E-03	1.56E-02	1.22E-02	1.07E-02	4.84E-03	3.87E-02	1.46E-02	3.72E-02	1.36E-01	2.07E-03	1.38E-01
5000.	2.13E-03	1.73E-02	1.37E-02	1.21E-02	5.46E-03	4.38E-02	1.63E-02	4.12E-02	1.52E-01	2.40E-03	1.54E-01
6000.	2.34E-03	1.87E-02	1.48E-02	1.33E-02	5.99E-03	4.80E-02	1.76E-02	4.46E-02	1.65E-01	2.94E-03	1.68E-01
7000.	2.50E-03	1.99E-02	1.58E-02	1.42E-02	6.41E-03	5.15E-02	1.86E-02	4.72E-02	1.76E-01	4.81E-03	1.81E-01
8000.	2.63E-03	2.08E-02	1.65E-02	1.50E-02	6.76E-03	5.42E-02	1.94E-02	4.93E-02	1.85E-01	1.45E-02	1.99E-01
9000.	2.74E-03	2.16E-02	1.70E-02	1.56E-02	7.04E-03	5.64E-02	2.00E-02	5.10E-02	1.91E-01	4.56E-02	2.37E-01
10000.	2.83E-03	2.25E-02	1.75E-02	1.61E-02	7.27E-03	5.83E-02	2.04E-02	5.23E-02	1.97E-01	9.38E-02	2.91E-01
20000.	4.25E-02	3.23E-01	2.55E-01	2.41E-01	1.09E-01	8.72E-01	2.95E-01	8.56E-01	2.99E-00	1.39E-00	4.38E-00
30000.	3.29E-02	2.57E-01	1.81E-01	1.86E-01	8.41E-02	6.73E-01	2.03E-01	6.51E-01	2.27E-00	5.91E-00	8.16E-00
40000.	2.52E-02	2.09E-01	1.28E-01	1.43E-01	6.43E-02	5.16E-01	1.38E-01	7.10E-01	1.93E-00	1.17E-01	1.36E-01
50000.	2.06E-02	1.93E-01	1.01E-01	1.17E-01	5.27E-02	4.22E-01	1.08E-01	7.77E-01	1.79E-00	1.59E-01	1.77E-01
60000.	1.73E-02	1.91E-01	8.79E-02	9.82E-02	4.44E-02	3.56E-01	9.51E-02	7.72E-01	1.66E-00	1.62E-01	1.99E-01
70000.	1.46E-02	1.94E-01	8.01E-02	8.27E-02	3.74E-02	3.00E-01	8.96E-02	7.37E-01	1.53E-00	1.96E-01	2.12E-01
80000.	1.22E-02	1.96E-01	7.45E-02	6.93E-02	3.13E-02	2.51E-01	8.69E-02	6.92E-01	1.41E-00	2.04E-01	2.18E-01
90000.	1.02E-02	1.98E-01	7.03E-02	5.83E-02	2.63E-02	2.11E-01	8.54E-02	6.49E-01	1.31E-00	2.09E-01	2.21E-01
100000.	8.72E-03	1.99E-01	6.76E-02	4.96E-02	2.24E-02	1.80E-01	8.51E-02	6.13E-01	1.23E-00	2.10E-01	2.22E-01
200000.	1.72E-01	2.63E-00	1.66E-00	9.79E-01	4.41E-01	3.54E-00	2.21E-00	5.77E-00	1.74E-01	9.16E-01	1.09E-02
300000.	1.46E-01	4.71E-00	1.61E-00	8.31E-01	3.76E-01	3.01E-00	2.19E-00	1.66E-01	2.95E-01	5.07E-02	5.37E-02
400000.	1.59E-01	4.06E-00	1.54E-00	9.07E-01	4.09E-01	3.28E-00	2.05E-00	1.40E-01	2.64E-01	4.01E-02	4.27E-02
500000.	1.66E-01	3.29E-00	1.42E-00	9.41E-01	4.25E-01	3.41E-00	1.84E-00	1.11E-01	2.26E-01	2.91E-02	3.14E-02
600000.	1.67E-01	2.67E-00	1.29E-00	9.47E-01	4.28E-01	3.43E-00	1.62E-00	8.89E-00	1.94E-01	2.09E-02	2.28E-02
700000.	1.65E-01	2.20E-00	1.17E-00	9.39E-01	4.24E-01	3.40E-00	1.43E-00	7.28E-00	1.70E-01	1.51E-02	1.68E-02
800000.	1.62E-01	4.06E-00	1.06E-00	9.19E-01	4.15E-01	3.32E-00	1.28E-00	6.10E-00	1.73E-01	1.10E-02	1.28E-02
900000.	1.56E-01	1.52E-02	9.74E-01	8.90E-01	4.02E-01	3.22E-00	1.14E-00	5.20E-00	1.34E-01	9.16E-01	2.55E-02
1000000.	1.51E-01	2.29E-03	8.98E-01	8.59E-01	3.88E-01	3.11E-00	1.04E-00	4.53E-00	2.30E-03	2.18E-02	2.52E-03
TOTAL	1.65E-00	2.47E-03	1.28E-01	9.38E-00	4.23E-00	3.39E-01	1.61E-01	8.63E-01	2.63E-03	2.21E-03	4.84E-03

Appendix P

Table P-12. AMRAW-B Output Table 4-2

TABLE 4 - 2 : LOW POPULATION SCENARIO
NUMBER OF DEATHS PER TIME INTERVAL. (1260000.)

TIME	REPO	EDDY	REBD	MIDD	WTE	LEA	CHAV	REGA	TOT.ZONE	NON-SPEC	TTOTAL
0.	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
5.	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
10.	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
15.	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
20.	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
25.	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
30.	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
40.	6.19E-06	3.30E-05	1.53E-05	5.56E-06	2.41E-06	2.25E-05	2.35E-05	5.41E-05	1.63E-04	2.31E-03	2.47E-03
50.	6.55E-06	5.05E-05	2.25E-05	7.27E-06	3.11E-06	2.87E-05	3.51E-05	6.57E-05	2.19E-04	1.93E-03	2.15E-03
60.	6.51E-06	5.91E-05	2.57E-05	7.96E-06	3.39E-06	3.12E-05	4.03E-05	6.49E-05	2.39E-04	1.62E-03	1.86E-03
70.	6.23E-06	6.17E-05	2.62E-05	8.07E-06	3.43E-06	3.14E-05	4.12E-05	5.96E-05	2.38E-04	1.35E-03	1.59E-03
80.	5.85E-06	6.05E-05	2.52E-05	7.86E-06	3.33E-06	3.05E-05	3.95E-05	5.32E-05	2.26E-04	1.12E-03	1.34E-03
90.	5.49E-06	5.70E-05	2.32E-05	7.54E-06	3.20E-06	2.92E-05	3.64E-05	4.72E-05	2.09E-04	9.22E-04	1.13E-03
100.	5.17E-06	5.23E-05	2.10E-05	7.25E-06	3.07E-06	2.81E-05	3.27E-05	4.22E-05	1.92E-04	7.55E-04	9.46E-04
200.	7.63E-05	6.67E-04	2.35E-04	1.14E-04	4.53E-05	4.39E-04	3.51E-04	8.32E-04	2.76E-03	5.58E-03	8.34E-03
300.	6.67E-05	2.66E-04	1.24E-04	1.04E-04	4.39E-05	3.99E-04	1.66E-04	5.01E-04	1.67E-03	9.23E-04	2.59E-03
400.	7.25E-05	2.51E-04	1.32E-04	1.15E-04	4.84E-05	4.39E-04	1.75E-04	5.20E-04	1.75E-03	4.26E-04	2.18E-03
500.	7.86E-05	2.75E-04	1.46E-04	1.25E-04	5.27E-05	4.79E-04	1.95E-04	5.55E-04	1.91E-03	3.47E-04	2.25E-03
600.	8.41E-05	2.98E-04	1.58E-04	1.34E-04	5.67E-05	5.15E-04	2.11E-04	5.84E-04	2.04E-03	3.17E-04	2.36E-03
700.	8.87E-05	3.15E-04	1.67E-04	1.42E-04	5.99E-05	5.44E-04	2.23E-04	6.08E-04	2.15E-03	2.94E-04	2.44E-03
800.	9.22E-05	3.25E-04	1.73E-04	1.48E-04	6.23E-05	5.66E-04	2.30E-04	6.25E-04	2.22E-03	2.72E-04	2.49E-03
900.	9.46E-05	3.30E-04	1.76E-04	1.52E-04	6.41E-05	5.82E-04	2.34E-04	6.35E-04	2.27E-03	2.52E-04	2.52E-03
1000.	9.65E-05	3.32E-04	1.78E-04	1.55E-04	6.55E-05	5.95E-04	2.36E-04	6.41E-04	2.30E-03	2.34E-04	2.53E-03
2000.	1.52E-03	5.01E-03	2.71E-03	2.46E-03	1.04E-03	9.40E-03	3.55E-03	1.12E-02	3.69E-02	2.25E-03	3.92E-02
3000.	1.62E-03	4.90E-03	2.71E-03	2.63E-03	1.11E-03	1.01E-02	3.47E-03	1.16E-02	3.81E-02	1.89E-03	4.00E-02
4000.	1.89E-03	5.53E-03	3.08E-03	3.05E-03	1.29E-03	1.17E-02	3.92E-03	1.32E-02	4.36E-02	2.07E-03	4.57E-02
5000.	2.13E-03	6.15E-03	3.44E-03	3.46E-03	1.46E-03	1.32E-02	4.36E-03	1.46E-02	4.88E-02	2.40E-03	5.12E-02
6000.	2.34E-03	6.63E-03	3.73E-03	3.79E-03	1.60E-03	1.45E-02	4.71E-03	1.58E-02	5.31E-02	2.94E-03	5.60E-02
7000.	2.50E-03	7.05E-03	3.96E-03	4.05E-03	1.71E-03	1.55E-02	5.00E-03	1.67E-02	5.65E-02	4.81E-03	6.13E-02
8000.	2.63E-03	7.37E-03	4.15E-03	4.28E-03	1.80E-03	1.64E-02	5.21E-03	1.75E-02	5.93E-02	1.45E-02	7.38E-02
9000.	2.74E-03	7.67E-03	4.24E-03	4.45E-03	1.88E-03	1.70E-02	5.35E-03	1.81E-02	6.15E-02	4.56E-02	1.07E-01
10000.	2.83E-03	7.97E-03	4.40E-03	4.60E-03	1.94E-03	1.76E-02	5.48E-03	1.85E-02	6.33E-02	9.38E-02	1.57E-01
20000.	4.25E-02	1.15E-01	6.41E-02	6.89E-02	2.90E-02	2.63E-01	7.91E-02	3.03E-01	9.65E-01	1.39E-00	2.35E-00
30000.	3.29E-02	9.12E-02	4.56E-02	5.31E-02	2.24E-02	2.03E-01	5.45E-02	2.31E-01	7.34E-01	5.91E-00	6.65E-00
40000.	2.52E-02	7.42E-02	3.21E-02	4.08E-02	1.72E-02	1.56E-01	3.69E-02	2.52E-01	6.34E-01	1.17E-01	1.23E-01
50000.	2.06E-02	6.85E-02	2.55E-02	3.33E-02	1.41E-02	1.28E-01	2.88E-02	2.75E-01	5.94E-01	1.59E-01	1.65E-01
60000.	1.73E-02	6.79E-02	2.21E-02	2.81E-02	1.18E-02	1.07E-01	2.55E-02	2.74E-01	5.54E-01	1.82E-01	1.88E-01
70000.	1.46E-02	6.87E-02	2.02E-02	2.36E-02	9.97E-03	9.05E-02	2.40E-02	2.61E-01	5.12E-01	1.96E-01	2.01E-01
80000.	1.22E-02	6.96E-02	1.87E-02	1.98E-02	8.35E-03	7.58E-02	2.33E-02	2.45E-01	4.73E-01	2.04E-01	2.09E-01
90000.	1.02E-02	7.01E-02	1.77E-02	1.66E-02	7.02E-03	6.36E-02	2.29E-02	2.30E-01	4.38E-01	2.08E-01	2.12E-01
100000.	8.72E-03	7.06E-02	1.70E-02	1.42E-02	5.98E-03	5.43E-02	2.28E-02	2.17E-01	4.11E-01	2.10E-01	2.14E-01
200000.	1.72E-01	9.33E-01	4.18E-01	2.80E-01	1.18E-01	1.07E-00	5.91E-01	2.04E-00	5.62E-00	9.16E-01	9.72E-01
300000.	1.46E-01	1.67E-00	4.05E-01	2.38E-01	1.00E-01	9.09E-01	5.87E-01	5.90E-00	9.95E-00	5.07E-02	5.17E-02
400000.	1.59E-01	1.44E-00	3.88E-01	2.59E-01	1.09E-01	9.91E-01	5.50E-01	4.95E-00	8.83E-00	4.01E-02	4.10E-02
500000.	1.66E-01	1.17E-00	3.57E-01	2.69E-01	1.13E-01	1.03E-00	4.92E-01	3.92E-00	7.51E-00	2.91E-02	2.99E-02
600000.	1.67E-01	9.46E-01	3.24E-01	2.71E-01	1.14E-01	1.04E-00	4.34E-01	3.15E-00	6.44E-00	2.09E-02	2.15E-02
700000.	1.65E-01	7.80E-01	2.94E-01	2.68E-01	1.13E-01	1.03E-00	3.84E-01	2.58E-00	5.61E-00	1.51E-02	1.57E-02
800000.	1.62E-01	1.44E-00	2.68E-01	2.63E-01	1.11E-01	1.00E-00	3.42E-01	2.16E-00	5.75E-00	1.10E-02	1.16E-02
900000.	1.56E-01	5.38E-01	2.45E-01	2.54E-01	1.07E-01	9.74E-01	3.07E-01	1.84E-00	5.77E-01	9.16E-01	1.49E-02
1000000.	1.51E-01	8.12E-02	2.26E-01	2.43E-01	1.03E-01	9.39E-01	2.78E-01	1.60E-00	8.15E-02	2.18E-02	1.03E-03
TOTAL	1.65E-00	8.75E-02	3.22E-00	2.68E-00	1.13E-00	1.03E-01	4.33E-00	3.06E-01	9.29E-02	2.21E-03	3.13E-03

Appendix P.

Table P-13. AMRAW-B Output Table 5-1

TABLE 5 - 1 : TOTAL UNDISCOUNTED DAMAGES FOR EACH ZONE FOR EACH TIME INTERVAL - HIGH POPULATION

TIME	REPO	EDDY	FEDO	MIDO	WTE	LEA	CHAV	REGS	TOT.ZONE	NON-SPEC	TTOTAL
0.	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
5.	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
10.	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
15.	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
20.	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
25.	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
30.	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
40.	1.61E 00	2.42E 01	1.58E 01	5.06E 00	2.34E 00	1.93E 01	2.28E 01	3.97E 01	1.31E 02	6.00E 02	7.30E 02
50.	1.70E 00	3.70E 01	2.32E 01	6.62E 00	3.03E 00	2.47E 01	3.41E 01	4.82E 01	1.79E 02	5.02E 02	6.80E 02
60.	1.69E 00	4.33E 01	2.65E 01	7.25E 00	3.31E 00	2.68E 01	3.91E 01	4.76E 01	1.96E 02	4.22E 02	6.17E 02
70.	1.62E 00	4.52E 01	2.71E 01	7.34E 00	3.34E 00	2.70E 01	4.00E 01	4.37E 01	1.95E 02	3.51E 02	5.46E 02
80.	1.52E 00	4.43E 01	2.60E 01	7.15E 00	3.25E 00	2.63E 01	3.83E 01	3.91E 01	1.86E 02	2.91E 02	4.77E 02
90.	1.43E 00	4.18E 01	2.40E 01	6.86E 00	3.12E 00	2.51E 01	3.53E 01	3.47E 01	1.72E 02	2.40E 02	4.12E 02
100.	1.35E 00	3.84E 01	2.17E 01	6.59E 00	2.99E 00	2.42E 01	3.17E 01	3.10E 01	1.58E 02	1.96E 02	3.54E 02
200.	1.98E 01	4.89E 02	2.43E 02	1.04E 02	4.71E 01	3.78E 02	3.41E 02	6.11E 02	2.23E 03	1.45E 03	3.68E 03
300.	1.74E 01	1.95E 02	1.28E 02	9.46E 01	4.28E 01	3.43E 02	1.61E 02	3.67E 02	1.35E 03	2.40E 02	1.59E 03
400.	1.89E 01	1.84E 02	1.36E 02	1.04E 02	4.71E 01	3.78E 02	1.70E 02	3.81E 02	1.42E 03	1.11E 02	1.53E 03
500.	2.04E 01	2.02E 02	1.51E 02	1.14E 02	5.14E 01	4.12E 02	1.89E 02	4.07E 02	1.55E 03	9.03E 01	1.64E 03
600.	2.19E 01	2.18E 02	1.63E 02	1.22E 02	5.52E 01	4.43E 02	2.05E 02	4.29E 02	1.66E 03	8.25E 01	1.74E 03
700.	2.31E 01	2.31E 02	1.73E 02	1.29E 02	5.84E 01	4.68E 02	2.16E 02	4.46E 02	1.74E 03	7.64E 01	1.82E 03
800.	2.40E 01	2.38E 02	1.79E 02	1.34E 02	6.07E 01	4.87E 02	2.23E 02	4.59E 02	1.81E 03	7.06E 01	1.88E 03
900.	2.46E 01	2.42E 02	1.82E 02	1.38E 02	6.25E 01	5.01E 02	2.27E 02	4.66E 02	1.84E 03	6.54E 01	1.91E 03
1000.	2.51E 01	2.44E 02	1.84E 02	1.41E 02	6.38E 01	5.12E 02	2.29E 02	4.71E 02	1.87E 03	6.07E 01	1.93E 03
2000.	3.95E 02	3.67E 03	2.80E 03	2.24E 03	1.01E 03	8.09E 03	3.44E 03	8.25E 03	2.99E 04	5.85E 02	3.05E 04
3000.	4.22E 02	3.60E 03	2.80E 03	2.40E 03	1.08E 03	8.66E 03	3.37E 03	8.53E 03	3.08E 04	4.89E 02	3.13E 04
4000.	4.91E 02	4.05E 03	3.18E 03	2.78E 03	1.26E 03	1.01E 04	3.80E 03	9.63E 03	3.53E 04	5.39E 02	3.59E 04
5000.	5.54E 02	4.51E 03	3.55E 03	3.15E 03	1.42E 03	1.14E 04	4.23E 03	1.07E 04	3.95E 04	6.23E 02	4.02E 04
6000.	6.07E 02	4.86E 03	3.86E 03	3.45E 03	1.56E 03	1.25E 04	4.57E 03	1.16E 04	4.30E 04	7.65E 02	4.37E 04
7000.	6.50E 02	5.17E 03	4.10E 03	3.69E 03	1.67E 03	1.34E 04	4.85E 03	1.23E 04	4.56E 04	1.25E 03	4.70E 04
8000.	6.65E 02	5.40E 03	4.29E 03	3.89E 03	1.76E 03	1.41E 04	5.05E 03	1.28E 04	4.80E 04	3.78E 03	5.18E 04
9000.	7.13E 02	5.62E 03	4.43E 03	4.05E 03	1.83E 03	1.47E 04	5.19E 03	1.33E 04	4.98E 04	1.18E 04	5.16E 04
10000.	7.36E 02	5.84E 03	4.55E 03	4.18E 03	1.89E 03	1.52E 04	5.31E 03	1.36E 04	5.13E 04	2.44E 04	7.57E 04
20000.	1.11E 04	8.41E 04	6.62E 04	6.27E 04	2.83E 04	2.27E 05	7.67E 04	2.22E 05	7.78E 05	3.61E 05	1.14E 06
30000.	8.54E 03	6.68E 04	4.71E 04	4.84E 04	2.19E 04	1.75E 05	5.29E 04	1.69E 05	5.90E 05	1.54E 06	2.13E 06
40000.	6.54E 03	5.44E 04	3.32E 04	3.71E 04	1.67E 04	1.34E 05	3.58E 04	1.85E 05	5.03E 05	3.03E 06	3.54E 06
50000.	5.34E 03	5.02E 04	2.63E 04	3.03E 04	1.37E 04	1.10E 05	2.80E 04	2.02E 05	4.66E 05	4.13E 06	4.60E 06
60000.	4.50E 03	4.98E 04	2.29E 04	2.55E 04	1.15E 04	9.25E 04	2.47E 04	2.01E 05	4.32E 05	4.74E 06	5.18E 06
70000.	3.78E 03	5.04E 04	2.08E 04	2.15E 04	9.71E 03	7.79E 04	2.33E 04	1.91E 05	3.99E 05	5.10E 06	5.50E 06
80000.	3.18E 03	5.10E 04	1.94E 04	1.80E 04	8.14E 03	6.53E 04	2.26E 04	1.80E 05	3.67E 05	5.30E 06	5.67E 06
90000.	2.66E 03	5.14E 04	1.83E 04	1.51E 04	6.84E 03	5.48E 04	2.22E 04	1.69E 05	3.40E 05	5.41E 06	5.75E 06
100000.	2.27E 03	5.18E 04	1.76E 04	1.29E 04	5.83E 03	4.67E 04	2.21E 04	1.59E 05	3.19E 05	5.47E 06	5.78E 06
200000.	4.47E 04	6.84E 05	4.32E 05	2.54E 05	1.15E 05	9.20E 05	5.73E 05	1.50E 06	4.52E 06	2.38E 07	2.63E 07
300000.	3.80E 04	1.23E 06	4.18E 05	2.16E 05	9.78E 04	7.82E 05	5.70E 05	4.33E 06	7.68E 06	1.32E 08	1.39E 08
400000.	4.14E 04	1.05E 06	4.01E 05	2.36E 05	1.06E 05	8.53E 05	5.34E 05	3.63E 06	6.86E 06	1.04E 08	1.11E 08
500000.	4.30E 04	8.55E 05	3.69E 05	2.45E 05	1.10E 05	8.87E 05	4.77E 05	2.89E 06	5.86E 06	7.57E 07	8.16E 07
600000.	4.34E 04	6.93E 05	3.35E 05	2.46E 05	1.11E 05	8.92E 05	4.21E 05	2.31E 06	5.05E 06	5.43E 07	5.93E 07
700000.	4.25E 04	5.72E 05	3.03E 05	2.44E 05	1.10E 05	8.84E 05	3.72E 05	1.89E 06	4.42E 06	3.92E 07	4.37E 07
800000.	4.20E 04	1.06E 06	2.76E 05	2.39E 05	1.08E 05	8.63E 05	3.32E 05	1.59E 06	4.50E 06	2.87E 07	3.32E 07
900000.	4.07E 04	3.94E 07	2.53E 05	2.31E 05	1.05E 05	8.38E 05	2.97E 05	1.35E 06	4.25E 07	2.38E 07	6.64E 07
1000000.	3.92E 04	5.95E 08	2.33E 05	2.23E 05	1.01E 05	8.09E 05	2.70E 05	1.18E 06	5.98E 08	5.66E 07	6.55E 08
TOTAL	4.29E 05	6.41E 08	3.33E 06	2.44E 06	1.10E 06	8.82E 06	4.20E 06	2.24E 07	6.84E 08	5.73E 08	1.26E 09

Appendix P.

Table P-14: AMRAW-B Output Table 5-2

TABLE 5 - 2 : TOTAL UNDISCOUNTED DAMAGES FOR EACH ZONE FOR EACH TIME INTERVAL - LOW POPULATION												
TIME	REPO	EDDY	REBD	MIDO	WTE	LEA	CHAV	REGS	TOT.ZONE	NON-SPEC	TTOTAL	
0.	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
5.	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
10.	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
15.	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
20.	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
25.	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
30.	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
40.	1.61E 00	8.59E 00	3.97E 00	1.44E 00	6.25E-01	5.84E 00	6.10E 00	1.41E 01	4.23E 01	6.00E 02	6.42E 02	02
50.	1.70E 00	1.31E 01	5.84E 00	1.69E 00	8.09E-01	7.47E 00	9.14E 00	1.71E 01	5.71E 01	5.02E 02	5.59E 02	02
60.	1.69E 00	1.54E 01	6.68E 00	2.07E 00	8.82E-01	8.11E 00	1.05E 01	1.69E 01	6.21E 01	4.22E 02	4.84E 02	02
70.	1.62E 00	1.60E 01	6.81E 00	2.10E 00	8.91E-01	8.16E 00	1.07E 01	1.55E 01	6.18E 01	3.51E 02	4.13E 02	02
80.	1.52E 00	1.57E 01	6.54E 00	2.04E 00	8.66E-01	7.93E 00	1.03E 01	1.38E 01	5.87E 01	2.91E 02	3.50E 02	02
90.	1.43E 00	1.48E 01	6.04E 00	1.96E 00	8.32E-01	7.60E 00	9.45E 00	1.23E 01	5.44E 01	2.40E 02	2.94E 02	02
100.	1.35E 00	1.36E 01	5.46E 00	1.88E 00	7.98E-01	7.30E 00	8.50E 00	1.10E 01	4.99E 01	1.96E 02	2.46E 02	02
200.	1.98E 01	1.74E 02	6.11E 01	2.97E 01	1.26E 01	1.14E 02	9.13E 01	2.16E 02	7.19E 02	1.45E 03	2.17E 03	03
300.	1.74E 01	6.91E 01	3.22E 01	2.70E 01	1.14E 01	1.04E 02	4.31E 01	1.30E 02	4.34E 02	2.40E 02	6.74E 02	02
400.	1.89E 01	6.53E 01	3.43E 01	2.98E 01	1.26E 01	1.14E 02	4.55E 01	1.35E 02	4.56E 02	1.11E 02	5.66E 02	02
500.	2.04E 01	7.16E 01	3.80E 01	3.23E 01	1.37E 01	1.25E 02	5.06E 01	1.44E 02	4.96E 02	9.03E 01	5.86E 02	02
600.	2.19E 01	7.75E 01	4.11E 01	3.49E 01	1.47E 01	1.34E 02	5.49E 01	1.52E 02	5.31E 02	8.25E 01	6.13E 02	02
700.	2.31E 01	8.18E 01	4.34E 01	3.69E 01	1.56E 01	1.41E 02	5.80E 01	1.58E 02	5.58E 02	7.64E 01	6.35E 02	02
800.	2.40E 01	8.44E 01	4.50E 01	3.84E 01	1.62E 01	1.47E 02	5.99E 01	1.62E 02	5.77E 02	7.06E 01	6.48E 02	02
900.	2.46E 01	8.58E 01	4.58E 01	3.93E 01	1.67E 01	1.51E 02	6.09E 01	1.65E 02	5.90E 02	6.54E 01	6.55E 02	02
1000.	2.51E 01	8.64E 01	4.63E 01	4.04E 01	1.70E 01	1.55E 02	6.13E 01	1.67E 02	5.98E 02	6.07E 01	6.59E 02	02
2000.	3.95E 02	1.30E 03	7.05E 02	6.39E 02	2.70E 02	2.44E 03	9.23E 02	2.92E 03	9.60E 03	5.85E 02	1.02E 04	04
3000.	4.22E 02	1.28E 03	7.05E 02	6.84E 02	2.88E 02	2.61E 03	9.02E 02	3.02E 03	9.91E 03	4.89E 02	1.04E 04	04
4000.	4.91E 02	1.44E 03	8.01E 02	7.94E 02	3.36E 02	3.04E 03	1.02E 03	3.43E 03	1.13E 04	5.39E 02	1.19E 04	04
5000.	5.54E 02	1.60E 03	8.94E 02	9.00E 02	3.79E 02	3.44E 03	1.13E 03	3.80E 03	1.27E 04	6.23E 02	1.33E 04	04
6000.	6.07E 02	1.72E 03	9.70E 02	9.86E 02	4.15E 02	3.77E 03	1.23E 03	4.10E 03	1.38E 04	7.65E 02	1.46E 04	04
7000.	6.50E 02	1.81E 03	1.03E 03	1.05E 03	4.45E 02	4.04E 03	1.30E 03	4.34E 03	1.47E 04	1.25E 03	1.59E 04	04
8000.	6.85E 02	1.92E 03	1.08E 03	1.11E 03	4.69E 02	4.25E 03	1.35E 03	4.58E 03	1.54E 04	3.78E 03	1.92E 04	04
9000.	7.13E 02	1.99E 03	1.11E 03	1.16E 03	4.88E 02	4.43E 03	1.39E 03	4.69E 03	1.60E 04	1.18E 04	2.78E 04	04
10000.	7.36E 02	2.07E 03	1.14E 03	1.20E 03	5.04E 02	4.58E 03	1.42E 03	4.81E 03	1.65E 04	2.44E 04	4.09E 04	04
20000.	1.11E 04	2.98E 04	1.67E 04	1.79E 04	7.54E 03	6.85E 04	2.06E 04	7.88E 04	2.91E 05	3.61E 05	6.12E 05	05
30000.	8.54E 03	2.37E 04	1.19E 04	1.38E 04	5.83E 03	5.29E 04	1.42E 04	6.00E 04	1.91E 05	1.54E 05	1.73E 06	06
40000.	6.54E 03	1.93E 04	8.35E 03	1.06E 04	4.46E 03	4.05E 04	9.59E 03	6.54E 04	1.65E 05	3.03E 06	3.20E 06	06
50000.	5.34E 03	1.78E 04	6.62E 03	8.66E 03	3.65E 03	3.32E 04	7.49E 03	7.16E 04	1.54E 05	4.13E 06	4.26E 06	06
60000.	4.50E 03	1.77E 04	5.75E 03	7.30E 03	3.08E 03	2.79E 04	6.63E 03	7.11E 04	1.44E 05	4.74E 06	4.89E 06	06
70000.	3.78E 03	1.79E 04	5.24E 03	6.14E 03	2.59E 03	2.35E 04	6.25E 03	6.75E 04	1.33E 05	5.10E 06	5.23E 06	06
80000.	3.18E 03	1.81E 04	4.87E 03	5.15E 03	2.17E 03	1.97E 04	5.95E 03	6.37E 04	1.23E 05	5.30E 06	5.43E 06	06
90000.	2.66E 03	1.82E 04	4.60E 03	4.33E 03	1.83E 03	1.65E 04	5.95E 03	5.97E 04	1.14E 05	5.41E 06	5.52E 06	06
100000.	2.27E 03	1.84E 04	4.42E 03	3.69E 03	1.55E 03	1.41E 04	5.93E 03	5.65E 04	1.07E 05	5.47E 06	5.57E 06	06
200000.	4.47E 04	2.43E 05	1.09E 05	7.27E 04	3.06E 04	2.78E 05	1.54E 05	5.31E 05	1.46E 06	2.38E 07	2.53E 07	07
300000.	3.80E 04	4.35E 05	1.05E 05	6.18E 04	2.61E 04	2.36E 05	1.53E 05	1.53E 06	2.59E 06	1.32E 08	1.34E 08	08
400000.	4.14E 04	3.74E 05	1.01E 05	6.74E 04	2.84E 04	2.58E 05	1.43E 05	1.29E 06	2.30E 06	1.04E 08	1.07E 08	08
500000.	4.30E 04	3.03E 05	9.29E 04	6.59E 04	2.95E 04	2.68E 05	1.28E 05	1.02E 06	1.95E 06	7.57E 07	7.77E 07	07
600000.	4.34E 04	2.46E 05	8.42E 04	7.03E 04	2.97E 04	2.69E 05	1.13E 05	8.19E 05	1.67E 06	5.43E 07	5.60E 07	07
700000.	4.29E 04	2.03E 05	7.64E 04	6.98E 04	2.94E 04	2.67E 05	9.98E 04	6.71E 05	1.46E 06	3.92E 07	4.07E 07	07
800000.	4.20E 04	3.74E 05	6.96E 04	6.83E 04	2.88E 04	2.61E 05	8.90E 04	5.62E 05	1.49E 06	2.87E 07	3.02E 07	07
900000.	4.07E 04	1.40E 07	6.37E 04	6.61E 04	2.79E 04	2.53E 05	7.97E 04	4.79E 05	1.50E 07	2.38E 07	3.88E 07	07
1000000.	3.92E 04	2.11E 08	5.87E 04	6.38E 04	2.69E 04	2.44E 05	7.23E 04	4.17E 05	2.12E 08	5.66E 07	2.69E 08	08
TOTAL	4.29E 05	2.27E 08	8.38E 05	6.97E 05	2.94E 05	2.67E 06	1.12E 06	7.95E 06	2.41E 08	5.73E 08	8.15E 08	08

APPENDIX Q

PROGRAMMER'S NOTES

Variables

The variables used and their definitions are presented in the list of nomenclature in the front pages of this volume.

"Index" File Structure

"Index" is an unformatted temporary file allocated to logical unit 2. Index holds a maximum of 260 records, each 400 bytes in length. Index is calculated for each nuclide and zone.

Number of Zones

The number of geographic zones, designated by the variable MZ, in the initial demonstration is 8. Nonspecific doses and corresponding damages are treated in the calculations as though they are for an additional zone ($MZP1 = MZ + 1$, or 9 for the demonstration). While input provides for a number of zones other than 8, and the ranges of calculation loops correspond, there are some program changes required for $MZ \neq 8$, to provide consistent table formats. For example, in FORMATS 850, 918, and 957, the multiplier of the repeated group (A4, 6X) must be changed from 8 to a new and different value of MZ. Follow-on work can make modifications to automatically accommodate a range of MZ values, but the user is cautioned that these improvements have not yet been made.

Output of Table 2

Table 2 is output (providing the flag ITB3 is set to 1) for all values of time after an initial sequence of times which are bypassed. "IF" statements in lines 1820 and 1900 (numbered on the right side in Appendix R listing) bypass calculations and output for time subscripts through 7 (i.e., through 30 y or subscript 6 in the demonstration). If a different bypass control is desired, the 2 "IF" statements must be modified. It may be desirable in the future to use an input variable

for this purpose. This could be the variable NRO suggested in the next paragraph.

Basis for Table 3

Table 3 includes columns of marginal present value costs for decay groups. The values are obtained by dividing the sum of present values of damage for each nuclide in a decay group, \$, by the total mass of nuclides, g, comprising the decay group at a specified time. Presently, the specified time for which mass values, X, are obtained (see input data file AM1E) in the beginning of the terminal storage phase, or a reference time of 30 y (time subscript 7). In a new application, the "7" in lines 2630 and 2670 should be replaced by the integer corresponding to the appropriate time subscript. Line 2290 also uses this time, designated NYRO (number of years of repository operations); this is set equal to 30 in line 402. It may be desirable in the future to use an input variable (e.g., NRO) for the time subscript representing the end of repository operations. This subscript variable could then be used instead of 7 in lines 2630 and 2670, and line 402 could be changed to NYRO = TIME(NRO).

Discount Rate

The discount rate, RATE, is read in as a decimal number in F format. When a zero discount value, 0.0, is read in, it is changed to RATE = .00001 (line 720) for use as a routing flag which bypasses discounting calculations. For output as a percentage, PRATE = RATE x 100 (line 722) is used. When a write statement outputs PRATE, F5.2 format is used which ignores the 1 for the converted zero discount and writes it as 0.00. If a non-zero discount value is used, RATE remains as read in (as low as 0.01%, or RATE = .0001), the discounting calculations are executed, and the proper percentage rate is output as PRATE.

Dose Rate Multiplier

Calculations within AMRAW-B are done in terms of man-rem of dose. AMRAW-A output is in units of milli-rem for local dose and man-rem for nonspecific dose. A multiplier, THO, is used as a conversion factor and is assigned values of .001 and 1.0 for local dose and nonspecific dose, respectively (see lines 1000 and 1020).

Population

Population projections (high and low) are used for local dose calculations in each zone. Nonspecific dose is based upon a total agricultural production implying a nonspecific population. Calculation of damage for nonspecific dose in line 1980 provides for adjustment by including POPH(9) and POPL(9), high and low "populations" for the nonspecific category as designated by subscript 9. These are set equal to 1.0 (see lines 730 and 740) at present.

Input File Containing MAN1

MAN1L and MAN1N from AMRAW-A are processed to MAN1 in file ECONxx for input to AMRAW-B. This can be via disk or tape file. The user is cautioned that JCL for use of COMPRESS must specify disk or tape to be consistent with the input device specification provided for by the user in AMRAW-B.

Modification for Running on Other Systems

AMRAW, written in FORTRAN IV, was developed with implementation on an IBM 360 system. Some changes may be necessary for operation of AMRAW-B on a CDC or other system. However, some of the conditions which require changes in AMRAW-A such as quadruply dimensioned arrays (see Appendix G in Part 1) do not exist in AMRAW-B, which should simplify conversion.

Page Intentionally Blank

APPENDIX R

AMRAW-B LISTING

The AMRAW-B code consists of a main program only; there are no sub-programs. The code has 394 lines including comment statements.

Appendix R. AMRAW-B Program Listing

```

****                                00000160
**** AMRAW: ASSESSMENT METHOD FOR RADIOACTIVE WASTE. 00000170
**** A CODE DEVELOPED BY UNIVERSITY OF NEW MEXICO 00000180
**** UNDER EPA CONTRACT #68-01-3256 00000190
**** THIS LISTING IS AMRAW-B. THE ECONOMIC MODEL, MAY 1978. 00000200
****                                00000210
      IMPLICIT INTEGER*2 (1-N) 00000220
      DOUBLE PRECISION NUCNAM(25),HEAD 00000230
      DOUBLE PRECISION NUC2(25) 00000240
      DATA HEAD/'PV3/GM.'/ 00000250
      REAL MAN1(50,8),DDP(8),DPY(8),TIME(50),LAMBDA(8) 00000260
      REAL POPL(9),POPH(9),DAMAGE(50),PVN(7,25),TDTKH(25) 00000270
      REAL YDTKL(25),X(25,50),DTZ(9),SPV(7),TTO(11),THD(50,11) 00000280
      REAL DTH(50,25),DTL(50,25),DYRL(50,11),DYRH(50,11),DLD(11) 00000290
      DIMENSION IK(25),IG(11),PV2(7,25),SS(7,11),TUDH(11),TUDL(11) 00000300
      DIMENSION IFLAGH(8),TITLE(10),SITE(8,5),REG(8),IKK(25) 00000310
      DATA LAMBDA/8*0./ 00000320
      DATA IFLAGH/1,2,3,4,5,6,7,8/ 00000330
      INTEGER*4 INDEX,POS(2),IN,IP,IS 00000340
      DATA POS/'HIGH','LOW'/ 00000350
      DEFINE FILE 2(260,400,U,INDEX) 00000360
      CALL FSPIE 00000370
      IN=5 00000380
      IP=6 00000390
      IS=1 00000400
      NYRQ=30 00000402
****                                00000410
**** READ # OF TIME PERIODS,DISCOUNT RATE, RISK OF DEATH(%), *** 00000420
**** DOSE BY BODY SITE, POPULATION PROJECTION(LOW&HIGH) FROM AMB 00000430
**** PRINT INPUT DATA 00000440
****                                00000450
      READ(IN,651)TITLE 00000460
      651 FORMAT(10A4) 00000470
      READ(IN,1806)RATE 00000480
      READ(IN,1806)VOL 00000490
      READ(IN,856)NT,MZ,NK,NIHT 00000500
      DO 1640 I=1,NIHT 00000510
1640 READ(IN,1651)(SITE(I,J),J=1,5),DPY(I) 00000520
      DO 1650 I=1,MZ 00000530
1650 READ(IN,1652)REG(I),POPH(I),POPL(I) 00000540
1651 FORMAT(5A4,F5.0) 00000550
1652 FORMAT(A4,1X,2F10.0) 00000560
      652 FORMAT(///5X,10A4) 00000570
      WRITE(IP,652)TITLE 00000580
      LL=0 00000590
      READ(IN,653)NG 00000600
      DO 660 I=1,NG 00000610
      READ(IN,653)K,(IKK(J),J=1,K) 00000620
      IG(I)=K 00000630
      DO 665 J=1,K 00000640
      L=LL+J 00000650
1665 IK(L)=IKK(J) 00000660
1660 LL=L 00000670

```

Appendix R. Table R-1 continued

```

653 FORMAT(3X,25I3)                                00000680
      MZP1=MZ+1                                      00000690
      DO 2807 I=1,NIHT                               00000700
2807  DDP(I)=DPY(I)*.26                               00000710
      IF(RATE.EQ.0.)RATE=0.00001                     00000720
      PRATE=RATE*100.                                  00000722
      FOPH(9)=1.                                       00000730
      POPL(9)=1.                                       00000740
      WRITE(IP,2806)PRATE,VOL                          00000750
2806  FORMAT(/5X,'DISCOUNT RATE =',F5.2,' X'/5X,'COST OF INCREASED '
      *,'LEVEL OF RISK OF DEATH = ',F8.0//33X.
      *,'COST OF EXCESS RISK OF DEATH'/7X,'SITE OR TYPE',8X.
      *,'DEATH /MIL. MAN-REM',4X,'S/MAN-REM'/)
      DO 2601 I=1,NIHT                               00000800
2601  WRITE(IP,2607)(SITE(I,J),J=1,5),DPY(I),DDP(I)  00000810
2607  FORMAT(5X,5A4,1X,2F16.1)                      00000820
      WRITE(IP,2608)
2608  FORMAT(/7X,'POPULATION PROJECTIONS'/5X,' ZONE ',5X.
      *,'HIGH',6X,'LOW'/)
      DO 2602 I=1,MZ                                  00000860
2602  WRITE(IP,2609)I,REG(I),FOPH(I),POPL(I)         00000870
2609  FORMAT(5X,11,1X,A4,2F10.0)                    00000880
C***                                                    00000890
C***  READ TIME INTERVALS AND NUCLIDE INVENTORY FROM AMIE *** 00000900
C***                                                    00000910
      READ(5,806)(TIME(I),I=1,NT)                    00000920
      DO 650 K=1,NK                                    00000930
      READ(5,808)NUCNAH(K),(X(K,IT),IT=1,7)           00000940
650  READ(5,809)(X(K,IT),IT=8,NT)                    00000950
C***                                                    00000960
C***  READ MAN1 (AMRAW-A OUTPUT) FROM ECONXX ***         00000970
C***  CALCULATE DAMAGES AND STORE ON DISK ***           00000980
C***                                                    00000990
      THC=.001                                         00001000
      DO 900 IZ=1,MZP1                                00001010
      IF(IZ.EQ.9)THO=1.0                              00001020
      DO 900 K=1,NK                                    00001030
C      WRITE(IP,3806)IZ,K                             00001040
3806  FORMAT('1','IZ=',I1,' K=',I2//)               00001050
      DO 901 IT=1,NT                                   00001060
      DAMAGE(IT)=0.0                                   00001070
      READ(15,806)(MAN1(IT,IH),IH=1,NIHT)             00001080
C      WRITE(IP,806)(MAN1(IT,IH),IH=1,NIHT)           00001090
901  CCNTINUE                                         00001100
      DO 902 IT=1,NT                                   00001110
      DO 902 IH=1,NIHT                                00001120
      I+T=IH                                           00001130
C***                                                    00001140
C***  CHECK IF TOTAL BODY DOSE RATE IS TO BE USED ***   00001150
C***                                                    00001160
      IF(IFLAGH(IH).NE. IH)IHT=I                     00001170
902  DAMAGE(IT)=DAMAGE(IT)+MAN1(IT,IHT)*DDP(IH)*.
      IEXP=(-LAMDA(IHT)*TIME(IT))*THO                 00001180
                                                    00001190

```

Appendix R. Table R-1 continued

INDEX=10*(K-1)+IZ	00001200
900 WRITE(2,INDEX)(DAMAGE(IT),IT=1,NT)	00001210
C***	00001220
C*** CALCULATE AND PRINT TABLES ON ZONAL AND TOTAL DAMAGES ***	00001230
C*** {HIGH & LOW POPULATION PROJECTION -- \$/YEAR } ***	00001240
C*** TABLE - 1	00001250
C***	00001260
WRITE(IP,860)	00001270
NTABLE=1	00001280
WRITE(IP,850)NTABLE,POS(1),(REG(J),J=1,MZ)	00001290
DO 921 IT=1,NT	00001300
DO 921 IR=1,11	00001310
DYRL(IT,IR)=0	00001320
921 DYRH(IT,IR)=0	00001330
DO 906 NTABLE=1,2	00001340
DO 903 IT=1,NT	00001350
DT=0.0	00001360
DT9=0.0	00001370
DO 905 IZ=1,MZP1	00001380
905 DTZ(IZ)=0.0	00001390
DO 904 IZ=1,MZP1	00001400
IF(IT.LE.7)GO TO 903	00001410
DO 904 K=1,NK	00001420
INDEX=10*(K-1)+IZ	00001430
READ(2,INDEX)(DAMAGE(ITE),ITE=1,NT)	00001440
IF(NTABLE.EQ.1)POP=POPH(IZ)	00001450
IF(NTABLE.EQ.2)POP=POPL(IZ)	00001460
DTZ(IZ)=DTZ(IZ)+DAMAGE(IT)*POP	00001470
904 CCNTINUE	00001480
DT=DTZ(1)+DTZ(2)+DTZ(3)+DTZ(4)+DTZ(5)+DTZ(6)+DTZ(7)+DTZ(8)	00001490
DT9=DT+DTZ(9)	00001500
IF(NTABLE.EQ.2)GO TO 917	00001510
DO 1501 IZ=1,MZ	00001520
DYRH(IT,IZ)=DTZ(IZ)	00001530
1501 CCNTINUE	00001540
DYRH(IT,9)=DT	00001550
DYRH(IT,10)=DTZ(9)	00001560
DYPH(IT,11)=DT9	00001570
917 CCNTINUE	00001580
IF(NTABLE.EQ.1)GO TO 903	00001590
DO 1502 IZ=1,MZ	00001600
DYRL(IT,IZ)=DTZ(IZ)	00001610
1502 CCNTINUE	00001620
DYRL(IT,9)=DT	00001630
DYRL(IT,10)=DTZ(9)	00001640
DYRL(IT,11)=DT9	00001650
903 WRITE(IP,851)TIME(IT),(DTZ(IZ),IZ=1,MZ),DT,DTZ(9),DT9	00001660
IF(NTABLE.LT.2)WRITE(IP,860)	00001670
NT2=NTABLE+1	00001680
IF(NTABLE.LT.2)WRITE(IP,850)NT2,POS(2),(REG(J),J=1,MZ)	00001690
906 CCNTINUE	00001700
C***	00001710
C*** 9 DAMAGES BY NUCLIDE AND BY TIME PERIOD ***	00001720

Appendix R. Table R-1 continued

```

C***      SET ITB3 TO 1 TO PRINT, TO 0 TO SUPPRESS PRINT. ***      00001730
C***      TABLE - 2      00001740
C***      00001750
          ITB3=0      00001760
          DC 920 IT=1,NT      00001770
          DO 920 K=1,NK      00001780
          DTL(IT,K)=0      00001790
920      DTH(IT,K)=0      00001800
          DC 907 IT=1,NT      00001810
          IF(IT.LE.7)GO TO 916      00001820
          IF(ITB3.EQ.1)WRITE(IP,860)      00001830
          IF(ITB3.EQ.1)WRITE(IP,861)IT,TIME(IT)      00001840
          IF(ITB3.EQ.1)WRITE(IP,853)      00001850
916      CCNTINUE      00001860
          DO 915 K=1,NK      00001870
          DO 908 I=1,9      00001880
908      DTZ(I)=0.0      00001890
          IF(IT.LE.7)GO TO 907      00001900
          DO 909 IZ=1,MZ      00001910
          INDEX=10*(K-1)+IZ      00001920
          READ(2,INDEX)(DAMAGE(ITE),ITE=1,NT)      00001930
          DTZ(1)=DTZ(1)+DAMAGE(IT)*POPH(IZ)      00001940
909      DTZ(2)=DTZ(2)+DAMAGE(IT)*POPL(IZ)      00001950
          INDEX=10*(K-1)+9      00001960
          READ(2,INDEX)(DAMAGE(ITE),ITE=1,NT)      00001970
          DTZ(3)=DTZ(3)+DAMAGE(IT)*{POPL(9)+POPH(9)}/2.      00001980
          DTZ(4)=DTZ(1)+DTZ(3)      00001990
          DTZ(5)=DTZ(2)+DTZ(3)      00002000
          DTH(IT,K)=DTZ(4)      00002010
          DTL(IT,K)=DTZ(5)      00002020
          IF(ITB3.EQ.1)WRITE(IP,854)NUCNAM(K),(DTZ(I),I=1,5)      00002030
915      CCNTINUE      00002040
907      CCNTINUE      00002050
C***      00002060
C***      DISCOUNTED PRESENT VALUE FOR HIGH & LOW POPULATION BY NUCLIDE *      00002070
C***      TABLE - 3      00002080
C***      00002090
          WRITE(IP,2222)PRATE      00002100
2222      FORMAT('1',5X,'TABLE 3 : DISCOUNTED PRESENT VALUES ( % )' /
          * 16X,'DISCOUNT RATE =' ,F5.2,' %'//
          * 14X,'HIGH POPULATION',9X,'LOW POPULATION' /
          * 1X,'NUCLIDE ',2(3X,'DISCOUNTED',4X,'PV $/GM')//)
          MI=2      00002150
          DO 912 II=1,2      00002160
          DC 911 K=1,NK      00002170
911      PVN(I,K)=0.0      00002180
          DO 913 K=1,NK      00002190
          DC 913 IT=2,NT      00002200
          IF(II.EQ.1)TD=DTH(IT,K)      00002210
          IF(II.EQ.2)TD=DTL(IT,K)      00002220
          Z1=TIME(IT-1)      00002230
          Z2=TIME(IT)      00002240
          IF(RATE.EQ.0.00001)GO TO 914      00002250

```


Appendix R. Table R-1 continued

```

IF(RATE*Z1.GT.15.)GO TO 913
IF(RATE*Z2.GT.15.)GO TO 913
PVN(1,K)=PVN(1,K)+TD*[(1/RATE)*(EXP(RATE
**NYRO))*(EXP(-RATE*Z1))-(EXP(-RATE*Z2)))]
IF(RATE.NE.0.00001)GO TO 913
914 PVN(1,K)=PVN(1,K)+TD*(Z2-Z1)
913 CCONTINUE
DO 10 K=1,NK
ID=IK(K)
NUC2(K)=NUCNAM(ID)
10 FV2(1,K)=PVN(1,ID)
L2=0
DO 20 J=1,NG
ID=IG(J)
L1=L2+1
L2=L2+ID
SS(1,J)=0
DO 20 K=L1,L2
20 SS(1,J)=SS(1,J)+PV2(1,K)
L2=0
DO 1001 J=1,NG
ID=IG(J)
L1=L2+1
L2=L2+ID
DO 1002 K=L1,L2
1002 PV2(M1,K)=PV2(1,K)
1001 SS(M1,J)=SS(1,J)
SPV(1)=0
DO 935 K=1,NK
935 SPV(1)=SPV(1)+PVN(1,K)
SPV(M1)=SPV(1)
M1=M1+1
***
*** DISCOUNTED PRESENT VALUE PER GRAM OF INITIAL WASTE MIX ***
*** FOR HIGH & LOW POPULATION ***
***
DO 910 K=1,NK
910 PVN(1,K)=PVN(1,K)/X(K,7)
DO 30 K=1,NK
ID=IK(K)
NUC2(K)=NUCNAM(ID)
PVN(2,K)=X(ID,7)
30 FV2(1,K)=PVN(1,ID)
L2=0
DO 40 J=1,NG
ID=IG(J)
L1=L2+1
L2=L2+ID
SS(1,J)=0
DO 40 K=L1,L2
40 SS(1,J)=SS(1,J)+PVN(2,K)
M1=M1-1
L2=0

```

Appendix R. Table R-1 continued

DC 1003 J=1,NG	00002790
ID=IG(J)	00002800
L1=L2+1	00002810
L2=L2+ID	00002820
DO 1004 K=L1,L2	00002830
1004 PV2(M1,K)=PV2(1,K)	00002840
1003 SS(M1,J)=SS(M11,J)/SS(1,J)	00002850
SPV(1)=0	00002860
DC 2935 K=1,NK	00002870
2935 SPV(1)=SPV(1)+PVN(2,K)	00002880
SPV(M1)=SPV(M11)/SPV(1)	00002890
M1=M1+1	00002900
912 CCNTINUE	00002910
L2=0	00002920
DO 1014 J=1,NG	00002930
ID=IG(J)	00002940
L1=L2+1	00002950
L2=L2+ID	00002960
DO 1013 K=L1,L2	00002970
1013 WRITE(IP,2855)NUC2(K),PV2(2,K),PV2(4,K)	00002980
2855 FORMAT((1X,A8,1X,1PE12.2,12X,1PE12.2))	00002990
1014 WRITE(IP,1967)(SS(L,J),L=2,5)	00003000
1015 WRITE(IP,967)(SPV(L),L=2,5)	00003010
C***	00003020
C*** # OF DEATHS PER TIME INTERVAL FOR HIGH & LOW POPULATION ***	00003030
C*** TABLE - 4	00003040
C***	00003050
DC 933 I=1,2	00003060
PL=0	00003070
IF(1.EQ.1)WRITE(IP,919)1,POS(1)	00003080
IF(1.EQ.2)WRITE(IP,919)1,POS(2)	00003090
WRITE(IP,918)VOL,(REG(J),J=1,MZ)	00003100
DO 969 IR=1,11	00003110
DLD(IR)=0	00003120
969 TTD(IR)=0	00003130
DC 970 IT=1,NT	00003140
DC 970 IR=1,11	00003150
970 THD(IT,IR)=0	00003160
DC 932 IT=1,NT	00003170
DO 931 IR=1,11	00003180
IF(1.EQ.1)DY=DYRH(IT,IR)	00003190
IF(1.EQ.2)DY=DYRL(IT,IR)	00003200
IF(IT.EQ.1)GO TO 989	00003210
PL=TIME(IT)-TIME(IT-1)	00003220
989 CCNTINUE	00003230
DLD(IR)=(DY/VOL)*(PL)	00003240
931 THD(IT,IR)=DLD(IR)	00003250
932 WRITE(IP,851)TIME(IT),(DLD(IR),IR=1,11)	00003260
DO 955 IR=1,11	00003270
TTD(IR)=0	00003280
DO 955 IT=1,NT	00003290
955 TTD(IR)=TTD(IR)+THD(IT,IR)	00003300
934 WRITE(IP,968)(TTD(IR),IR=1,11)	00003310

Appendix R. Table R-1 continued

```


933 CONTINUE                                00003320
C***                                         00003330
C*** TOTAL UNDISCOUNTED DAMAGES FOR EACH ZONE & FOR EACH TIME *** 00003340
C*** INTERVAL -- FOR HIGH & LOW POPULATION *** 00003350
C*** TABLE - 5 00003360
C***                                         00003370
PL=0                                         00003380
DC 1600 IR=1,11                             00003390
TUDH(IR)=0.                                00003400
TUOL(IR)=0.                                00003410
DC 1600 IT=2,NT                             00003420
PL=TIME(IT)-TIME(IT-1)                     00003430
DYRH(IT,IR)=DYRH(IT,IR)*PL                 00003440
TUDH(IR)=TUDH(IR)+DYRH(IT,IR)              00003450
DYRL(IT,IR)=DYRL(IT,IR)*PL                 00003460
1600 TUDL(IR)=TUDL(IR)+DYRL(IT,IR)          00003470
K1=1                                         00003480
K2=2                                         00003490
WRITE(IP,957)K1,POS(1),(REG(J),J=1,MZ)     00003500
DO 1601 IT=1,NT                             00003510
1601 WRITE(IP,851)TIME(IT),(DYRH(IT,IR),IR=1,11) 00003520
WRITE(IP,968)(TUDH(IR),IR=1,11)            00003530
WRITE(IP,957)K2,POS(2),(REG(J),J=1,MZ)     00003540
DO 1602 IT=1,NT                             00003550
1602 WRITE(IP,851)TIME(IT),(DYRL(IT,IR),IR=1,11) 00003560
WRITE(IP,968)(TUOL(IR),IR=1,11)            00003570
STOP                                         00003580
806 FORMAT(1P8E10.2)                       00003590
1806 FORMAT(15X,F10.0)                      00003600
1807 FORMAT(8F5.0)                          00003610
808 FORMAT(A8,2X,7E10.2)                   00003620
809 FORMAT(10X,7E10.2)                     00003630
850 FORMAT(16,20X,'TABLE 1 - ',11,' : ',    00003640
*'ZCNAL AND TOTAL DAMAGES FOR ',A4,' POP. PROJECTION ($/YR)' 00003650
'//,6X,' TIME',2X,8(A4,6X),'TOT.ZONE',2X,'NON-SPEC',    00003660
*2X,'TTOTAL'//) 00003670
851 FORMAT(F11.0,1P11E10.2)                00003680
853 FORMAT(2X,'NUCLIDE',5X,'HIGH POP',4X,'LOW POP',5X,'NON-SPEC' 00003690
*,4X,'TOT-HIGH',4X,'TOT-LOW') 00003700
854 FORMAT(1X,A8,1X,1P5E12.2)              00003710
857 FORMAT('1',A8,' POPULATION SCENARIO - DISCOUNTED PRESENT ', 00003720
*'VALUE ($)'//, NUCLIDE INTEREST RATES-',F6.3//) 00003730
855 FORMAT(1X,A8,1X,1P7E12.2)              00003740
856 FORMAT(20X,15)                          00003750
860 FORMAT('1')                             00003760
861 FORMAT(10X,'TABLE 2 - ',12,' : ',*TIME PERIOD=',F11.0//) 00003770
918 FORMAT(33X,'NUMBER OF DEATHS PER TIME INTERVAL,(S',F7.0,')' 00003780
'//,6X,' TIME',2X,8(A4,6X),'TOT.ZONE',2X,'NON-SPEC',    00003790
*2X,'TTOTAL'//) 00003800
950 FORMAT(18X,'0X',10X,'1X',10X,'2X',10X,'3X',10X,'4X',10X, 00003810
*'5X',10X,'6X'//) 00003820
919 FORMAT('1',T37,'TABLE 4 - ',11,' : ',A4,' POPULATION SCENARIO') 00003830
967 FORMAT(1X,'TOTAL ',1X,1P7E12.2)         00003840
1967 FORMAT(1X,' SUB TOT',1X,1P7E12.2)      00003850
968 FORMAT(1X,'TOTAL',5X,1P11E10.2)         00003860
957 FORMAT('1',6X,'TABLE 5 - ',11,' : ',*TOTAL UNDISCOUNTED DAMAGES * 00003870
*,*FOR EACH ZONE',1X,*FOR EACH TIME INTERVAL -' 00003880
*,1X,A4,1X,'POPULATION'//,6X,' TIME',2X, 00003890
*8(A4,6X),'TOT.ZONE',2X,'NON-SPEC', 00003900
*2X,'TTOTAL'//) 00003910
END                                           00003920

```

APPENDIX S

FLOWCHART

Figure S-1 shows a simplified flowchart for AMRAW-B. The chart represents flow through the code for a specified waste management phase, such as repository operations or terminal storage. The reader is referred to Volume III, which describes AMRAW-B, for detailed descriptions of each step.



^aThe term "Each Zone" also indicates the sums of all zones, nonspecific, and total of zones and nonspecific.

^bMarginal damages are based upon inventory of each decay chain at beginning of e.g. terminal storage.

Figure S-1. AMRAW-B simplified flowchart.

APPENDIX T

AUXILIARY PROGRAM

An auxiliary program COMPRESS, is used to process dose rate output from AMRAW-A for use as input to AMRAW-B via the file ECONxx. All of the AMRAW-A output tables in Section 3 (Local Dose to Individual) and Section 4 (Nonspecific Dose to Population) comprise the major input to AMRAW-B (Economic Model). COMPRESS, written in PL-1 and Fortran IV language, finds these tables in the full output stored on tape, strips off the headings and left hand column of time, and outputs a continuous "compressed" file in a form ready to be read by AMRAW-B. Appendix P includes samples of AMRAW-A output and the COMPRESS output file.

The COMPRESS output file consists of the calculated value of dose rates (each line is for sequence of organs calculated for a specific time), for each nuclide in the first geographic zone, followed by the same sequence in each of the other zones in turn and finally, by the nonspecific category. The program may be used separately to produce AMRAW-B input files ECONxx from AMRAW-A output (xx identifies the case number), or it may be joined to AMRAW-B to process data directly. Table T-1 is a listing of COMPRESS, including JCL, as run on the IBM360/67 computer at UNM. The first execution step employs PL-1 and the second step employs Fortran IV. It is necessary to specify, in the JCL cards, the name of the tape and label number storing the AMRAW-A output (see line 390), and the name and label for the output file tape or the DSN for the output disk if used instead of tape (see lines 125 and 690).

Table T-1. Listing of COMPRESS

```

100 //A          JOB (B411,L6K,500,20),'HENRY NG'
110 // REGION=256K
120 /*SETUP      9NLHN1619,BD5  2314
121 //DELETE     EXEC PGM=IEHPR08M
122 //SYSPRINT   DD SYSOUT=A
123 //SCT        DD UNIT=2314,VOL=SER=BD5,DISP=SHR
124 //SYSIN      DD *
125             SCRATCH DSN=ECON35,VOL=2314=BD5
126 /*
130 //SQUEEZ EXEC LPL1FCB,CPARM='ST,NEST,NOL',P2=DUMMY
140 //PL1.SYSIN DD *
150 /*  FIND EXTRANEIOUS MATERIAL AND DELETE IT */
160 EXCESS: PROC OPTIONS(MAIN);
170   DCL CRUNCH FILE RECORD OUTPUT;
180   DCL EXTRA FILE RECORD INPUT;
190   DCL DATA CHAR(133) VARYING;
200   DCL SUBSTR BUILTIN;
210   ON ENDFILE (EXTRA) GO TO FINISH;
220       OPEN FILE(CRUNCH);
230       OPEN FILE(EXTRA);
240 /* FIND 'SECTION 3' IN OUTPUT */
250   AGAIN: READ FILE(EXTRA) INTO (DATA);
260   IF SUBSTR(DATA,61,10)I='SECTION 3' THEN GO TO AGAIN;
270   PUT SKIP LIST(DATA);
280 /* FIND 'TIME' IN OUTPUT */
290   TIMER: READ FILE(EXTRA) INTO (DATA);
300   IF SUBSTR(DATA,7,4)I='TIME' THEN GO TO TIMER;
310   DO IN=1 TO 50;
320     READ FILE(EXTRA) INTO (DATA);
330     WRITE FILE(CRUNCH) FROM (DATA);
340   END;
350   GO TO TIMER;
360   FINISH: CLOSE FILE(CRUNCH);
370   CLOSE FILE(EXTRA);
380 END EXCESS;
390 //GO.EXTRA DD UNIT=TAPE9,VOL=SER=HN1619,DSN=EPAJOB,LABEL=(5,SL),
400 // DISP=(OLD,PASS)
410 //GO.CRUNCH DD UNIT=SYSW,DSN=22&SQUEEZE,DISP=(NEW,PASS),
420 // DCB=(RECFM=FB,LRECL=133,BLKSIZE=6650),SPACE=(CYL,(1,1),RLSE)
430 //REVAMP EXEC LFORTGCB,LPARM='SIZE=225K'
440 //FORT.SYSIN DD *
450   DIMENSION RDATA(50,8)
460   DO 10 IZ=1,9
470     DO 10 NUC=1,25
480     DO 10 IT=1,50
490     READ(1,100)(RDATA(IT,IORGN),IORGN=1,8)
495     WRITE(2,200)(RDATA(IT,IORGN),IORGN=1,8)
497   10 CONTINUE
500   100 FORMAT(11X,1P8E10.2)
510   200 FORMAT(1P8E10.2)
650   ENDFILE 2
660   REWIND 2
670   STOP
680 //GO.FT01F001 DD UNIT=SYSW,DSN=22&SQUEEZE,DISP=(OLD,DELETE)
690 //GO.FT02F001 DD UNIT=2314,VOL=SER=BD5,DSN=ECON35,DISP=(NEW,KEEP),
700 // DCB=(RECFM=FB,LRECL=80,BLKSIZE=7200),SPACE=(CYL,(5,2),RLSE)
710 //
720 /*

```