

Superfund



Guidance for Data Useability in Risk Assessment (Part A)

Final



Guidance for Data Useability in Risk Assessment (Part A)

Final

Notice: Guidance for Radioanalytical
Data Useability in Risk Assessment is
Given in Part B

Office of Emergency and Remedial Response
U.S. Environmental Protection Agency
Washington, DC 20460

NOTICE

The policies and procedures set forth here are intended as guidance to U.S. Environmental Protection Agency and other government employees. They do not constitute rulemaking by the Agency, and may not be relied on to create a substantive or procedural right enforceable by any other person. The U.S. Environmental Protection Agency may take action that is at variance with the policies and procedures in this guidance and may change them at any time without public notice.

Copies of the guidance can be obtained from:

National Technical Information Service
5285 Port Royal Road
Springfield, VA 22161
Phone: 703-487-4650

Contents

CHAPTER 1 INTRODUCTION AND BACKGROUND	1
1.1 CRITICAL DATA QUALITY ISSUES IN RISK ASSESSMENT	1
1.1.1 Data Sources	2
1.1.2 Detection Limits	2
1.1.3 Qualified Data	2
1.1.4 Background Samples	2
1.1.5 Consistency in Data Collection	2
1.2 FRAMEWORK AND ORGANIZATION OF THE GUIDANCE	3
CHAPTER 2 THE RISK ASSESSMENT PROCESS	7
2.1 OVERVIEW OF BASELINE HUMAN HEALTH RISK ASSESSMENT AND THE EVALUATION OF UNCERTAINTY	7
2.1.1 Data Collection and Evaluation	11
2.1.2 Exposure Assessment	13
2.1.3 Toxicity Assessment	15
2.1.4 Risk Characterization	17
2.2 ROLES AND RESPONSIBILITIES OF KEY RISK ASSESSMENT PERSONNEL	18
2.2.1 Project Coordination	18
2.2.2 Gathering Existing Site Data and Developing the Conceptual Model	18
2.2.3 Project Scoping	18
2.2.4 Quality Assurance Document Preparation and Review	20
2.2.5 Budgeting and Scheduling	21
2.2.6 Iterative Communication	21
2.2.7 Data Assessment	22
2.2.8 Assessment and Presentation of Environmental Analytical Data	23
CHAPTER 3 USEABILITY CRITERIA FOR BASELINE RISK ASSESSMENTS	25
3.1 DATA USEABILITY CRITERIA	26
3.1.1 Data Sources	26
3.1.2 Documentation	29
3.1.3 Analytical Methods and Detection Limits	30
3.1.4 Data Quality Indicators	31
3.1.5 Data Review	34
3.1.6 Reports from Sampling and Analysis to the Risk Assessor	36
3.2 PRELIMINARY SAMPLING AND ANALYTICAL ISSUES	37
3.2.1 Chemicals of Potential Concern	40
3.2.2 Tentatively Identified Compounds	41
3.2.3 Identification and Quantitation	45
3.2.4 Detection and Quantitation Limits and Range of Linearity	47
3.2.5 Sampling and Analytical Variability Versus Measurement Error	50
3.2.6 Sample Preparation and Sample Preservation	54
3.2.7 Identification of Exposure Pathways	55
3.2.8 Use of Judgmental or Purposive Sampling Design	55

Contents

(cont'd)

3.2.9	Field Analyses Versus Fixed Laboratory Analyses	57
3.2.10	Laboratory Performance Problems	58
CHAPTER 4 STEPS FOR PLANNING FOR THE ACQUISITION OF USEABLE ENVIRONMENTAL DATA IN BASELINE RISK ASSESSMENTS		63
4.1	STRATEGIES FOR DESIGNING SAMPLING PLANS	63
4.1.1	Completing the Sampling Design Selection Worksheet	65
4.1.2	Guidance for Completing the Sampling Design Selection Worksheet	72
4.1.3	Specific Sampling Issues	76
4.1.4	Soil Depth Issues	78
4.1.5	Balancing Issues for Decision-Making	80
4.1.6	Documenting Sampling Design Decisions	81
4.2	STRATEGY FOR SELECTING ANALYTICAL METHODS	81
4.2.1	Completing the Method Selection Worksheet	83
4.2.2	Evaluating the Appropriateness of Routine Methods	84
4.2.3	Developing Alternatives When Routine Methods are not Available	87
4.2.4	Selecting Analytical Laboratories	87
4.2.5	Writing the Analysis Request	88
4.3	BALANCING ISSUES FOR DECISION-MAKING	88
CHAPTER 5 ASSESSMENT OF ENVIRONMENTAL DATA FOR USEABILITY IN BASELINE RISK ASSESSMENTS		95
5.1	ASSESSMENT OF CRITERION I: REPORTS TO RISK ASSESSOR	100
5.1.1	Preliminary Reports	100
5.1.2	Final Report	100
5.2	ASSESSMENT OF CRITERION II: DOCUMENTATION	101
5.3	ASSESSMENT OF CRITERION III: DATA SOURCES	101
5.4	ASSESSMENT OF CRITERION IV: ANALYTICAL METHOD AND DETECTION LIMIT	102
5.5	ASSESSMENT OF CRITERION V: DATA REVIEW	102
5.6	ASSESSMENT OF CRITERION VI: DATA QUALITY INDICATORS	103
5.6.1	Assessment of Sampling and Analytical Data Quality Indicators	105
5.6.2	Combining the Assessment of Sampling and Analysis	114
CHAPTER 6 APPLICATION OF DATA TO RISK ASSESSMENTS		117
6.1	ASSESSMENT OF THE LEVEL OF CERTAINTY ASSOCIATED WITH THE ANALYTICAL DATA	117
6.1.1	What Contamination is Present and at What Levels?	117
6.1.2	Are Site Concentrations Sufficiently Different from Background?	119
6.1.3	Are All Exposure Pathways and Areas Identified and Examined?	120
6.1.4	Are All Exposure Areas Fully Characterized?	120
6.2	ASSESSMENT OF UNCERTAINTY ASSOCIATED WITH THE BASELINE RISK ASSESSMENT FOR HUMAN HEALTH	121

Contents

(cont'd)

APPENDICES

I.	DESCRIPTION OF ORGANICS AND INORGANICS DATA REVIEW PACKAGES	125
II.	LISTING OF COMMON POLLUTANTS GENERATED BY SEVEN INDUSTRIES	153
III.	LISTING OF ANALYTES, METHODS, AND DETECTION OR QUANTITATION LIMITS FOR POLLUTANTS OF CONCERN TO RISK ASSESSMENT	167
IV.	CALCULATION FORMULAS FOR STATISTICAL EVALUATION	235
V.	"J" DATA QUALIFIER SOURCE AND MEANING	239
VI.	"R" DATA QUALIFIER SOURCE AND MEANING	245
VII.	SUMMARY OF COMMON LABORATORY CONTAMINANTS, CONCENTRATION REQUIRE- MENTS, AND RISK ASSESSMENT IMPLICATIONS	249
VIII.	CLP ANALYTICAL METHODS SHORT SHEETS AND TCL COMPOUNDS	253
IX.	EXAMPLE DIAGRAM FOR A CONCEPTUAL MODEL FOR RISK ASSESSMENT	263

Exhibits

1	Data Useability Criteria to Plan Sampling, Analysis and Assessment Efforts in Baseline Risk Assessment	3
2	Organization of the Guidance	5
3	Data Relevant to Components of the Risk Assessment Process	8
4	Baseline Risk Assessment Process and Typical Sources of Uncertainty	9
5	Range of Uncertainty of Risk Assessment	10
6	Development of Conceptual Site Model	12
7	Generic Equation for Calculating Chemical Intakes	16
8	Roles and Responsibilities of Risk Assessment Team Members	19
9	Example Risk Assessment Checklist for Use in Scoping	20
10	Checklist for Reviewing the Workplan	21
11	Checklist for Reviewing the Sampling and Analysis Plan	22
12	Importance of Data Useability Criteria in Planning for Baseline Risk Assessment	26
13	Data Sources and Their Use in Risk Assessment	28
14	Relative Importance of Documentation in Planning and Assessment	30
15	Relevance of Sampling Data Quality Indicators	31
16	Relevance of Analytical Data Quality Indicators	32
17	Alternative Levels of Review of Analytical Data	34
18	Automated Systems to Support Data Review	35
19	Data and Documentation Needed for Risk Assessment	36
20	Importance of Sampling Issues in Risk Assessment	38
21	Sampling Variability and Measurement Error	39
22	Importance of Analytical Issues in Risk Assessment	40
23	Median Coefficient of Variation for Chemicals of Potential Concern	42
24	Munitions Compounds and Their Detection Limits	43
25	Summary of Most Frequently Occurring Chemicals of Potential Concern by Industry	44
26	Steps in the Assessment of Tentatively Identified Compounds	45
27	Requirements for Confident Identification and Quantitation	45
28	Relative Impacts of Detection Limit and Concentration of Concern: Data Planning	46
29	The Relationship of Instrument Calibration Curve and Analyte Detection	48
30	Example of Detection Limit Calculation	49
31	Measurement of Variation and Bias Using Field Quality Control Samples	51
32	Sampling Issues Affecting Confidence in Analytical Results	52
33	Sources of Uncertainty that Frequently Affect Confidence in Analytical Results	53
34	Sample Preparation Issues	54
35	Information Available from Different Sampling Techniques	54
36	Comparison of Sample Preparation Options	56
37	Identification of Exposure Pathways Prior to Sampling Design is Critical to Risk Assessment	57
38	Strengths and Weaknesses of Biased and Unbiased Sampling Designs	58
39	Characteristics of Field and Fixed Laboratory Analyses	59
40	Strengths and Weaknesses of Field and Fixed Laboratory Analyses	60
41	Examples of Spatially and Temporally Dependent Variables	64
42	Examples of Sampling Designs	65

Exhibits

(cont'd)

43	Applicability of Sampling Designs	66
44	Common Sampling Designs	67
45	Hierarchical Structure of Sampling Design Selection Worksheet	68
46	Factors in Determining Total Number of Samples Collected	72
47	Relationships Between Measures of Statistical Performance and Number of Samples Required	73
48	Number of Samples Required to Achieve Given Levels of Confidence, Power and MDRD	76
49	Confidence Levels for the Assessment of Measurement Variability	77
50	Soil Depth Sampling Worksheet	79
51	Automated Systems to Support Environmental Sampling	81
52	Method Selection Worksheet	82
53	Automated Systems to Support Method Selection	84
54	Common Laboratory Contaminants and Interferences by Organic Analyte	85
55	Common Laboratory Contaminants and Interferences by Inorganic Analyte	86
56	Comparison of Analytical Options for Organic Analytes in Water	90
57	Comparison of Analytical Options for Organic Analytes in Soil	91
58	Comparison of Analytical Options for Inorganic Analytes in Water and Soil	92
59	Comparison of Analytical Options for Organic and Inorganic Analytes in Air	93
60	Data Useability Assessment of Criteria	95
61	Minimum Requirements, Impact if Not Met, and Corrective Actions for Data Useability Criteria	96
62	Corrective Action Options When Data Do Not Meet Performance Objectives	97
63	Data Useability Worksheet	98
64	Relative Importance of Detection Limit and Concentration of Concern: Data Assessment	103
65	Consequences of Alternative Sampling Strategies on Total Error Estimate	104
66	Use of Quality Control Data for Risk Assessment	105
67	Steps to Assess Sampling Performance	110
68	Recommended Minimum Statistical Performance Parameters for Risk Assessment	111
69	Basic Model for Estimating Total Variability Across Sampling and Analysis Components	114
70	Combining Data Quality Indicators From Sampling and Analysis into a Single Assessment of Uncertainty ...	115
71	Data Useability Criteria Affecting Contamination Presence	118
72	Data Useability Criteria Affecting Background Level Comparison	119
73	Data Useability Criteria Affecting Exposure Pathway and Exposure Area Examination	120
74	Data Useability Criteria Affecting Exposure Area Characterization	121
75	Uncertainty in Data Collection and Evaluation Decisions Affects the Certainty of the Risk Assessment	122

Tips*

- The analytical data objective for baseline risk assessments is that uncertainty is known and acceptable, not that uncertainty be reduced to a particular level. (p. 3)
- To maximize data useability for the risk assessment, the risk assessor must be involved from the start of the RI. (p. 7)
- All data can be used in the baseline risk assessment as long as their uncertainties are clearly described. (p. 11)
- Uncertainty in the analytical data, compounded by uncertainty caused by the selection of the transport models, can yield results that are meaningless or that cannot be interpreted. (p. 14)
- Uncertainties in toxicological measures and exposure assessment are often assumed to be greater than uncertainties in environmental analytical data; thus, they are assumed to have a more significant effect on the uncertainty of the risk assessment. (p. 17)
- Analytical data collected solely for other purposes may not be of optimal use to the risk assessment. (p. 20)
- Effective planning improves the useability of environmental analytical data in the final risk assessment. (p. 25)
- Use historical analytical data and a broad spectrum analysis to initially identify the chemicals of potential concern or exposure areas. (p. 26)
- To expedite the risk assessment, preliminary data should be provided to the risk assessor as soon as they are available. (p. 35)
- To protect human health, place a higher priority on preventing false negatives in sampling and analysis than on preventing false positives. (p. 41)
- Use preliminary data to identify chemicals of potential concern and to determine any need to modify the sampling or analytical design. (p. 41)
- Specific analysis for compounds identified during library search can be requested. (p. 41)
- The closer the concentration of concern is to the detection limit, the greater the possibility of false negatives and false positives. (p. 47)
- The wide range of chemical concentrations in the environment may require multiple analyses or dilutions to obtain useable data. Request results from all analyses. (p. 47)
- Define the type of detection or quantitation limit for reporting purposes; request the sample quantitation limit for risk assessment. (p. 47)
- When contaminant levels in a medium vary widely, increase the number of samples or stratify the medium to reduce variability. (p. 50)
- Sampling variability typically contributes much more to total error than analytical variability. (p. 50)
- Field methods can produce legally defensible data if appropriate method QC is available and if documentation is adequate. (p. 57)
- To minimize the potential for false negatives, obtain data from a broad spectrum analysis from each medium and exposure pathway. (p. 58)
- The CLP or other fixed laboratory sources are most appropriate for broad spectrum analysis or for confirmatory analysis. (p. 58)
- Solicit the advice of the chemist to ensure proper laboratory selection and to minimize laboratory and/or methods performance problems that occur in sample analysis. (p. 58)
- Use of the Sampling Design Selection Worksheet will help the RPM or statistician determine an appropriate sampling design. (p. 65)

* For further information, refer to the text. Page numbers are provided.

Tips (cont'd)

- While other designs may be appropriate in many cases, stratified random or systematic sampling designs are always acceptable. (p. 65)
- If the natural variability of the chemicals of potential concern is large (e.g., greater than 30%), the major planning effort should be to collect more environmental samples. (p. 72)
- At least one broad spectrum analytical sample is required for risk assessment, and a minimum of two or three are recommended for each medium in an exposure pathway. (p. 73)
- Collect and analyze background samples prior to the final determination of the sampling design since the number of samples is significantly reduced if little background contamination is present. (p. 75)
- Systematic sampling supplemented by judgmental sampling is the best strategy for identifying hot spots. (p. 75)
- Focus planning efforts on maximizing the collection of useable data from critical samples. (p. 78)
- The ability to combine data from different sampling episodes or different sampling procedures is a very important consideration in selecting a sampling design but should be done with caution. (p. 78)
- Ensure that critical requirements and priorities are specified on the Method Selection Worksheet so that the most appropriate methods can be considered. (p. 83)
- Use routine methods wherever possible since method development is time-consuming and may result in problems with laboratory implementation. (p. 83)
- Analyte-specific methods that provide better quantitation can be considered for use once chemicals of potential concern have been identified by broad spectrum analysis. (p. 84)
- All results should be reported for samples analyzed at more than one dilution. (p. 85)
- Field analysis can be used to decrease cost and turnaround time providing data from a broad spectrum analysis are available. (p. 89)
- Focus corrective action on maximizing the useability of data from critical samples. (p. 97)
- Use preliminary data as a basis for identifying sampling or analysis deficiencies and taking corrective action. (p. 100)
- Problems in data useability due to sampling can affect all chemicals involved in the risk assessment; problems due to analysis may only affect specific chemicals. (p. 100)
- Qualified data can usually be used for quantitative risk assessments. (p. 105)
- Anticipate the need to combine data from different sampling events and/or different analytical methods. (p. 107)
- Determine the distribution of the data before applying statistical measures. (p. 109)
- Determine the statistical measures of performance most applicable to site conditions before assessing data useability. (p. 110)
- Use data qualified as U or J for risk assessment purposes. (p. 113)
- The major concern with false negatives is that the decision based on the risk assessment may not be protective of human health. (p. 117)
- False negatives can occur if sampling is not representative, if detection limits are above concentrations of concern, or if spike recoveries are very low. (p. 117)
- False positives can occur when blanks are contaminated or spike recoveries are very high. (p. 118)
- Statistical analysis may determine if site concentrations are significantly above background concentrations when the differences are not obvious. (p. 120)
- The primary planning objective is that uncertainty levels are acceptable, known and quantifiable, not that uncertainty be eliminated. (p. 121)

PREFACE

The U.S. Environmental Protection Agency (EPA) has established a Data Useability Workgroup to develop national guidance for determining data useability requirements needed for environmental data collection on hazardous waste sites under the Comprehensive Environmental Response, Compensation, and Liability Act of 1980 (CERCLA) as amended by the Superfund Amendments and Reauthorization Act of 1986 (SARA). Data useability is the process of assuring or determining that the quality of data generated meets the intended use. This guidance has been designed by the Risk Assessment Subgroup of the Data Useability Workgroup to provide data users with a nationally consistent basis for making decisions about the minimum quality and quantity of environmental analytical data that are sufficient to support Superfund risk assessment decisions, regardless of which parties conduct the investigation. This document is the first part (Part A) of the two-part *Guidance for Data Useability in Risk Assessment*. Part B of this guidance addresses radioanalytical issues.

Risk Assessment Guidance for Superfund (RAGS), Volume I: Human Health Evaluation Manual, Part A (EPA 1989a) serves as a general guidance document for the risk assessment process. Building upon RAGS, an "interim final" version of *Guidance for Data Useability in Risk Assessment* was issued by the Risk Assessment Subgroup of the Data Useability Workgroup in October 1990. The guidance was issued as "interim final" in order to obtain and incorporate comments and criticisms from data users who tested it in real-world situations.

The authors acknowledge the significant help of all who have provided comments and criticisms. The results indicate that many people react favorably to the guidance and find it useful in planning a risk assessment or in evaluating assessments already underway. Issues were identified where guidance in the interim final needed to be supplemented or discussed in more detail. These issues include providing a more detailed discussion of sampling strategies, incorporating groundwater factors, addressing soil depth for exposure, and obtaining background data. Issues concerning data reporting formats, validation and use of non-CLP data, and tentatively identified compounds were also identified. The final version of the guidance provides greater detail in the discussion of these and other issues.

This guidance provides direction for planning and assessing analytical data collection activities for the baseline human health risk assessment, conducted as part of the remedial investigation (RI) process. Although the guidance addresses the baseline risk assessment within the RI, it is appropriate for use in the new Superfund Accelerated Cleanup Model (SACM) where data needs for risk assessment are considered at the onset of site evaluation. Site-

specific conditions may often require sampling or analysis beyond the basic recommendations given in this guidance. The guidance does not directly address the use of ecological data for purposes other than baseline risk assessments for human health, although some considerations have been included when data may be used for both ecological and human health evaluation.

This guidance complements guidance provided in RAGS (EPA 1989a), *Guidance for Conducting Remedial Investigations and Feasibility Studies Under CERCLA* (EPA 1988a), and *Data Quality Objectives for Remedial Response Activities: Development Process* (EPA 1987a). RAGS provides the framework for making data quality assessments in baseline risk assessments, and this guidance supplements and strengthens important technical details of the framework by providing direction on minimum requirements for environmental analytical data used in baseline risk assessments. As such, it complements and builds upon Agency guidance for the development and use of data quality objectives in all data collection activities.

This guidance is addressed primarily to the remedial project managers (RPMs) who have the principal responsibility for leading the data collection and assessment activities that support the human health risk assessment and, secondarily, to risk assessors who must effectively communicate their data needs to the RPMs and use the data provided to them. Chemists, quality assurance specialists, statisticians, hydrogeologists and other technical experts involved in the RI process can use this guidance to optimize the useability of data collected in the RI for use in baseline risk assessments.

Comments on the guidance should be sent to:

Toxics Integration Branch
Office of Emergency and Remedial Response
401 M Street, SW (OS-230)
Washington, DC 20460
Phone: 202-260-9486

ACKNOWLEDGEMENTS

This guidance was developed by an EPA workgroup with membership from EPA Headquarters, EPA Regional offices and representatives of the contractor community. The EPA Risk Assessment Subgroup of the Data Useability Workgroup provided valuable input regarding the content, approach and organization of the guidance. Members of the Risk Assessment Subgroup, responsible for generating this guidance, have experience in human health risk assessment, remedial project management, chemistry, toxicology, hydrogeology, and quality assurance. Technical review was provided by toxicologists, chemists, quality assurance specialists, engineers, project managers, and statisticians from both EPA and contractor staff.

Leadership for development of the "interim final" version of this guidance was provided by Data Useability Workgroup Region III Co-chairpersons Chuck Sands [currently at the Analytical Operations Branch (AOB)] and Claudia Walters, and Ruth Bleyler of the Toxics Integration Branch (TIB).

Leadership for development of the "final" version of this guidance was provided by Ruth Bleyler and Lisa Matthews of TIB and Chuck Sands of AOB. We wish to acknowledge Region V and Region VI for their assistance with the implementation effort for the final version of the guidance.

Members of the Risk Assessment Subgroup include:

Ruth Bleyler	Toxics Integration Branch
Richard Brunker	USEPA Region III
Rex Bryan	Viar & Company
Matt Charsky	Office of Waste Programs Enforcement
Skip Ellis	CH2M HILL
Gwen Hooten	USEPA Region VIII
Dawn Ioven	USEPA Region III
Peter Isaacson	Viar & Company
Cindy Kaleri	USEPA Region VI
Jim LaVelle	USEPA Region VIII
Jim Luey	USEPA Region VIII
Jon Rauscher	USEPA Region VI
Chuck Sands	Analytical Operations Branch
Robin Smith	CH2M HILL
Pat Van Leeuwen	USEPA Region V
Chris Weis	USEPA Region VIII
Leigh Woodruff	USEPA Region X

Additional Workgroup participation includes:

Wayne Berman	ICF
Ann Marie Burke	USEPA Region I
Dorothy Campbell	USEPA Region VIII
Judy Hsieh	USEPA Region I
Mark Moese	Ebasco
Sheila Sullivan	USEPA Region V
Hans Waetjen	Office of Waste Programs Enforcement

Chapter 1

Introduction and Background

This guidance was developed by the U.S. Environmental Protection Agency (EPA) for remedial project managers (RPMs), risk assessors, and contractors. It is published in two parts; this document is Part A. Part B solely addresses useability issues in radioanalytical sampling and analysis for risk assessment. Both parts of this guidance are designed to assist RPMs in maximizing the useability of environmental analytical data collected in the remedial investigation (RI) process for baseline human health risk assessments. Since RPMs, with assistance from technical experts, oversee the preparation of workplans and sampling and analysis plans for RI data collection, it is important for them to understand the types, quality and quantity of data needed by risk assessors, and the impact that their data collection decisions have on the level of certainty of baseline risk assessments for human health. This guidance provides detailed approaches and basic recommendations for both obtaining and interpreting data for risk assessment that specifically address:

- How to design RI sampling and analytical activities that meet the data quantity and data quality needs of risk assessors,
- Procedures for assessing the quality of the data obtained in the RI,
- Options for combining environmental analytical data of varying levels of quality from different sources and incorporating them into the risk assessment,
- Procedures for determining the level of certainty in the risk assessment based on the uncertainty in the environmental analytical data, and
- Guidelines on the timing and execution of the various activities in order to most efficiently produce deliverables.

Although the guidance addresses the baseline risk assessment within the RI, it is appropriate for use in the new Superfund Accelerated Cleanup Model (SACM) where data needs for risk assessment are considered at the onset of site evaluation.

Risk assessors should be an integral part of the RI planning process to ensure that adequate environmental analytical data of acceptable quality and quantity for the risk assessment are collected during the RI. This guidance assists risk assessors in communicating their environmental analytical data needs to the RPMs. Risk assessors should work closely with the RPMs to identify

and recommend sampling designs and analytical methods that will maximize the quality of the baseline risk assessment for human health within the site-related and budgetary constraints of the RI, and will produce consistent risk assessments useful to risk managers.

This guidance provides a number of worksheets and exhibits that can be used as bases for the organization of sampling or analytical planning or assessment processes. However, implementation of guidance will be site-specific, and site personnel should develop and modify these guidance materials to best suit the conditions at their site.

Although ecological data useability is not addressed specifically in this guidance, the chemical data obtained from site characterization are useable for certain elements of the ecological assessment. In an ecological assessment, the chemicals of potential concern and their priorities may be different than those of the human health risk assessment. For example, iron is rarely of concern in human health risk assessments, but high levels of iron may pose a threat to aquatic species. Ecoguidance documents relevant to risk assessment include *Risk Assessment Guidance for Superfund, Volume II: Environmental Evaluation Manual* (EPA 1989b), *ECO Update* (EPA 1991a) and *Ecological Assessment of Hazardous Waste Sites: A Field and Laboratory Reference* (EPA 1989c).

1.1 CRITICAL DATA QUALITY ISSUES IN RISK ASSESSMENT

Five basic environmental data quality issues are frequently encountered in risk assessments. This guidance provides procedures, minimum requirements, and other information to resolve or minimize the effect of these issues on the assessment of uncertainty in the risk assessment. The issues affect both the planning for and the assessment of analytical data for use in RI risk assessments. The following sections describe these issues and their impact on data useability, and highlight the resolutions of these issues.

Acronyms

CLP	Contract Laboratory Program
EPA	U.S. Environmental Protection Agency
QAPjP	quality assurance project plan
RAGS	Risk Assessment Guidance for Superfund
RI	remedial investigation
RPM	remedial project manager
SACM	Superfund Accelerated Cleanup Model

1.1.1 Data Sources

Data users must select sampling and analytical procedures and providers appropriate to the data needs of each risk assessment. Practical tradeoffs among detection limits, response time, documentation, analytical costs, and level of uncertainty should be considered prior to selecting sampling designs, analytical methods, and service providers.

The Contract Laboratory Program (CLP) has been the principal source of analytical data for investigations at hazardous waste sites. The CLP requires adherence to specific data acceptance criteria which results in data of known analytical quality produced in a standardized package. Another principal source of analytical data is the EPA Regional laboratory, which often produces data similar in quality to that of the CLP. Other analytical sources, such as field analysis or fixed laboratories (EPA, state, or private), can also produce data of acceptable quality. Accordingly, RPMs and risk assessors should seek the source of data that best meets the data quality needs of the risk assessment. Section 4.2 provides guidance for selecting analytical sources.

Field analytical data have been used primarily to aid in making decisions during sampling. However, recent advances in technology, when accompanied by sufficient and appropriate quality control measures, allow field analytical data to be used in risk assessments with more frequency and more confidence than in the past. By using field analyses, RPMs can increase the number of samples to better characterize the site and significantly decrease sample turnaround time (to provide real-time decision-making in the field) as long as acceptable data quality is maintained. Guidance for assessing the useability and applicability of field analytical data in the risk assessment process is also provided in Section 4.2.

For any source of monitoring data, RPMs must ensure that data quality objectives, analytical methods, quality control requirements and criteria, level of documentation, and degree and assignment of responsibilities for quality assurance oversight are clearly documented in the quality assurance project plan (QAPjP). In addition, the RPM is responsible for the enforcement of these parameters. For non-Superfund-lead analyses, the potentially responsible party, state, or federal agency determines and documents these parameters. The QAPjP is then submitted to the RPM for review. In all cases involving risk assessment, the RPM should always seek the source of data that best meets the data quality needs of the risk assessor. The data source chosen must generate data of known quality.

1.1.2 Detection Limits

Selecting the analytical method to meet the required detection limits is fundamental to the useability of analytical data in risk assessments. In addition, the type of detection limit, such as method detection limit or sample quantitation limit, used in making data quality decisions affects the certainty of the risk assessment. Guidance for making these decisions is provided in Section 4.2. Preliminary remediation goals, as defined in *Risk Assessment Guidance for Superfund (RAGS) Volume I: Human Health Evaluation Manual, Part B* (EPA 1991b), provide criteria to be considered in evaluating the adequacy of detection limits.

1.1.3 Qualified Data

Laboratories, and individuals conducting independent data review, affix coded qualifiers to data when quality control requirements or other evaluation criteria are not met. Data reviewers assess these and many other criteria to determine the useability of data. Qualified data must be used appropriately in risk assessments. Data are almost always useable in the risk assessment process, as long as the uncertainty in the data and its impact on the risk assessment are thoroughly explained. Section 5.6 describes procedures for incorporating qualified data and data of varying analytical quality into the risk assessment.

1.1.4 Background Samples

In conducting a risk assessment, it is critical to distinguish site contamination from background levels due to anthropogenic or naturally occurring contamination in order to determine the presence or absence of contamination and to compare with background risk. Analytical data reported near method detection limits and sample results qualified during data review complicate the use of background sample data to determine site contamination. Planning for the collection of a sufficient number of background samples from representative locations increases the certainty in decisions about the significance of site contamination. Section 4.1 discusses how statistical analysis and professional judgment can be combined to design a sampling program for collecting adequate background data.

1.1.5 Consistency in Data Collection

Data collection activities may vary among parties conducting RIs. Consistency in all Superfund activities is increasingly crucial. All parties collecting

environmental analytical data for baseline risk assessments for human health should use guidance provided in *Risk Assessment Guidance for Superfund (RAGS) Volume I: Human Health Evaluation Manual, Part A* (EPA 1989a) and this guidance to ensure that baseline risk assessments for human health are conducted consistently and are protective of the public health.

1.2 FRAMEWORK AND ORGANIZATION OF THE GUIDANCE

This guidance is organized following the usual sequence used to determine the useability of environmental analytical data for baseline human health risk assessments. Exhibit 1 illustrates the conceptual framework for the guidance. Six criteria are used to evaluate data useability for baseline risk assessments for human health:

- Data sources,
- Documentation,
- Available analytical services in terms of analytical methods and detection limits,

- Data quality indicators,
- Data review, and
- Reports to risk assessor.

These criteria address the five major data quality issues described in Section 1.1 and other issues that impact data useability in the risk assessment. The data useability criteria are applied in RI planning to guide the design of sampling plans and select analytical methods for the data collection effort. The criteria are employed again to assess the useability of the analytical data collected during the RI, and of data from other studies and sources, such as site inspections. This guidance also describes how to determine the uncertainties in the risk assessment based on the level of uncertainty of the environmental analytical data, determined using the data useability criteria.

• *The analytical data objective for baseline risk assessments is that the uncertainty is known and acceptable, not that the uncertainty be reduced to a particular level.*

EXHIBIT 1. DATA USEABILITY CRITERIA TO PLAN SAMPLING, ANALYSIS AND ASSESSMENT EFFORTS IN BASELINE RISK ASSESSMENT




Exhibit 2 summarizes the purpose of each chapter of this guidance and highlights how the chapters can best assist RPMs and risk assessors. Worksheets, assessment tables, and other aids are used extensively throughout the guidance. These are tools that can be used "as is," or they can be modified for use or used as the basis for site-specific worksheets or summaries. Chapter contents are summarized below.

- **Chapter 2—The Risk Assessment Process:** This chapter explains the purpose and objectives of a baseline human health risk assessment and describes the four basic elements of a risk assessment: data collection and evaluation, exposure assessment, toxicity assessment, and risk characterization. The chapter discusses the uncertainties associated with the risk assessment process and emphasizes the impact of analytical data quality on each element. The roles and responsibilities of the RPM, the risk assessor, and others involved in planning and conducting data collection activities to support the risk assessment are described.
- **Chapter 3—Useability Criteria for Baseline Risk Assessments:** Six criteria are defined in this chapter for interpreting the importance of sample collection, analytical techniques, and data review procedures to the useability of analytical data in risk assessments. The sampling and analytical issues that need to be addressed in using these criteria are discussed. The chapter stresses the need to consider and plan for risk assessment data requirements in the early design stages of the RI.
- **Chapter 4—Steps for Planning for the Acquisition of Useable Environmental Data in Baseline Risk Assessments:** This chapter provides explicit guidance for designing sampling plans and selecting analytical methods based on the data quality requirements of baseline risk assessments. Worksheets for sampling design selection, soil depth sampling, and method selection are provided as part of the step-by-step guidance for making data collection decisions for individual sites.
- **Chapter 5—Assessment of Environmental Data for Useability in Baseline Risk Assessments:** This chapter explains how to assess the useability of site-specific data for risk assessments after data collection according to the six criteria defined in Chapter 3. For each assessment criterion, the chapter defines minimum data requirements and explains how to determine actual performance compared to performance objectives and execute appropriate corrective actions for data critical to the risk assessment. The chapter also describes options available to risk assessors for incorporating analytical data from different sources and varying levels of quality into the baseline risk assessment.
- **Chapter 6—Application of Data to Risk Assessments:** This chapter details procedures for determining the overall level of uncertainty associated with the risk assessment. The discussion addresses characterization of contaminant concentrations within exposure areas, determining the presence or absence of chemicals of potential concern, and distinguishing site contamination from background levels.
- **Appendices—**The appendices provide analytical and sampling technical reference materials, including descriptions of generic organic and inorganic data review packages; listings of common industrial pollutants; analytical methods and detection or quantitation limits (see Section 3.2.4 for definitions); common laboratory contaminants; calculation formulas for statistical evaluation; information on analytical data qualifiers; a summary of Contract Laboratory Program methods with corresponding Target Compound List compounds and Target Analyte List analytes; and an example of a conceptual site model.
- **Index—**The index provides cross-references throughout the guidance. This is important because Chapters 3, 4, and 5 present planning and assessment issues as complementary discussions that can be viewed independently.
- **Tips—**Tips, marked with a ♦, are incorporated into the text of the chapters. These tips draw attention to key issues in the text but are not intended to summarize the discussion in the chapter.

EXHIBIT 2 . ORGANIZATION OF THE GUIDANCE

Chapter 1 **Introduction and Background**

- Presents critical data useability issues.
- Specifies audience to be primarily RPMs and risk assessors.
- Defines scope and specifies organization of the guidance.

Chapter 2 **The Risk Assessment Process**

- Explains the elements of a risk assessment and the impact of analytical data quality on each element.
- Defines the uncertainties in the risk assessment process.
- Describes the roles of the risk assessor, RPM and others involved with the risk assessment planning and assessment process.

Chapter 3 **Useability Criteria for Baseline Risk Assessments**

- Defines six criteria for assessing data useability: data sources, documentation, analytical methods/detection limits, data quality indicators, data review, and reports to the risk assessor.
- Applies criteria to sampling and analytical issues.

Chapter 4 **Steps for Planning for the Acquisition of Useable Environmental Data in Baseline Risk Assessments**

- Provides guidelines for designing sampling plans and selecting analytical methods.
- Provides worksheets to support sampling design selection, soil depth sampling, and analytical method selection.

Chapter 5 **Assessment of Environmental Data for Useability in Baseline Risk Assessments**

- Describes minimum requirements for useable data.
- Explains how to determine actual performance compared to objectives.
- Recommends corrective actions for critical data not meeting objectives.
- Describes options for combining data from different sources and of varying quality into the risk assessment.

Chapter 6 **Application of Data to Risk Assessments**

- Provides procedures to determine the uncertainty of the analytical data.
- Explains how to distinguish site from background levels of contamination and determine the presence (absence) of chemicals of potential concern.
- Discusses how to characterize contaminant concentrations within exposure areas.

Appendices

- Provide technical reference materials for sampling and analysis.
- Describe data review packages and meanings of selected data qualifiers.

Chapter 2

The Risk Assessment Process

This chapter is an overview of the data collection and evaluation issues that affect the quality and useability of baseline human health risk assessments. Ecological risk assessment is not discussed in this guidance. The discussion focuses on how the quality of environmental analytical data influences the level of certainty of the risk assessment and stresses the importance of understanding data limitations in characterizing risks to human health.

The chapter has two sections. Section 2.1 is an overview of baseline human health risk assessment and the significance of uncertainty in each stage of the risk assessment process. Section 2.2 summarizes the roles and responsibilities of key participants in the risk assessment process.

2.1 OVERVIEW OF BASELINE HUMAN HEALTH RISK ASSESSMENT AND THE EVALUATION OF UNCERTAINTY

The approach to the baseline human health risk assessment process used for exposure to chemicals of potential concern is well established. The National Research Council (NRC) prepared a comprehensive overview of this process (NRC 1983), which has become the foundation for subsequent EPA guidance (EPA 1986a, EPA 1989a, EPA 1989b). RAGS, Part A (EPA 1989a), discusses in detail the human health baseline risk assessment process which is used in the Superfund program.

The risk assessment process has four components:

- Data collection and evaluation,
- Exposure assessment,
- Toxicity assessment, and
- Risk characterization.

Exhibit 3 lists information sought in each component of the baseline risk assessment.

Uncertainty analysis is often viewed as the last step in the risk characterization process. However, as discussed in detail in RAGS, Part A, uncertainty analysis is a fundamental element of each component of risk assessment, and the results for each component require an explicit statement of the degree of uncertainty. These results are the bases for estimating the degree of

uncertainty in the risk assessment as a whole. This chapter reviews the issues that determine the level of uncertainty in each component of risk assessment.

• To maximize data useability for the risk assessment, the risk assessor must be involved from the start of the RI.

The importance of obtaining analytical data that fulfill the needs of risk assessment cannot be overstated. The risk assessor must be involved from the start of the risk assessment process to help establish the scope of the investigation and the design of the sampling and analysis program.

All analytical data collected for baseline risk assessment must be evaluated for their useability. The procedures for evaluating the adequacy of the data are documented, along with the resulting estimates of the levels of certainty. Limitations in the analytical data are not the only source of uncertainty in risk assessment. Exhibit 4 identifies some typical sources of uncertainty, inherent in each component of the risk assessment, which restrict the depth and breadth of the evaluation. This guidance deals only with the uncertainty inherent in data collection and evaluation. Consult RAGS, Part A, for a more complete discussion of these and other uncertainties.

Acronyms


ATSDR	Agency for Toxic Substances and Disease Registry
DQO	data quality objective
EPA	U.S. Environmental Protection Agency
GIS	Geographical Information System
HEAST	Health Effects Assessment Summary Tables
IRIS	Integrated Risk Information System
LOAEL	lowest-observable-adverse-effect level
NOAEL	no-observable-adverse-effect level
NRC	National Research Council
PAH	polycyclic aromatic hydrocarbon
PCB	polychlorinated biphenyl
QA	quality assurance
QAPJP	quality assurance project plan
QC	quality control
RAGS	Risk Assessment Guidance for Superfund
RfC	reference concentration
RfD	reference dose
RI	remedial investigation
RME	reasonable maximum exposure
RPM	remedial project manager
SAP	sampling and analysis plan
SOP	standard operating procedure
UCL	upper confidence limit

EXHIBIT 3. DATA RELEVANT TO COMPONENTS OF THE RISK ASSESSMENT PROCESS

Risk Assessment Component	Data
Data Collection and Evaluation	<ul style="list-style-type: none"> • Background monitoring data for all affected media. • Environmental data for all relevant media. • List of chemicals of potential concern. • Distribution of sampling data. • Confidence limits surrounding estimates of representative values.
Exposure Assessment	<ul style="list-style-type: none"> • Release rates. • Physical, chemical and biological parameters, for evaluating transport and transformation of site-related chemicals. • Parameters to characterize receptors according to their activity, behavior and sensitivity. • Estimates of exposure concentrations for all chemicals, environmental media and receptors at risk. • Estimates of chemical intake or dose for all exposure pathways and exposure areas.
Toxicity Assessment	<ul style="list-style-type: none"> • Toxicity values for all chemicals, exposure pathways, and exposure areas of concern. • Uncertainty factors and confidence measures for RfDs; weight-of-evidence classifications for cancer slope factors.
Risk Characterization	<ul style="list-style-type: none"> • Hazard quotients and indices. • Estimates of excess lifetime cancer risk. • Uncertainty analysis.

21-002-003

EXHIBIT 4. BASELINE RISK ASSESSMENT PROCESS AND TYPICAL SOURCES OF UNCERTAINTY



Risk assessment can be a simple operation, using only screening-level data, or can be comprehensive, requiring a robust data set designed to support statistical analyses. Exhibit 5 discusses the range of uncertainty of baseline risk assessment. The first column in Exhibit 5 defines the range of the analysis from a low to a high degree of uncertainty. The second column describes the associated data useability and limitations in the risk analysis.

- The first level of analysis in Exhibit 5 is a quantitative risk assessment based on a sampling program that can be statistically analyzed. The assessment explicitly bounds and quantitates the uncertainty in all estimates. This analysis may strive to attain an ideal based upon the complexity of the site. The assessment is "quantitative" in that numeric estimates are derived for potentially adverse non-carcinogenic and carcinogenic effects, and in that the level of certainty is quantitated.
- The second level of analysis in Exhibit 5 is a quantitative assessment based on a limited number of samples or on data that cannot be fully

quantitated. The risk characterization may include numeric estimates of excess lifetime cancer risks and the calculation of hazard indices. However, the level of analytical uncertainty for these measures may be significant but is either not quantitated or is estimated. Given the limitations of the analytical data, only a qualitative evaluation of the analytical uncertainty is feasible. Most baseline risk assessments fall within this category. Bias may need to be determined for its effect on predicted exposures and consequent risk.

- The third level of the continuum is a qualitative assessment of risk. The assessment is qualitative because no numeric measures can be derived to indicate the potential for adverse effects, and the level of certainty cannot be assessed. The risk to human health is considered only in general terms. Qualitative assessments are based upon limited sources of historical information, such as disposal records, circumstantial evidence of contamination, or preliminary site assessment data.

EXHIBIT 5. RANGE OF UNCERTAINTY OF RISK ASSESSMENT

Range of Analyses	Description/Limitations
Quantitative Assessment of Risk: Uncertainty minimized, quantified, and explicitly stated. Resulting or final uncertainty may be highly variable (either high or low).	Risk assessment conducted using well-designed, robust data sets and models directly applicable to site conditions. Sampling program, based on geostatistical or random design, will support statistical analysis of results. Statistical analysis used to characterize monitoring data. Confidence limits or probability distributions may be developed for all key input variables.
Quantitative Assessment of Risk: Magnitude of uncertainty unknown. No explicit quantitative estimates provided. Qualitative, tabular summary of factors influencing risk estimates may be provided for determination of possible bias in error.	Risk assessment conducted using data set of limited quality and size. No meaningful statistical analysis can be conducted. Results of risk assessment may be quantified but uncertainty surrounding these measures cannot be quantified. Only a qualitative statement is possible. The majority of baseline risk assessments typically fall within this category.
Qualitative Assessment of Risk: Only qualitative statement of uncertainty is possible. Uncertainty is high.	Risks cannot be quantified due to insufficient monitoring or modeling data. Qualitative statement of risks based on historical information or circumstantial evidence of contamination is provided. This evaluation must be considered a preliminary, screening level assessment.

☛ *All data can be used in the baseline risk assessment as long as their uncertainties are clearly described.*

Risk assessments must sometimes be conducted using data of limited quantity and of differing quality. When RPMs and other technical experts involved in the RI understand the quantity and quality of data required in risk assessments, they are better able to design data collection programs to meet these requirements.

2.1.1 Data Collection and Evaluation

Overview of methods for data collection and evaluation. Data collection begins with a statement of the risk assessment purpose and a conceptual model of the current understanding of the problems to be addressed for the site under investigation. The model draws from all available historical data (EPA 1989a). It is first created with a best estimate of the types and concentrations of chemicals, or of key chemicals that are likely to be present, given the history of the site. Site records, site maps, the layout of existing structures, topography, and readily observable soil, water and air characteristics on and off the site help to estimate chemicals of potential concern, likely important exposure pathways, potentially exposed populations, and likely temporal and spatial variation. All of these elements comprise the conceptual model (Exhibit 6 and Appendix IX). Once the conceptual model has been developed and information has been disseminated to project staff, the site is scoped to identify data gaps and requirements for the baseline risk assessment.

Several key issues that are part of the development of data quality objectives (DQOs) should be addressed at scoping (Neptune, *et. al.* 1990):

- The types of data needed (e.g., environmental, toxicological),
- How the data will be used (e.g., site characterization, extent of plume, etc., what chemicals of concern will drive the risk-based decision), and
- The desired level of certainty for the conclusions derived from the analytical data (e.g., what are the probabilities of false positive and false negative results as a function of risk and concentration).

Carefully designed sampling and analysis programs minimize the subsequent need to qualify the environmental data during the data assessment phase. The objective of the data collection effort is to produce data that can be used to assess risks to human health with a known degree of certainty.

A complete list of chemicals of potential concern is produced when the analytical data have been collected and evaluated. This list of analytes is the focus of the risk assessment. EPA no longer advocates the selection of "indicator compounds," because this practice may not accurately reflect the total risk from exposure to multiple site chemicals of potential concern, nor does it improve the quality or accuracy of the risk assessment (EPA 1989a).

Uncertainty in data collection and evaluation. Four principal decisions must be made during data collection and evaluation in the risk assessment:

- The presence and levels of contaminants at the site at a predefined level of detail,
- If the levels of site-related chemicals differ significantly from their background levels,
- Whether the analytical data are adequate to identify and examine exposure pathways and exposure areas, and
- Whether the analytical data are adequate to fully characterize exposure areas.

These decisions are examined in detail in subsequent chapters. The discussion in this section introduces basic concepts.


Determining what contamination is present and at what level. Once a site is suspected to be contaminated and chemicals of potential concern have been identified, the levels of chemical contamination in the affected environmental media must be quantitated to derive exposure and intake estimates. Estimates of the site contamination must be produced, with explicit descriptions of the degree of certainty associated with the concentration values.

Variability in observed concentration levels arises from a combination of variance in sampling characteristics of the site, in sampling techniques, and in laboratory analysis. The key issue in optimizing the useability of data for risk assessment is to understand, quantify, and minimize these variabilities.

EPA's objective is to protect human health and the environment. Therefore, the design of RI programs is intended to minimize two potential errors:

- Not detecting site contamination that is actually present (i.e., false negative values), and
- Deriving site concentrations that do not accurately characterize the magnitude of contamination.

EXHIBIT 6. DEVELOPMENT OF CONCEPTUAL SITE MODEL



Determining if site concentrations differ significantly from background concentrations. A fundamental decision in baseline risk assessments is whether the site poses an increased risk to human health and the environment. The decision depends on the degree of certainty that the background concentrations are significantly different from the concentrations of the chemicals of potential concern at the site. Generally, this question can be confidently answered only if the design of the sampling program accommodates the collection of both site and background samples and if the selection of analytical methods is appropriate.

The differences between site and background concentrations is evaluated by comparing observed levels of chemicals of potential concern at the site with measured background concentrations of the same chemicals in the same environmental media. Statistically, this is a test of the null hypothesis, that the mean concentration of a chemical at the study area is not significantly different from the mean concentration of the chemical at the background location. (Historical on-site levels or nearby off-site levels may be used to supplement background data. An example of an off-site area is the 4-mile radius used for the air exposure pathway in the Hazard Ranking System.) If data from background samples are clearly different from the results of site monitoring (e.g., mean chemical concentrations differ consistently by two orders of magnitude), statistical analysis of the data may not be necessary. Under such circumstances, RAGS indicates that the primary issue is establishing a reliable representation of the extent of the contaminated area. Determining extent of contamination is not discussed in this guidance and involves different decisions, DQOs, and sampling designs. If the results of site monitoring are less than two orders of magnitude above background, the procedures used for sampling and analysis for risk assessment should follow the recommendations of Chapter 4.

The null hypothesis is always evaluated and accepted or rejected with a specified level of certainty. This level of certainty is defined by the significance, or confidence, level. A type I error is the probability that the null hypothesis is rejected when in fact it is true (which contributes to false positive conclusions). A type II error is the probability that the null hypothesis is accepted when it is false (a false negative conclusion). How sampling and analysis design affects the likelihood of these two types of errors is described in Chapter 4.

Evaluating whether analytical data are adequate to identify and examine exposure pathways and their exposure areas. Identifying and delineating exposure pathways and their exposure areas are important in identifying potentially exposed populations and for

developing intake estimates. In the baseline risk assessment, the risk assessor combines data on contamination with information on human activity patterns to identify exposure pathways and to determine the exposure area. The ability to accomplish this depends on the adequacy of analytical data.

Sampling should be designed to provide representative data for exposure areas at a site, to address hot spots, to evaluate the transport of site-related chemicals of potential concern, and to facilitate the identification of all exposure pathways. A well-designed sampling and analysis program results in data of known quality and quantification of spatial and temporal variability; it specifies how to interpret the magnitude of observed values (such as by comparison with background levels or some other benchmark). Analytical data should characterize the extent of contamination at the site in three dimensions.

Evaluating whether analytical data are adequate to fully characterize exposure areas. Heterogeneity should be considered in the environmental medium under evaluation. Hot spots need to be identified and characterized. Neptune, *et. al.* 1990, have proposed the concept of an "exposure unit" as the area over which receptors integrate exposure. This concept establishes a basis for summarizing the results of monitoring and transport modeling. The sampling and analysis program must be designed to enable the risk assessor to refine the initial characterization of exposure pathways and to spatially and temporally identify the critical areas of exposure.

2.1.2 Exposure Assessment

Overview of methods for exposure assessment. The objectives of the exposure assessment are:

- To identify or define the source of exposure,
- To define exposure pathways along with each of their components (e.g., source, mechanism of release, mechanism of transport, medium of transport, etc.),
- To identify potentially exposed populations (receptors), and
- To measure or estimate the magnitude, duration, and frequency of exposure to site contaminants for each receptor (or receptor group).

Actions at hazardous waste sites are based on an estimate of the reasonable maximum exposure (RME) expected to occur under both current and future conditions of land use (EPA 1989a). EPA defines the RME as the highest exposure that is reasonably expected to occur at a site

over time. RMEs are estimated for individual pathways and combined across exposure pathways if appropriate. Once potentially exposed populations are identified, environmental concentrations at points of exposure must be determined or projected. Intake estimates (in mg/kg-day) are then developed for each chemical of potential concern using a conservative estimate of the average concentration to which receptors are exposed over the exposure period. (RAGS recommends a 95% upper confidence limit (UCL) on the arithmetic mean.) The concentration estimate is then combined with other exposure parameters (e.g., frequency, duration, and body weight) to calculate intake.

In the risk assessment report, estimates of intake are accompanied by a full description (including sources) of the assumptions made in their development. This information may be used subsequently in sensitivity and uncertainty analyses in the risk characterization.

Uncertainty analysis in exposure assessment. Exposure assessments can introduce a great deal of uncertainty into the baseline risk assessment process. Small measures of uncertainty in each of the input parameters which comprise an exposure scenario may result in substantial uncertainty in the final assessment. The largest measure of uncertainty is associated with characterizing transport and transformation of chemicals in the environment, establishing exposure settings, and deriving estimates of chronic intake. The ultimate effect of uncertainty in the exposure assessment is an uncertain estimate of intake.

The following sections discuss the significance of the uncertainty in the analytical data set on selected aspects of exposure assessment. For a more complete discussion of the exposure assessment process, the reader is referred to RAGS, Part A.

Characterizing environmental fate, identifying exposure pathways, and identifying receptors at risk. An evaluation of the transport and transformation of chemicals in the environment is conducted for several reasons:

- To understand the behavior of site-related chemicals of potential concern,
- To project the ultimate disposition of these chemicals,
- To identify exposure pathways and receptors potentially at risk, and
- To characterize environmental concentrations at the point of exposure.

These evaluations cannot be accomplished with any degree of certainty if the analytical data are inadequate.

Monitoring data are most appropriately used to estimate current or existing exposure when direct contact with contaminated environmental media is the primary concern. Modeling may be required, however, in order to evaluate the potential for future exposure, or exposure at a distance from the source of release, or to predict present concentrations where measurement is too costly. In each case, success in estimating potential exposures depends heavily on the adequacy of the analytical data.

Environmental fate and transport assessment often uses models to estimate concentrations in environmental media at points distant from the source of release. Models, of necessity, are simplifications of a real, physical system. Consequently, it is critical that the limitations of the model (the way that the model differs from reality) be understood and considered when applying the model to a particular site. The degree to which the model differs from reality (in critical areas of the analysis) contributes to the uncertainty of the analysis. Transport models are commonly selected for their utility in describing or interpreting a set of monitoring data. Chemical transport models must be carefully selected for their ability to meaningfully characterize the behavior of chemicals in the environmental medium for the specific site under investigation. Models that are inappropriate for the geophysical conditions at the site will result in errors in the exposure assessment. For example, the model may be designed to predict contaminant movement through sand, while soils at the site are primarily made up of clay. Additionally, if the analytical data set is severely limited in size or does not accurately characterize the nature of contamination at the site, a transport model cannot be properly selected or accurately calibrated. This introduces additional uncertainty.

Uncertainty in the analytical data, compounded by uncertainty caused by the selection of the transport models, can yield results that are meaningless or that cannot be interpreted.

Estimating chemical intake. Uncertainties in all elements of the exposure assessment come together, and are compounded, in the estimate of intake. It is here that the professional judgment of the risk assessor is particularly important. The risk assessor must examine and interpret a diversity of information:

- The nature, extent and magnitude of contamination,
- Results of environmental transport modeling,
- Identification of exposure pathways and areas,

- Identification of receptor groups currently exposed and potentially exposed in the future, and
- Activity patterns and sensitivities of receptors and receptor groups.

Based on this information, the risk assessor characterizes the exposure setting and quantifies all parameters needed in the equations to estimate intake (EPA 1989a). Chemical intake is a function of the concentration of the chemical at the point of contact, the amount of contaminated medium contacted per unit time or event, the exposure frequency and duration, body weight, the ability of the chemical to penetrate the exchange boundary, and the average time period during which exposure occurs. Exhibit 7 is the generic form of the intake equation used in exposure assessment.

The specific form of the intake equation varies depending upon the exposure pathway under consideration (e.g., ingestion, inhalation, dermal contact) (EPA 1989a). Each of the variables in these equations, including chemical concentration, is commonly characterized as a point estimate. However, each intake variable in the equation has a range of possible values. Site-specific characteristics determine the selection of the most appropriate values. In an effort to increase consistency among Superfund risk assessments, EPA has established standardized exposure parameters to be used when site-specific data are unavailable (EPA 1991b). Note that the combination of all factors selected should result in an estimate of reasonable maximum exposure for each chemical in each pathway (EPA 1989a).

For most risk assessments, it may not be possible, nor necessarily advantageous, to develop a quantitative uncertainty analysis. In these cases, a summary of major assumptions and their anticipated effects on final exposure estimates should be included to provide a qualitative characterization of the level of certainty in the intake estimates.

2.1.3 Toxicity Assessment

Overview of methods for toxicity assessment. The objectives of toxicity assessment are to evaluate the inherent toxicity of the compounds at the site, and to identify and select toxicity values to evaluate the significance of receptor exposure to these compounds. Toxicity assessments rely on scientific data available in the literature on adverse effects on humans and nonhuman species.

Several values of toxicity are important in human health risk assessments. Reference doses (RfDs) and reference concentrations (RfCs) are used for oral and inhalation exposure, respectively, to evaluate non-carcinogenic

and developmental effects; cancer slope factors and unit risk estimates are used for the oral and inhalation pathways for carcinogens.

RfDs and RfCs are values developed by EPA to evaluate the potential for non-carcinogenic effects in humans. The RfD is defined as an estimate (with uncertainty spanning an order of magnitude or more) of a daily exposure level for human populations, including sensitive sub-populations, that is likely to be without an appreciable risk of adverse health effects over the period of exposure (EPA 1989a). Subchronic or chronic RfDs may be derived for a chemical for intermediate or long-term exposure scenarios. These values are typically derived from the no-observable-adverse-effect level (NOAEL) or the lowest-observable-adverse-effect level (LOAEL) and the application of uncertainty and modifying factors (EPA 1989a). Uncertainty factors are used to account for the variation in sensitivity of human sub-populations and the uncertainty inherent in extrapolating the results of animal studies to humans. Modifying factors account for additional uncertainties in the studies used to derive the NOAEL or LOAEL.

Cancer slope factors and unit risk values are defined as plausible, upper-bound estimates of the probability of cancer response in an exposed individual, per unit intake over a lifetime exposure period (EPA 1989a). EPA commonly develops slope factors for carcinogens with weight-of-evidence classifications that reflect the likelihood that the toxicant is a human carcinogen (EPA 1989a).

To reduce variability in toxicological values used for risk assessment, a standardized hierarchy of available toxicological data is specified for Superfund. The primary source of information for these data is the Integrated Risk Information System (IRIS) database (EPA 1989d). IRIS consists of verified RfDs, RfCs, cancer slope factors, unit risks, and other health risk and EPA regulatory information. Data in IRIS are regularly reviewed and updated by an EPA workgroup. If toxicity values are not available in IRIS, the EPA *Health Effects Assessment Summary Tables* (HEAST) (EPA 1990a) are used as a secondary current source of information. Additional sources of toxicity information are provided in RAGS.

The toxicity assessment is conducted parallel with the exposure assessment, but may begin as early as the data collection and evaluation phase. As chemicals of potential concern are identified at the site, the toxicologist begins to identify the appropriate toxicity values. A well-designed sampling and analysis program facilitates timely identification of the chemicals that will be the focus of the risk assessment.

EXHIBIT 7. GENERIC EQUATION FOR CALCULATING CHEMICAL INTAKES

$$I = C \times \left(\frac{CR \times EFD}{BW} \right) \times \frac{1}{AT}$$

Where:

I = intake; the amount of chemical at the exchange boundary (mg/kg body weight-day)

Chemical-related variable

C = chemical concentration; the average concentration contacted over the exposure period (e.g., mg/liter water)

Variables that describe the exposed population

CR = contact rate; the amount of contaminated medium contacted per unit time or event (e.g., liters/day)

EFD = exposure frequency and duration; describes how long and how often exposure occurs. Often calculated using two terms (EF and ED):

EF = exposure frequency (days/year)

ED = exposure duration (years)

BW = body weight; the average body weight over the exposure period (kg)

Assessment-determined variable

AT = averaging time; period over which exposure is averaged (days)

Source: RAGS (EPA 1989a).

21-002-007

Uncertainty analysis and toxicity assessment. The toxicity assessment is another contributor to uncertainty in risk assessment. Limitations in the analytical data from environmental samples affect the results of the toxicity assessment, but not to the extent that they affect other components of the risk assessment process. Data on physical and chemical parameters that may influence bioavailability can influence route-to-route and vehicle-related adjustments to toxicity values. The selection of appropriate toxicity values is influenced by monitoring data from environmental samples to the extent that this information assists in identifying chemicals of potential concern, exposure pathways, and the time periods over which exposure may occur. Based on this information, the toxicologist identifies sub-chronic or chronic RfDs, RfCs, and cancer slope factors for oral, dermal, and inhalation exposure pathways.

A list of toxicity values for risk assessment should include an indication of the degree of certainty associated with these values. Weight-of-evidence classifications provide a qualitative estimate of certainty and should be included in the discussion of cancer slope factors. Uncertainty and modifying factors used in deriving RfDs and RfCs should also be included in the discussion of non-carcinogenic effects.

2.1.4 Risk Characterization

Overview of methods for risk characterization. The last step in the baseline risk assessment is risk characterization. This is the process of integrating the results of the exposure and toxicity assessments, by comparing estimates of intake with appropriate toxicological values to determine the likelihood of adverse effects in potentially exposed populations. Risk characterization is considered separately for carcinogenic and non-carcinogenic effects, because organisms typically respond differently following exposure to carcinogenic and non-carcinogenic agents. For non-carcinogenic effects, toxicologists recognize the existence of a threshold of exposure below which there is likely to be no appreciable risk of adverse health impacts in an exposed individual. It is the current EPA position that exposure to any level of carcinogenic compounds is considered to carry a risk of adverse effect, and that exposure is not characterized by the existence of a threshold.

EPA's procedure for calculating risk from exposure to carcinogenic compounds (EPA 1986a, EPA 1989a, EPA 1989b) uses a non-threshold, dose-response model. The model is used to calculate a cancer slope factor (mathematically, the slope of the dose-response curve) for each chemical. Generally, the cancer slope factor is used in conjunction with the chronic daily intake to derive a probabilistic upperbound estimate of excess lifetime cancer risk to the individual.

The dose-response model most commonly used by EPA in deriving the cancer slope estimates is linearized and multistage. The mathematical relationship of the model assumes that the dose-response relationship is linear in the low-dose portion of the curve (EPA 1989a). Given this assumption, the slope factor is a constant, and risk is directly proportional to intake.

The recommended practice for evaluating the potential for non-carcinogenic effects is to compare the RfD of a given chemical to the estimated intake of the potentially exposed population from a given exposure pathway (EPA 1989a). This ratio (intake/RfD) is termed the "hazard quotient." It is not a probabilistic estimate of risk, but simply a measure of concern, or an indicator of the potential for adverse effects. A more detailed discussion of risk characterization is presented in RAGS. Further discussion of methods for risk characterization, and of specific factors such as metabolic rate factors, gender differences, and variable effects due to multiple chemicals of potential concern, is available from many sources (EPA 1988a, EPA 1989b, EPA 1989c).

Uncertainty analysis in risk characterization. No risk assessment is certain. Risk assessment is a process that provides an estimate of potential (present and future) individual risk, along with the limitations or uncertainties associated with the estimates. The most obvious effect of limitations in the analytical data on risk characterization is the ability to accurately estimate the potential for adverse effects in potentially exposed individuals. Clearly, if the available monitoring data do not facilitate a meaningful determination of RME values, the risk estimates will directly reflect this uncertainty.

Uncertainties in toxicological measures and exposure assessment are often assumed to be greater than uncertainties in environmental analytical data; thus, they are assumed to have a more significant effect on the uncertainty of the risk assessment.

Resource and time constraints often limit the opportunity to develop a well-designed and comprehensive data set. Risk assessments must be conducted using the available information, even when there is no opportunity to improve the data set. However, the results should be presented with an explicit statement regarding limitations and uncertainty.

If possible, a sensitivity analysis should be conducted to bound the results of risk assessments. A simple approach might consist of establishing the range of potential values (e.g., minimum, most likely, and maximum) for key input variables and discussing the influence on the resulting risk estimates. The key variables can then be ranked with respect to the magnitude of potential effect on the risk estimates. In certain instances, more

quantitative approaches to uncertainty analysis may be useful if they can be supported by the available information. Combining probability distributions using Monte Carlo techniques is one commonly cited example (EPA 1988b, EPA 1989a, Finkel 1990). An overview of recommended methods for assessment of uncertainty in risk characterization is presented in RAGS. Risk*Assistant, a software tool developed for EPA, provides an uncertainty analysis that determines the effect on the final risk estimate of using alternative parameter values, indicates the relative contribution of each pathway to risks from the contaminated media, and (for carcinogenic risks) determines the percentage of total risk from a contaminant in each medium (Thistle Publishing 1991). A more detailed consideration of uncertainty analysis in risk assessment may be found in *Methodology for Characterization of Uncertainty in Exposure Assessment* (EPA 1985) and *Confronting Uncertainty in Risk Management: A Guide for Decision-Makers* (Finkel 1990).

2.2 ROLES AND RESPONSIBILITIES OF KEY RISK ASSESSMENT PERSONNEL

The risk assessor generally enlists the participation of individuals with specific skills and technical expertise. The quality and utility of the baseline risk assessment will ultimately depend on the planning and interaction of these technical professionals. Key participants include the RPM and the risk assessor, who are primarily responsible for ensuring that data collected during the RI are useable for risk assessment activities. Other participants include hydrogeologists, chemists, statisticians, quality assurance staff, and other technical support personnel involved in planning and conducting the RI. Exhibit 8 summarizes the roles and responsibilities of the risk assessment participants.

2.2.1 Project Coordination

All data collection activities that support the risk assessment are coordinated by the RPM. The RPM's responsibilities begin upon site listing and continue through deletion of the site from the National Priorities List. A network of technical experts, including representatives of other agencies involved in human health or environmental/ecological assessments or related issues, is established at the start of the RI. This ensures that the potential for adverse effects to human health and the environment is adequately assessed during the RI. To successfully plan and direct the sampling and analysis effort, the RPM must facilitate interaction among key participants.

2.2.2 Gathering Existing Site Data and Developing the Conceptual Model

The RPM is responsible for gathering and evaluating all historical and existing site data. This is an important element in planning the scope of the risk assessment and data collection, and in determining additional data needs. Sources of information especially pertinent for risk assessment include data from potentially responsible parties, industrial records identifying chemicals used in processes, preliminary natural resource studies, Agency for Toxic Substances and Disease Registry (ATSDR) health studies, environmental impact statements, transport manifests, site records, site inspection documents, and site visits. Aerial photographs and site maps showing past and present locations of structures and transportation corridors should also be collected. The RPM should also consider the application of a computer-based Geographical Information System (GIS) as a major tool.

The RPM should ensure that a broad spectrum analysis was conducted at the site for all media and should review industry-specific records to minimize the potential for false negatives. From the inspection of historical data and broad spectrum analyses, a preliminary list of the chemicals of potential concern is prepared to assist in scoping and in developing the conceptual model of the site. Once all the existing historical site data have been collected, the RPM works with the risk assessor to develop a conceptual model. The conceptual model is a depiction and discussion of the current understanding of the contamination, the sources of release to the environment, transport pathways, exposure pathways, exposure areas and receptors at risk. Preliminary identification of potential exposure pathways at the site under investigation is particularly important for the design of a thorough data collection effort. The conceptual site model should be provided to all key participants in the RI during the project scoping and should be included in the workplan. As work progresses and the site is better characterized, the RPM and the risk assessor should update the conceptual model.

2.2.3 Project Scoping

The adequacy of the sampling and analysis effort determines the quality of the risk assessment. Therefore, it is imperative that the risk assessor be an active member of RI planning and continue to be involved during the entire course of the project.

EXHIBIT 8. ROLES AND RESPONSIBILITIES OF RISK ASSESSMENT TEAM MEMBERS

Remedial project manager

- Directs, coordinates and monitors all activities.
- Establishes network with other data users including federal, state and local agencies.
- Creates conceptual model.
- Gathers existing site data.
- Organizes scoping meetings.
- Controls budget and schedule.
- Guides preparation of QA documents.
- Ensures that the risk assessor receives preliminary analytical data.
- Contributes to data assessment.
- Develops preliminary list of chemicals of potential concern.
- Resolves problems affecting RI objectives, including risk assessment issues (e.g., resampling, reanalysis).

Risk assessor

- Reviews all relevant existing site data.
- Assists the RPM in developing the conceptual model and the preliminary list of chemicals of potential concern.
- Contributes to recommendations on sampling design, analytical requirements, including chemicals of potential concern, detection limits and quality control needs during project scoping.
- Helps to refine the conceptual model.
- Communicates frequently with the RPM, hydrogeologist and chemist to ensure that data collection meets needs.
- Reviews and contributes to SAP and QA documents.
- Assesses preliminary data as soon as available to verify conceptual site model.
- Specifies additional needs.
- Assesses reviewed data for useability in risk assessment.
- Communicates all site activities with specific groups, such as chemists.
- Prepares risk assessment.

Hydrogeologist, chemist and other technical support

- Provides technical input to scoping.
- Prepares/provides input to SAP and QA documents in support of risk assessment data needs.
- Communicates frequently with the RPM and/or risk assessor on status of data collection and issues affecting data.
- Provides preliminary data to the RPM and/or risk assessor for review.
- Supports fate and transport modeling for the exposure assessment.
- Implements corrective actions to improve data useability.

Quality assurance specialist

- Responsible for data quality review and technical assistance in preparing QA documents.
- Provides historical performance QA data or recommendations for appropriate QC.
- Ensures adequate QA procedures are in place, including field and analytical audits.

• *Analytical data collected solely for other purposes may not be of optimal use to the risk assessment.*

Data obtained solely with the aim of characterizing the nature and extent of contamination at a site may not fully support the needs of the risk assessor in quantitating exposure, and therefore the potential for adverse effects in human and nonhuman receptors. Data on the nature and extent of contamination may therefore be rejected by the risk assessor, requiring an additional round of sampling. For example, data identifying the boundaries of the site may not be representative of the level of contamination within an exposure area. Therefore, it is important to maintain the risk assessment data requirements as a high priority throughout remedial investigations.

Sampling and analysis methods discussed during scoping should ultimately be based on site-specific data needs. The RPM, risk assessor, hydrogeologist, statistician, and project chemist must maintain open communication

during scoping and throughout the RI to ensure that this occurs. Data review and deliverable requirements should be determined during the scoping meetings so that these specifications can be included in the sampling and analysis plan (SAP) for the RI. The RPM should prepare a checklist of considerations for the scoping meetings and provide it to all individuals involved. Exhibit 9 presents an example checklist of items useful for risk assessment to be considered by the RPM during scoping. Chapters 3 and 4 give specific guidance for planning the data collection efforts to support risk assessments.

2.2.4 Quality Assurance Document Preparation and Review

After scoping, the RPM guides the preparation of the workplan and quality assurance documents. The workplan, the SAP, and the quality assurance project plan (QAPjP) should document the combined decisions of the RPM, risk assessor, and other project staff.

EXHIBIT 9. EXAMPLE RISK ASSESSMENT CHECKLIST FOR USE IN SCOPING

- Has all historical information been gathered and characterized and is it appropriate and available for use?
- What sample matrices should be investigated?
- What analytical methods should be used?
- Are the methods appropriate for risk assessment, given specific contaminants present and their toxicity?
- Will any special quality control requirements be necessary?
- Who will conduct the analysis (e.g., which type of laboratory)?
- What analytical data sources should be used (fixed laboratory and/or field analysis)?
- What sampling designs are appropriate?
- How many samples will be needed?
- How will the data review be accomplished?
- What types of deliverables will be required? Specify the types of deliverables required from both laboratory and data validation.
- What budget or other limitations constrain data collection (e.g., due date, contractor availability)?

Particular emphasis is placed on establishing confidence limits, acceptable error, and level of quality control (discussed in Chapter 3). This facilitates cost-effective design of the sampling and analytical program and minimizes the collection of data of limited use for risk assessment.

The risk assessor reviews the workplan and SAP to ensure that the relevant data quality issues, sampling design, analytical needs, and data assessment procedures are adequately addressed for risk assessment. Exhibits 10 and 11 provide checklists to aid the review of the workplan and SAP.

2.2.5 Budgeting and Scheduling

As the overall site manager, the RPM must address and balance risk assessment data needs with other data use needs, such as health and safety, treatability studies, transport, and the nature and extent of contamination. The risk assessor is responsible for identifying specific data requirements for risk assessment and communicating these needs to the RPM. The RPM is responsible for developing and implementing the schedule for acquiring the data. Balancing costs and services while adhering to the schedule is a major responsibility of the RPM.

The RPM must coordinate the use of analytical services. Data from different analytical sources provide the

flexibility needed to balance cost with sampling needs and time constraints. The advantages and disadvantages of field analyses and fixed laboratory analyses should be considered, as described in Chapters 3 and 4. The risk assessment participants can assist in the development of field sampling plans and the selection of appropriate analytical methods that will provide the risk assessor with a set of useable data, within the budgeting and scheduling constraints of the RPM.

2.2.6 Iterative Communication

Continuing, open, and frequent communication among the participants is critical to the success of the RI and baseline risk assessment. A single meeting or discussion is rarely adequate to ensure that all relevant issues have been addressed. Development of the risk assessment within the RI report is an iterative process of action, feedback, and correction or adjustment.

After review of the workplan, the SAP, and the QAPjP, the RPM monitors the flow of information. The risk assessor assists the RPM to ensure that the data produced are in compliance with the requirements of the workplan and SAP. Key questions they consider once the data become available are:

- Have correct sampling protocols been followed?
- Have all critical samples been collected?

EXHIBIT 10. CHECKLIST FOR REVIEWING THE WORKPLAN

- Does the workplan address the objectives of baseline risk assessment?
- Does the workplan document the current understanding of site history and the physical setting?
- Have historical data been gathered and assessed?
- Has information on probable background concentrations been obtained?
- Does the workplan provide a conceptual site model for the baseline risk assessment, including a summary of the nature and extent of contamination, exposure pathways of potential concern, and a preliminary assessment of potential risks to human health and the environment?
- Does the workplan document the decisions and evaluations made during project scoping, including specific sampling and analysis requirements for risk assessment?
- Does the workplan address all data requirements for the baseline risk assessment and explicitly describe the sampling, analysis and data review tasks?

EXHIBIT 11. CHECKLIST FOR REVIEWING THE SAMPLING AND ANALYSIS PLAN

- Do the objectives of the QAPjP and the field sampling plan meet risk assessment needs established in the scoping meeting?
- Are QA/QC procedures provided for in the SAP adequate for the purposes of the baseline risk assessment?
- Have the data gaps for risk assessment that were identified in the RI workplan been adequately addressed in the SAP?
- Are there sufficient QC samples to measure the likelihood of false negatives and false positives, and to determine the precision and accuracy of resulting data?
- Have analytical methods been selected that have detection limits adequate to quantitate contaminants at the concentration of concern?
- Have SOPs been prepared for sampling, analysis and data review?
- Will the sampling and analysis program result in the data needed for the baseline risk assessment:
 - to address each medium, exposure pathway and chemical of potential concern,
 - to evaluate background concentrations,
 - to provide detail on sample locations, sampling frequency, statistical design and analysis,
 - to evaluate temporal as well as spatial variation, and
 - to support evaluation of current as well as future resource uses?

21-002-011

- Have the samples been analyzed as requested?
- Are data arriving in a timely fashion?
- Have appropriate sample quantitation limits/detection limits been achieved?
- Has quality assurance been addressed as stated in the SAP and QAPjP?
- Have the data been reviewed as stated in the SAP?
- Is the quality of the analytical data acceptable for their intended use?

Based upon these considerations, the RPM, risk assessor and other technical team members must jointly determine if any corrective actions are needed, such as requesting additional sampling, using alternative analytical methods, or reanalyzing samples.

2.2.7 Data Assessment

The RPM and risk assessor work with other participants to identify a list of chemicals of potential concern and

decide on data review procedures. This information is developed during project scoping and incorporated into the workplan and SAP. The RPM, risk assessor, and project chemist should agree on the type and level of data review required for both positive and "non-detect" results. Typically, the RPM assesses the overall data reviewed by the chemist, and the risk assessor reviews data relevant to risk assessment, unless other arrangements have been established and explicitly stated in the SAP.

The risk assessor may request preliminary data, or results that have received only a partial review, in order to expedite the risk assessment to save time and resources. Preliminary data can be used to validate the conceptual model or to begin the toxicity assessment. The data may also indicate a need for modifying sampling or analytical procedures. However, preliminary data should not be used in calculating risk. Once the full analytical data set is obtained, the RPM and risk assessor should consult with the project chemist and statistician to assess the utility of all available information.

2.2.8 Assessment and Presentation of Environmental Analytical Data

Once environmental data are evaluated in the data review process, the risk assessor develops a final data set for use in the baseline risk assessment. All chemicals of potential concern should now be identified. The risk assessor prepares summary tables containing the following information:

- Site name and sample locations,
- Number of samples per defined, representative area of each medium (e.g., do not count background samples together with other samples),
- Sample-specific results,
- Analyte-specific sample quantitation limits,
- Number of values above the quantitation limit,

- Measures of central tendency (e.g., 95% UCL on the arithmetic mean of the environmental concentration),
- Specifications for the treatment of detection or quantitation limits and treatment of qualified data, and
- Ranges of concentrations.

All assumptions, qualifications, and limitations should be explicitly stated in the tables. The risk assessor provides the final data summary tables to the RPM, project hydrogeologist, project chemist, and other appropriate project staff for review. These are the data that will be used in the baseline risk assessment to determine the potential risk to human health. It is essential, therefore, that this information consists of the best data available and reflects the collective review of the key participants in the risk assessment. An example of such a set of data is given in Appendix I.

Chapter 3

Useability Criteria for Baseline Risk Assessments

This chapter applies data useability criteria to data collection planning efforts to maximize the useability of environmental analytical data in baseline risk assessments. It also addresses preliminary issues in planning sampling and analysis programs.

The chapter has two sections. Section 3.1 discusses data useability criteria involved in risk assessment and suggests ways they can be applied to ensure data are useable. Section 3.2 presents preliminary sampling and analysis issues including identification of chemicals of potential concern, available sampling and analytical strategies or methods, and probable sources of uncertainty.

Before scoping the RI, it is critical for successful planning that the RPM develop a conceptual site model (Exhibit 6) in consultation with the risk assessor and all appropriate personnel. This chapter provides the background information necessary to plan for the acquisition of environmental data for baseline risk assessments. The quality of a risk assessment is intimately tied to the adequacy of the sampling and analysis plan (SAP) developed during the RI.

➤ *Effective planning improves the useability of environmental analytical data in the final risk assessment.*

Data needs for baseline risk assessments are not necessarily met by data the RPM acquires to identify the nature and extent of contamination at a Superfund site. For example, a sampling strategy designed to determine the boundaries of a contaminated area may not provide data to quantitate concentrations within an exposure area. The risk assessment may also require more precision and accuracy, and lower detection limits. Accordingly, the risk assessor should be an active member of the team planning the RI and must be consulted from the start of the planning process.

Four fundamental decisions for risk assessment are to be made with the data acquired during the RI, as discussed in Chapter 2.

- If the sampling design is representative, the question of what contamination is present and at what concentration is an analytical problem. Key concerns are the probability of false negatives and false positives. The selection of analytical methods, laboratory performance, and type and amount of data review affects these issues for both site and background samples.
- Assuming that chemicals of potential concern have been identified, the second question involves

background levels of contamination. Are site concentrations sufficiently elevated from true background levels to indicate an increased risk for human health due to site contamination?

- All exposure pathways and exposure areas must be identified and examined. The two decisions concerning exposure pathways and areas primarily involve identifying and sampling the media of concern.
- The final decision involves characterizing exposure areas. Sampling and analysis must be representative and satisfy performance objectives determined during the planning process.

RI planning and implementation of RI plans affect the certainty of chemical identification and quantitation. Therefore, the RI needs to collect useable environmental analytical data to enable the risk assessor to make these decisions.

Acronyms

AA	atomic absorption
CLP	Contract Laboratory Program
CRDL	contract required detection limit
CRQL	contract required quantitation limit
DQI	data quality indicator
DQO	data quality objective
GC	gas chromatography
HRS	Hazard Ranking System
ICP	inductively coupled plasma
IDL	instrument detection limit
LOL	limit of linearity
LOQ	limit of quantitation
MDL	method detection limit
MS	mass spectrometry
OVA	organic vapor analyzer
PA/SI	primary assessment/site inspection
PAH	polycyclic aromatic hydrocarbon
PCB	polychlorinated biphenyl
PQL	practical quantitation limit
QA	quality assurance
QC	quality control
QAPjP	quality assurance project plan
QTM	Quick Turnaround Method
RI	remedial investigation
RI/FS	remedial investigation/feasibility study
RPM	remedial project manager
RRF	relative response factor
RRT	relative retention time
SAP	sampling and analysis plan
SOP	standard operating procedure
SQL	sample quantitation limit
TIC	tentatively identified compound
TRIS	Toxic Release Inventory System
XRF	X-ray fluorescence

3.1 DATA USEABILITY CRITERIA

Exhibit 12 lists the six data useability criteria involved in planning for the risk assessment, summarizes the importance of each criterion to risk assessment, and suggests actions to take during the planning process to improve the useability of data. The following sections define each criterion and describe its effect on risk assessment.

3.1.1 Data Sources

The data sources selected during the RI planning process depend on the type of data required and their intended use. Data collected prior to the RI are considered historical; data collected during the RI are considered current and are usually specified in the RI planning process. Data may be analytical or non-analytical. The same analytical data requirements apply, whether the data are current or historical. Field screening methods can be used, and sufficient documentation produced, to act as an initial source of data. The minimum criteria for analytical data are discussed in Chapter 5.

Exhibit 13 identifies available data sources and their primary uses in the risk assessment process. Historical and current analytical data sources are briefly discussed below.

Data sources prior to remedial investigation. Historical data sources are useful for determining sampling locations and analytical approaches in the RI. Early site inspections may locate industrial process information that suggests chemicals of potential concern. Historical data indicate industry-specific analytes and general levels of contamination and trends that are useful for identifying exposure pathways, for developing the sampling design, and for selecting analytical methods. Historical analytical data are often available from the preliminary assessment/site inspection (PA/SI), including reports on the physical testing, screening, and analysis of samples. Other sources of analytical data for baseline risk assessment include the Hazard Ranking System (HRS) documentation, site records on removal and disposal, and industry-specific systems for chemical discharge permits. Results from analyses by state or local governments may also indicate chemicals of potential concern. Exact locational data for historical samples should be obtained whenever possible.

• *Use historical analytical data and a broad spectrum analysis to initially identify the chemicals of potential concern or exposure areas.*

The quality of historical data must be determined prior to their use in the RI. For historical analytical data to be

EXHIBIT 12. IMPORTANCE OF DATA USEABILITY CRITERIA IN PLANNING FOR BASELINE RISK ASSESSMENT

Data Useability Criterion	Importance	Suggested Action
Data Sources (3.1.1)	Data sources must be comparable if data are combined for quantitative use in risk assessment. Plans can be made in the RI for use of appropriate data sources so that data compatibility does not become an issue.	Use data from different data sources together to balance turnaround time, quality of data, and cost. Consult with a chemist or statistician to assess compatibility of data sets.
Documentation (3.1.2)	Deviations from the SAP and SOPs must be documented so that the risk assessor will be aware of potential limitations in the data. The risk assessor may need additional documentation, such as field records on weather conditions, physical parameters and site-specific geology. Data useable for risk assessment must be linked to a specific location.	Review the workplan and SAP and, if appropriate, SOPs. As the data arrive, check for adherence to the SAP so that corrective action such as resampling may be taken and still adhere to the project timetable. Stress importance of chain-of-custody for sample point identification in RI planning meetings.
Analytical Methods and Detection Limits (3.1.3)	The method chosen must test for the chemical of potential concern at a detection limit that will meet the concentration levels of concern in applicable matrices. Samples may have to be reanalyzed at a lower detection limit if the detection limit is not low enough to confirm the presence and amount of contamination.	Participate with chemist in selecting methods with appropriate detection limits during RI planning. Consultation with a chemist is required when a method's detection limit is at or above the concentration level of concern.

**EXHIBIT 12. IMPORTANCE OF DATA USEABILITY CRITERIA
IN PLANNING FOR BASELINE RISK ASSESSMENT
(Cont'd)**

Data Useability Criterion	Importance	Suggested Action
Data Quality Indicators (3.1.4)		
Completeness	Completeness for critical samples must be 100%. Unforeseen problems during sample collection (as defined in Chapter 4) and analysis can affect data completeness. If a sample data set for risk assessment is not complete, more samples may have to be analyzed, affecting RI time and resource constraints.	Define completeness in the SAP for both the number of samples and quantity of useable data needed to meet performance objectives. Identify critical samples during scoping. The SAP should be reviewed by the RPM before initiation of sampling.
Comparability	The risk levels generated in quantitative risk assessment may be questionable if incompatible data sets are used together.	Plan to use comparable methods, sufficient quality control, and common units of measure for different data sets that will be used together, to facilitate data compatibility. Consult with a chemist to ensure comparability of data sets.
Representativeness	Sample data must accurately reflect the site characteristics to effectively represent the site's risk to human health and the environment. Hot spots and exposure area media must have representative data.	Discuss plans for collection of sufficient number of samples, a sample design that accounts for exposure area media, and an adequate number of samples for risk assessment during scoping and document plans in the SAP. This guidance may be modified by Region-specific guidelines.
Precision	If the reported result is near the concentration of concern, it is necessary to be as precise as possible in order to quantify the likelihood of false negatives and false positives.	Plan for the use of QC samples (duplicates, replicates and/or collocated samples) applicable to risk assessment before sampling activities begin. Assess confidence limits from the QC data on the basis of the sampling design or analytical method used.
Accuracy	Quantitative accuracy information is critical when results are reported near the level of concern. Contamination in the field, during shipping, or in the laboratory may bias the analytical results. Instruments that are not calibrated or tuned according to Statement of Work requirements may also bias results. The use of data that is biased may affect the interpretation of risk levels.	Plan and assess QC data (blanks, spikes, performance evaluation samples) to measure bias in sampling and analysis. Consult a chemist to interpret data qualified as "estimated" that are near a concentration of concern.
Data Review (3.1.5)	Use of preliminary data or partially reviewed data can conserve time and resources by allowing modification of the sampling plan while the RI is in process. Critical analytes and samples used for quantitative risk assessment require a full data review.	Decisions regarding level and depth of review will conserve time and project resources and should be made in conjunction with the RPM and analytical chemist. "Non-detect" results require a full review.
Reports to Risk Assessor (3.1.6)	Data reviewers should report data in a format that provides readability as well as clarifying information. SQLs, a narrative, and qualifiers that are fully explained reduce the time and effort required in interpreting and using the analytical results. Limitations can be readily identified and documented in the risk assessment report.	Prescribe a report format during scoping, and include it in the SAP. Communicate with the potential data reviewer to aid the definition of a specific report format. Region-specific guidelines may apply.

EXHIBIT 13. DATA SOURCES AND THEIR USE IN RISK ASSESSMENT

Available Data Sources	Data Type	Primary Use(s)
PA/SI data	Analytical	<ul style="list-style-type: none"> • Scoping and planning • Identifying data trends • Determining historical background levels
HRS documentation	Site records, manifests, PA/SI, analytical	<ul style="list-style-type: none"> • Quantitating the risk assessment • Identifying trends • Planning (by identifying the chemicals present)
Site records on removal and disposal	Administrative	<ul style="list-style-type: none"> • Planning (by identifying the chemicals present)
Toxic Release Inventory System (TRIS) (Industry-Specific)	Chemical discharge	<ul style="list-style-type: none"> • Planning (by identifying the chemicals present)
Site, source and media characteristics as found in PA/SI data and reference materials	Physical parameters (e.g., meteorological, geological)	<ul style="list-style-type: none"> • Determining fate and transport • Defining exposure pathways
Field screening	Analytical	<ul style="list-style-type: none"> • Performing a preliminary assessment • Characterizing the site
Field analytical	Analytical	<ul style="list-style-type: none"> • Quantitating the risk assessment • Characterizing the site
Fixed laboratory,* both CLP and non-CLP (EPA, state, PRP, commercial)	Analytical	<ul style="list-style-type: none"> • Quantitating the risk assessment • Providing a reference • Broad screen • Confirming screening data • Characterizing a site
* Mobile laboratories often have the same instrumentation available as fixed laboratories, with the exception of ICP or MS.		

21-002-013

useful in the quantitative risk assessment, sampling design, sampling and analytical techniques, and detection limits must be documented, and the data must have been reviewed.

Historical analytical data of unknown quality may be used in developing the conceptual model or as a basis for scoping, but not in determining representative exposure concentrations. Analytical data from the PA/SI that meet minimum data useability requirements (see Section 5.1.1) can be combined with data from the RI to

estimate exposure concentrations. Similarly, historical data of lower quality may be used if the concentrations are confirmed by subsequent RI analyses.

Data sources for the remedial investigation. It may be efficient to use a variety of data sources during an RI. For example, analytical services providing a rapid turnaround of estimated data can be used to estimate the three-dimensional extent of contamination or to "chase" a groundwater pollutant plume. Rapid turnaround analytical services include field analysis or Quick

Turnaround Method (QTM) analyses under the Contract Laboratory Program (CLP). On the other hand, if an unexpected situation arises, such as the discovery of buried drums on the site, it may be appropriate to procure the analytical services of a local commercial laboratory. Data requiring a rapid turnaround are typically produced from streamlined analytical methods, and a certain percentage should be analyzed using a confirmatory method, such as CLP analytical services.

The planning process for the RI identifies gaps in the available analytical data and determines additional data collection requirements. Three types of analytical data sources can be used during the RI to acquire analytical data for a risk assessment. These include field screening, field analyses, and fixed laboratory analyses.

- Field screens are performed using chemical field test kits, ion-specific probes, and other monitoring equipment, but should be confirmed by other techniques. Field screening is usually performed to provide a preliminary assessment of the type and level of concentration of the chemicals of potential concern.
- Field analyses are performed using instruments and procedures equivalent to fixed laboratory analyses; they produce legally defensible data if QC procedures are implemented. Field analyses are usually performed as part of an integrated sampling and analysis plan to quantitate risk assessment and site characterization.
- Fixed laboratory analyses are particularly useful for broad spectrum and confirmation analyses. They often provide more detailed information over a wider range of analytes than field analyses. Fixed laboratory analyses are critical to quantitative risk assessment and site characterization.

A discussion of issues related to field and fixed laboratory analyses is presented in Section 3.2.9.

Analytical services constitute a significant portion of the Superfund budget and should be conserved when possible. CLP costs do not appear on the remedial investigation/feasibility study (RI/FS) project budget. Analyte-specific methods may be used for chemicals identified after a broad spectrum analysis by CLP or other fixed laboratory analysis, and may provide more accurate results. Site samples analyzed by CLP routine analytical services take an average of 35 days to produce results and data review will add to the overall turnaround time. Other data sources, such as a mobile laboratory or CLP QTM or special analytical services, can quickly produce good "first look" results which can be followed up immediately while on site. Mobile laboratory services

can replace some CLP services if analytical capabilities are adequately demonstrated by method validation data and if minimum QC requirements are met (see p. 59). At least 10% of sample analyses should be confirmed by fixed laboratory analysis in all situations.

3.1.2 Documentation

Data collection and analysis procedures must be accurately documented to substantiate the analysis of the sample, conclusions derived from the data, and the reliability of the reported analytical data. Plans should be prepared during the RI scoping to document data collection activities. This RI documentation can be used later to evaluate completeness, comparability, representativeness, precision, and accuracy of the analytical data sets. Four major types of documentation are produced during an RI:

- The sampling and analysis plan, including a quality assurance project plan (QAPjP),
- Standard operating procedures (SOPs),
- Field and analytical records, and
- Chain-of-custody records.

Sampling and analysis plan. The scoping meetings and the SAP must clearly establish the end use requirements for data. The data quality indicators for assessing results against stated performance objectives should also be documented in the SAP (see Section 3.1.4). The SAP includes the QAPjP and information required in the SOPs, field and analytical records, and chain-of-custody records (EPA 1989a).

Standard operating procedures and field and analytical records. SOPs for field and analytical methods must be written for all field and laboratory processes. Adherence to SOPs provides consistency in sampling and analysis and reduces the level of systematic error associated with data collection and analysis. Exhibit 14 lists the types of SOPs, field records, and analytical records that are usually associated with RI data collection and analyses, and relates the importance of each to the risk assessment.

All deviations from the referenced SOPs should be pre-approved by the RPM and documented. Samples that are not collected or analyzed in accordance with established SOPs may be of limited use because their quality cannot be determined.

Chain-of-custody. The technical team must decide during scoping what data may be used for cost recovery actions, and plan accordingly for the use of full-scale chain-of-custody or less formal chain-of-custody procedures. Full-scale chain-of-custody is required for

EXHIBIT 14. RELATIVE IMPORTANCE OF DOCUMENTATION IN PLANNING AND ASSESSMENT

Documentation	Importance
Sampling and Analysis Plan <ul style="list-style-type: none"> • Selection and identification of sampling points • Sample collection SOP • Analytical procedures or protocols • SOP for data reporting and review • QA project plan • Method-specific QC procedures • QA/QC procedures • Documented procedures for corrective action • SOP for corrective action and maintenance • Sample preservation and shipping SOP • SOPs for sample receipt, custody, tracking and storage • SOP for installation and monitoring of equipment 	Critical High High High High Medium Medium Medium Medium Medium Low Low
Chain-of-Custody <ul style="list-style-type: none"> • Documentation records linking data to sample location • Sampling date • Sample tags • Custody seals • Laboratory receipt and tracking 	Critical Critical High Low Low
Field and Analytical Records <ul style="list-style-type: none"> • Field log records • Field information describing weather conditions, physical parameters or site-specific geology • Documentation for deviations from SAP and SOPs • Data from analysis -- raw data such as instrument output, spectra, chromatograms and laboratory narrative • Internal laboratory records 	High High High High Low
KEY Critical = Essential to the useability of data for risk assessment. High = Should be addressed in planning for risk assessment. Medium = Primarily impacts how data are qualified in risk assessment. Low = Usually has little effect on useability of data for risk assessment.	

21-002-014

cost recovery and enforcement actions, but does not affect a quantitative determination of risk. Full-scale chain-of-custody includes sample labels and formal documentation that prove the sample was not tampered with or lost in the data collection and analysis process. Sample identity must be verifiable from the collector's notebook and laboratory data sheets, as well as from a formal chain-of-custody.

3.1.3 Analytical Methods and Detection Limits

The choice of analytical methods is important in RI planning. Appropriate analytical methods have detection

limits that meet risk assessment requirements for chemicals of potential concern and have sufficient QC measures to quantitate target compound identification and measurement. The detection limit of the method directly affects the useability of data because chemicals reported near the detection limit have a greater possibility of false negatives and false positives. The risk assessor or RPM must consult a chemist for assistance in choosing an analytical method when those available have detection limits near the required action level. Whenever possible, methods should not be used if the detection limits are above the relevant concentrations of concern.

3.1.4 Data Quality Indicators

Data quality indicators (DQIs) are identified during the development of data quality objectives (DQOs), to provide quantitative measures of the achievement of quality objectives. This section discusses each of five DQIs as they relate to the assessment of sampling and analysis.

- Completeness
- Comparability
- Representativeness
- Precision
- Accuracy

These indicators are evaluated through the review of sampling and analytical data and accompanying

documentation. The risk assessor may need to communicate with a chemist or statistician after the data collection process has been completed to evaluate DQIs. Therefore, the SAP, field and analytical records, and SOPs should be accessible. Exhibits 15 and 16 summarize the importance of DQIs to sampling and analysis in risk assessment and suggest planning actions.

Each DQI is defined in this section. Note that the specific use of the indicators to measure data useability is different for sampling and analysis. For example, completeness as applied to sampling refers to the number of samples to be collected. Completeness as applied to analytical performance primarily refers to the number of data points that indicate an analytical result for each chemical of interest (e.g., 10 samples analyzed for 25 chemicals will produce a total of 250 data points, 10 data points for each chemical).

EXHIBIT 15. RELEVANCE OF SAMPLING DATA QUALITY INDICATORS

Data Quality Indicators	Importance	Suggested Planning Action
Completeness	Complete materials enable assessment of sample representativeness for identification of false negatives and estimation of average concentration.	Stipulate SOPs for sample collection and handling in the SAP to specify requirements for completeness.
Comparability	Comparable data give the ability to combine analytical results across sampling episodes and time periods.	Use the same sample design across sampling episodes and similar time periods.
Representativeness	Representative data avoid false negatives and false positives (field sampling contamination). Non-representative data may result in bias of concentration estimates.	Use an unbiased sample design. Collect additional samples as required. Prepare detailed SOPs for handling field equipment.
Precision	Variability in concentration estimates may increase uncertainty.	Increase number of samples. Use appropriate sample designs. Use QC results for monitoring.
Accuracy	Contamination during sampling process, loss of sample from improper collection or handling (loss of volatiles) may result in bias, false negatives, or false positives and inaccurate estimates of concentration.	Use SOPs for sample collection, handling, and decontamination. Use QC results for monitoring.

21-002-015

EXHIBIT 16. RELEVANCE OF ANALYTICAL DATA QUALITY INDICATORS

Data Quality Indicators	Importance	Suggested Planning Action
Completeness	Poor data quality or lost samples reduces the size of the data set and decreases confidence in supporting information.	Prepare SOPs to support sample tracking and analytical procedures, review, and reporting aspects of laboratory operations.
Comparability	Comparable data allow the ability to combine analytical results acquired from various sources using different methods for samples taken over the period of investigation.	Reference analyte-specific method performance characteristics. Reference applicable fate and transport documentation. Anticipate field and laboratory variability.
Representativeness	Non-representative data or non-homogeneity of sample increases the potential for false negatives or false positives. Potential for change in sample before analysis may decrease representativeness.	Include requirement for broad spectrum analyses across site area. Ensure sample is mixed and adequately represents the environment (not applicable to volatiles). Include provision for blank (transport, storage and analytical) QC monitoring. Use field methods when applicable, since they have an advantage in minimizing variability from transport and storage.
Precision	Monitoring can indicate the level of precision. Precision provides the level of confidence to distinguish between site and background levels of contamination. It is of primary importance when the concentration of concern approaches the detection limit.	Method QC component and site-specific QC samples that use external reference are the best monitoring techniques. Consider in method selection whether anticipated site levels are near the MDL and above action limits.
Accuracy	Accuracy also provides the level of confidence to distinguish between site and background levels of contamination. As concentration of concern approaches the detection limit, the differentiation includes confidence in determining presence or absence of chemical of potential concern.	Broad spectrum screening methods may have significant negative bias for chemicals of potential concern. Consider method accuracy and detection limits if site levels approach concentrations of concern.

Completeness. Completeness is a measure of the amount of useable data resulting from a data collection activity. The required level of completeness should be defined in the QAPjP for the number of samples required in the sampling design and for the quantity of useable data for chemical-specific data points needed to meet performance objectives. All required data items must be obtained for critical samples and chemicals, which are identified in the QAPjP. Incompleteness in any data item may bias results as well as reduce the amount of useable data.

Problems that occur during data collection and analysis affect the completeness of a data set. Fewer samples may be collected and analyzed than originally planned because of site access problems. Laboratory performance may be affected if capacity is exceeded, causing data to be rejected. Some samples may not be analyzed due to matrix problems. Samples that are invalid due to holding time violations may have to be re-collected or the data set may be determined as useable only to a limited extent. Therefore, both advance planning in identifying critical samples and the use of alternative sampling procedures are necessary to ensure completeness of a data set for the baseline risk assessment.

Comparability. Comparability expresses the confidence with which data are considered to be equivalent. Combined data sets are used regularly to develop quantitative estimates of risk. The ability to compare data sets is particularly critical when a set of data for a specific parameter is applied to a particular concentration of concern.

Comparability for sampling primarily involves sampling designs and time periods. Typical questions to consider in determining sampling comparability include:

- Was the same approach to sampling taken in two sampling designs?
- Was the sampling performed at the same time of year and under similar physical conditions in the individual events?
- Were samples filtered or unfiltered?
- Were samples preserved?

Typical questions to consider in determining analytical comparability include:

- Were different analytical methodologies used?
- Were detection limits the same or at least similar?

- Were different laboratories used?
- Were the units of measure the same?
- Were sample preparation procedures the same?

Use routine available methods and consistent units of measure when data collection will span several different sampling events and laboratories, to increase the likelihood that analytical results will be comparable. For field analyses confirmed by laboratory analyses, careful attention must be taken to ensure that the data from field and fixed laboratories are comparable or equivalent (see Section 3.2.9). When precision and accuracy are known, the data sets can be compared with confidence. Planning ahead for comparable sampling designs, methods, quality control, and documentation will aid the risk assessor in combining data sets for each exposure pathway.

Representativeness. For risk assessment, representativeness is the extent to which data define the true risk to human health and the environment. Samples must be collected to reflect the site's characteristics and sample analyses must represent the properties of the field sample. The homogeneity of the sample, use of appropriate handling, storage, preservation procedures, and the detection of any artifacts of laboratory analyses, such as blank contamination, are particularly important. For risk assessment, sampling and analyses must adequately represent each exposure area or the definition of an exposure boundary.

Representativeness can be maximized by ensuring that sampling locations are selected properly, potential hot spots are addressed, and a sufficient number of samples are collected over a specified time span. The SAP should describe sampling techniques and the rationale used to select sampling locations.

Precision. Precision is a quantitative measure of variability, comparing results for site samples to the mean, and is usually reported as a coefficient of variation or a standard deviation of the arithmetic mean. Results of QC samples are used to calculate the precision of the analytical or sampling process. Measurement error is a combination of sample collection and analytical factors. Field duplicate samples help to clarify the distinction between uncertainty from sampling techniques and uncertainty from analytical variability. Analytical variability can be measured through the analysis of laboratory duplicates or through multiple analyses of performance evaluation samples. If analytical results are reported near a concentration of concern, the standard deviation or coefficient of variation can be incorporated in standard statistical evaluations to determine the confidence level of the reported data. A statistician or

a chemist should be consulted to make this determination. Total variability must be evaluated to assess the precision of data used to define parameters in risk assessment.

Accuracy. Accuracy is a measure of the closeness of a reported concentration to the true value. This measure is usually expressed as bias (high or low) and determined by calculating percent recovery from spiked samples. The risk assessor should know the required level of certainty for the end use of the data, expressed as DQOs, when reviewing accuracy information. When results are reported at or near a concentration of concern, accuracy information is critical.

Accuracy of identification may be affected by sample contamination introduced in the field, during shipping, or at the laboratory. Field and trip blanks should be used during the RI to identify contamination and the associated bias related to sample collection or shipment. Method blanks, audit samples, and calibration check standards should be used to monitor laboratory contamination. Accuracy information may be of less importance if the precision (bias) is known.

3.1.5 Data Review

This section discusses the importance of alternative levels of data review to the risk assessment. The two major effects of data review on data useability are:

- The timeliness of the data review and
- The level and depth of review (e.g., entire site, specific sample focus, specific analyte focus, amount of QC data assessed).

A tiered approach involving combinations of data review alternatives is recommended so that the risk assessor can use preliminary data before extensive review. The RPM, in conjunction with the risk assessor and the project chemist, must reach a consensus on the level and depth of data review to be performed for each data source, to balance useability of data and resource constraints. Exhibit 17 summarizes the characteristics and uses of different levels of data review.

Timing of review. Plans for the timing of the data review should be made prior to data collection and analysis. The risk assessor uses preliminary data in a qualitative manner to identify compounds for toxicity studies and, initially, to ascertain trends in concentrations and distributions of the analytes of concern, to plan for additional sampling, and to request additional analyses. Using data as they become available will usually reduce the time needed to complete the risk assessment. However, all data must receive a minimum level of review before use in the quantitative aspects of risk assessment. Iterations on data review is resource intensive; if they are used, they should be planned carefully as part of a structured process.

EXHIBIT 17. ALTERNATIVE LEVELS OF REVIEW OF ANALYTICAL DATA

Level of Review	Samples	Analytes	Parameters	Potential Uses
None	Initial	All	Analytical results	Qualitatively identify risk assessment analytes. Modify SAP.
Full	Initial samples analyzed for broad spectrum components	All	All analytical results, QC, and raw data	Quantitatively perform risk assessment. Modify SAP. Modify review process.
Partial	Critical samples for all analytes or All samples for critical analytes		Selected analytical results, QC, or raw data	Improve timeliness, overall efficiency, save resources. Focus on chemicals of potential concern.
Automated	All	All	Parameters available to the automated system. No raw data are evaluated.	Improve timeliness, consistency, cost effectiveness. If data are electronically transferred to a database, eliminates transcription errors.

• To expedite the risk assessment, preliminary data should be provided to the risk assessor as soon as they are available.

Level and depth of review. The RPM may select different levels of data review, in consultation with the risk assessor or other data users and the project chemist. All data must have a minimum level of review. Data review levels can range from all site samples with all reported data to specific key analytes and samples and may be specified in EPA Regional policies. Careful consideration is required in selecting a level of review that is consistent with data quality requirements.

A full data review minimizes false positives, false negatives, calculation errors, and transcription errors. "Non-detect" results must be reviewed to avoid "false negative" conclusions. Partial review should be utilized only after broad spectrum analysis results have undergone full review; it may be useful after chemicals of potential concern have been identified. A flexible approach to data review alternatives allows the RPM to balance time and resource constraints.

Depth of data review refers to which evaluation criteria are selected, ranging from generalized criteria that may affect an entire data set (e.g., holding time) to analyte-

specific criteria that may affect only a portion of results from one sample (e.g., recovery of a surrogate spike for organics or analyte spike recovery for inorganics). The RPM decides the depth of review for each data source, to provide a balance between useability of data and resource constraints. Chemicals of potential concern in the quantitative risk assessment should not be eliminated from concern without a full data review.

Automated data review systems. Automated data review systems can be used to assess all samples and analytes for which there are computer-readable data in the format required by the automated system. The depth of review depends on both the data and the assessment system. The primary advantages of automated data review systems for the risk assessor are timeliness, the elimination of transcription errors that can be introduced during manual review processes, and computer-readable output which usually includes results and qualifiers. This information can be transferred to computer-assisted risk assessment and exposure modeling systems. Exhibit 18 provides a list of software that aid data review and evaluation.

EXHIBIT 18. AUTOMATED SYSTEMS* TO SUPPORT DATA REVIEW

System	EPA Contact	Description
CADRE Computer Assisted Data Review and Evaluation	Gary Robertson Quality Assurance Div. USEPA, EMSL-LV (702) 798-2215	An automated evaluation system that accepts files from CLP format disk delivery or mainframe transfer and assesses data based on <i>National Functional Guidelines for Organic (or Inorganic) Data Review</i> (EPA 1991e, EPA 1988e) (default criteria). System accepts manual entry of other data sets, and rules for evaluation can be user-defined to reflect specific information needs. (Inorganic system is in development.)
eDATA Electronic Data Transfer and Validation System	William Coakley USEPA, Emergency Response Team (908) 906-6921	An automated review system developed to assist in rapid evaluation of data in emergency response. May be applicable for both CLP and non-CLP data. System combines DQOs, pre-established site specifications, QC criteria, and sample collection data with laboratory results to determine useability.

* Both systems operate on an IBM-compatible PC AT with a minimum of 640K RAM. A fixed disk is recommended.

3.1.6 Reports from Sampling and Analysis to the Risk Assessor

Preliminary data reports assist the risk assessor in identifying sampling or analytical problems early enough so that corrective actions can be taken during data collection, before sampling or analysis resources are exhausted. The risk assessor should request preliminary data during RI planning and formalize the request in the SAP. The use of such information may reduce the overall time required for the risk assessment and increase the quality of a quantitative risk assessment.

Exhibit 19 lists the final data and documentation needed to support risk assessment, and rates the importance of each item. Data are most useable when reported in a readable format and accompanied by additional, clarifying information. Regional policy usually defines report structures which specify the format for manual summaries, for machine-readable data (where required), and for summary tables from data review. The RPM can request the data reviewers to provide a data summary table listing sample results, sample quantitation limits, and qualifiers on diskette for downloading into Risk* Assistant (an automated tool to support risk assessment), spreadsheets, or other software programs that the risk

EXHIBIT 19. DATA AND DOCUMENTATION NEEDED FOR RISK ASSESSMENT

Data and Documentation	Importance
<ul style="list-style-type: none"> • Site description with a detailed map indicating site location, showing the site relative to surrounding structures, terrain features, population or receptors, indicating air and water flow, and describing the operative industrial process if appropriate. 	Critical
<ul style="list-style-type: none"> • Site map with sample locations (including soil depths) identified. 	Critical
<ul style="list-style-type: none"> • Description of sampling design and procedures including rationale. 	Critical
<ul style="list-style-type: none"> • Description of analytical method used and detection limits including SQLs and detection limits for non-detect data. 	Critical
<ul style="list-style-type: none"> • Results given on a per-sample basis, qualified for analytical limitations and error, and accompanied by SQLs. Estimated quantities of compounds/tentatively identified compounds. 	Critical
<ul style="list-style-type: none"> • Field conditions and physical parameter data as appropriate for the media involved in the exposure assessment. 	Critical
<ul style="list-style-type: none"> • Narrative explanation of qualified data on an analyte and sample basis, indicating direction of bias. 	High
<ul style="list-style-type: none"> • QC data results for audits, blanks, replicates and spikes from the field and laboratory. 	High
<ul style="list-style-type: none"> • Definitions and descriptions of flagged data. 	High
<ul style="list-style-type: none"> • Hardcopy or diskette results. 	Medium
<ul style="list-style-type: none"> • Raw data (instrument output, chromatograms, spectra). 	High
<ul style="list-style-type: none"> • Definitions of technical jargon used in narratives. 	Low
<p>KEY</p> <p>Critical = Essential to the useability of data for risk assessment.</p> <p>High = Should be addressed in planning for risk assessment.</p> <p>Medium = Primarily impacts how data are qualified in risk assessment.</p> <p>Low = Has little effect on useability of data for risk assessment.</p>	

assessor may use. An example of a recommended report format for tabular results appears in Appendix I.

The data reviewer should provide a narrative summary, which is comprehensible to a nonchemist, describing specific sampling or analytical problems, data qualification flags, detection limit definitions, and interpretation of QC data. This summary must always be followed and supported by a detailed commentary that explicitly addresses each item from the narrative on a technical basis. The explanation for data qualification in the commentary facilitates data use. If a nontechnical narrative is unavailable, the risk assessor must (at a minimum) be provided with explanations of qualification flags, detection limits, and interpretation of QC data (see Appendices I, V and VI for examples). A chemist familiar with the site can be requested to interpret the analytical review with site-specific information, such as physical site conditions that affect sample results.

3.2 PRELIMINARY SAMPLING AND ANALYTICAL ISSUES

This guidance cannot encompass sampling design in the assessment of environmental sampling and analysis procedures; however, this section does sketch a framework for these activities. It discusses key issues for determining the potential impact of sampling and analysis procedures on data useability for risk assessment and for identifying situations that require statistical or methodological support. The sampling discussion primarily focuses on soil issues, but some generalizations can be made to other media such as sediment or groundwater. Rules of thumb, reference tables, statistical formats and checklists support the statistical understanding and sophistication of RPMs and risk assessors. A Sampling Design Selection Worksheet, a Soil Depth Sampling Worksheet, and a Method Selection Worksheet are tools, presented with step-by-step instructions in Chapter 4, to focus planning efforts.

Sampling issues. Resolving statistical and non-statistical sampling issues provides the risk assessor, project chemist, and QA personnel with a basis for identifying sampling design and data collection problems, interpreting the significance of analytical error, and selecting methods based on the expected contribution of sampling and analytical components to total measurement error. Comprehensive discussions of environmental sampling procedures are given in *Principles of Environmental Sampling* (Keith 1987), *Environmental Sampling and Analysis* (Keith 1990a), *Methods for Evaluating the Attainment of Cleanup Standards* (EPA 1989e), and the *Soil Sampling Quality Assurance User's Guide* (EPA 1989f).

Several assumptions concerning sampling and associated statistical procedures have been made to simplify the discussion in this section:

- The RPM and risk assessor are familiar with basic environmental sampling and statistical terms and logic and have access to a statistician.
- Sampling designs are mainly based on stratified random or systematic random sampling (grid), or variations thereof. Systematic sampling requires special variance calculations for estimating statistical performance parameters such as power and confidence level; these calculations are not provided in this guidance.
- Statisticians are consulted for any significant problems or issues not covered in this guidance.
- Superfund contaminant concentrations for a site generally fit a log-normal distribution. Measurements of variability are generally given in log-transformed units. Overviews of statistical methodology include Gilbert (1987) and Koch and Link (1971). Parametric tests in transformed units (Aitchison and Brown 1957) have logarithmic forms (Seichel 1956). Graphical methods of determining re-transformed means and their 95% confidence levels are available (Krige 1978).
- Quality assurance procedures for sampling and analysis are not separate, even though the discussion addresses them separately.

Exhibit 20 summarizes the importance of each of the preliminary sampling planning issues to the risk assessment, proposes planning actions to reduce or eliminate their effect on data useability, and refers the reader to further discussion in the text. Information relevant to preliminary sampling planning can be obtained by collecting site maps, photographs and other historical and current documents which depict production, buildings, sewage and storm drains, transport corridors, dump sites, loading zones, and storage areas. A reliable and current base map is particularly important.

Data adequacy. All data users should clearly state the level of data adequacy they desire. These statements, and the resources that will be committed, should be incorporated into the sampling plan objectives. If an appropriate level of uncertainty cannot be determined at this stage, an initial goal should be agreed on for the final level of reliability, which may be revised during the iterative sampling process. Since each site is unique, it may be extremely difficult to attain a given level of data adequacy. An iterative sampling program may

EXHIBIT 20. IMPORTANCE OF SAMPLING ISSUES IN RISK ASSESSMENT

Issue	Importance	Suggested Action
Chemicals of Potential Concern (3.2.1)	Chemicals have different rates of occurrence and coefficients of variation. This impacts the probability of false negatives and reduces confidence limits for estimates of concentration.	Increase the number of samples for chemicals with low occurrence and/or high coefficients of variation.
Sampling and Analytical Variability versus Measurement Error (3.2.5)	Sampling variability can exceed measurement error by a factor of three to four (EPA 1989c). Sampling variability increases uncertainty or variability; measurement error increases bias.	Reduce sampling variability by taking more samples (using less expensive methods). This allows more samples to be analyzed. Use QC samples to estimate and control bias. Prepare SOPs for handling all field equipment.
Media Variability (3.2.5)	Sampling problems vary widely by media as do variability and bias.	Design media-specific sampling approaches.
Sample Preparation and Sample Preservation (3.2.6)	Contamination can be introduced during sample preparation, producing false positives. Filtering may remove contaminants sorbed on particles.	Use blanks at sources of potential contamination. Collect filtered and unfiltered samples.
Identification of Exposure Pathways (3.2.7)	Not all samples taken in a site characterization are useful for risk assessment. Often only a few samples have been taken in the area of interest.	Specifically address exposure pathways in sampling designs. Risk assessors should participate in scoping meeting.
Use of Judgmental or Purposive Sampling Design (3.2.8)	Statistical sampling designs may be costly and do not take advantage of known areas of contamination.	Use judgmental sampling to examine known contaminated areas, then use an unbiased method to characterize exposure.

21-002-020

allow a realistic appraisal of the variability present at the site; a phased investigation may be warranted, with an increase in data adequacy at each phase.

Natural variation. It is important to realize that natural variation (environmental heterogeneity) in both soil and water systems may be so great that variation due to field sampling is significantly greater than that due to laboratory analysis. For example, laboratory sample-sample precision is commonly of the order of less than 1%, whereas soil sample-sample precision is commonly between 30% to 40%. Sampling variation is influenced by the homogeneity of material being sampled, the number of samples, collection procedures, and the size of individual samples.

Uncertainty in sampling measurements is additive. Exhibit 21 lists the components of sampling variability and measurement error. The final error associated with an estimate is the sum of the errors associated with natural variation (intrinsic randomness, microstructure, macrostructure), plus sampling error, plus laboratory

measurement error. Poor sampling techniques can swamp the natural phenomenon that is being evaluated. Therefore, sampling options must be fully reviewed and the probable uncertainty from sampling must be acceptable.

Initial survey sampling plan. A preliminary sampling plan should be chosen that provides a basis for evaluation of overall sampling goals, sampling techniques, feasibility, and statistical analysis techniques. General categories of sampling plans include simple random, stratified random, systematic, judgmental/purposive, and spatial systematic. The features of these different plans are discussed in more detail in Chapter 4.

Statistical analysis of the survey data allows evaluation of how well the sampling program is doing. Depending on the contaminant, current technology may allow on-site "laboratory" analysis of the samples using portable microcomputers and telecommunications. On-site statistical analysis is also possible. On-site analysis reduces project completion time and costs. In a truly

EXHIBIT 21. SAMPLING VARIABILITY AND MEASUREMENT ERROR

Sampling variability: The variation between true sample values that is a function of the spatial variation in the pollutant concentrations.

Measurement error: The variation resulting from differences between true sample values and reported values. Measurement error is a function of uncertainty due to the following:

- Sample collection variation
- Sample preparation/handling/preservation/storage variation
- Analytical variation
- Data processing variation

21-002-021

iterative sampling campaign, on-site statistical analysis can guide the sampling teams, maximizing information capture and minimizing time-related costs.

Analytical issues. The following assumptions concerning analytical procedures have been made in this section:

- The RPM and the risk assessor are familiar with standard analytical chemical procedures. Reference books on environmental issues in analytical chemistry are available and can be consulted (ASTM 1979, Manahan 1975, Dragun 1988, Baudo, *et al.*, eds. 1990, Taylor 1987).
- Chemists are available and will be consulted for any significant problems or situations not covered in this guidance.
- Analytical QA procedures are used in conjunction with and affect sampling QA procedures, even though the discussion treats these procedures separately.

Exhibit 22 summarizes the importance of each analytical issue to risk assessment, lists suggested actions during the planning process, and refers the reader to further discussion in the text. Each issue is discussed in terms of its effect on data quality for risk assessment, and how to anticipate and plan for potential problems. The RPM should also consult the project chemist to determine the appropriate sample volumes or weights required for different types of analysis.

Biota sampling and analytical issues. The type of assessment (e.g., human health or ecological) determines the type of samples to be collected. An ecological

assessment may require analysis of the whole body or of a specific organ system of a target species (because organic, and some inorganic, chemicals of concern are often concentrated in tissues with high lipid contents). Human health risk assessment usually concentrates on edible portions.

Typical sampling considerations for biota include specifying the species to be sampled, sampling locations, tissue to be analyzed, number of individuals to be sampled, and the method of analysis of the chemical of concern. Biota analyses should include a method validation that incorporates tissues or plant analyte spikes, and any available performance evaluation materials. The purpose of spiking is to determine whether the analytes are recoverable from the matrix or clean-up steps hinder detection of the analyte.

Spiking and duplicate information can be used to assess method precision and accuracy. The primary source of performance evaluation materials is the National Bureau of Standards repository. Samples and performance evaluation materials should be matched by matrix (species and whole/edible portions).

Volatile analytes are very difficult to measure in biota. Samples should be stored on dry ice immediately after collection. Fat and cholesterol can also block columns and impede chromatography for base/neutral/acid extractable tissue analysis. Gel permeation chromatography procedures may only be marginally effective in clean up, and the lipids present may retain analytes of concern, thereby reducing recoveries. Plant matrices are often difficult to digest, and a variety of digestion procedures using hydrogen peroxide or phosphoric acid may be warranted. Tissues for organic analysis should be wrapped in aluminum foil for shipment to the laboratory, and tissues for metals analysis should be wrapped in plastic film. All tissues should be sent frozen on dry ice.

Air sampling and analysis issues. Air sampling procedures should account for wind speed and direction as well as seasonal and daily fluctuations; they should also account for the influence of these factors on the exposed population (e.g., the largest population may be potentially exposed in the evening when the wind speed may be least). The definition of detection limits is very important for air analyses. For example, the same concentration will appear very different if expressed on a weight/volume basis than on a volume/volume basis.

Sampling strategies may need to distinguish between particulate and gaseous forms of chemicals of concern. It is important to collect media blanks to determine the type and amount of contamination that may be found. Blanks should also be provided to the laboratory for spiking to determine analytical precision and accuracy.

EXHIBIT 22. IMPORTANCE OF ANALYTICAL ISSUES IN RISK ASSESSMENT

Analytical Issue	Importance	Suggested Action
Chemicals of Potential Concern (3.2.1)	Chemicals of potential toxicological significance may be omitted.	Examine existing data and site history for industry-specific wastes to determine analytes for measurement. Perform broad spectrum analysis.
Tentatively Identified Compounds (3.2.2)	Identification and quantitation do not have high confidence.	Be prepared to request further analyses if potentially toxic compounds are discovered during screening. Compare results from multiple samplings or historical data.
Identification and Quantitation (3.2.3)	False negatives may occur when analytes are present near the MDL.	Use technique with definitive identification (e.g., GC-MS). Alternatively, use technique with definitive identification first, followed by another technique (e.g., GC) to achieve lower quantitation limits.
Detection Limits (3.2.4)	Significant risk may result at concentrations lower than measurable.	Review available methods for appropriate detection limit.
Media Variability (3.2.5)	Variability and bias may be introduced to analytical measurements.	Use environmental samples as QC samples to determine recovery and reproducibility in the sample media.
Sample Preparation (3.2.6)	Variability and bias may be introduced to analytical measurements.	Select analytical methods based on sample medium and strengths of the sample preparation technique.
Field Analyses versus Fixed Laboratory Analyses (3.2.9)	Tradeoffs required with regard to speed, precision, accuracy, personnel requirements, identification, quantitation and detection limits.	Consider options and set priorities.
Laboratory Performance Problems (3.2.10)	Quality of data may be compromised.	Select experienced laboratory and maintain communication.

21-002-022

The sample medium should be checked to ensure that recovery rates are documented.

3.2.1 Chemicals of Potential Concern

Chemicals of potential concern are chemicals that may be hazardous to human health or the environment and are identified at the site, initially from historical sources. Chemicals identified at Superfund sites have varying rates of occurrence, average concentrations, and coefficients of variation. These differences are a function

of fate and transport properties, occurrence in different media, and interactions with other chemicals, in addition to use and disposal practices. Information on frequency of occurrence and coefficient of variation determines the number of samples required to adequately characterize exposure pathways and is essential in designing sampling plans. Low frequencies of occurrence and high coefficients of variation mean that more samples will be required to characterize the exposure pathways of interest. Potential false negatives

occur as variability increases and occurrence rates decrease. From an ecological standpoint, chemicals of potential concern may be different from those for human health concerns. For example, copper is an analyte of high concern from an ecological perspective, but of low concern from a human health perspective. In addition, if water quality criteria are used as toxicological thresholds, it should be determined whether the criteria are based on ecological or human health effects.

➤ *To protect human health, place a higher priority on preventing false negatives in sampling and analysis than on preventing false positives.*

Data are available for volatiles, extractable organics, pesticides/PCBs, tentatively identified organic compounds, and metals (see Appendix II), for aqueous and soil/sediment matrices, and releases from industries known to produce waste commonly found at Superfund sites. Data from CLP Superfund sites are also available for calculating site-specific coefficients of variation. Exhibit 23 indicates the occurrence rates and coefficients of variation for selected chemicals of potential concern to risk assessors. Many other chemicals (which are not of concern) may be present without affecting the level of risk to the exposed population.

➤ *Use preliminary data to identify chemicals of potential concern and to determine any need to modify the sampling or analytical design.*

The need for risk assessment indicates that there is already some knowledge of contamination at the site. Based on available toxicological and site data, the risk assessor can recommend target chemicals (or chemical classes) for analysis and desired detection limits. For example, explosive chemicals are likely to be present at a former munitions site. Exhibit 24 presents data on munitions compounds, such as feasible detection limits and health advisory limits.

Information on industry-specific analytes is summarized in Exhibit 25 and detailed in Appendix II. If historical data are incomplete, a broad spectrum analysis should be performed on selected samples from each sampling location to provide necessary scoping information.

The RPM or risk assessor should inform the planning team about chemicals of potential concern at the site, exposure pathways, if known, concentrations of concern, and other pertinent information, particularly any requirement to distinguish specific states of the chemicals of potential concern. Some oxidation states of metals (e.g., chromium) are more easily absorbed or are more toxic than others, and organically substituted metals

such as mercury are more toxic than their elemental states. If these concerns are important, analyses that determine metal specification rather than elemental analyses should be performed, if available. Similarly, for organic compounds, such as tetrachloroethane, degradation products or metabolites may be more toxic than the parent compounds. In this case, sampling procedures and analytical methods should include the parent compound, degradation products, and metabolites of chemicals of potential concern.

3.2.2 Tentatively Identified Compounds

Gas chromatography-mass spectrometry (GC-MS) analyses categorize organic compounds in two ways. Target compounds are those compounds for which the GC-MS instrument has been specifically calibrated using authentic chemical standards. A target compound in an environmental sample is identified by matching its mass spectrum and relative retention time (RRT) to those obtained for the authentic standard during calibration. Quantitation of a target compound is achieved by comparison of its chromatographic peak area to that of an internal standard compound, normalized to the relative response factor (RRF) which is the ratio of the peak areas of the authentic chemical standard and the internal standard measured during calibration.

➤ *Specific analysis for compounds identified during library search can be requested.*

Tentatively Identified Compounds (TICs) are any other compounds which are reported in the sample analysis, but for which the GC-MS instrument was not specifically calibrated. A TIC is identified by taking its mass spectrum from the environmental sample, and comparing it to a computerized library of mass spectra. Computerized comparison routines score the various library spectra for their similarity to the TIC and rank the spectra most similar to the TIC's spectrum. If the TIC is reported as a specific compound, it is usually reported to be one of the compounds whose spectra were retrieved in the library search. Quantitation of a TIC is less accurate than for target compounds, because the true RRF is not known (since no calibration for this specific compound was performed). The RRF is assumed to be 1.0; whereas, measured RRFs below 0.05 and above 10.0 are known.

Confidence in the identification of a TIC can be increased in several ways. The main steps in identifying and quantitating TIC data are summarized in Exhibit 26. An analytical chemist trained in the interpretation of mass spectra and chromatograms can review TIC data

EXHIBIT 23. MEDIAN COEFFICIENT OF VARIATION FOR CHEMICALS OF POTENTIAL CONCERN¹

Chemical of Potential Concern	Soil/Sediment Median %CV ²	Number of Sites at Which Chemical was detected ³	Water Median %CV ²	Number of Sites at Which Chemical was detected ³
Chloromethane	16.7	61	50.0	134
Trichloromethane/Chloroform	53.9	392	45.2	519
Tetrachloromethane/Carbon tetrachloride	15.4	38	9.3	90
1,2-Dichloroethane	17.6	64	24.7	158
Tetrachloroethane	17.0	56	17.4	101
Vinyl chloride	11.0	55	15.7	197
Tetrachloroethene	24.5	392	33.3	367
Dichloropropane	19.0	29	13.3	79
Isophorone	0.7	74	18.4	72
Bis (2-chloroethyl) ether	0.5	10	20.1	34
1,4-Dichlorobenzene	0.9	120	17.3	119
Bis (2-ethylhexyl) phthalate	0.7	1197	29.5	782
Benzo(a) pyrene	0.5	1058	10.8	76
Styrene	16.9	117	33.3	69
N-nitrosodiphenylamine	0.5	142	30.5	96
DDE	4.5	329	813.0	40
DDT	2.9	521	588.2	125
Dieldrin	4.4	274	3.3	101
Heptachlor	4.8	249	351.9	151
Gamma-BHC (lindane)	6.3	142	454.1	134
PCB1260	0.21	251	41.7	23
Arsenic	40.3	1098	58.0	940
Beryllium	271.3	1091	100.0	931
Cadmium	134.6	1096	33.7	945
Chromium	11.9	1098	23.0	948
Mercury	1032.3	1098	500.0	948
Lead (Pb)	10.9	1098	97.3	939

¹ List of chemicals of potential concern is derived from health-based levels and frequency of occurrence at Superfund sites listed in the CLP Statistical Database. (Number of sites for which data exist totals 8,900.)

² Median percent coefficient of variation of analyte concentrations.

³ November 1988 to present.

EXHIBIT 24. MUNITIONS COMPOUNDS AND THEIR DETECTION LIMITS

Health Advisory	Acronym	Compound Name ¹	Detection Limit ² (ppb)
*	HMX	Octahydro-1,3,5,7-tetranitro-1,3,5,7-tetrazocine	5.1
*	RDX	Hexahydro-1,3,5-trinitro-1,3,5-triazine	4.2
	---	Nitrobenzene	6.4
	TNB	1,3,5- Trinitrobenzene	5.9
**	DNB	1,3-Dinitrobenzene	9.1
	Tetryl	Methyl-2,4,6-trinitrophenylnitramine	4.4
*	TNT	2,4,6- Trinitrotoluene	6.3
**	2,4 DNT	2,4-Dinitrotoluene	2.3
	TAX	Hexahydro-1-(N)-acetyl-3,5-dinitro-1,3,5-triazine	
	SEX	Octahydro-1-(N)-acetyl-3,5,7-trinitro-1,3,5,7-tetrazocine	
**	2,6 DNT	2,6-Dinitrotoluene	5.1
*	2,4,5 TNT	2,4,5- Trinitrotoluene	
	2 Am DNT	2-Amino-4,6-dinitrotoluene	
	4 Am DNT	4-Amino-2,6-dinitrotoluene	
	2,4 DAmNT	2,4-Diamino-6-nitrotoluene	
	2,6 DAmNT	2,6-Diamino-4-nitrotoluene	
*	DIMP	Disopropyl-methylphosphonate	
*	TNG	Glycerol trinitrate (Nitroglycerin)	
*	---	Nitrocellulose	
**	DMMP	Dimethyl methylphosphonate	
**	NG	Nitroguanadine	

* Health advisory complete.

** Health advisory in preparation (1990).

¹ Depending upon matrix and instrument conditions, these compounds may be chromatographable and may be tentatively identified as indicators of the presence of munitions during GC-MS library search procedures.

² Detection limits are provided where available. Specific compounds with complete health advisories are designated as target analytes with defined detection limits specified in a high performance liquid chromatographic method developed and provided by the U.S. Army Toxic and Hazardous Materials Agency.

**EXHIBIT 25. SUMMARY OF MOST FREQUENTLY OCCURRING
CHEMICALS OF POTENTIAL CONCERN BY INDUSTRY***

Compound	Industry						
	1	2	3	4	5	6	7
Acetone		X					
Aluminum							X
Ammonia		X	X		X	X	X
Ammonium Nitrate		X					
Ammonium Sulfate	X					X	
Anthracene					X		
Arsenic					X		
Benzene							X
Biphenyl					X		
Chlorine		X					
Chlorobenzene			X				
Chromium				X	X	X	
Copper					X		
Cyclohexane		X					
Dibenzofuran					X		
Dichloromethane			X	X			
Formaldehyde					X		
Freon	X						
Glycol Ethers						X	
Hydrochloric Acid			X	X			
Lead	X						
Manganese	X						
Methanol	X		X				
Methyl Ethyl Ketone		X				X	X
Naphthalene					X		
Nickel				X			
Nitric Acid		X		X			
Pentachlorophenol		X			X		
Propylene							X
Sodium Sulfate	X	X	X	X		X	X
Sodium Hydroxide	X		X	X		X	X
Sulfuric Acid	X	X		X		X	X
Trichloroethene	X			X			
Toluene			X			X	X
Titanium Tetrachloride			X				
Xylene			X			X	X
1,1,1-trichloroethane	X			X			

KEY
 1 = Battery Recycling
 2 = Munitions/Explosives
 3 = Pesticide Manufacturing
 4 = Electroplating
 5 = Wood Preservatives
 6 = Leather Tanning
 7 = Petroleum Refining

* Summarized from Appendix II.

EXHIBIT 26. STEPS IN THE ASSESSMENT OF TENTATIVELY IDENTIFIED COMPOUNDS

Identification	<ul style="list-style-type: none"> • GC-MS analysis indicates the presence of a tentatively identified compound. • Incorporate retention time/retention index matching and use physical characteristics (boiling point or vapor pressure) to determine if identification is reasonable. • Examine historical data and industry-specific compound lists. • Reanalyze sample with an authentic standard.
Quantitation	<ul style="list-style-type: none"> • Assess known analytical response characteristics for similar compounds or similar compound classes. • Determine response characteristics by analysis of an authentic standard.

21-002-026

mass spectra and chromatograms can review TIC data and eliminate many false positive identifications. The use of retention indices or relative retention times can confirm TICs identified by the GC-MS computer (Eckel, *et. al.* 1989). Examination of historical data, industry-specific compound lists, compound identifications from iterative sampling episodes, and analyses performed by different laboratories may also increase confidence in the identification of a TIC. The final identification step is to reanalyze the sample after calibrating the GC-MS instrument with an authentic standard of the compound that the TIC is believed to be.

If toxic compounds are identified as TICs by this type of broad spectrum analysis, the RPM or risk assessor should request further analyses to positively identify the compound and to accurately quantitate it. The risk assessor or RPM should discuss data requirements with an analytical chemist to determine the appropriate analytical method.

Many compounds that appear as TICs during broad spectrum analyses belong to compound classes. Examples of compound classes are saturated aliphatic hydrocarbons and polycyclic aromatic hydrocarbons

(PAHs). The risk assessor may be able to make a preliminary judgment of toxicity at the compound class level without a definitive identification of each compound present. For example, in a sample contaminated by gasoline, organics analysis would indicate a series of TICs as aliphatic hydrocarbons of increasing size. These may not be carcinogenic, and more precise identification may not be required. If a similar sample were contaminated with coal tar, larger hydrocarbons and a series of PAHs would be found during the analysis. The aliphatic hydrocarbons are not especially toxic, but the PAH compound class contains carcinogens and are of greater concern.

3.2.3 Identification and Quantitation




A risk assessor first confirms chemical identification, and then determines the level of contamination. This section summarizes the effects of detection limits and sample contamination considerations on the confidence in analyte identification and quantitation. Requirements for confidence are specified in Exhibit 27. When analytes have concentrations of concern approaching method detection limits, the confidence in both identification and quantitation is low. This case is illustrated in Exhibit 28. In addition, confidence in identifying and quantitating as representative of site

EXHIBIT 27. REQUIREMENTS FOR CONFIDENT IDENTIFICATION AND QUANTITATION

Identification	<ul style="list-style-type: none"> • Analyte present above the IDL. • Organic -- Retention time and/or mass spectra matches authentic standards. • Inorganic -- Spectral absorptions compared to authentic standards. • Knowledge of blank contamination (if any).
Quantitation	<ul style="list-style-type: none"> • Instrument response known from analysis of an authentic standard. • Detected concentration above the limit of quantitation and within the limit of linearity (instrument response not saturated).

21-002-027

EXHIBIT 28. RELATIVE IMPACTS OF DETECTION LIMIT AND CONCENTRATION OF CONCERN: DATA PLANNING

Relative Position of Method Detection Limit (MDL) and Concentration of Concern (COC)	Consequence
 <p>Confidence Limits MDL COC Confidence Limits</p> <p>Concentration</p>	Non-Detects and Detects Useable
 <p>MDL COC</p> <p>Concentration</p>	Possibility of False Positives and False Negatives
 <p>COC MDL</p> <p>Concentration</p>	<p>Non-Detects Not Useable</p> <p>Detects Useable</p> <p>Possibility of False Negatives</p>

21-002-028

conditions is potentially diminished if the chemicals of potential concern are present as contaminants from laboratory or field procedures. This section identifies analytes and cites situations in which this is most likely to occur.

The first requirement of analysis is confidence in the identification of chemicals of potential concern. Identification means that the chemical was present in the environmental sample above the detection limit. Chemicals can be correctly identified at lower concentrations than are suitable for accurate quantitation. If lower quantitation limits are required for risk assessment purposes, a larger initial sample size may be processed, or the sample extract may be concentrated to a smaller final volume. However, concentration of an extract to a smaller volume, or increasing the sample size, may saturate the instrument in the presence of

matrix interferences. The RPM should discuss these issues with an analytical chemist to determine the best approach. A further discussion of limits of quantitation is presented in Section 3.2.4. and Appendix III.

To ensure maximum confidence in the identification of an organic chemical contaminant, an instrumental technique, such as mass spectrometry, that provides definitive results is necessary. Although alternative techniques are available, GC-MS determination is the best available procedure for confident identification or confirmation of volatile and extractable organic chemicals of potential concern. The application of this technique minimizes the risk of error in qualitative identification and measures chemicals of potential concern at environmental levels above the detection or quantitation limits listed in Appendix III. In cases where the target detection limit is too low to allow

but more definitive, instrumental techniques can be used.

The identification of inorganic chemicals is more certain. A reported concentration determined by atomic absorption (AA) spectroscopy or inductively coupled plasma (ICP) atomic emission spectroscopy is generally considered evidence of presence at the designated level reported, provided there is no interference. If interferences exist, the laboratory should try to characterize the type of interferences (background, spectral or chemical) and take the necessary steps to correct them.

3.2.4 Detection and Quantitation Limits and Range of Linearity

The following discussion is intended to provide the RPM and risk assessor with an understanding of the various ways that detection or quantitation limits can be reported. The term "detection limit" is frequently used without qualification. However, there are several methods for calculating detection limits. The RPM should consult with the project chemist and the risk assessor whenever analytical methods are to be selected,

Common Detection and Quantitation Limits

Instrument detection limit. The IDL includes only the instrument portion of detection, not sample preparation, concentration/dilution factors, or method-specific parameters.

Method detection limit. The MDL is the minimum amount of an analyte that can be routinely identified using a specific method. The MDL can be calculated from the IDL by using sample size and concentration factors and assuming 100% analyte recovery.

Sample quantitation limit. The SQL is the MDL adjusted to reflect sample-specific action such as dilution or use of a smaller sample aliquot for analysis due to matrix effects or the high concentration of some analytes.

Contract required quantitation (detection) limit. The CRQL for organics and CRDL for inorganics are related to the SQL that has been shown through laboratory validation to be the lower limit for confident quantitation and to be routinely within the defined linear ranges of the required calibration procedures.

Practical quantitation limit. The PQL, defined in SW846 methods, is the lowest level that can be reliably achieved within specified limits of precision and accuracy during routine laboratory operating conditions.

and specify the nature of the detection limits that must be reported; it is the laboratory's responsibility to adhere to this requirement. If no requirement has been specified, then the laboratory should be requested to explicitly describe the types of the detection limits it reports. Detection limits can be calculated for the instrument used for measurement, for the analytical method, or as a sample-specific quantitation limit. The risk assessor should request that the sample quantitation limit (SQL) be reported whenever possible. The term "detection limit" should be considered generic unless the specific type is defined. Exhibit 29 illustrates the relationship between instrument response and the quantity of analyte presented to the analytical system (i.e., a calibration curve).

• *The closer the concentration of concern is to the detection limit, the greater the possibility of false negatives and false positives.*

• *The wide range of chemical concentrations in the environment may require multiple analyses or dilutions to obtain useable data. Request results from all analyses.*


The definitions that follow are intended to provide the RPM and risk assessor with an understanding of the various methods for calculating detection limits, the terms used to describe specific detection limits, and the limitations associated with identification and quantitation of chemicals of potential concern at concentrations near specified detection limits. Understanding the different terms used to describe detection limits helps avoid reporting problems. Exhibit 30 provides examples of calculations of the three most commonly reported types of detection limits.

• *Define the type of detection or quantitation limit for reporting purposes; request the sample quantitation limit for risk assessment.*

Instrument detection limit. The instrument detection limit (IDL) includes only the instrument portion of detection, not sample preparation, concentration/dilution factors, or method-specific parameters. The IDL is operationally defined as three times the standard deviation of seven replicate analyses at the lowest concentration that is statistically different from a blank. This represents 99% confidence that the signal identified is the result of the presence of the analyte, not random noise. The IDL is not the same as the method detection limit. Use of the IDL should be avoided for risk assessment.

Method detection limit. The method detection limit

EXHIBIT 29. THE RELATIONSHIP OF INSTRUMENT CALIBRATION CURVE AND ANALYTE DETECTION



21-002-029

Method detection limit. The method detection limit (MDL) is the minimum amount of an analyte that can be routinely identified using a specific method. The MDL can be calculated from the IDL by using sample size and concentration factors and assuming 100% analyte recovery. This estimate of detection limit may be biased low because recovery is frequently less than 100%. MDLs are operationally determined as three times the standard deviation of seven replicate spiked samples run according to the complete method. Since this estimate includes sample preparation effects, the procedure is more accurate than reported IDLs. However, the evaluation is routinely completed on reagent water. As a result, potentially significant matrix interferences that decrease analyte recoveries are not addressed.

The impact of an MDL on risk assessment is illustrated in Exhibit 28. When planning to obtain analytical data, the risk assessor knows the concentration of concern or preliminary remediation goal. When the concentration of concern of an analyte is greater than the MDL, to the extent that the confidence limits of both the MDL and concentration of concern do not overlap, then both "non-detect" and "detect" results can be used with confidence. There will be a possibility of false positives and false negatives if the confidence limits of the MDL and concentration of concern overlap. When the concentration of concern is sufficiently less than the MDL that the confidence limits do not overlap, then there is a strong possibility of false negatives and only "detect" results are useable.

EXHIBIT 30. EXAMPLE OF DETECTION LIMIT CALCULATION

IDL = 3 x SD* of replicate injections

Example: 100 ppb pentachlorophenol standard

If: SD = 5 ppb

Then: IDL = 3 x 5 ppb = 15 ppb

MDL = 3 x SD of replicate analyses (extraction and injection)

Example: 100 ppb pentachlorophenol spiked in sample producing average measured concentration of 50 ppb (not all analyte is recovered or measured)

If: SD = 18 ppb

Then: MDL = 3 x 18 ppb = 54 ppb

Incorporate calculation of MDL from IDL

SQL = MDL corrected for sample parameters

Example: 100 ppb pentachlorophenol with MDL of 57 ppb

If: Dilution factor = 10 (sample is diluted due to matrix interference or high concentrations of other analytes)

Then: SQL = 10 x 57 ppb = 570 ppb

* SD = Standard Deviation

21-002-030

Sample quantitation limit. The SQL is the MDL adjusted to reflect sample-specific action such as dilution or use of smaller aliquot sizes than prescribed in the method. These adjustments may be due to matrix effects or the high concentration of some analytes. The SQL is the most useful limit for the risk assessor and should always be requested.

For the same chemical, the SQL in one sample may be higher than, lower than, or equal to SQL values for other samples. In addition, preparation or analytical adjustments, such as dilution of the sample for quantitation of an extremely high level of one chemical, could result in non-detects for other chemicals included in the analysis, even though these chemicals may have been present at trace quantities in the undiluted sample. The risk assessor should request results of both original and dilution analyses in this case. Since the reported SQLs take into account sample characteristics, sample preparation, and analytical adjustments, they are the most relevant quantitation limits for evaluating non-detected chemicals.

Contract required quantitation (detection) limit. The CLP specifies a contract required quantitation limit

(CRQL) for organics and a contract required detection limit (CRDL) for inorganics. Each of these quantities is related to the SQL that has been shown through laboratory validation to be the lower limit for confident quantitation and to be routinely within the defined linear ranges of the required calibration procedures.

The use of CRQLs and CRDLs attempts to maintain the analytical requirements within performance limits (which are based upon laboratory variability using a variety of instruments). CRQLs are typically two to five times the reported MDLs and they generally correspond to the limit of quantitation.

Practical quantitation limit. The practical quantitation limit (PQL), defined in SW846 methods, is the lowest level that can be reliably achieved within specified limits of precision and accuracy during routine laboratory operating conditions. It is important to note that the SQL and PQL are not equivalent. Use of PQL values as measures of quantitation limits should be avoided wherever possible in risk assessment.

Other quantitation measurements. The limit of quantitation (LOQ) is the level above which quantitative

results may be obtained with a specified degree of confidence. At analyte concentrations close to, but above the MDL, the uncertainty in quantitation is relatively high. Although the presence of the analyte is accepted at 99% confidence, the reported quantity may be in the range of $\pm 30\%$. Ten times the standard deviation measured for instrument detection is recommended to demonstrate a level at which confidence is maximized (Borgman 1988).

The limit of linearity (LOL) is the point at or above the upper end of the calibration curve at which the relationship between the quantity present and the instrument response ceases to be linear (Taylor 1987). Instrument response usually decreases at the LOL, and the concentration reported is less than the amount actually present in the sample because of instrument saturation. Dilution is necessary to analyze samples in which analyte concentrations are above the LOQ. However, dilutions correspondingly increase SQLs. Data should be requested from both diluted and undiluted analyses.

3.2.5 Sampling and Analytical Variability Versus Measurement Error

Sampling and analytical variability and measurement error are two key concepts in data collection. Each is discussed in the context of evaluating strategies for the collection and analysis of both site and background samples.

Exhibit 21 defines sampling variability and measurement error. Most SAPs are a necessary compromise between cost and confidence level. Basically, two types of decisions must be made in planning:

- What statistical performance is necessary to produce the quality of data appropriate to meet the risk assessor's sampling variability performance objectives and
 - What types and numbers of QC samples are required to detect and estimate measurement error.
- *When contaminant levels in a medium vary widely, increase the number of samples or stratify the medium to reduce variability.*

Sampling plans attempt to estimate and minimize both sampling variability and measurement error. Sampling variability affects the degree of confidence and power the risk assessor can expect from the results. Confidence is the ability to detect a false positive hypothesis, and power is the ability to detect a false negative. Power is more important for risk assessment. An estimate of the

sampling variability that is a function of the spatial variation in the concentrations of chemicals of potential concern is obtained by calculating the coefficient of variation for each chemical. When the coefficient of variation is less than 20% and a substantial quantity of data are available, the effect of spatial and temporal variation on concentrations of chemicals of potential concern is minimal, and the power and certainty of statistical tests is high (EPA 1989c).

Spatial variability can be analyzed after an initial sampling effort through simple statistical summation or through the use of variogram analysis, a part of the geostatistics. EPA has developed software to assist a risk assessor in this analysis: Geostatistical Environmental Assessment Software (GEOEAS) (EPA 1988c) and Geostatistics for Waste Management (GEOPACK) (EPA 1990b).

Measurement error is estimated using the results of QC samples and represents the difference between the true sample value and the reported value. This difference has five basic sources: the contaminant being measured, sample collection procedures, sample handling procedures, analytical procedures, and data production procedures. Measurement error due to analytical procedures is discussed in Section 3.2 under analytical issues. Measurement error due to sampling is estimated by examining the precision of results from field duplicates. The minimum recommended number of field duplicates is 1 for every 20 environmental samples (5%). A minimum of one set of duplicates should be taken per medium sampled unless many strata are involved; five sets are recommended. Exhibit 31 summarizes the types and uses of QC samples in defining variation and bias in measurement.

- *Sampling variability typically contributes much more to total error than analytical variability.*

In summarizing the discussion of sampling variability and measurement error, one finding puts the concepts in perspective: "An analysis of the components of total error from soils data from an NPL site sampled for PCBs indicated that 92% of the total variation came from the location of the sample and 8% from the measurement process" (EPA 1989f). Of the 8%, less than 1% could be attributed to the analytical process. The rest of the 8% is attributable to sample collection, sample handling, data processing and pollutant characteristics. Sampling variability is often three to four times that introduced by measurement error. Exceptions to this observation on the components of variation or sources of error occur in instances of poor method performance for specific analytes.

EXHIBIT 31. MEASUREMENT OF VARIATION AND BIAS USING FIELD QUALITY CONTROL SAMPLES

Quality Control Sample Types	Variation or Bias Measured
Field duplicate	Provides data required to estimate the sum of subsampling and analytical variances.
Field blank	Provides data required to estimate the bias due to contamination introduced during field sampling or cleaning procedures. Also measures contamination at laboratory. Compare with laboratory method blank to determine source of contamination.
Field rinsate	Provides data required to estimate the sum of the bias caused by contamination at the time of sampling from sampling equipment and by analysis and data handling. Indicates cross-contamination and potential contamination due to sampling devices.
Trip blank	Provides data required to estimate the bias due to contamination from migration of volatile organics into the sample during sample shipping from the field and sample storage at the laboratory.

Source: EPA 1990c.

21-002-031

Media or matrix variability. Appropriate samples must be collected from each medium of concern and, for heterogeneous media, from designated strata. Stratification reduces variability in results from individual strata, which can be different layers or surface areas. Media to be sampled should include those currently uncontaminated but of concern, as well as those currently contaminated. For media of a heterogeneous nature (e.g., soil, surface water, or hazardous waste), strata should be established and samples specified by stratum to reduce variability, the coefficient of variation and the required number of samples.

Sampling considerations vary according to media. The sampling concern may involve contaminant occurrence, temporal variation, spatial variation, sample collection, or sample preservation. Exhibit 32 indicates potential sampling problem areas for each medium. Problem areas are classified relative to other media. RPMs can use this exhibit to plan for possible sampling problems in the data collection design. Sampling designs must be structured to identify and characterize hot spots. Information needed for fate and transport modeling should be obtained during a site sampling investigation.

This information also differs by the medium of concern (EPA 1989a).

The type of medium in which a chemical is present affects the potential sensitivity, precision, and accuracy of the measurement. Sharp distinctions occur in applying a single method to media such as water, oil, sludge, soil, or tissue. Medium or matrix problems are indicated by the presence of analytical interferences, poor recovery of analytes from the matrix, physical problems such as viscosity (flow parameters), and particulate content that affect sample processing. Exhibit 33 shows the sources of uncertainty across media. Spiked environmental samples monitor the effect of these sources of uncertainty on the accuracy of recovery of target compounds from the matrix. Duplicates quantify the effect of these parameters on precision. The method must be chosen carefully if a difficult medium such as oily waste or soil is to be analyzed. Routine methods usually specify the medium or media for which they are applicable.

Method detection and general confidence in analytical determinations are also often affected by specific media types and by analytical interference. The impact of matrix interference on detection limits, identification,

EXHIBIT 32. SAMPLING ISSUES AFFECTING CONFIDENCE IN ANALYTICAL RESULTS

Major Sampling Issues	Problem Likelihood by Medium					
	Soil	Ground Water	Surface Water	Air	Biota	Hazardous Waste
Contaminant Migration	√√		√	√		√√
Temporal Variation			√√	√		
Spatial Variation	√√	√√	√√	√	√	√√
Topographic/ Geological Properties	√√			√		
Hot Spots	√√	√√				√√
Sample Collection	√		√√	√√		√
Sample Preparation/ Handling	√√	√	√√	√√	√	√
Sample Storage		√√	√√	√√	√√	
Sample Preservation		√√	√√		√√	
Key: √√ = Likely source of significant sampling problem. √ = Potential source of sampling problem.						
Source: Modified from Keith 1990b.						

21-002-032

and quantitation is illustrated by the following discussions (which are not meant to be comprehensive).

- Oil and hydrocarbons affecting GC-MS analyses,
- Phthalates and non-pesticide chlorinated compounds that can interfere with pesticide analyses, and
- Iron spectral interference affecting ICP sample results.

Oil and hydrocarbons. The presence of appreciable concentrations of oil and other hydrocarbons may interfere with the extraction or concentration process. Also, even at low concentrations, oil in a sample usually produces a large series of chromatographic peaks that interfere with the detection of other chemicals of potential concern during gas chromatography. Any chemicals of potential concern that may elute concurrently from the

GC column are obscured by the hydrocarbon response and may not present a distinct spectrum. Also, hydrocarbons that are present in significant quantity are often identified as TICs, potentially adding a large number of compounds for consideration by the risk assessor.

During RI planning, the risk assessor should determine if there is a potential for hydrocarbon contamination, through knowledge of historical site use and examination of historical data. The laboratory can be instructed to add cleanup protocols to the analysis, or to use a supplemental analysis for which the hydrocarbons are not interferences (e.g., electron capture detection for halogenated compounds).

Phthalates and non-pesticide chlorinated compounds. Phthalates interfere with pesticide analyses by providing a detector response similar to that for chlorinated compounds. Phthalates and non-pesticide

EXHIBIT 33. SOURCES OF UNCERTAINTY THAT FREQUENTLY AFFECT CONFIDENCE IN ANALYTICAL RESULTS

Source of Uncertainty	Degree of Significance by Medium				
	Soil	Water	Air	Biota	Hazardous Waste
SAMPLING					
Design	√√	√	√√		√
Contamination	√√	√	√		
Collection	√	√√	√√		√
Preparation	√√				
Storage		√√	√√		
Preservation		√√			
LABORATORY					
Storage	√√	√√	√√		
Preparation	√√/√	√√/√		√√	√√
Analysis	√√		√	√	√√
Reporting			√	√√	√√
ANALYTE-SPECIFIC					
Volatility	√√	√	√		
Photodegradation		√	√		
Chemical Degradation	√	√√			
Microbial Degradation	√√	√√			
Contamination	√√		√√		
KEY: √√ = Likely source of significant error or uncertainty. √ = Potentially source of significant error or uncertainty. √√/√ = Magnitude of effect determined by examination of data.					

21-002-033

chlorinated compounds are often present in greater concentrations than the pesticides of concern. Pesticide data are often required at low detection limits and, therefore, GC-MS analyses are not used for quantitation. In these cases, a gas chromatographic analysis using electron capture detection is more sensitive, providing a wider useful range of detection. The phthalates and chlorinated compounds can coelute with chemicals of potential concern, thereby obscuring the detection of target analytes and raising the analyte-specific quantitation limit. Phthalates and chlorinated compounds also produce additional peaks on the chromatogram that can be interpreted as false positive responses to pesticides. A second analysis using a different column provides an extra measure of confidence in identification. Alternatively, sample extracts from positive analyses can be further concentrated for

confirmation by GC-MS if concentrations of analytes are sufficient.

Iron. Large quantities of iron in a sample affect the detection and quantitation of other metallic elements analyzed by ICP atomic emission spectroscopy at wavelengths near the iron signals. The strong iron response overlaps nearby signals, thereby obscuring the results of potentially toxic elements present at much lower concentrations. An interference check sample for ICP analyses monitors the effect of such elements. High concentrations of iron are analyzed with low concentrations of other metals in these samples to indicate whether iron interfered with metal detection at lower concentrations. If spectral interferences are observed, data may be qualified as overestimated. The risk assessor or RPM should consult the project chemist to determine if a particular method requires a performance check.

3.2.6 Sample Preparation and Sample Preservation

Some samples require preparation in the field to ensure that the results of analyses reflect the true characteristics of the sample. Sample filtration and compositing procedures are discussed in this section. Exhibit 34 summarizes the issues which the various sample preparation methods address. Exhibit 35 outlines the primary information gained with the various sampling techniques.

EXHIBIT 34. SAMPLE PREPARATION ISSUES

Issue	Action
Sample Integrity	Preservation --- acids, biocides (may be applicable to volatiles or metals).
Source of Analyte Media	Unfiltered samples -- measure total analytes Filtered samples -- discriminate sorbed and unsorbed analytes
Analyte Speciation	Choice of sample preparation protocols affects analyte speciation
Large Number of Samples to be Analyzed	Composite samples (However, this raises the effective detection limit in proportion to the number of samples composited.)

21-002-034

Filtration. If the risk assessor needs to discriminate between the amount of analyte present in true solution in a sample and that amount sorbed to solid particles, then the sample must be filtered and analyses should be performed for both filtered and unfiltered compounds. Some samples, such as tap water, are never filtered because there is no particulate content. Filtration should be performed in the field as soon as possible after the sample has been taken and before any preservative has been added to the sample. Filtration often does not proceed smoothly. It is common practice only to filter a small proportion of all samples taken, and to perform analyses for the total content of the analyte in the majority of samples. Filtered samples generally provide a good indication of the fraction of contaminant likely to be transported over large distances horizontally in a plume. However, in the immediate vicinity of a source or point of exposure, unfiltered samples may be valuable in providing an indication of suspended material that

EXHIBIT 35. INFORMATION AVAILABLE FROM DIFFERENT SAMPLING TECHNIQUES

Sample Type	Information
Filtered	Can differentiate sorbed and unsorbed analytes.
Unfiltered	Total amount of analyte in sample is measured.
Grab	Can be used to locate hot spots.
Composite	Can provide average concentrations over an area at reduced cost.

21-002-035

may act as a source or sink of dissolved contaminants and may therefore modify overall transport.

Compositing. Reducing the number of samples by compositing is also a form of sample preparation. Compositing may be performed to reduce analytical costs, or in situations where the risk assessor has determined that an average value will best characterize an exposure pathway. Compositing cannot be used to identify hot spots, but can be effective when averaging across the exposure area. Caution should be exercised when compositing since low level detects can be averaged out and become non-detects.

Preservation. Sample characteristics can be disturbed by post-sampling biological activity or by irreversible sorption of analytes of concern onto the walls of the sample container. A variety of acids and biocides used for preservation are discussed in standard works such as *Standard Methods for the Examination of Water and Wastewater* (Clesceri, et. al., eds. 1989). Samples are also usually shipped with ice to reduce biological activity.

Preparation. Several factors in sample preparation affect analytical data. These factors include sample matrix, desired detection limit, extraction solvent, extraction efficiency, sample preparation technique, and whether the analysis is performed in the field or in a fixed laboratory. In addition, parameters such as turnaround time may preclude the use of some sample preparation alternatives.

An extraction method must be able to release the chemicals of concern from the sample matrix. For example, organic solvents will extract non-polar organic compounds from water. Polar and ionic compounds

(such as unsymmetrically halogen-substituted compounds, phenols, and carboxylic acids) may require additional techniques for extraction from water. The choice of solvent is also critical to the extraction efficiency. Methanol would be expected to extract a larger quantity of volatile organic material from soils or sediments than from water. For inorganic analyses, the matrix may require additional acidification to dissolve metal salts that have precipitated from the solution.

Sample preparation procedures for organic analytes are applied based on volatility. Volatile organics are analyzed using head-space or purge and trap techniques. Extraction alternatives for the analysis of less volatile (extractable) organic chemicals include separatory funnels, Soxhlet extraction apparatus, continuous liquid-liquid extractors, and solid phase cartridges. Details of these extraction options can be obtained from the project chemist. Strengths and weaknesses of each of these preparation procedures are described in Exhibit 36.

For inorganic analyses, the sample matrix is usually digested in concentrated acid. The released metals are introduced into the instrument, then analyzed by flame AA or ICP atomic emission spectrophotometry. The selection of the acid for digestion influences the detection limit because different acids have different digestion abilities.

- If digestion is not used, the sample measurement corresponds to a determination of soluble metals rather than total metals. If soluble metals have a greater toxicological significance, this difference may be important to the risk assessment.
- If the sample is filtered in the field or the laboratory before digestion, any metals associated with particulates are removed before analysis. If particulates are an exposure pathway in the risk assessment, sample filtration would underestimate risk.

The analytical request must specify if the sample is to be filtered and whether or not it is to be digested (to measure soluble metals). Unless otherwise specified, samples are usually digested but not filtered.

3.2.7 Identification of Exposure Pathways

Exposure pathways and their components, such as source, mechanism of release, etc., should be designated prior to the design of the sampling procedures. For the risk assessment, at least one broad spectrum analytical sample is required and two or three are recommended

for each medium and potential source in an exposure pathway. If the site sampling design fails to consider all exposure pathways and media, additional samples will be required.

Current and future exposure pathways may be limited to particular areas of a site. If sampling activity can be concentrated in these areas, the precision and accuracy of the data supporting risk assessments can be improved.

Risk assessment requires characterization of each exposure area for the site. Samples not falling within the areas of potential concern are not used in the identification of chemicals of potential concern nor in the calculation of reasonable maximum exposure concentration. Depending on exposure pathways, the risk assessor may utilize only a small number of samples that were collected at a site. Exhibit 37 shows why the identification of exposure pathways is critical to the sampling design in order to maximize the number of samples that are useable in the risk assessment.

3.2.8 Use of Judgmental or Purposive Sampling Design

Judgmental or purposive designs that specify sampling points based on existing site knowledge may be appropriate for the initial phase of site sampling or when the risk assessment is performed using few samples. In such instances, non-statistical approaches may be more effective in accomplishing the purpose of the risk assessment for human health, than statistical designs with unacceptably large sampling variability.

Judgmental samples can be incorporated into a statistical design if the samples designate the area of suspected contamination as an exposure area or stratum. The judgmental samples are then selected randomly or within a grid in the area of known contamination. Under the procedures described, the initial judgmental samples are not considered biased for the exposure area. Exhibit 38 summarizes some strengths and weaknesses of biased and unbiased sampling designs.

Resource constraints sometimes restrict the number of samples for the risk assessment and therefore potentially increase the variability associated with the results. When the number of samples that can be taken is restricted, judgmental sampling may identify the chemicals of potential concern, but cannot estimate the uncertainty of chemical quantities. The reasonable maximum exposure or upper confidence limit cannot be calculated from results of a judgmental design. Bias can be avoided with the procedures described in the previous paragraph.


EXHIBIT 36. COMPARISON OF SAMPLE PREPARATION OPTIONS

Fraction & Matrix	Preparation	Strengths	Weaknesses
Volatile Soil/Water	Head-space	Rapid, simple, potentially automated and minimal interferences if standards are prepared using sample media to minimize the effects of ionic strength variability between samples and standards.	Qualitative identification; comparison of concentration possible but quantitative standardization is difficult, especially true for complex matrix (e.g., particulates and clay in soil); no mechanism for concentration; application and sensitivity are very analyte-specific.
	Purge and Trap	Generally recommended for this analysis (comparabilities); can be automated; broadly applicable and allows concentration factor; good recoveries across analyte list. High precision and recoveries for waters.	Sacrifice of either highly volatile analytes or inadequate purge of low volatility analytes; dependent on purge and trap parameters. Soils have variable response dependent on soil characteristics. Efficiency of soil purge is not monitored.
Extractable Organics in Water	Separatory Funnel	Relatively rapid processing and low set-up costs; relatively high PAH recovery.	Generally low recovery of target analytes; high potential for matrix problems; poor method precision.
	Continuous Extraction	Minimal matrix problems; generally higher analytical precision and high phenol recoveries; overall high extraction efficiency (accuracy).	Lower recovery of PAH and phthalates (especially higher molecular weight); time-consuming procedure and high initial set-up costs; more potential for contamination.
	Solid Phase Extraction	Very rapid, simple technique; samples can be extracted in the field for laboratory analysis; potentially low MDL in a clean matrix.	Procedure has limited available performance data. Presence of interference and matrix problems can affect extraction efficiency and data quality. Each batch of extraction medium must be tested for efficiency by recovery of standards, preferably in the same matrix. Breakthrough (loss) occurs at high sample concentrations.
Extractable Organics in Soil	Sonication	Rapid sample preparation; relatively low solvent requirement; good efficiency of analyte recovery/matrix exposure to solvent.	Labor intensive; constant attention to procedure; relatively high initial cost. Methylene chloride/acetone solvent mixture results in many condensation products and often in method blank contamination.
	Soxhlet Extraction	Relatively routine requirement for direct analytical support; relatively good exposure of sample to solvent if sample texture appropriate; relatively low initial cost.	Relatively high operating cost-replacement apparatus; solvent; for some matrices may not provide efficient sample/solvent contact (e.g., channeling, very slow sample output).
Inorganics	Acid Digestion	Dissolves particulates; provides results for total metals.	Some compounds are acid insoluble; digestion may promote interference effects.
	0.45 um Membrane Filtration	Isolates dissolved metals species.	Filtration problems in field; does not provide a total metals assay; is an extra step in sample collection.
	Direct Aspiration	No preparation required; provides results for dissolved metals.	Particulates affect sample introduction.

EXHIBIT 37. IDENTIFICATION OF EXPOSURE PATHWAYS PRIOR TO SAMPLING DESIGN IS CRITICAL TO RISK ASSESSMENT

Examples of sampling design missing exposure areas of concern:

Systematic Grid:




No samples
for exposure
pathway A
and
five for B

(B)

(A)

Random:



No samples
for exposure
pathway B
and
three for A

(B)

(A)

21-002-097

3.2.9 Field Analyses Versus Fixed Laboratory Analyses

Field analyses are typically used to gather preliminary information to reduce errors associated with spatial heterogeneity, or to prepare preliminary maps to guide further sampling. Field analyses are often conducted during the RI to provide data to determine worker protection levels, the extent of contamination, well screen casing depths, and the presence of underground contamination, and to locate hot spots. For many sites, field analyses can often provide useful data for risk assessment. The analyses provide semi-quantitative results, often free of significant matrix interference, that can be used quantitatively if confirmed by a quantitative analysis from fixed laboratories.

Field instruments are usually divided into three classes: field portable instruments that can be carried by a single person, field transportable instruments that can be moved and used in the field or in a mobile laboratory, and mobile laboratory instruments that are installed in a trailer for transport to a site. Instrumentation used may be GC, X-ray fluorescence (XRF), or organic vapor

analyzer (OVA). Examples and applications of these instruments might include on-site GC analysis of soil gas to indicate the presence of underground contamination, XRF for soil lead analyses, and the OVA to detect volatile organics, reported in benzene equivalents rather than in standard units of concentration.

Analytical methods that have traditionally been restricted to off-site laboratories can now be employed in the field. In addition, the quality of field instrumentation has improved steadily, allowing for better measurements at the site. Rugged versions of fixed laboratory instrumentation, such as XRF and GCs, can often be performed in trailers if adequate ventilation and power supplies are available. With field analyses, greater numbers of samples can be analyzed with immediate, or very short, holding times with no shipping and storage requirements. At least 10% of field analyses should be confirmed by fixed laboratory analyses to ensure comparability.

• *Field methods can produce legally defensible data if appropriate method QC is available and if documentation is adequate.*

EXHIBIT 38. STRENGTHS AND WEAKNESSES OF BIASED AND UNBIASED SAMPLING DESIGNS

Sampling Design	Strengths	Weaknesses
Biased (judgmental, purposive)	<ul style="list-style-type: none"> • Uses knowledge of location • Fewer resources • Timeliness • Focuses sampling effort 	<ul style="list-style-type: none"> • Inability to calculate uncertainty • Inability to determine upper confidence limit • Decreases representativeness • Increases probability of false negatives
Unbiased (random, systematic grid, geostatistical)	<ul style="list-style-type: none"> • Ability to calculate uncertainty • Ability to determine upper confidence limit • Representativeness • Reduces probability of false negative 	<ul style="list-style-type: none"> • Resource intensive • May require statistician • Timeliness • More samples required

21-002-038

Significant QA oversight of field analyses is recommended to enable the data to be widely used. Field analysis performance data are often not available—in part because of the variety of equipment and operating environments, variety of sample matrices, and relative “newness” of certain technologies. Therefore, an in-field method validation program is recommended. Spikes and performance evaluation materials should be incorporated, if available in addition to other standard QC measures such as blanks, calibration standards, and duplicates.

The precision and accuracy of individual measurements may be lower in the field than at fixed laboratories, but the quicker turnaround and the possibility of analyzing a larger number of samples may compensate for this factor. A final consideration is the qualifications of operators in the field. The RPM, in consultation with chemists and quality assurance personnel, should set proficiency levels required for each instrument class and decide whether proposed instrument operators comply with these specifications.

Fixed laboratory analyses are particularly useful for conducting broad spectrum analyses for target compounds, to avoid the possibility of false negatives. They generally provide more information for a wider

range of analytes than field analyses, and are generally more reliable than field screening or field analytical techniques.

- *To minimize the potential for false negatives, obtain data from a broad spectrum analysis from each medium and exposure pathway.*

Fixed laboratory analysis commonly uses mass spectrometry for organic analyses, which provides greatly enhanced abilities for compound identification. For inorganics, AA spectroscopy or ICP atomic emission spectroscopy should be used for reliable identification of target analytes. Once the broad spectrum analysis and contaminant identification has occurred, other methods may be employed that offer lower detection limits, better quantitate specific analytes of concern, and that may be less expensive.

- *The CLP or other fixed laboratory sources are most appropriate for broad spectrum analysis or for confirmatory analysis.*

Characteristics such as turnaround time, detection and identification ability of the instruments, precision and accuracy requirements of the measurements, and operator qualifications should be considered when selecting field or fixed laboratory instrumentation. Exhibit 39 compares the characteristics of field and fixed laboratory analyses. The risk assessor and RPM should consult the project chemist to consider the available options and make a choice of analysis based on method parameters, turnaround time, and cost, as well as other data requirements pertinent to risk assessment needs (e.g., legal defensibility). Exhibit 40 compares the strengths and weaknesses of field and fixed laboratory analyses.

3.2.10 Laboratory Performance Problems

The RPM should be aware of problems that occur during laboratory analyses, even though the resolution of such problems are usually handled by the project chemist. This section discusses common performance problems and explains how to differentiate laboratory performance problems from method performance problems.

- *Solicit the advice of the chemist to ensure proper laboratory selection and to minimize laboratory and/or methods performance problems that occur in sample analysis.*

EXHIBIT 39. CHARACTERISTICS OF FIELD AND FIXED LABORATORY ANALYSES

Characteristic	Field Analysis	Fixed Laboratory Analysis
Prevention of false negatives	Immediate analysis means volatiles not lost due to shipment and storage.	More extensive sample preparation available to increase recovery of analytes.
Prevention of false positives	No sample to sample contamination during shipment and storage.	Contamination by laboratory solvents minimized by storage away from analytical system.
Analytical Turnaround Time	Data available immediately or in up to 24 to 48 hours (additional time necessary for data review).	Data available in 7 to 35 days unless quick turnaround time requested (at increased cost).
Sample Preparation	Limited ability to prepare samples prior to analysis.	Samples can be extracted or digested, thereby increasing the range of analyses available.

21-002-039

Laboratory performance problems may occur for routine or non-routine analytical services and can happen with the most technically experienced and responsive laboratories. Laboratory problems include instrument problems and down-time, personnel inexperience or insufficient training, and overload of samples. Issues that may appear to be laboratory problems, although they are actually planning problems, include inadequate access to standards, unclear requirements in the analytical specifications, difficulty in implementing non-routine methods, and some sample-related problems. Another problem for the RPM may be a lack of laboratories with appropriate experience or available capacity to meet analytical needs. These problems can usually be averted by "up-front" planning and by a detailed description of required analytical specifications.

- Instrument problems can be revealed with a unique identifier for each instrument in the laboratory that is reported with the analyses. Calibration and

performance standards, such as calibration check standards, internal standards, or system monitoring compounds, should be specified in the analytical method to monitor performance of each instrument. In addition, the use of instrument blanks should be specified (to avoid the possibility of carry-over during the analysis).

- Some degradation in data quality may appear when new personnel are operating or when the sample load for a laboratory is high. The contributing personnel for each analysis should be identified clearly in laboratory records and reports, and qualifications of personnel required in contracts should be documented.
- Sample and method problems can often be distinguished from laboratory problems if they are not associated with a specific instrument or analyst. A review of method QC data should distinguish between laboratory and sample problems.

EXHIBIT 40. STRENGTHS AND WEAKNESSES OF FIELD AND FIXED LABORATORY ANALYSES

Analysis*	Strengths	Weaknesses
Field -Portable XRF (Metals)	Extremely high volume sampling and analysis; compatible with sophisticated sampling and data handling software. Detection limit may be above laboratory instrument values but applicable to specific site levels of interest.	Confirmation technique recommended. Comparability may require external standardization of calibration because quantitation is based on soil surface area versus a soil volume. Results often lower than from AA analyses.
Field GC	Rapid analysis supporting high volume sampling for variety of volatile and extractable organic target compounds (includes pesticides/PCBs). Minimization of sample handling variability and data quality indicators comparable to fixed laboratory methods.	Requires prior site knowledge to ensure applicability to specific conditions (e.g., soil-gas may not be appropriate for investigation in sandy area). Confidence in identification is matrix- and site-specific and highly variable depending on sample complexity. Confirmation technique recommended.
Mobile Laboratory XRF, AA (Metals)	Combines the high volume sample capacity of field analyses with the detection limits, data quality and confidence associated with laboratory analyses.	Requires significant resources, time, and personnel to transport, maintain and operate; generally most appropriate at high volume sites, especially remote.
Mobile Laboratory Luminescence	Rapid survey of analytes that routinely require sample preparation (e.g., PAHs and PCBs). Detection limits can be adjusted within limits to site-specific concentrations of concern.	Technique has had minimal use in EPA site investigation. Comparability may be an issue and require extensive confirmatory analyses.
Mobile Laboratory GC, GC-MS	Combines high volume capacity of field analyses with increased confidence in identification (GC-MS) or improved data quality (GC). GC methods may be identical to laboratory procedures but quality is intermediate due to site conditions (e.g., temperature, humidity and power requirements).	Same weaknesses as for mobile laboratory inorganics. An additional weakness is the increased training requirements and decreased availability of experienced GC-MS operators for totally independent system operation. Possibility of site contamination and cross-contamination.
Fixed Laboratory XRF, AA, ICP (Metals - Available Routine Methods)	Highest comparability and representativeness. Data quality, including detection limits, generally predictable. Efficient match of analyses required to instrument (e.g., multiple analyses run simultaneously by ICP).	Slow delivery of data; increased documentation requirement due to the number of participants--relatively high sample cost.
Fixed Laboratory GC & GC-MS (Organics - Available Routine Methods)	Highest comparability and representativeness. Necessary confirmation of qualitative identification. Data quality and detection limits generally predictable. In depth analysis and sample archives for follow-up testing.	Same weaknesses as for fixed laboratory metals; analyte-specific performance.

* ICP = Inductively Coupled Plasma Spectroscopy. Graphite AA = Graphite Furnace (electrothermal) Atomic Absorption Spectroscopy. Flame AA = Flame Atomic Absorption Spectroscopy. ICP-MS = Inductively Coupled Plasma-Mass Spectrometry. XRF = X-Ray Fluorescence. GC = Gas Chromatography. GC-MS = Gas Chromatography-Mass Spectrometry. AA = Atomic Absorption Spectroscopy.

**EXHIBIT 40. STRENGTHS AND WEAKNESSES OF FIELD
AND FIXED LABORATORY ANALYSES
(Cont'd)**

Analysis*	Strengths	Weaknesses
ICP	Simple, automated, extremely rapid; can assay metals simultaneously; can detect ppb levels.	Subject to salt or iron interferences; lacks detection capability at low levels; not suitable for less than 20 ppb Arsenic, Lead, Selenium, Thallium, Cadmium, Antimony; requires background and interelement correction.
Graphite AA	Simple, automated; can assay most metals; can assay low level metals; can detect ppb levels.	Lower precision and accuracy result unless methods of standard additions used. Method is time-consuming; requires background correction; requires matrix modifiers; subject to spectral interferences. Graphite tube requires replacement frequently.
Flame AA	Simple, rapid, very suitable for high concentration sodium and potassium assays; commonly used and rugged.	Not as sensitive as graphite AA; salts can interfere; limited by lamp capabilities; detects ppm levels.
ICP-MS	Rapid; can detect low levels; accurate.	Method is subject to isobaric molecular and ion interferences. Nebulization, transport process, and memory physical interferences occur. Method is relatively new and is expensive. Specialized training is required.
ICP-Hydride	Rapid; can detect low levels of Antimony, Arsenic, Selenium; Hydride formation eliminates spectral interferences.	Dependent on analyte oxidation state; especially sensitive to copper interference. Method is relatively new. Specialized training is required.
* ICP = Inductively Coupled Plasma Spectroscopy. Graphite AA = Graphite Furnace (electrothermal) Atomic Absorption Spectroscopy. Flame AA = Flame Atomic Absorption Spectroscopy. ICP-MS = Inductively Coupled Plasma-Mass Spectroscopy. XRF = X-Ray Fluorescence. GC = Gas Chromatography. GC-MS = Gas Chromatography-Mass Spectrometry. AA = Atomic Absorption Spectroscopy.		

21-002-040-01

Chapter 4

Steps for Planning for the Acquisition of Useable Environmental Data in Baseline Risk Assessments

This chapter provides planning guidance to the RPM and risk assessor for designing an effective sampling plan and selecting suitable analytical methods to collect environmental analytical data for use in baseline risk assessments. It is important to understand that the variances inherent in both sampling and analytical designs combine to contribute to the overall level of uncertainty. The chapter also provides a number of charts and worksheets that should be useful in planning. It is important to remember that these are provided for guidance only. Each Region, or the staff at an individual site, may modify these for their use or develop their own materials.

The chapter has two sections. The first section of the chapter describes the process of selecting a sampling design strategy and developing a sampling plan to resolve the four fundamental risk assessment decisions presented in Chapter 2:

- What contamination is present and at what levels?
- Are site concentrations sufficiently different from background?
- Are all exposure pathways and exposure areas identified and examined?
- Are all exposure areas fully characterized?

A Sampling Design Selection Worksheet and a Soil Depth Sampling Worksheet are used as data collection and decision-making tools in this process. Guidance for evaluating alternative sampling strategies and designing statistical sampling plans is included.

The second section of the chapter provides guidance on selecting the methods for analyzing samples collected during the RI. A Method Selection Worksheet is used to compile the list of chemicals of potential concern and to determine analytical priorities so that the most suitable combination of methods is selected.

The risk assessor or RPM, in consultation with other technical experts, will probably complete several worksheets, representing different media, exposure pathways, potential sampling strategies, chemicals of potential concern, and analytical priorities. This is done to compile sufficient information to communicate basic risk assessment requirements to the RPM, and to ensure that these requirements are addressed in the sampling and analysis plan (SAP).

The selection of sampling plans and analytical methods should be based on the performance measures discussed

in this chapter. These measures are assessed by data quality indicators that quantify attainment of the data quality objectives (DQOs) developed by the RPM for the total data collection and evaluation effort.

4.1 STRATEGIES FOR DESIGNING SAMPLING PLANS

This section provides guidance for evaluating alternative sampling strategies. Risk assessment may involve sampling many media at a site: groundwater, surface water, soil, sediment, industrial sludge, mine tailings, or air. The strategies for sampling different media often vary. For example, random stratified sampling may be the appropriate method for examination of soils at a site, but the positioning of groundwater monitoring wells is seldom done on a random basis. Sampling designs for soils and sediments are usually created to examine spatial distribution and heterogeneity of chemicals of concern. Groundwater sampling plans examine the

Acronyms

AA	atomic absorption
BNA	base/neutral/acid
CAS	Chemical Abstracts Service
CLP	Contract Laboratory Program
CV	coefficient of variation
CVAA	cold vapor atomic absorption
DQO	data quality objective
EMMI	Environmental Monitoring Methods Index
EMSL-LV	Environmental Monitoring Systems Laboratory - Las Vegas
EPA	U.S. Environmental Protection Agency
GC	gas chromatography
GFAA	graphite furnace atomic absorption
GIS	Geographic Information System
GPC	gel permeation chromatography
ICP	inductively coupled plasma
MDL	method detection limit
MDRD	minimum detectable relative difference
MS	mass spectrometry
PA/SI	primary assessment/site inspection
PCB	polychlorinated biphenyl
QA	quality assurance
QC	quality control
RAS	routine analytical services
RI	remedial investigation
RME	reasonable maximum exposure
RPM	remedial project manager
SAP	sampling and analysis plan
VOA	volatile organics
XRF	X-ray fluorescence

extent of a plume containing the chemical of concern, and also often examine seasonal or temporal variability in chemical concentrations. Exhibit 41 summarizes the relative variation in spatial and temporal properties for different types of measurement.

The terms stratum and strata are used frequently in this section. A stratum is usually a physically defined layer or area; it can also be a conceptual grouping of data or site characteristics that is used in statistical analysis.

Sampling guidance in this section is focused on determining the spatial extent and variability of the concentration of chemicals of potential concern. Therefore, it applies most directly to soils and sediments. Some EPA Regions have developed sampling guidances for groundwater, and the RPM and risk assessor should consult these whenever available.

Examples of common sampling designs are given in Exhibit 42, and their overall applicability is shown in

Exhibit 43. Schematic examples of some of the designs are illustrated in Exhibit 44.

The objective of the sampling plan is to determine a strategy that collects data representative of site conditions. The data must have acceptable levels of precision and accuracy, obtain minimum required levels of detection for chemicals of potential concern, and have acceptable probabilities of false positives and false negatives. Meeting these objectives involves optimizing the confidence in concentration estimates and the ability to detect differences between site and background levels. To accomplish these objectives, the RPM can optimize the number of samples, the sampling design, or the efficiency of statistical estimators (e.g., mean, standard deviation, and standard error).

Increasing the number of samples may increase initial costs, depending on whether fixed or field analytical methods are used for analysis, but it is necessary in

EXHIBIT 41. EXAMPLES OF SPATIALLY AND TEMPORALLY DEPENDENT VARIABLES

Measurement	Relative Variation in Measurements Attributable to:	
	Spatial	Temporal
Geophysical Measurements	Large	Small
Soil-Gas Measurements	Large	Large
Weather/Air Quality	Large	Large
Surface Water Quality	Usually Small	Usually Large
Physical Soil Properties	Large	Small
Soil Moisture	Large	Large
Soil Quality	Large	Small
Aquifer Properties	Large	Small
Groundwater Flow	Usually Large	Usually Small
Concentration of Groundwater Contaminants	Large	Large

EXHIBIT 42. EXAMPLES OF SAMPLING DESIGNS

Design	Examples of Application
Judgmental/ Purposive	Monitoring Wells Hot Spots
Classical Random	Background Soil
Classical Stratified:	
Random	Drums at Surface
Systematic	Waste Piles
Cluster	Soil from Boreholes
Composite	Soil from Test Pits
Systematic:	
Random	Determine Concentrations of Chemicals of Potential Concern in Soil
Grid	Concentrations of Chemicals of Potential Concern. Surface Soil Characteristics
Search	Contaminant Hot Spots
Surrogate	Gas Detector Measurements
Phased	Extent of Contamination
Geostatistical	Distribution of Contamination

21-002-042

certain situations (see Section 4.1.2). The sampling design can often be improved by stratifying within a medium to reduce variability, or by selecting a different sampling approach, such as a geostatistical procedure termed "kriging." Improving the efficiency of the statistical estimators involves specifying the type of data distribution if parametric procedures are being used, or switching from nonparametric to parametric procedures if distributional assumptions can be made.

Exhibit 45 is a Sampling Design Selection Worksheet, structured to assist design selection for the most complex environmental situation, which is usually soil sampling. The worksheet contains the elements needed to support the decisions for RI sampling design to meet data requirements for risk assessment. The RPM and risk assessor may use this worksheet or use it as a model to create one specifically suited to their needs. The final site sampling plan must meet the data usability requirements of risk assessment. The final procedure for sampling design should be selected based on the specific reason for sampling (e.g., defining a boundary

or obtaining an average over some surface or volume). The worksheet should be completed for each medium and exposure pathway at the site. Once completed, this initial set of worksheets can be modified to assess alternative sampling strategies. Completion of a set of worksheets (i.e., a worksheet for each medium and exposure pathway at a site, based on a single sampling strategy) specifies the total number of samples to be taken for an exposure pathway, and sample breakdown according to type (i.e., field samples, quality control samples, and background samples).

The remainder of this section is a step-by-step guide to completing the Sampling Design Selection Worksheet. Chemicals of potential concern listed on the Sampling Design Selection Worksheet should be the same as those used for the Method Selection Worksheet (Exhibit 52).

4.1.1 Completing the Sampling Design Selection Worksheet

- *Use of the Sampling Design Selection Worksheet will help the RPM or statistician determine an appropriate sampling design.*

Pathway, medium and design alternatives. Sampling procedures used in environmental sampling are either unbiased or biased. Classical and geostatistical models are unbiased in terms of sample evaluation and hypothesis testing. The classical model is based on random, or stratified random procedures, and the geostatistical model on optimizing co-variance. Systematic grid sampling can be utilized by either the classical or geostatistical model. Biased, or judgmental/purposive, design requires the use of different approaches to planning and evaluation.

- *While other designs may be appropriate in many cases, stratified random or systematic sampling designs are always acceptable.*

- **Classical model:** The classical model uses either a random or stratified random sampling design. It is appropriate for use in sampling any medium to define the representative concentration value over the exposure area. It is not subject to judgmental biases, and produces known estimates and recognized statistical measures and guidelines. A stratified random design provides the RPM and risk assessor with great flexibility. If the nature and extent of the exposure areas are not yet well defined, a pilot random study can be conducted and the results included in the final design. The data can be averaged for any exposure area. The classical model is the basis for calculating

EXHIBIT 43. APPLICABILITY OF SAMPLING DESIGNS

Design	Objective of Sampling		
	Estimate Chemical Concentration Distribution	Evaluate Trends	Identify Hot Spots
Judgmental/ Purposive	No	Maybe	Maybe
Classical Random	Yes	Yes	No
Classical Stratified:			
Random	Yes	Yes	Maybe
Systematic	Maybe	Yes	Maybe
Cluster	Yes	No	No
Composite	Maybe	No	Maybe
Systematic:			
Random	Maybe	Yes	Maybe
Grid	No	Yes	Yes
Search	No	No	Yes
Surrogate	No	Yes	Maybe
Phased	No	Maybe	Yes
Geostatistical	Yes	Yes	Yes

21-002-043

confidence levels, power, and minimum detectable relative differences (MDRDs).


- **Geostatistical model:** Geostatistical techniques are good for identifying hot spots and can be used for calculating reasonable maximum exposure (RME). These techniques require complex judgmental or purposive calculation procedures. Even with the use of available computer programs, a statistician should be consulted because different

approaches to estimating key parameters can produce different estimates.


- **Systematic grid sampling:** Systematic grid sampling procedures are good for identifying unknown hot spots and also provide unbiased estimates of chemical occurrence and concentration (Gilbert 1987) useful in calculating the RME. Systematic sampling can be used in geostatistical or classical estimation models. Variance

EXHIBIT 44. COMMON SAMPLING DESIGNS


Simple Random Sampling




Cluster Sampling




Stratified Random Sampling



Stratified Systematic Sampling



Systematic Grid Sampling



Systematic Random Sampling





EXHIBIT 45. HIERARCHICAL STRUCTURE OF SAMPLING DESIGN SELECTION WORKSHEET



**EXHIBIT 45. PART 1: MEDIUM SAMPLING SUMMARY
SAMPLING DESIGN SELECTION WORKSHEET
(Cont'd)**

A. Site Name _____ B. Base Map Code _____

C. Medium: Groundwater, Soil, Sediment, Surface Water, Air
Other (Specify) _____

D. Comments: _____

E. Medium/ Pathway Code	Exposure Pathway/ Exposure Area Name	F. Number of Samples from Part II					
		Judgmental/ Purposive	Back- ground	Statistical Design	Geo- metrical or Geo- statistical Design	QC	Row Total
Column Totals:							
G: Grand Total:							

**EXHIBIT 45. PART II: EXPOSURE PATHWAY SUMMARY
SAMPLING DESIGN SELECTION WORKSHEET
(Cont'd)**

H. Chemical of Potential Concern and CAS Number	I. Frequency of Occurrence	J. Estimation		K. CV	L. Background
		Arithmetic Mean	Maximum		

M. Code (CAS Number) of Chemical of Potential Concern Selected as Proxy _____

N. Reason for Defining New Stratum or Domain (Circle one)

1. Heterogeneous Chemical Distribution
2. Geological Stratum Controls
3. Historical Information Indicates Difference
4. Field Screening Indicates Difference
5. Exposure Variations
6. Other (specify) _____

O. Stratum or Exposure Area		Q. Number of Samples from Part III					
Name and Code	P. Reason	Judgmental/ Purposive	Back- ground	Statistical Design	Geo- metrical or Geo- statistical Design	QC	Row Total
R. Total (Part I, Step F):							

21-002-045-02

EXHIBIT 45. PART III: EXPOSURE AREA SUMMARY SAMPLING DESIGN SELECTION WORKSHEET (Cont'd)

O. Stratum or Exposure Area _____ Domain Code _____
E. Medium/Pathway Code _____ Pathway Code _____

S. Judgmental or Purposive Sampling

Comments: _____

Use prior site information to place samples, or determine location and extent of contamination. Judgmental or purposive samples generally cannot be used to replace statistically located samples.

An exposure area and stratum MUST be sampled by at least TWO samples.

Number of Samples

T. Background Samples

Background samples must be taken for each medium relevant to each stratum/area. Zero background samples are not acceptable. See the discussion on page pp. 74-75.

Number of Background Samples

U. Statistical Samples

CV of proxy or chemical of potential concern _____
Minimum Detectable Relative Difference (MDRD) _____ (<40% if no other information exists)
Confidence Level _____ (>80%) Power of Test _____ (>90%)

Number of Samples
(See formula in Appendix IV)

V. Geometrical Samples

Hot spot radius _____ (Enter distance units) _____
Probability of hot spot prior to investigation _____ (0 to 100%)
Probability that NO hot spot exists after investigation _____ (enter only if >75%)
(see formula in Appendix IV)

W. Geostatistical Samples

Required number of samples to complete grid +
Number of short range samples

X. Quality Control Samples

Number of Duplicates (Minimum 1:20 environmental samples) _____
Number of Blanks (Minimum 1 per medium per day or 1 per sampling process, whichever is greater) _____

Y. Sample Total for Stratum
(Part II, Step U)

Judgmental/ Purposive	Back- ground	Statis- tical Design	Geo- metrical or Geo- statistical	QC	Row Total

calculations required to estimate confidence limits on the average concentration are available (Caulcutt 1983). Systematic sampling is powerful for complete site or exposure area characterization when the exposure area is known to be heterogeneous.

Determining number of samples. Four factors need to be considered in determining the total number of samples required (see Exhibit 46):

- Exposure areas,
- Statistical performance objectives (based on site environmental samples),
- Quality assurance objectives (based on QC samples), and
- Background samples (based on MDRD).

EXHIBIT 46. FACTORS IN DETERMINING TOTAL NUMBER OF SAMPLES COLLECTED

<p>Number of Exposure Areas That will be Sampled (p. 74)</p> <ul style="list-style-type: none"> • Media within exposure area • Strata within exposure area medium <p>Number of Samples for Each Exposure Area Grouping Given Required Statistical Performance (p. 75)</p> <ul style="list-style-type: none"> • Confidence ($1 - \alpha$), where α is the probability of a type I error • Power ($1 - \beta$), where β is the probability of a type II error • Minimum detectable relative difference <p>Number of Quality Control Samples (p. 76)</p> <ul style="list-style-type: none"> • Field duplicate (collocated) • Field duplicate (split) • Blank (trip, field, and equipment (rinsate)) • Field evaluation <p>Number of Background Samples (p. 74)</p> <ul style="list-style-type: none"> • Number of site samples collected • Minimum detectable relative difference
--

21-002-046

The number of environmental site samples is ultimately controlled by performance requirements, given the statistical sampling design. The relationship between number of samples and measures of performance depends upon the variability of the chemicals of potential concern, which is measured by the coefficient of variation. In other words, the relationship between the coefficient of

variation for a chemical of potential concern and measures of performance is the basis for determining the number of samples necessary to provide useable data for risk assessment.

• If the natural variability of the chemicals of potential concern is large (e.g., greater than 30%), the major planning effort should be to collect more environmental samples.

The number of samples can be calculated given a coefficient of variation, a required confidence level or certainty, a required statistical power, and an MDRD. Exhibit 47 illustrates the relationships between the number of samples required given typical values for the coefficient of variation and statistical performance objectives. Calculation formulas in Appendix IV facilitate the examination of effects beyond the examples cited.

4.1.2 Guidance for Completing the Sampling Design Selection Worksheet

This section provides step-by-step instructions for completing the Sampling Design Selection Worksheet shown in Exhibit 45.

Part I: Medium Sampling Summary

- A. Enter the Superfund site name.
- B. Enter a code that uniquely identifies a base map of the site or the exposure unit.

All sampling events should be identified on a map or in a database such as a Geographical Information System (GIS).

- C. Identify the medium to be sampled (e.g., soil, groundwater, industrial sludge, mine tailings, smelter slag, etc.).
- D. Enter any comments required to describe the exposure area, and other information such as the RPM's name.
- E. Enter a medium/pathway code that has been assigned for the risk investigation.
- F. Specify the exposure pathway (e.g., ingestion of soil).

Leave this entry blank for now, then enter the number of samples for each category that have been selected from Part II (Step R) of the worksheet when completed.

EXHIBIT 47. RELATIONSHIPS BETWEEN MEASURES OF STATISTICAL PERFORMANCE AND NUMBER OF SAMPLES REQUIRED

Coefficient of Variation (%)	Power (%)	Confidence Level (%)	Samples Required to Meet Minimum Detectable Relative Difference		
			5%	10%	20%
10	95	90	36	10	3
15	95	90	78	21	6
20	95	90	138	36	10
25	95	90	216	55	15
30	95	90	310	78	21
35	95	90	421	106	28

Note: Number of samples required in a one-sided one-sample t-test to achieve a minimum detectable relative difference at confidence level and power. CV based on geometric mean for transformed data.

Source: EPA 1989c.

21-002-047

Sample types are broken out by sample type:

- Judgmental/Purposive,
- Background,
- Statistical design (e.g., stratified random sampling),
- Geometrical or geostatistical design (including hot spot sampling), and
- Quality control samples.

• At least one broad spectrum analytical sample is required for risk assessment, and a minimum of two or three are recommended for each medium in an exposure pathway.

G. Enter the grand total of all samples within a specific medium.

Part II: Exposure Pathway Summary

H. List the chemicals of potential concern and their CAS numbers.

List the known or suspected chemicals of potential concern based on historical data. This will generally be from the PA/SI.

I. List the frequency of occurrence (%).

The frequency of occurrence is the percent of samples in which the chemical of potential concern has been identified. This may be obtained from site-specific data or calculated from historical (PA/SI) data or fate and transport modeling.

J. Enter an estimate of the average (arithmetic mean) and maximum concentration of the chemical of potential concern.

Historical data or data from similar sites can be used to derive these values. More sampling will usually be necessary to determine statistically

significant differences if these values are close to background levels or to the levels of detection.

K. Estimate the coefficient of variation.

The coefficient of variation (CV) can be estimated from site-specific data or from data from similar sites. The number of samples necessary to produce useable data will generally increase as the CV increases. The definition of separate strata or domains should be investigated if a CV is above 50%. Exhibit 23 contains a listing of historical values for CVs that may be used as an estimate in the absence of site-specific data.

L. Estimate background concentration.

Background concentration estimates should be for each medium relevant to each strata/area. Site-specific data are preferred, but data from similar sites can be utilized.

M. Select a proxy chemical of potential concern.

Choose a proxy from the list of chemicals of potential concern to develop sampling plans. Note that a proxy that has the highest CV, lowest frequency of occurrence, or whose concentration at the site is closest to background levels will require the most samples.

N. Develop the reason for defining new strata or areas.

- **Heterogeneous Chemical Distribution:** If a chemical can be shown to have dissimilar distributions of concentration in different areas, then the areas should be subdivided. For example, hot spots may be considered separately.
- **Geological Stratum Controls:** Knowledge of local geologic conditions can be used to produce separate areas where similar statistical distributions are likely to exist. In particular, different "stratigraphic" layers may produce distinct strata.
- **Historical Information:** Historical information on production, discharge or storage of chemicals of potential concern can be used to identify separate areas.
- **Field Screening:** Field analytical results can be used to locate sub-populations that are mapped into exposure areas.
- **Exposure Variations:** Information or variations in behavior patterns, land use or receptor groups can be used to identify separate areas.

- Other reasons can be used to produce separate sampling areas, such as observed stress on vegetation, oily appearance of soils, or the existence of refuse, etc.

O. List the stratum or area name and code.

The stratum or area identifies sub-areas on the site base-map.

P. Annotate reason from Step N.

Q. List the number of samples estimated after completing Part III of this worksheet.

R. List the number of samples estimated after completing Part II and Part III of this worksheet.

Part III: Exposure Area Summary

S. Enter judgmental/purposive sampling comments.

A minimum of three to five judgmental or purposive samples must be used to sample a stratum or exposure area. Historical or prior site information can be used to locate sampling positions to determine the extent and magnitude of contamination. Chemical field screening, geophysics, vegetation stress, remote sensing, geology, etc. can also be used to guide judgmental sampling. Judgmental or purposive samples are not recommended for estimating average and maximum values within a stratum or domain area, but they can be used in geostatistical kriging estimations and can be included in calculating risk.

T. Identify background samples.

For statistical purposes, a sufficient number of background samples must be taken to determine the validity of the null hypothesis that there is no difference between mean values of concentration in the site and the background samples at the desired level of confidence. Early sampling and analysis of background samples will indicate the ease with which background levels can be discriminated, and allow modifications to be made to the SAP if necessary.

Background samples must be taken for each exposure pathway. As with QC samples, results from the background sample should be assessed early to see if background levels will severely impact the sampling design. The number of necessary background samples increases as the variability of the background values increases. Background samples should not be used in the estimation of average or maximum values within a stratum or exposure area, but they can be used in

kriging estimations. In those instances where background levels are close to on-site contamination levels, it may be necessary to collect as many background samples as site samples. Small numbers of background samples increase the probability of a type II, false negative error (i.e., that no difference exists between site and background when a difference does, in fact, exist). However, rigorous statistical analyses involving background samples may be unnecessary if site and non-site related contamination clearly differ.

☛ *Collect and analyze background samples prior to the final determination of the sampling design since the number of samples is significantly reduced if little background contamination is present.*

Background levels of contaminants vary by medium and the type of contamination. If a detectable background level of a contaminant occurs infrequently, the number of background samples analyzed might be kept small. Metals often have high rates of detection in background samples. Some pesticides, such as DDT, are anthropogenic and also have high rates of detection in particular matrices. Anthropogenic background levels are also found in sites near industries and urban areas. It is important to distinguish detection, or lack of detection, in a single sample from a false positive or false negative result. Results from single samples are different estimators than those from statistical parameters from pooled samples. Background sampling must be increased in the following situations:

- Contamination exists in more than one medium,
- Expected coefficients of variation in chemicals of concern are high and confirmed by actual data,
- Relative differences between site and background levels are small, and
- Site concentrations and concentrations of concern are low.

U. Identify statistical samples.

Samples should be systematically or randomly located. The number of samples can be calculated using the CV of the proxy variable, the required MDRD, the required confidence level and power of the test, and the appropriate statistical formula and appropriate charts.

For example, using the equation in Appendix IV:

Where Z_α and Z_β are obtained from the normal distribution tables for significance levels α and β respectively; α is the probability of the false positive error rate, and β is the probability of the false negative error rate.

Then, if α is 0.2 (20%) and the confidence level is 80% then Z_α is 0.842. If β is 0.05 (5%) then the power is 95% and Z_β is 1.648.

If the MDRD is 20% and the CV is 30%, then $D = \frac{\text{MDRD}}{\text{CV}}$ which equals 0.666 and $n > 15$ samples are required.

V. Identify samples from geometrical design.

☛ *Systematic sampling supplemented by judgmental sampling is the best strategy for identifying hot spots.*

For example, using the equation in Appendix IV:

Where $R = 20$ m

and $A = 37,160 \text{ m}^2$

and $X = 0.3$ Probability that a hot spot is in the exposure area from "historical records" or from field screening or geophysical tests.

and $C = 0.2$ The acceptable "walk away" probability that a hot spot exists after a sampling grid has been done.

then:

$$D = 2.7, R = 54.8 \text{ m, and} \\ n = 27,160/54.82 = 12.37$$

Therefore 12 samples are required.

Note that the requirements for 15 samples from a statistical sampling approach can be met in this example if the hot spot search is augmented by randomly locating two additional samples. The results for number of samples from U and V are not additive.

W. Identify samples from geostatistical design.

A geostatistical sampling pattern should be designed at the early stage of planning. A statistician should be consulted to develop the design.

X. Quality Control Samples

Generally, duplicates should be taken at a minimum of 1 duplicate for every 20 environmental samples (EPA 1989f). However, this frequency may be modified based on site conditions. For example, the number of duplicates and other QC samples may be set high for the beginning of site sampling, evaluated after several duplicates to determine routine measurement error, and subsequently adjusted according to observed performance. The information in Exhibit 48 shows that confidence in measurement error increases sharply when four or more pairs of duplicate samples are taken per medium. Critical samples are recommended for designation as duplicates in the QA sampling design.

EXHIBIT 48. NUMBER OF SAMPLES REQUIRED TO ACHIEVE GIVEN LEVELS OF CONFIDENCE, POWER, AND MDRD¹

Confidence (1- α)	Power (1- β)	MDRD	No. of Samples
90%	90%	10%	42
90% ²	90% ²	20%	12
90%	90%	20%	8
80%	80%	10%	19
80% ²	80% ²	20%	5
80%	90%	40%	3

¹ Values for number of samples are based on a CV of 25%.

² The minimum recommended performance measures for risk assessment are: confidence (80%) and power (90%).

Source: EPA 1989c.

Blanks provide an estimate of bias due to contamination introduced by sampling, transportation, carryover during field filtration, preservation, or storage. At least one field blank per medium should be collected each day, and at least one blank must be collected for each sampling process (EPA 1989f).

Examine results from duplicate and blank samples as early as possible in the sampling operation to ascertain if presumed sampling characteristics are accurate and discover areas where the sampling strategy requires modification. For a more detailed discussion of the types and use of QC samples see *A Rationale for the Assessment of Errors in the Sampling of Soils* (EPA 1990c).

Y. Calculate the sample total for stratum or exposure area (enter in Part II, Step U).

4.1.3 Specific Sampling Issues

Selection of performance measures. Quantitative data quality indicators based on performance objectives should be proposed for completeness, comparability, representativeness, precision, and accuracy during planning. Performance measures are specified as minimum limits for each stratum. Based on the coefficients of variation of the analyte concentrations, these limits will determine the numbers of samples required. The actual values or objectives are determined by the level of acceptable uncertainty, which includes that associated with hot spot identification. Recommended minimum criteria are specified in Exhibit 48 for statistical performance measures associated with the uncertainty in risk assessment: confidence level, power, and MDRD. Recommended minimum criteria for measurement error and completeness for critical samples are discussed in the following sections.

Setting minimum acceptable limits for confidence level, power, and minimum detectable relative difference. Confidence level, power, and MDRD are three measures of sampling design precision. These measures are ultimately determined by the coefficient of variation of chemical concentration and the number of samples. Each measure is briefly defined as follows:

- **Confidence level:** The confidence level is 100 minus α , where α is the percent probability of taking action when no action is required (false positive).
- **Power:** Power is 100 minus β , where β is the percent probability of not taking action when action is required (false negative).
- **Minimum detectable relative difference:** MDRD is the percent difference required between site and background concentration levels before the difference can be detected statistically.

The power and ability to detect differences between site concentration levels compared to background levels are critical for risk assessment. Given a CV, the required levels of confidence, power, and MDRD significantly affect the number of samples. Exhibit 48 illustrates the effect when the CV is equal to 25%.

It is important to note that the number of samples required to meet confidence and power requirements will be low if the acceptable MDRD is large; that is, if site contamination is easily discriminated from background levels.

Determining required precision of measurement error. Field duplicates and blanks are the major field QC samples of importance to the precision of measurement error. Duplicates provide an estimate of

total measurement error variance, including variance due to sample collection, preparation, analysis, and data processing. They do not discriminate between-batch error variance. If the duplicate is collocated, contaminant sample variation caused by a heterogeneous medium is also included in the measure. The precision of the measurement error estimate is subject to the number of duplicates on which the estimate is based. Exhibit 49 gives the estimated precision of the measurement error based on the number of duplicate pairs. With three duplicates, the true measurement error variance could be as much as 13.89 times the observed variance, if a 95% level of confidence is required. The resources needed for the collection and analysis of duplicates depend on the magnitude and variability of the concentration of concern for the chemicals of potential concern.

- Little room for measurement error exists if the level of concentration of concern is near the method

detection limit, and the precision of the estimate of measurement error is critical.

- If the natural variability of the chemicals of potential concern is relatively large, the major planning effort will be to collect more samples from the exposure areas, rather than collecting more QC samples. More detailed discussions of the use of QC measures and selection of the appropriate number of QC samples may be found in *A Rationale for the Assessment of Errors in the Sampling of Soils* (EPA 1990c).

Planning for 100% completeness for critical samples. Certain samples in a sampling plan may be designated by the RPM or risk assessor as critical in determining the potential risk for an exposure area. For example, if only one background sample is taken for a given medium and exposure area, then that sample would be considered

EXHIBIT 49. CONFIDENCE LEVELS FOR THE ASSESSMENT OF MEASUREMENT VARIABILITY

Number of Duplicate Pair Samples	Interval for 95% Confidence that Measurement Error is Within Limits				
	Observed Variance (s^2)		True Variance		Observed Variance (s^2)
2	.27	\leq	σ^2	\leq	39.21
3	.32	\leq	σ^2	\leq	13.89
4	.36	\leq	σ^2	\leq	8.26
5	.39	\leq	σ^2	\leq	6.02
6	.42	\leq	σ^2	\leq	4.84
7	.44	\leq	σ^2	\leq	4.14
8	.46	\leq	σ^2	\leq	3.67
9	.47	\leq	σ^2	\leq	3.33
10	.49	\leq	σ^2	\leq	3.08
15	.54	\leq	σ^2	\leq	2.40
20	.58	\leq	σ^2	\leq	2.08
25	.62	\leq	σ^2	\leq	1.91
50	.70	\leq	σ^2	\leq	1.61
100	.77	\leq	σ^2	\leq	1.35
s^2 = Observed variance (precision of an estimate).					
σ^2 = True variance (population variance).					
Note: Assumes data are or have been transformed to normal distribution.					
Source: EPA 1990c.					

“critical.” All data associated with such a sample must be complete. The only acceptable level of completeness for critical samples is 100%.

➤ *Focus planning efforts on maximizing the collection of useable data from critical samples.*

Hot spots and the probability of missing a hot spot. Hot spots are primarily an issue in soil sampling. The RPM and risk assessor must determine whether hot spots exist in the exposure area and the probable size of the hot spot. This information can often be deduced from historical data and assisted by judgmental sampling, although judgmental sampling alone cannot produce estimates of the probability that a hot spot has been missed. Procedures for determining the probability of missing a hot spot are not as effective in random designs as in systematic and geostatistical designs. However, a search strategy which stratifies the area based on grids and then randomly samples within each grid can be used within the classical technique. Systematic and geostatistical design approaches provide the best approach to unknown hot spot identification.

Appendix IV describes numerical procedures and assumptions to determine the probability that a given systematic design will detect a hot spot and provides a calculation formula based on a geometrical approach. To employ this formula, the distance between grid points and the estimated size of the hot spot as a radius must be specified.

Historical data comparability. The RPM may wish to assess historical data along with current results or may anticipate that the current data will need to be compared with results from future sampling activities. Consult a statistician in either of these cases to determine if the current sampling design will allow the production of data of known comparability. Factors other than statistics may need to be considered when attempting to combine data from different sampling episodes. Physical properties of the site such as weather patterns, rainfall and geologic characteristics of different exposure areas may need to be considered. Temporal effects, such as the seasonality or time period of sampling, or seasonal height of a water table, may also be important. Analytical methods have been modified over time and many required detection limits have been revised.

➤ *The ability to combine data from different sampling episodes or different sampling procedures is a very important consideration in selecting a sampling design but should be done with caution.*

4.1.4 Soil Depth Issues

The appropriate depth or depths to take soil samples can be a major issue in determining a sampling design. Exhibit 50 is a worksheet designed to help the RPM and risk assessor to determine an appropriate soil sampling depth. The conceptual site model (Exhibit 6) provides the basis for completing this worksheet. The nature and depth of soil horizons at the site should be established wherever possible. Features such as porosity, humic content, clay content, pH, and aerobic status often affect the movement or fate of chemicals of potential concern through a soil. As with other worksheets provided in this guidance, this worksheet is intended as a guide or basis for development. RPMs, in consultation with the risk assessor and other staff, can revise or modify this worksheet as appropriate to the site. Consider both current and future land use scenarios in soil exposure areas because of the sorptive and retentive properties of soils.

Completing the Soil Depth Sampling Worksheet

1. Land Use Alternatives

- A. Identify current or future land use.
- B. Identify exposure scenario.

The exposure scenario should be identified for current or future land use. Identify the scenario according to *Role of Baseline Risk Assessment in Superfund Remedy Selection Decision* (EPA 1991c) and *Human Health Evaluation Manual Supplemental Guidance: Standard Default Exposure Factors* (EPA 1991d). A residential exposure scenario should be used whenever there are, or may be, occupied residences on or adjacent to the site. Unoccupied sites should be assumed to be residential in the future unless residential land use is unreasonable. Sites that are surrounded by operating industrial facilities can be assumed to remain as industrial areas unless there is an indication that this assumption is not appropriate. Other potential land uses, such as recreation and agricultural, may be used if appropriate.

2. Chemicals of Potential Concern

- A. Specify class of chemical.

Circle the classes of chemicals of potential concern (e.g., volatile organics (VOAs), semivolatile organics (semi-VOAs), inorganics or metals, or special class) that apply.

EXHIBIT 50. SOIL DEPTH SAMPLING WORKSHEET

Step 1 - Land Use Specifications*						
1A (check one) <input type="checkbox"/> Current <input type="checkbox"/> Future <input type="checkbox"/> Current & Future, Same		1B (check one) <input type="checkbox"/> Residential <input type="checkbox"/> Commercial/Industrial <input type="checkbox"/> Other (Specify)				
				<input type="checkbox"/> Recreational <input type="checkbox"/> Agricultural		
Sampling Depth Considerations	Step 6. Expected Depth of Contamination by Chemicals of Potential Concern		Step 7. Exposure Pathways			Step 8. Representative Sample Depths (units _____)
	Surface Units	Subsurface	Ingestion	Dermal	Inhalation	
Step 2: Chemicals of Concern A Class: VOAs, Metals, semi-VOAs, Special (e.g., PCBs, dioxin) B Physical Properties: Mobile, Soluble, or Leachable Step 3: Soil Characteristics A Taxonomy _____ B Organic Content _____ C Particle Size _____ D Concern for Migration to Other Media, (Air, SW, sediments, GW) _____ Step 4: Vegetative Cover Heavy/Sparse/Intermittent Step 5: Other Factors _____ _____						

* The complexity of a site determines if multiple worksheets are necessary to distinguish between current and future land use scenarios (e.g., mix of residential and commercial use for different areas of a site, possible future residential use, etc.).

B. Record physical properties.

Circle the physical properties of the chemicals of potential concern that apply. These properties can be estimated from factors such as the octanol/water partition coefficient, Henry's law constant, and water solubility appropriate to each chemical.

3. Soil Characteristics

- A. Record the taxonomic designation of the soil, if known.
- B. Record the organic matter content of the soil.
- C. Record the most common particle size of the soil.
- D. Identify any concern for migration of the chemicals of potential concern to other media (e.g., air, sediment, surface water, and groundwater).

4. Vegetative Cover

Circle whether the vegetative cover of the site is heavy, sparse or intermittent.

5. Other Factors

List other factors or considerations that influence the desired depth of soil sampling. For example, geological factors (e.g., depth to groundwater or bedrock) could influence soil sampling.

6. Expected Depth of Contamination by Chemicals of Potential Concern

Enter expected depth (and units) of contamination by chemicals of potential concern, given the chemicals, soil characteristics and vegetative cover. Depth can be influenced by disposal practices or deposition patterns, soil characteristics, vegetative cover, and physical and chemical properties of the chemicals of potential concern.

7. Exposure Pathways

Enter exposure pathways by chemicals of potential concern, soil characteristics and vegetative cover. Physical and chemical properties of the chemicals of potential concern will influence their activity in the exposure pathway (e.g., VOAs and the inhalation pathway). Soil characteristics and vegetative cover will also influence the exposure pathway (e.g., groundwater and water ingestion pathway).

8. Representative Sample Depths

Record representative sample depths (including units) indicated by the data completed in Steps 2 through 7.

Basic Soil Depth Definitions

Surface dust is the top 0 to 2 inches of soil that can be carried by the wind and tracked into houses.

Surface soil is the top 0 to 6 inches of soil. If the surface is grass covered, surface soil is considered the 2 inches below the grass layer.

Subsurface soil can typically range from 6 inches to 6 or more feet in soil depth. For example, at sites with potential soil moving activity, soil depths greater than 6 feet could be of concern in risk assessment.

Other Performance Measures. Other performance measures may be designated to facilitate the monitoring and assessment of sampling. For example, field spikes and field evaluation or audit samples can be used to assess the accuracy and comparability of results. Field matrix spikes are routine samples spiked with the contaminant of interest in the field and do not increase the number of field samples. Field evaluation samples are of known concentration, which are introduced in the field at the earliest stage possible and subject to the same manipulation as routine samples. Field evaluation samples will increase the total number of samples collected. Performance measures for field spikes and evaluation samples are expressed in terms of percent recovery. Difficulties associated with field spiking, especially in soil, have resulted in limited use of this practice (EPA 1989f).

4.1.5 Balancing Issues for Decision-Making

Completing a number of Sampling Design Selection Worksheets (Exhibit 45) for different exposure areas, media, and sampling design alternatives will enable the RPM and risk assessor to compare and evaluate sampling design options and consequences and select the appropriate sampling design for each medium and exposure pathway. Practical tradeoffs between response time, analytical costs, number of samples, sampling costs, and level of uncertainty can then be weighed. For example, perhaps more samples can be collected if less expensive analyses are used. Or, if the risk assessment is based on a point source, collection of additional samples to estimate chemical concentrations and distribution can be avoided.

Computer programs are useful tools in developing and evaluating sampling strategies, especially in trading off costs against uncertainty, and identifying situations when additional samples will not significantly affect the useability of the data (i.e., the point of diminishing returns). Each automated system has specific data requirements and is based on specific site assumptions. The major systems that support environmental sampling decisions are listed, contacts for information given, and brief descriptions provided in Exhibit 51.

4.1.6 Documenting Sampling Design Decisions

It is important to document the primary issues considered in balancing tradeoff to accommodate resource concerns and their impact on data useability. Fully document all final sampling design decisions, including the rationale

for each decision. During the course of the RI, continue to document pertinent issues that arise and any sampling plan modifications which are implemented.

4.2 STRATEGY FOR SELECTING ANALYTICAL METHODS

This section describes how to use the Method Selection Worksheet shown in Exhibit 52 as a data collection and decision-making tool to guide the selection of analytical methods that meet the needs of the risk assessment and to select the most appropriate method for each analyte. The RPM and risk assessor should consult the project chemist and use this worksheet in method selection. Alternatively, it can be a model to create a worksheet specifically suited to their needs. Methods selected in this process may be routine or non-routine.

EXHIBIT 51. AUTOMATED SYSTEMS* TO SUPPORT ENVIRONMENTAL SAMPLING

System	EPA Contact	Description
Data Quality Objective (Training) - Expert System	Dean Neptune USEPA Quality Assurance Management Staff (202) 260-9464	Training system designed to assist in planning of environmental investigations based on DQO process.
ESES Environmental Sampling (Plan Design) - Expert System	Jeff Van Ee Exposure Assessment Div. USEPA, EMSL-LV (702) 798-2367	Expert system designed to assist in planning sample collection. Includes models that address statistical design, QC, sampling procedures, sample handling, budget, and documentation. Current system addresses metal contaminants in a soil matrix. (Expanded application under development, contact EMSL-LV.)
GEOEAS Geostatistical Environmental Assessment Software	Evan Englund Exposure Assessment Div. USEPA, EMSL-LV (702) 798-2248	Collection of software tools for two-dimensional geostatistical analysis of spatially distributed data points. Programs include file management, contour mapping, kriging, and variogram analysis.
SCOUT Multivariate Statistical Analysis Package	Jeff Van Ee Exposure Assessment Div. USEPA, EMSL-LV (702) 798-2367	A collection of statistical programs that accept GEOEAS files for multivariate analysis.
ASSESS	Jeff Van Ee Exposure Assessment Div. USEPA, EMSL-LV (702) 798-2367	System designed to assist in assessment of error in sampling of soils. Estimates measurement error variance components. Presents scatter plots of QC data and error plots to assist in determining the appropriate amount of QC samples.

* All systems will run on any IBM-compatible PC AT with a minimum of 640K RAM. A fixed disk is recommended.

EXHIBIT 52. METHOD SELECTION WORKSHEET

I. Analytes		II. Medium	III. Critical Parameters				IV. Routine Available Methods ⁴
A. Chemical or Class of Chemicals of Potential Concern	B. Reporting Requirement ¹ (Y or N)		A. Turnaround Time (enter hours or days)	B. ID Only or ID Plus Quant (ID or ID+Q)	C. Concen- tration of Concern ² (or PRG)	D. Required Method Detection Limit ³	

¹ Y= Total reported for compound class.

² N = Each analyte reported separately.

³ Preliminary remediation goal.

⁴ Method detection limit should be no greater than 20% of concentration of concern.

Refer to Appendix III for specific methods. Recommend consultation with chemist and/or automated methods search to determine all methods available.
(Exhibit 53 lists computer systems that support method selection.)

• *Ensure that critical requirements and priorities are specified on the Method Selection Worksheet so that the most appropriate methods can be considered.*

- Routine methods are issued by an organization with appropriate responsibility (e.g., state or federal agency with regulatory responsibility, professional organization), are validated, documented, and published, and contain information on minimum performance characteristics such as detection limit, precision and accuracy, and useful range.
- Non-routine methods address situations with unusual or problematic matrices, low detection limits or new parameters, procedures or techniques; they often contain adjustments to routine methods.

• *Use routine methods wherever possible since method development is time-consuming and may result in problems with laboratory implementation.*

4.2.1 Completing the Method Selection Worksheet

1. Identify analytes.

List the chemicals of potential concern to risk assessment for the site on the Method Selection Worksheet. Use the same list of chemicals that appears on the Sampling Design Selection Worksheets. Under Column 1B, indicate whether the concentration for each analyte should be reported separately, or the total for the compound class reported.

2. Identify medium for analysis.

Specify the analysis medium (e.g., soil, sediment, groundwater, surface water, air, biota).

3. Decide on critical parameters.

Specify the required data turnaround time (IIIA) as the number of hours or days from the time of sample collection. Indicate whether chemical identification alone is desired or identification plus quantitation (IIIB). Specify the concentration of concern (IIIC) and required detection or quantitation limit (IIID).

4. Identify routine available methods.

Use the final worksheet column, in consultation with the project chemist, to list the methods available that satisfy the requirements in the preceding steps. Reference sources and software are available to

assist in identifying routine analytical methods applicable for environmental samples (Exhibit 53). The most common routine methods for organics and inorganics analyses for risk assessment are listed in Appendix III. The methods in the appendix are from the following sources:

- Contract Laboratory Program (CLP) Statements of Work for Routine Analytical Services (EPA 1990d, EPA 1990e),
- *Test Methods for Evaluating Solid Waste (SW846): Physical/Chemical Methods* (EPA 1986b),
- *Standard Methods for the Examination of Water and Wastewater* (Clesceri, et. al., eds. 1989), and
- EPA Series 200, 300, 500, 600 and 1600 Methods (EPA 1983, EPA 1984, EPA 1988d, and EPA 1989g).

Other sources of methods are:

- Field Analytical Support Project (FASP) (EPA 1989h),
- *Field Screening Methods Catalog* (EPA 1987b),
- *Field Analytical Methods Catalog*,
- *ERT Standard Operating Guidelines*,
- *Close Support Analytical Methods*,
- *A Compendium of Superfund Field Operations Methods* (EPA 1987c),
- Association of Official Analytical Chemists (AOAC), and
- American Society for Testing and Materials (ASTM).

Several computer-assisted search and artificial intelligence-based tools are available, including the Environmental Monitoring Methods Index (EMMI), the Smart Methods Index, and a computerized reference book on analytical methods. Some of these systems are designed as teaching tools, as well as informational compendia. All offer the ability to rapidly search and compare lists of chemicals and method characteristics from accepted reference sources. Exhibit 53 lists software products that aid method selection, identifies contacts for information, and gives a short description of the product.

EXHIBIT 53. AUTOMATED SYSTEMS* TO SUPPORT METHOD SELECTION

System	Contact	Description
Environmental Monitoring Methods Index (EMMI)	W. A. Tellard USEPA Office of Water (202) 260-7120	An automated sorting and selection software package that currently contains over 900 methods and over 2600 analytes from more than 80 regulating and non-regulating lists. These are cross-referenced to facilitate selection based on required needs (e.g., analyte detection limit, instrument).
Smart Methods Index	John Nocerino Quality Assurance Div. USEPA, EMSL-LV (702) 798-2110	Natural language expert system prototype that provides interactive queries of databases cross-referenced by method, analyte, and performance features.
Geophysical Techniques Expert System	Aldo Maggella Advanced Monitoring Div. USEPA, EMSL-LV (702) 798-2254	An expert system that suggests and ranks geophysical techniques, including soil-gas, for applicability of use based on site-specific characteristics.
EPA Sampling and Analysis Data Base	Lewis Publishers 1-800-272-7737	A three-volume set of diskettes and a printed manual provides a search of sampling and analytical method summaries from a menu-driven program of 150 EPA-approved methods. The database can be searched by method, analyte, matrix, and various QA considerations.

* All systems will run on any IBM-compatible PC AT with a minimum of 640K RAM. A fixed disk is recommended.

21-002-053

4.2.2 Evaluating the Appropriateness of Routine Methods

• *Analyte-specific methods that provide better quantitation can be considered for use once chemicals of potential concern have been identified by a broad spectrum analysis.*

Choice of the proper method is critical to the acquisition of useable data. See Section 3.2 for a more detailed discussion. Routine methods provide data of known quality for the analysis of chemicals and sample types described in the method. Data quality issues (precision, accuracy, and interferences) are usually described in the method. Consult the project chemist and examine available methods with respect to the criteria defined on the Method Selection Worksheet. It may be helpful to divide the analyte list into categories based on the types of analysis. For example, a requirement for chromium, cadmium, and arsenic data could not be generated by the same analysis as data for chlorinated hydrocarbons because of sample extraction and treatment procedures. It may be possible to use several methods independently and combine the data sets for risk assessment purposes. This is done routinely by the CLP, where inorganics

(elemental analysis), volatiles, extractable organics, and pesticides are analyzed by different methods. In some cases, no routine method or series of methods will be able to satisfy all criteria and compromises must be considered. The RPM, with the advice of the risk assessor, must then determine which criteria are of highest priority and which can be modified. For example, if a low detection limit is of high priority, turnaround time and cost of analysis will likely increase. Alternatively, low detection limit and precision requirements may need to be modified if an initial broad spectrum analysis is of high priority to quickly determine the largest number of chemicals present at the site.

Turnaround time. Turnaround time is determined by the available instrumentation, sample capacity, and methods requirements. Turnaround times for field analyses can be as short as a few hours, while those for fixed laboratory analyses include transport time and range from several days to several weeks. Field instruments can provide the quickest results, especially if the data do not go through a formal review process. However, the confidence in chemical identification, and particularly quantitation, may not be as high. In general, methods with quick turnaround times may be less precise and have higher detection limits. If data are needed quickly, a field method can be used for initial results and a fixed laboratory method used to produce more detailed results (or confirm the earlier results), thereby increasing the confidence in field analyses.

Sample quantitation limits. Risk assessment often requires a sample quantitation limit at or below the detection limit for routine methods for many chemicals of toxicological concern (see Section 3.2.4). The sample quantitation limits vary according to the size, treatment, and analysis of each individual sample. The quantitation limits for chemicals in water samples are often far lower than for the same chemicals in soils because of co-extractable components in the soil. Interferences known for the method may hinder acquisition of data of acceptable quality and are more pronounced near the method detection limit. Compare documented method interferences with site conditions to identify potential method problems. Some common sources of interference in organic and inorganic analyses are summarized in Exhibits 54 and 55. If needed sample quantitation limits cannot be met by available methods, consult the project chemist for the feasibility of detection at the desired level in the required sample type. The chemist can help determine if method adaptation can resolve the problem, or if a non-routine method of analysis can be used.

Useful range. The useful range of a method is the range of concentration of chemicals for which precise and accurate results can be generated. This range is analyte-specific. The lower end of the useful range is the method detection limit, often generically referred to as

EXHIBIT 54. COMMON LABORATORY CONTAMINANTS AND INTERFERENCES BY ORGANIC ANALYTE

Contamination or Interference	Fraction	Matrix	Effects on Analysis	Removal / Action
Fat/Oil	Extractable organics, pesticides, and PCBs	Tissue, waste, soils	Increased detection limit, decreased precision/accuracy	GPC (all groups), florisil (pesticides), acid digestion (PCBs only)
Sulfur	Extractable organics, chlorinated and phosphorus-containing pesticides	Sediment, waste, soils	Presence/absence, detection limits, precision/accuracy	GPC, copper, mercury, tetrabutyl ammonium sulfate
Phthalate Esters	Chlorinated pesticides, PCBs, and extractable organics	All	False positive identification (pesticides and extractable organics) or positive bias (pesticides and extractable organics)	Florisil, GC-MS confirmation of identity (pesticides, PCBs), evaluation of reagents and method blanks for contamination
Laboratory Solvents	Volatile organics (methylene chloride, acetone, and 2-butanone)	All	False positive identification or positive bias	Confidence in data use based on interpretation of blank data

* Source: EPA 1986a.

21-002-054

the "detection limit." If a lower detection limit is required, use of a larger sample or smaller final extract volume can sometimes compensate. However, any interfering chemicals are also concentrated, thereby producing greater interference effects. Above the useful range, the response may not be linear and may affect quantitation. This causes inaccurate and/or imprecise measurements. Reducing the sample size for analysis or diluting the extracted material may bring the concentration within the useful range. With individual environmental samples, some chemicals are sometimes present at the low end of the useful range of the method, while others are above the useful range. In this situation, two analyses, at different effective dilutions, are necessary to produce accurate and precise data on all chemicals. If detailed criteria for performing and

reporting such actions are not already part of the analytical Statement of Work, then the laboratory should be instructed to notify the RPM if this situation occurs, to allow for sufficient time for reanalysis within the specified holding time. All relevant analyses should be reported to maximize the useability of both detected and non-detected analytes.

➤ *All results should be reported for samples analyzed at more than one dilution.*

Precision and accuracy. Routine methods often specify precision and accuracy with respect to specific analytes (chemicals) and matrices (sample media). However, be aware that environmental samples are often difficult to analyze because of the complexity of the matrix or the

EXHIBIT 55. COMMON LABORATORY CONTAMINANTS AND INTERFERENCES BY INORGANIC ANALYTE

Analyte	Technique	Interference	Removal/ Action
Arsenic	GFAA	Iron, Aluminum	Background correction (not deuterium) (Zeeman).
	ICP	Aluminum	If above 100 ppm, correction factor utilized.
Beryllium	ICP	Titanium, Vanadium	If above 100 ppm, correction factor utilized.
Cadmium	GFAA	None except possible sample matrix effects	Background correction for matrix effects.
	ICP	Iron	If above 100 ppm, correction factor utilized.
Chromium	GFAA	Calcium	Add calcium, standardize suppression, background correction.
	ICP	Iron, Manganese	If above 100 ppm, correction factor utilized.
Lead	GFAA	Sulfate	Lanthanum nitrate addition as matrix modifier, background correction.
	ICP	Aluminum	If above 100 ppm, correction factor utilized.
Mercury	CVAA	Sulfide, High Chloride	Remove interferences with cadmium carbonate (removes sulfide), potassium permanganate (removes chloride), excess hydroxylamine sulfate (removes free chlorine).
Selenium	GFAA	Iron, Aluminum	Alternate wavelength for analysis, background correction (not deuterium) (Zeeman).
	ICP	Aluminum	Above 100 ppm, correction factor utilized.
Cyanide	Colorimetric/ spectrophotometric	Acids, Sulfide, Chlorine oxidizing agents	Increase pH to > 12 in field to remove acids, cadmium carbonate (removes sulfide), ascorbic acid (removes free chlorine).

Key: ICP = Inductively coupled plasma.
 GFAA = Graphite furnace atomic absorption.
 CVAA = Cold vapor atomic absorption.

presence of a large number of contaminants; this usually results in lower levels of precision and accuracy than those cited in the method.

4.2.3 Developing Alternatives When Routine Methods are not Available

If routine methods are not available to suit the parameters of interest, it is often due to one or more of the following factors:

- The detection limit of commonly available instrumentation has been reached, and a lower detection limit is required for the risk assessment,
- An unusual combination of chemicals are of potential concern,
- The sample matrix is complex, and
- The chemicals of potential concern or other analytical parameters are unique to a particular site.

Consult an analytical chemist for specific guidance on the potential limitations of alternative approaches. These may include adaptation of a routine method or use of a non-routine method. Be aware that certain conditions, such as extremely low detection limits for some chemicals, may be beyond the capability of current analytical technology. Turnaround times and costs may also be increased.

Adaptation of routine methods. Adapting routine methods may be a solution when routine methods will not provide the desired data even after compromises have been made with respect to parameters such as turnaround time and cost. Using the completed Method Selection Worksheet as the starting point, work closely with an analytical chemist to formulate suitable modifications to the routine method. Evaluate and document any effects on data quality that will result from the modifications.

Within the CLP, such analyses can be obtained by special analytical requests. Before analysis of site samples, it is advisable to confirm a laboratory's ability to perform the adapted method with preliminary data.

Use of non-routine methods. Existing non-routine methods that meet criteria can be used if a routine method cannot be adapted to provide the necessary data. Such analyses can be found in the research literature, usually catalogued by analyte or instrument. On-line computerized search services can be of considerable help in identifying such methods. Work interactively with an analytical chemist in reviewing selected methods.

Recognize that non-routine analyses require a greater level of capability and experience from the analytical laboratory, and that turnaround time can be longer because the method may need alteration during analysis if problems develop.

Development of new methods. Developing new methods should be the option of last resort. The RPM, risk assessor, and project chemist should consider recommending the development of new methods only for chemicals of substantial potential concern that cannot currently be analyzed at appropriate limits of detection.

Although designing a method based on data available for a given instrument and analytes may seem straightforward, the process is time-consuming and expensive. Unforeseen problems can often arise when the method is implemented in the laboratory. Problems can occur even when laboratory personnel have superior training and experience. Consider the following points when requesting the development of a new method:

- If possible, select a laboratory with a recognized reputation for performance and flexibility in a related area. Treat laboratory personnel as partners in the development process. This is true whether a commercial or a government laboratory is used.
- Identify sources for authentic standards of the chemicals in question to support method development. Computerized databases such as the EPA EMMI (see Exhibit 53) may be useful for such a determination.
- Be aware that turnaround time for useable data may be long (potentially several months) because of the likelihood of trying different approaches before discovering an acceptable procedure.

4.2.4 Selecting Analytical Laboratories

In selecting a laboratory to produce analytical data for risk assessment purposes, identify and evaluate the following laboratory qualifications:

- Possession of appropriate instrumentation and trained personnel to perform the required analyses, as defined in the analytical specifications,
- Experience in performing the same or similar analyses,
- Performance evaluation results from formal monitoring or accreditation programs,
- Adequate laboratory capacity to perform all analyses in the desired timeframe,

- Intra-laboratory QC review of all generated data, independent of the data generators, and
- Adequate laboratory protocols for method performance documentation and sample security.

For non-routine analyses, the laboratory should have highly trained personnel and instrumentation not dedicated to production work, especially if new methods or untested modifications are requested.

Accreditation programs monitor the level of quality of laboratory performance within the scope of their charters. Many of these programs periodically provide performance evaluation samples that the laboratories must analyze within certain limits in order to maintain their status. Prior to laboratory selection, request that laboratories provide information about their performance in accreditation programs. This information can be used for evaluation of laboratory quality, in the case of similar matrices and analytes. Laboratory adherence to standards of performance such as the Good Laboratory Practices Standards (*Annual Book of ASTM Standards*) also provides a measure of laboratory quality.

4.2.5 Writing the Analysis Request

Include the following items in the analysis request:

- A clear, complete description of the sample preparation, extraction, and analysis procedures including detailed performance specifications. For adaptation of routine methods, specify the routine method and explicitly state alterations with applicable references.
- Documented reporting requirements.
- Laboratory access to required authentic chemical standards.
- A mechanism for the laboratory to obtain EPA technical assistance in implementing method modifications or performing non-routine methods.

If the analysis request is for a non-routine method, reference the published material with a detailed specification of procedures and requirements prepared by the analytical chemist who has been working with the RPM and risk assessor. The specification must include the frequency, acceptance criteria, and corrective action requirements for each of the following:

- Instrument standardization, including tuning and initial and continuing calibration,

- QC check samples such as surrogate compound and internal standard recoveries,
- Method blank performance (permissible level of contamination),
- Spike sample recovery requirements,
- Duplicate analysis requirements, and
- Performance evaluation or QC sample results.

Allow time for the laboratory to review the analysis request and question any part of the description that seems unclear or unworkable according to its experience with the analytes or sample matrix. Preliminary data, such as precision and accuracy data on a subset of the analytes, can be requested to determine if the laboratory can implement the proposed method. Should the criteria not be met in the preliminary analyses, the analytical chemist should advise the laboratory on additional method modifications to produce the required data. In some cases, even qualitative data can be used to note the presence of chemicals of potential concern.

In all cases, require the laboratory performing the analyses to contact the project chemist at the first sign of a problem that may affect data quality. The RPM and the site technical team can then judge the magnitude of the problem and determine appropriate corrective action.

4.3 BALANCING ISSUES FOR DECISION-MAKING

Resource issues. Resource limitations are a major reason for sampling design modification. The number of samples required to achieve desired performance measures may exceed resource availability. Modifying the sampling design and the efficiency of statistical estimators can reduce sample size and costs, and improve overall timeliness for the risk assessment. Analytical methods such as field analyses may also reduce cost. Systematic and geostatistical sampling designs can often achieve the required performance measures with fewer samples than classical random sampling (Gilbert 1987). Pilot sampling can be used to verify initial assumptions of the SAP, increase knowledge of contaminant distribution, and support SAP modifications to reduce the number of samples. Explain resource issues and record potential design modifications in documentation developed during planning.

Completing a number of Sampling Design Selection Worksheets (Exhibit 45) for different exposure areas,

media, and sampling design alternatives will enable the RPM and risk assessor to compare and evaluate sampling design options and consequences and select the appropriate sampling design for each medium and exposure pathway.

Computer programs are useful tools in developing and evaluating sampling strategies, especially in trading off costs against uncertainty, and identifying situations when additional samples will not significantly affect the useability of the data (i.e., the point of diminishing returns). Each automated system has specific data requirements and is based on specific site assumptions. The major systems that support environmental sampling decisions are listed, contacts for information given, and brief descriptions provided in Exhibit 51.

Documenting design decisions. It is important to document the primary issues considered in balancing tradeoffs to accommodate resource concerns and their impact on data useability. Several compromises among options are discussed in this section. Features of analytical options available for organic and inorganic analytes are summarized in Exhibits 56 through 59. Fully document all final sampling and analytical design decisions, including the rationale for each decision. During the course of the RI, continue to document pertinent issues that arise and any plan modifications which are implemented.

The goal of balancing issues in the selection of analytical methods is to obtain the best analytical performance without sacrificing risk assessment requirements. The selection of analytical methods often involves tradeoffs among the required detection limit, number of analytes involved, precision and accuracy, turnaround time, and cost. Some choices may conflict with others.

Cost should be considered only after the most appropriate methods have been determined. Methods requiring specialized instrumentation, such as high resolution mass spectrometry, will be more expensive. Methods

for use on matrices such as soil, can be more expensive than similar methods for a simpler matrix such as water. Less expensive methods often have higher detection limits and less specific confirmation of identification. However, the turnaround times are often quicker and a larger number of samples can be analyzed. This often significantly increases sampling precision and reduces the probability of missing hot spots. Less expensive methods are often chosen if the site has already been characterized by broad spectrum analyses. In evaluating routine methods, consider whether analysis of more samples through use of less expensive methods can provide a similar level of data quality to that achieved through the use of more expensive methods on fewer samples. By remaining aware of the effect of individual issues on the data quality, the RPM can determine the optimum choices.

☛ *Field analysis can be used to decrease cost and turnaround time, providing data from a broad spectrum analysis are available.*

In addition to turnaround time for analysis, time must also be scheduled for data review. This will not hinder the availability of laboratory and field data for preliminary use if a tiered data review sequence is incorporated.

When using the tiered approach, consider the use of split samples (i.e., sending sample splits for analysis by field and fixed laboratories). Quantitative comparison can then be made between the precision and accuracy of the field analyses and those of the fixed laboratory. Confirmation of identification by both field and fixed laboratories also increases data confidence and useability. It is recommended that field methods should be used with at least a 10% rate of confirmation or comparison by fixed laboratory analyses.

EXHIBIT 56. COMPARISON OF ANALYTICAL OPTIONS FOR ORGANIC ANALYTES IN WATER

Method	MDL	Quantitative Confidence	Timeliness	Precision & Accuracy	Comparability
FIELD SCREEN/FIELD ANALYSIS (Assumes preparation step)					
GC(PCB)	✓	✓	✓		✓
GC (Pesticides)	✓		✓		✓
GC (VOA)	✓		✓		✓
G C (Soil Gas)	✓		✓		✓
GC (BNA)	✓		✓		✓
PHOTO VAC Detector			✓		
FIXED LABORATORY					
CLP RAS					
VOA		✓			✓
BNA		✓			✓
Pesticides					✓
Dioxin		✓		✓	✓
CLP LOW CONC					
GC	✓			✓	✓
VOA	✓	✓		✓	✓
BNA	✓	✓		✓	✓
500 SERIES					
GC	✓				✓
VOA	✓	✓			✓
BNA	✓	✓			✓
600 SERIES					
GC	✓				✓
VOA	✓	✓			✓
BNA	✓	✓			✓
SW846					
GC	✓				✓
VOA		✓			✓
BNA		✓			✓
1600 SERIES					
GC	✓			✓	✓
VOA		✓		✓	✓
BNA		✓		✓	✓
Dioxin		✓		✓	✓
PCDDs, PCDFs		✓		✓	✓
Key: ✓ = Method strength					

EXHIBIT 57. COMPARISON OF ANALYTICAL OPTIONS FOR ORGANIC ANALYTES IN SOIL

Method	MDL	Quantitative Confidence	Timeliness	Precision & Accuracy	Comparability
FIXED LABORATORY					
CLP RAS					
VOA		√			√
BNA		√			√
Pesticides					√
Dioxin (2,3,7,8 TCDD)		√		√	√
SW846					
GC	√				√
VOA		√			√
BNA		√			√
1600 SERIES					
GC	√			√	√
VOA		√		√	√
BNA		√		√	√
Dioxin		√		√	√
FIELD SCREEN					
GC(PCB)	√	√	√		√
GC(Pesticides)			√		√
GC(VOA)	√		√		√
GC(Soil Gas)	√		√		√
GC(BNA)	√		√		√
PHOTO VAC Detector			√		
Key: √ = Method strength					

EXHIBIT 58. COMPARISON OF ANALYTICAL OPTIONS FOR INORGANIC ANALYTES IN WATER AND SOIL

Method	MDL	Quantitative Confidence	Timeliness	Precision & Accuracy ¹	Comparability ²
FIXED LABORATORY					
CLP RAS					
ICP		✓		✓	✓
GFAA	✓	✓		✓	✓
Flame AA					
200 Series					
GFAA	✓	✓		✓	✓
AA					
ICP-MS ³	✓	✓			✓
ICP-Hydride ³	✓				
FIELD SCREEN					
XRF			✓		
AA			✓		

Key: ✓ = Method strength

¹ CLP inorganic water assays are more accurate and precise than soil assays.

² ICP and GFAA are comparable at medium to high ppb levels. For As, Pb, Se, Tl and Sb at less than 20 ppb, GFAA is the method of choice.

³ ICP-MS and ICP-Hydride methods are relatively new; therefore, precision, accuracy, and comparability estimates based on large statistical sampling are not available.

**EXHIBIT 59. COMPARISON OF ANALYTICAL OPTIONS* FOR
ORGANIC AND INORGANIC ANALYTES IN AIR**


Method	MDL	Quantitative Confidence	Timeliness	Precision & Accuracy	Comparability
FIXED LABORATORY					
CLP VOA					
Cannister	2-5 ppb	√		√	
Tenax	2-30 ppb (for most)	√		√	
CLP BNA	0.00001- 0.001 ug/m3	√		√	
CLP Metals	3-10 ng/m3	√		√	
<p>Key: √ = Method strength</p> <p>* The methods described are new Statements of Work.</p>					

Chapter 5

Assessment of Environmental Data for Useability in Baseline Risk Assessments

This chapter provides guidance for the assessment and interpretation of environmental data for use in baseline human health risk assessments. Ecological risk assessments follow a similar logic but may differ in some details of sampling and analytical methodologies and minimum data requirements. The discussion of data assessment is presented as six steps that define the assessment process for each data useability criterion. Exhibit 60 lists the six criteria in the order that a risk assessor would evaluate them. It also gives references to the sections in this chapter where they are further discussed.

**EXHIBIT 60. DATA USEABILITY
ASSESSMENT OF CRITERIA**



21-902-060

The four basic decisions to be made from data collected in the RI are:

- What contamination is present and at what levels?
- Are site concentrations sufficiently different from background?
- Are all exposure pathways and exposure areas identified and examined?
- Are all exposure areas fully characterized?

The uncertainty associated with each data useability criterion affects the level of confidence associated with each of these decisions.

How to conduct the data assessment. The risk assessor or RPM examines the data, documentation, and reports for each assessment criterion (I - VI) to determine if performance is within the limits specified in the planning objectives. The data assessment process for each criterion should be conducted according to the step-by-step procedures discussed in this chapter. Minimum requirements are listed for each criterion. Potential effects of not meeting the minimum requirements are also discussed and corrective action options are presented. Exhibit 61 summarizes the major impact on assessment if the minimum requirements associated with each data useability criterion have not been met.

Acronyms

CLP	Contract Laboratory Program
CV	coefficient of variation
CRDL	contract required detection limit
CRQL	contract required quantitation limit
DQO	data quality objective
GC	gas chromatography
ICP	inductively coupled plasma
MDL	method detection limit
MS	mass spectrometry
QA	quality assurance
QC	quality control
RAGS	Risk Assessment Guidance for Superfund
RI	remedial investigation
RME	reasonable maximum exposure
RPD	relative percent difference
RPM	remedial project manager
SAP	sampling and analysis plan
SOP	standard operating procedure
SQL	sample quantitation limit

EXHIBIT 61. MINIMUM REQUIREMENTS, IMPACT IF NOT MET, AND CORRECTIVE ACTIONS FOR DATA USEABILITY CRITERIA

Data Useability Criterion	Minimum Requirement	Impact on Risk Assessment if Criterion Not Met	Corrective Action
5.1 Reports to Risk Assessor	<ul style="list-style-type: none"> Site description Sampling design with sample locations Analytical method and detection limit Results on per-sample basis, qualified for analytical limitations Sample quantitation limits and detection limits for non-detects Field conditions for media and environment Preliminary reports Meteorological data Field reports 	<ul style="list-style-type: none"> Unable to perform quantitative risk assessment 	<ul style="list-style-type: none"> Request missing information Perform qualitative risk assessment
5.2 Documentation	<ul style="list-style-type: none"> Sample results related to geographic location (chain-of-custody records, SOPs, field and analytical records) 	<ul style="list-style-type: none"> Unable to assess exposure pathways Unable to identify appropriate concentration for exposure areas 	<ul style="list-style-type: none"> Request locations identified Resampling
5.3 Data Sources	<ul style="list-style-type: none"> Analytical data results for one sample per medium per exposure pathway Broad spectrum analysis for one sample per medium per exposure pathway Field measurements data for media and environment 	<ul style="list-style-type: none"> Potential for false negatives or false positives Increased variability in exposure modeling 	<ul style="list-style-type: none"> Resampling or reanalysis for critical samples
5.4 Analytical Method and Detection Limit	<ul style="list-style-type: none"> Routine (federally documented) methods used to analyze chemicals of potential concern in critical samples 	<ul style="list-style-type: none"> Unquantified precision and accuracy False negatives 	<ul style="list-style-type: none"> Reanalysis Resampling or reanalysis for critical samples Documented statements of limitation for non-critical samples
5.5 Data Review	<ul style="list-style-type: none"> Defined level of data review for all data 	<ul style="list-style-type: none"> Potential for false negatives or false positives Increased variability and bias due to analytical process, calculation errors or transcription errors 	<ul style="list-style-type: none"> Perform data review
5.6 Data Quality Indicators	<ul style="list-style-type: none"> Sampling variability quantified for each analyte QC samples to identify and quantify precision and accuracy Sampling and analytical precision and accuracy quantified 	<ul style="list-style-type: none"> Unable to quantify confidence levels for uncertainty Potential for false negatives or false positives 	<ul style="list-style-type: none"> Resampling for critical samples Perform qualitative risk assessment Perform quantitative risk assessment for non-critical samples with documented discussion of potential limitations

The following activities should be performed for each assessment criterion:

- Identify or determine performance objectives and minimum data requirements.

Quantitative or qualitative performance objectives should be specified in the sampling and analysis plan for all components of the acquisition of environmental data (as discussed in Chapter 4). The first step in assessing each criterion is to assemble these performance objectives and note any changes. Performance objectives should also be compared with the minimum acceptable requirements for data useability presented in this chapter. These minimum requirements can be adopted as performance objectives if objectives were not specified. For example, the requirement that there must be a broad spectrum analysis for at least one sample in each medium for each exposure area would be a performance objective, if performance were not specified during planning.

- Determine actual performance compared to performance objectives.

The next step in the assessment of each criterion is to examine results to determine the performance that was achieved for each data useability criterion. This performance should then be compared with the objectives established during planning. Take particular note of performance for samples or analyses that are critical to the baseline risk assessment. All deviations from the objectives should be noted. In those cases where performance was better than that required in the objective, it may be useful for assessment of future activities to determine if this is due to unanticipated characteristics of the site or to superior performance in some stage of the data acquisition. Corrective action is the next step where performance does not meet performance objectives for data critical to the risk assessment.

- Determine and execute any corrective action required.

• *Focus corrective action on maximizing the useability of data from critical samples.*

Corrective action should be taken to improve data useability when performance fails to meet objectives for data critical to the risk assessment. Corrective action options are described in Exhibit 62. These options require communication among the risk assessor, the RPM, and the technical team. Sensitivity analysis may be performed by the risk assessor to estimate the effects

of not meeting performance requirements given the certainty of the risk assessment. Corrective actions may improve data quality and reduce uncertainty, and may eliminate the need to qualify or reject data.

EXHIBIT 62. CORRECTIVE ACTION OPTIONS WHEN DATA DO NOT MEET PERFORMANCE OBJECTIVES

- Retrieve missing information.
- Resolve technical or procedural problems by requesting additional explanation or clarification from the technical team.
- Request reanalysis of sample(s) from extract.
- Request construction and re-interpretation of analytical results from the laboratory or the project chemist.
- Request additional sample collection and analysis for site or background characterization.
- Model potential impact on risk assessment uncertainty using sensitivity analysis to determine range of effect.
- Adjust or impute data based on approved default options and imputation routines.
- Qualify or reject data for use in risk assessment.

21-002-062

Using a worksheet to organize the data assessment. The level of certainty associated with the data component of risk assessment depends on the amount of data that meet performance objectives. The risk assessor determines whether the data for each performance measure are satisfactory (data accepted), questionable (data qualified) or unsatisfactory (data rejected). The worksheet provided in this chapter may be used as a guide or organizational tool.

Use the Data Useability Worksheet, Exhibit 63, to document data assessment decisions. Record the decision as accepted, accepted with qualification, or rejected for use in the risk assessment for each data

EXHIBIT 63. DATA USEABILITY WORKSHEET

Data Useability Criterion		Decision	Comments
I	Reports to Risk Assessor		
II	Documentation A. Work Plan/SAP/QAPIP		
	B. SOPs		
	C. Field and Analytical Records		
III	Data Sources A. Analytical		
	B. Non-analytical		
IV	Analytical Methods		
V	Data Review		
* Decision: Accept, Qualified Accept, Reject			

EXHIBIT 63. DATA USEABILITY WORKSHEET (Cont'd)

Data Useability Criterion		Decision*		Comments
VI	Data Quality Indicators A. Completeness	Sampling		
		Analytical		
		Combined		
	B. Comparability	Sampling		
		Analytical		
		Combined		
	C. Representativeness	Sampling		
		Analytical		
		Combined		
	D. Precision	Sampling		
		Analytical		
		Combined		
	E. Accuracy	Sampling		
		Analytical		
		Combined		
* Decision: Accept, Qualified Accept, Reject				

21-002-063-01

useability criterion. Outline the justification for each decision in the comments section.

The remainder of this chapter explains how to assess data using the data useability criteria. Assessment of Criterion I involves identifying the data and documentation required for risk assessment (Section 5.1). Assessment of Criteria II through V examines available data and results in terms of the assessment of

data useability criteria for documentation (Section 5.2), data sources (Section 5.3), analytical method and detection limit (Section 5.4), and data review (Section 5.5). Criterion VI includes the assessment of sampling and analytical performance (Section 5.6) according to five data quality indicators: completeness, comparability, representativeness, precision, and accuracy.

5.1 ASSESSMENT OF CRITERION I: REPORTS TO RISK ASSESSOR

Minimum Requirements

- Site description.
- Sampling design with sample locations, related to site-specific data needs and data quality objectives.
- Analytical method and detection limit.
- Results on per-sample basis qualified for analytical limitations.
- Sample quantitation limits and detection limits for non-detects.
- Field conditions for media and environment.
- Preliminary reports.
- Meteorological data.
- Field reports.

Data and documentation supplied to the risk assessor must be evaluated for completeness and appropriateness, and to determine if any changes were made to the work plan or the sampling and analysis plan (SAP) during the course of the work. The SAP discusses the sampling and analytical design and contains the quality assurance project plan and data quality objectives (DQOs), if they have been developed. The risk assessor should receive preliminary and final data reports, as described in the following sections.

5.1.1 Preliminary Reports

Use preliminary data as a basis for identifying sampling or analysis deficiencies and taking corrective action.

Preliminary analytical data reports allow the risk assessor to begin assessment as soon as the sampling and analysis effort has begun. These initial reports have three functions:

- The risk assessor can begin to characterize the baseline risk assessment on the basis of actual data. Chemicals of interest will be identified and the variability in concentration can be estimated.
- Potential problems in sampling or analysis can be identified and the need for corrective action can be assessed. For example, additional samples may be required, or the method may need to be modified because of matrix interferences.

- RI schedules are more likely to be met if the risk assessment process can begin before the final data reports are produced.

The major advantage of preliminary review of data by the risk assessor is the potential for feedback and corrective action while the RI is still in process. This can improve the quality of data for risk assessment.

5.1.2 Final Report

Problems in data useability due to sampling usually can affect all chemicals involved in the risk assessment; problems due to analysis may only affect specific chemicals.

The minimum data reports and documentation needed to prepare the risk assessment are:

- A description of the site, including a detailed map showing the location of each sample, surrounding structures, terrain features, receptor populations, indications of air and water flow, and a description of the operative industrial process (if any),
- A description and rationale for the sampling design and sampling procedures,
- A description of the analytical methods used,
- Results for each analyte and each sample, qualified for analytical limitations, and a full description of all deviations from SOPs, SAPs, and QA plans,
- Sample quantitation limits (SQLs) and detection limits for undetected analytes, with an explanation of the detection limits reported and any qualifications,
- A narrative explanation of the level of data review used and the resulting data qualifiers. The narrative should indicate the direction of bias, based on the assessment of the results from QC samples (e.g., blanks and field and laboratory spikes), and
- A description of field conditions and physical parameter data as appropriate for the media involved in the exposure assessment.

It may not be possible to perform a quantitative baseline risk assessment if any of these materials are not available and cannot be obtained. The RPM or risk assessor should attempt to retrieve missing deliverables from the source.

Additional reports and data that are useful to the risk assessor, such as data results on Contract Laboratory Program (CLP) diskettes, are listed in Exhibit 19. Access

to this information can improve the efficiency and quality of the risk assessment. However, not having access does not necessarily require the data to be qualified or rejected. Minimum requirements for reports to the risk assessor are listed in Exhibit 61.

5.2 ASSESSMENT OF CRITERION II: DOCUMENTATION

Minimum Requirements

- Sample results related to geographic location (chain-of-custody records, SOPs, field and analytical records).

Three types of documentation must be assessed: chain-of-custody records, SOPs, and field and analytical records. Chain-of-custody records for risk assessment must document the sample locations and the date of sampling so that sample results can be related to geographic location and specific sample containers. If a sample result cannot be related to a sampling date and the point of sample collection, the results are unusable for quantitative risk assessment. Full scale chain-of-custody procedures (from sample collection through analysis) are required for enforcement or cost recovery.

SOPs describe and specify the procedures to be followed during sampling and analysis. They are QA procedures that increase the probability that a data collection design will be properly implemented. SOPs also increase consistency in performing tasks and, as a result, determine the level of systematic error and reduce the random error associated with sampling and analysis. Knowledge that SOPs were developed and followed increases confidence that the quality of data can be determined, and the level of certainty in risk assessment can be established. The existence of SOPs for each process or activity involved in data collection is not a minimum requirement, but SOPs can be useful if data problems occur, particularly in assessing the comparability of data sets.

Field and analytical records document the procedures followed and the conditions of the procedures. Field and analytical records, such as field logs and raw instrument output, may be useful to the risk assessor as back-up documentation, but they are not minimum requirements. QC data from blanks, spikes, duplicates, replicates, and standards should also be accessible, in either raw or summary formats, to support qualitative or quantitative assessments of the analytical results. Like SOPs, such records are critical to resolving problems in interpretation, but they may not directly affect the level

of certainty of the risk assessment. Minimum requirements for documentation are listed in Exhibit 61.

5.3 ASSESSMENT OF CRITERION III: DATA SOURCES

Minimum Requirements

- Analytical sample data results for each medium within an exposure area.
- Broad spectrum analysis for one sample per medium per exposure area.
- Field measurements data for media and environment.

Data source assessment involves the evaluation and use of historical and current analytical data. Historical analytical data should be evaluated according to data quality indicators and not source (e.g., analytical protocols may have changed significantly over time).

The minimum analytical data requirement for risk assessment is that results are produced for each medium within an exposure area using a broad spectrum analytical technique, such as GC-MS methods for organic analytes or ICP for inorganic analytes. The useability of data will almost always increase as more broad spectrum analyses are performed for each exposure area. The absence of a broad spectrum analysis from a fixed laboratory results in an increased probability of false negatives; all chemicals of potential concern at the site may not be identified. In the absence of a broad spectrum analysis, the best corrective action is to take additional samples. If additional samples cannot be obtained, the probability of false negatives and false positives should be considered high, and the level of certainty of the risk assessment is decreased.

The broad spectrum analysis, and any other analytical data, are subject to the basic documentation and data review requirements discussed in this chapter. The location of the sample data point must be known, as well as the method and SQL achieved for analytical results. Guidance for the assessment of analytical data to determine false positives and false negatives and the precision and accuracy of concentration results is provided in Section 5.6.1.

Field measurements of physical characteristics of the site, medium, or contamination source are a critical data source, whose omission can significantly affect the ability of the risk assessor to perform a quantitative assessment. Physical site information is also required to perform exposure fate and transport modeling. Examples

of such data are particle size, pH, clay content and porosity of soils, wind direction and speed, topography, and percent vegetation. RAGS, Part A, Exhibit 4-2, "Examples of Modeling Parameters for Which Information May Need to be Obtained During a Site Sampling Investigation," (EPA 1989a) provides a list of data elements according to medium modeling category. These measurements must be collected during sampling. The use of default options and routines to estimate missing values allows the use of the model but increases the uncertainty associated with the exposure assessments.

5.4 ASSESSMENT OF CRITERION IV: ANALYTICAL METHOD AND DETECTION LIMIT

Minimum Requirements

- Routine (federally documented) methods used to analyze chemicals of potential concern in critical samples.

The risk assessor compares SQLs or method detection limits (MDLs) with analyte-specific results to determine their consequence given the concentration of concern. Assessment of preliminary data reports provides an opportunity to review the detection limits early and resolve any problems. When a chemical of potential concern is reported as not detected, the result can only be used with confidence if the quantitation limits reported are lower than the corresponding concentration of concern. The minimum recommended requirement is that the MDL be no more than 20% of the concentration of concern, so that the SQL will also be below the concentration of concern. Chemicals identified above this ratio of detection limit to concentration of concern can be used with good confidence. For example, if the concentration of concern for arsenic in groundwater is 70 ug/L for an average daily consumption of 2 L of water by a 70 kg adult, the detection limit of a suitable method for examination of groundwater samples from such a site should be no greater than 14 ug/L. Minimum requirements for analytical methods and detection limits are listed in Exhibit 61.

If the concentration of concern is less than or equal to the detection limit, and the chemical of concern is not detected, do not use zero in the calculation of the concentration term. When the MDL reported for an analyte is near to the concentration of concern, the confidence in both identification and quantitation may be low. This is illustrated in Exhibit 64. Information concerning non-detects or detections at or near detection

limits should be qualified according to the degree of acceptable uncertainty, as described in Section 5.6.1.

The concentration of concern for ecological risk may be different than the concentration of concern for human health risk. In addition, aquatic life criteria should be examined to determine if they are based on ecological or human health risk.

5.5 ASSESSMENT OF CRITERION V: DATA REVIEW

Minimum Requirements

- Defined level of data review for all data.




Data review assesses the quality of analytical results and is performed by a professional with a knowledge of the analytical procedures. The requirement for risk assessment is that only data that have been reviewed according to a specified level or plan will be used in the quantitative risk assessment. Any analytical errors, or limitations in data that are identified by the review, must be noted in the risk assessment if the data are used. An explanation for qualifiers used must be included with the review report.

All data should receive some level of review. The risk assessor may receive data prior to the quantitative baseline risk assessment that were not reviewed. Data that have not been reviewed must be identified because the lack of review increases the uncertainty for the risk assessment. These data may lead to false positive or false negative assessments and quantitation errors. Unreviewed data may also contain transcription errors and calculation errors. Data may be used in the preliminary assessment before review, but must be reviewed at a predetermined level before use in the final risk assessment.

Depending upon data user requirements, the level and depth of the data review are variable. The level and depth of the data review may be determined during the planning process and must include an examination of laboratory and method performance for the samples and analytes involved. This examination includes:

- Evaluation of data completeness,
- Verification of instrument calibration,
- Measurement of laboratory precision using duplicates; measurement of laboratory accuracy using spikes,
- Examination of blanks for contamination,

EXHIBIT 64. RELATIVE IMPORTANCE OF DETECTION LIMIT AND CONCENTRATION OF CONCERN: DATA ASSESSMENT

Relative Position of Method Detection Limit (MDL) and Concentration of Concern (COC)	Consequence
 <p>Confidence Limits MDL COC Confidence Limits</p> <p>Concentration</p>	Non-Detects and Detects Useable
 <p>MDL COC</p> <p>Concentration</p>	Possibility of False Positives and False Negatives
 <p>COC MDL</p> <p>Concentration</p>	<p>Non-Detects Not Useable</p> <p>Detects Useable</p> <p>Possibility of False Negatives</p>

21-002-064

- Assessment of adherence to method specifications and QC limits, and
- Evaluation of method performance in the sample matrix.

Specific data review procedures are dependent upon the method and data user requirements. Section 5.6.1 details procedures for evaluating QC samples for laboratory and method performance. CLP data review procedures are performed according to criteria outlined in *National Functional Guidelines for Organic Data Review* (EPA 1991e) and *Laboratory Data Validation: Functional Guidelines for Evaluating Inorganics Analyses* (EPA 1988e). Minimum requirements for data review are listed in Exhibit 61.


5.6 ASSESSMENT OF CRITERION VI: DATA QUALITY INDICATORS

Minimum Requirements

- Sampling variability quantitated for each analyte.
- QC samples required to identify and quantitate precision and accuracy.
- Sampling and analytical precision and accuracy quantitated.

The assessment of data quality indicators presented in this chapter is significant to determine data useability.

EXHIBIT 65. CONSEQUENCES OF ALTERNATIVE SAMPLING STRATEGIES ON TOTAL ERROR ESTIMATE



☛ *Qualified data can usually be used for quantitative risk assessments.*

The assessment of data quality indicators for either sampling or analysis involves the evaluation of five indicators: completeness, comparability, representativeness, precision, and accuracy. Uncertainties in completeness, comparability, and representativeness increase the probability of false negatives and false positives when the data are used to test particular hypotheses as part of the site evaluation. This increase in uncertainty can affect the confidence of chemical identification. Variation in completeness, comparability, representativeness, precision, and accuracy affects the uncertainty of estimates of average concentration and reasonable maximum exposure (RME). Once the indicator is examined or a numerical value is determined, the results can be compared to the performance objectives established during RI planning. This comparison determines the useability of the data and any required corrective actions.

A summary of the minimum requirements for data quality indicators is presented in Exhibit 61, and the evaluation process is illustrated in Exhibit 65. Specific requirements for each indicator are presented in the following sections.

5.6.1 Assessment of Sampling and Analytical Data Quality Indicators

The major activity in determining the useability of data based on sampling is assessing the effectiveness of the sampling operations performed. Samples provided for analysis must answer the four basic decisions to be made with RI data in risk assessment (cited at the beginning of this chapter) that are translated into site-specific objectives based on scoping and planning decisions.

Independent data review evaluates laboratory results, not sampling. Determining the useability of analytical results begins with the review of QC samples and qualifiers to assess analytical performance of the laboratory and the method. It is more important to evaluate the effect on the data than to determine the source of the error. The data package is reviewed as a whole for some criteria; data are reviewed at the sample level for other criteria, such as holding time. Factors affecting the accuracy of identification and the precision and accuracy of quantitation of individual chemicals, such as calibration and recoveries, must be examined analyte-by-analyte. The qualifiers used in the review of CLP data are presented and their effect on data quality is discussed in this section. Exhibit 66 presents a

EXHIBIT 66. USE OF QUALITY CONTROL DATA FOR RISK ASSESSMENT

Quality Control Criterion	Effect on Identification When Criterion is not Met	Quantitative Bias	Use
Spikes (High Recovery)	--	High	Use data as upper limit.
Spikes (Low Recovery)	False Negative ¹	Low	Use data as lower limit.
Duplicates	None, unless analyte found in one duplicate and not the other. Then either false positive or false negative.	High or Low ²	Use data as estimate--poor precision.
Blanks	False Positive	High	Set confidence level 5x blank. Use data above confidence level. Use data below confidence level as estimate.
Calibration	--	High or Low ²	Use data as estimate unless problem is extreme.
Tune	False Negative	--	Reject data or examine raw data and use professional judgment.
Internal Standards (Reproducibility) ³	--	--	Use data as estimate--poor precision.
Internal Standards (High Recovery)	--	Low	Use data as lower limit.
Internal Standards (Low Recovery)	False Negative ¹	High	Use data as upper limit.

¹ False negative only likely if recovery is near zero.

² Effect on bias determined by examination of data for each individual analyte.

³ Includes surrogates and system monitoring compounds.

summary of the QC samples and the data use implications of qualified data. Corrective action options are shown in Exhibit 62.

Sample media can be more complex than expected in environmental analysis. For example, sludge or oily wastes may contain interfering chemicals whose presence cannot be predicted in precision and accuracy measurements. The risk assessor must examine the reported precision [relative percent difference (RPD)] and accuracy [percent recovery (%R)] data to determine useability. Ranges used for rejection and qualification of CLP data have been determined based on the analysis of target compounds in environmental media. These ranges, documented in the Functional Guidelines (EPA 1991e, EPA 1988e) can be used in the absence of specifications in the planning documents.

Completeness. Completeness for sampling is calculated by the following formula:

$$\text{Percent Completeness} = \frac{(\text{Number of Acceptable Data Points}) \times 100}{\text{Total Number of Samples Collected}}$$

This measure of completeness is useful for data collection and analysis management but misses the key risk assessment issue, which is the total number of data points available and acceptable for each chemical of potential concern. Incompleteness should be assessed to determine if an acceptable level of data useability can still be obtained or whether the level of completeness must be increased, either by further sampling or by other corrective action. Any decrease in the number of samples from that specified in the sampling design will affect the final results. In this case, the option of obtaining more samples should be reviewed.

Minimum Requirements for Completeness	Impact When Minimum Requirements Are Not Met	Corrective Action
<ul style="list-style-type: none"> Percentage of sample completeness determined during planning to meet specified performance measures. 100% of all data for analytes in critical samples (at least one sample per medium per exposure area). All data from critical samples considered crucial. Background samples and broad spectrum analyses are usually critical. 	<ul style="list-style-type: none"> Higher probability of false negatives. Reduction in confidence level and power. A reduction in the number of samples reduces site coverage and may affect representativeness. Data for critical samples have significantly more impact than incomplete data for non-critical samples. Useability of data is decreased for critical samples. Useability of data is potentially decreased for non-critical samples. Reduced ability to differentiate site levels from background. Impact of incompleteness generally decreases as the number of samples increases. 	<ul style="list-style-type: none"> Resampling or reanalysis to fill data gaps. Additional analysis of samples already at laboratory. Determine whether the missing data are crucial to the risk assessment (i.e., data from critical samples).

21-002-081

Typical causes for sample attrition include site conditions preventing sample collection (e.g., a well runs dry), sample breakage, and invalid or unuseable analytical results. Incompleteness can increase the uncertainty involved in risk assessments by reducing the available number of samples on which identification and estimates of concentration of chemicals at the site are based. The reduction in the number of samples from the original design further affects representativeness by reducing site coverage and increases the variability in concentration estimates. Only the collection of additional samples will resolve the problem, unless the samples involved were duplicates or splits. In this case, or if the cause was laboratory performance, the extracts may be considered for reanalysis.

Completeness for analytical data is calculated by the following formula:

$$\text{Percent Completeness} = \frac{(\text{Number of Acceptable Samples}) \times 100}{\text{Total Number of Samples Analyzed}}$$

The completeness for analytical data required for risk assessment is defined as the number of chemical-specific data results for an exposure area in an operable unit that are determined acceptable after data review.

An analysis is considered complete if all data generated are determined to be acceptable measurements as defined in the SAP. Results for each analyte should be present for each sample. In addition, data from QC samples necessary to determine precision and accuracy should be present. QC samples and the effects of problems associated with these samples are discussed later in this section.

Comparability. Comparability is not compromised provided that the sampling design is unbiased, and the sampling design or analytical methods have not changed over time. If any of these factors change, the risk assessor may experience difficulties in combining data sets to estimate the RME. The determination of the RME is based on the principal of estimating risk over time for the exposure area. The ideal situation occurs when samples can be added within the basic design, decreasing the level of uncertainty.

➤ *Anticipate the need to combine data from different sampling events and/or different analytical methods.*

Comparability is a very important qualitative data indicator for analytical assessment and is a critical

Minimum Requirements for Comparability	Impact When Minimum Requirements Are Not Met	Corrective Action
<ul style="list-style-type: none"> Unbiased sampling design or documented reasons for selecting another sampling design. The analytical methods used must have common analytical parameters. Same units of measure used in reporting. Similar detection limits. Equivalent sample preparation techniques. 	<ul style="list-style-type: none"> Non-additivity of sample results. Reduced confidence, power, and ability to detect differences, given the number of samples available. Increased overall error. 	<p>For Sampling:</p> <ul style="list-style-type: none"> Statistical analysis of effects of bias. <p>For Analytical Data:</p> <ul style="list-style-type: none"> Preferentially use those data that provide the most definitive identification and quantitation of the chemicals of potential concern. For organic chemical identification, GC-MS data are preferred over GC data generated with other detectors. For quantitation, examine the precision and accuracy data along with the reported detection limits. Reanalysis using comparable methods.

21-002-062

parameter when considering the combination of data sets from different analyses for the same chemicals of potential concern. The assessment of data quality indicators determines if analytical results being reported are equivalent to data obtained from similar analyses. Only comparable data sets can readily be combined for the purpose of generating a single risk assessment calculation.

The use of routine methods simplifies the determination of comparability because all laboratories use the same standardized procedures and reporting parameters. In other cases, the risk assessor may have to consult with an analytical chemist to evaluate whether different methods are sufficiently comparable to combine data sets. The RPM should request complete descriptions of non-routine methods. A preliminary assessment can be made by comparing the analytes, useful range, and detection limit of the methods. If different units of measure have been reported, all measurements must be converted to a common set of units before comparison.

Representativeness. Representativeness of data is critical to risk assessments. The results of the risk assessment will be biased to the degree that the data do not reflect the chemicals and concentrations present in the exposure area or unit of interest. Non-representative chemical identification may result in false negatives. Non-representative estimates of concentration levels may be higher or lower than the true concentration. Non-representative sampling can usually only be

resolved by additional sampling, unless the potential limitations of the risk assessment are acceptable.

It is important to determine whether any changes have occurred in the actual sample collection that convert an originally unbiased sampling plan into a biased sampling episode. Bias in unbiased designs is difficult to assess because no measure of the true value is known. Bias is assumed in non-statistical designs.

Representativeness is primarily a planning concern. The solution is in the design of a sampling plan that is representative. Once the design is implemented, only the sampling variability is evaluated during the assessment process, unless contamination occurs in the QC samples or blanks, or problems exist during sample preparation that affect sample results. Incompleteness of data potentially decreases representativeness and increases the potential for false negatives and the bias in estimations of concentration.

Representativeness is determined by examining the sampling plan, as discussed in Section 3.2. In determining the representativeness of the data, the evaluator examines the degree to which the data meet the performance standards of the method and to which the analysis represents the sample submitted to the laboratory. Analytical data quality affects representativeness since data of low quality may be rejected for use in risk assessments. Holding time, sample preservation, extraction procedures, and results

Minimum Requirements for Representativeness	Impact When Minimum Requirements Are Not Met	Corrective Action
<ul style="list-style-type: none"> • Sample data representative of exposure area and operable units. • Documented sample preparation procedures. Filtering, compositing, and sample preservation may affect representativeness. • Documented analytical data as specified in the SAP. 	<ul style="list-style-type: none"> • Bias high or low in estimate of RME. • Increased likelihood of false negatives. • Inaccurate identification or estimate of concentration that leads to inaccurate calculation of risk. • Remaining data may no longer sufficiently represent the site if a large portion of the data are rejected, or if all data from analyses of samples at a specific location are rejected. 	<ul style="list-style-type: none"> • Additional sampling. • Examination of effects of sample preparation procedures. • For critical samples, reanalyses of samples or resampling of the affected site areas. For non-critical samples, reanalyses or resampling should be decided by the RPM in consultation with the technical team. • If the resampling or reanalyses cannot be performed, document in the site assessment report what areas of the site are not represented due to poor quality of analytical data.

from analyses of blanks affect the representativeness of analytical data (see Appendix V).

Precision. The two basic activities performed in the assessment of precision are estimating sampling variability from the observed spatial variation and estimating the measurement error attributable to the data collection process. Assumptions concerning the sampling design and data distributions must be examined prior to interpreting the results. This examination will provide the basis for selecting calculation formulas and knowing when statistical consultation is required.

The type of sampling design selected is critical to the estimation of sampling variability as discussed in Sections 3.2 and 4.1. If the sampling design is judgmental, the nature of the sampling error cannot be determined and estimates of the average concentrations of analytes may not be representative of the site.

- Determine the distribution of the data before applying statistical measures.

The nature of the observed chemical data distribution affects estimation procedures. The estimation of variability and confidence intervals will become complex if the distribution cannot be assumed normal or to approximate normal when transformed to log normal. Estimates of the 95% upper confidence limit of the average concentration for the RME should be based on an analysis of the frequency distribution of the data whenever the database is sufficient to support such analysis. Statistical tests may be used to compare the distribution of the observed data with the normal or log normal distribution (Gilbert 1987). Graphs of data without statistical test results may also be acceptable for some data sets. Statistical computer software can assist in the analyses of data distribution.

Sampling variability. Exhibit 67 summarizes the assessment procedures for the evaluation of variability from different sampling procedures. The estimation of confidence levels, power, and minimum detectable relative differences requires assumptions about the coefficients of variation from sampling variability for

Minimum Requirements for Precision	Impact When Minimum Requirements Are Not Met	Corrective Action
<ul style="list-style-type: none"> • Confidence level of 80% (or as specified in DQOs). • Power of 90% (or as specified in DQOs). • Minimum detectable relative differences specified in SAP and modified after analysis of background samples if necessary. • One set of field duplicates or more as specified in the SAP. • Analytical duplicates and splits as specified in the SAP. • Measurement error specified. 	<ul style="list-style-type: none"> • Errors in decisions to act or not act based on analytical data. • Unacceptable level of uncertainty. • Increased variability of quantitative results. • False negatives for measurements near the detection limits. 	<p>For Sampling:</p> <ul style="list-style-type: none"> • Add samples based on information from available data that are known to be representative. • Adjust performance objectives. <p>For Analysis:</p> <ul style="list-style-type: none"> • Analysis of new duplicate samples. • Review laboratory protocols to ensure comparability. • Use precision measurements to determine confidence limits for the effects on the data. • The risk assessor can use the maximum sample results to set an upper bound on the uncertainty in the risk assessment if there is too much variability in the analyses.

EXHIBIT 67. STEPS TO ASSESS SAMPLING PERFORMANCE

1. Confirm statistical assumptions.
2. Summarize analyte detection data by strata: media within site or site subgroups and strata within media.
3. Transform analyte concentration data so distribution is approximately normal.
4. Calculate the coefficient of variation for each analyte detected.
5. Using Exhibit 47 "Relationships Between Measures of Statistical Performance and Number of Samples Required," look up the range of power, confidence level and minimal detectable relative differences for the calculated coefficient of variation.
6. Compare the statistical performance measures required to those achievable given the coefficient of variation and sample size.
7. If the performance objectives are achieved, go to Step 9.

If the required statistical performance levels are not met, then additional samples must be taken or one or more of the performance parameters must be changed.

If samples are to be added, Exhibit 47 and the calculation formulas in Appendix IV can be used to determine the number needed.
8. If the performance parameters are to be changed, the parameter to be changed should be the one which will increase the probability of taking unnecessary action as opposed to unnecessary risk.
9. Examine the results of the QC samples. Sample results must be considered to be qualitative if no results are available for QC samples.
10. If the QC sample results indicate possible bias through contamination, take appropriate corrective action.

21-002-067

each chemical of potential concern. The RPM or risk assessor should discuss the implications of these assumptions with a statistician to determine their potential impacts on data useability.

• *Determine the statistical measures of performance most applicable to site conditions before assessing data useability.*

Once the statistical assumptions and observed analyte variability are known, selected statistical performance measures can be assessed to determine the data quality achieved. Additional samples may be needed, or modified DQOs required, as a result of evaluating

sampling variability. Three issues are involved in the assessment of required statistical performance:

- Level of certainty or confidence,
- Power, and
- Minimum detectable relative difference.

The required level for each of these performance measures should be included in the SAP as DQOs. The user's data quality requirements defined by these statistical measures determine the number of samples that are taken during data collection. Recommended minimum statistical performance parameters for

discriminating contaminant concentrations from background levels in risk assessment are provided in Exhibit 68.

EXHIBIT 68. RECOMMENDED MINIMUM STATISTICAL PERFORMANCE PARAMETERS FOR RISK ASSESSMENT

Null Hypothesis: On-site Contaminant Concentrations are not Higher than the Background
<ul style="list-style-type: none">Confidence level: ¹ 80% minimum, reject null when true (take unnecessary action).Power: ² 90% minimum, accept null when false (fail to take action when action is required).Minimum detectable relative difference: 10% - 20%, usually depends on concentration of concern.
1 (1-false positive estimate) or (1 - α).
2 (1-false negative estimate) or (1 - β).
Source: EPA 1989f.

21-002-068

First, summarize the sample results at the analyte level by stratum and strata within media to determine whether the performance objectives have been met. Sampling error is not relevant if a particular combination of stratum and analyte yields only a single data point. In that case, assessment proceeds to that of analytical error for that stratum and analyte combination.

The distribution for stratum and analyte combinations with multiple data points should usually be examined for normality and transformed to log normal. The coefficient of variation is calculated for each stratum and analyte combination. If the distribution resulting from the transformation is not normal, a new distributional model will need to be identified and validated in consultation with a statistician. Non-parametric procedures which require no distributional assumptions may also be used.

Conversely, the statistical performance achieved can be determined, given the coefficient of variation. This performance should be compared to the requirements stated in planning. If the performance objectives are achieved, the risk assessor can proceed to the assessment of measurement error.

If the required statistical performance objectives are not met, additional samples must be taken, or one (or more) of the performance parameters must be changed. If samples are added, the tables and formulas provided in Chapter 4 and Appendix IV can be used to calculate the number of samples required. If a performance parameter is changed, it should be the one that will increase the probability of taking unnecessary action as opposed to an increased probability of unnecessary risk. The uncertainty level will then be reduced first, the minimum detectable relative difference will be increased second, and the level of power will be reduced last. Minimum recommended levels for performance parameters in risk assessment in the absence of site-specific DQOs are 80% confidence levels, 90% power, and 10-20% minimum detectable relative differences (EPA 1989f). Exhibit 68 summarizes the recommended DQOs for statistical performance parameters.

Measurement error. Measurement error is estimated using the results of field duplicate samples. Field duplicates determine total within-batch measurement error, including analytical error if the samples are also analyzed as laboratory duplicates. The estimate is of the difference between analytical values reported for duplicates. This type of variation has four basic sources: sample collection procedures, sample handling and storage procedures, analytical procedures, and data processing procedures.

The formula for computing the relative percent difference between duplicates is:

$$RPD = \frac{|R_1 - R_2|}{(R_1 + R_2)/2} \times 100$$

where R_1 and R_2 are the results from the first and second duplicate samples, respectively. Precision is a measure of the repeatability of a single measurement and is evaluated from the results of duplicate samples and splits.

Low precision can be caused by poor instrument performance, inconsistent application of method protocols, or by a difficult, heterogeneous sample matrix. The last effect can be distinguished from the others by evaluation of laboratory QC data.

If split samples have been analyzed by different methods or different laboratories, then data users have a measure of the quality of individual techniques. Splits are particularly effective when one laboratory is a reference laboratory. If both sets of data exhibit the same problems, then laboratory performance can usually be ruled out as a source of error. Splits are also useful when using non-routine methods or comparing results from different analytical methods.

Accuracy. Accuracy is a measure of overestimation or underestimation of reported concentrations and is evaluated from the results of spiked samples. The procedure for determining accuracy will vary according to differences in the number of measurements and the precision of the estimates. Data that are not reported with confidence limits cannot be assigned weights based on precision and should not be combined for use (Taylor 1987).

Spiked samples are particularly useful in the analysis of complex sample types because they help the reviewer determine the extent of bias on the sample measurement. A set of standards at known concentrations is mixed into a portion of the sample or into distilled water prior to sample preparation and analysis. The analytical results are compared to the amount spiked to determine the level of recovery. It is important to note that unless every sample is spiked, spike recoveries indicate only a trend rather than a specific quantitative measure.

Accuracy is controlled primarily by the analytical process and is reported as bias. The absolute bias of a sampling design cannot be determined unambiguously because the true value of the chemicals of concern in the exposure area can never be known. However, statistically based sampling designs described in Chapter 4 are structured to produce unbiased results.

Bias can be estimated using field spikes on field evaluation or audit samples to assess the accuracy and

comparability of results. These estimates will reflect the effects of sample collection, handling, holding time, and the analytical process on the result for the sample collected.

Bias is estimated for the measurement process by computing the percent recovery (%R) for the spiked or reference compound as follows:

$$\%R = \frac{(\text{Measured Amount} - \text{Amount in Unspiked Sample}) \times 100}{\text{Amount Spiked}}$$

Because of the inherent problems associated with the spiking procedure and the interpretation of recovery, spikes are considered minimum requirements only if specified in the SAP. Field matrix spikes are currently not recommended for use in soils (EPA 1989f).

Field blanks are evaluated to estimate the potential bias caused by contamination from sample collection, preparation, shipping and/or storage. Results for the analysis of field blanks indicate whether contamination resulted in bias, but they are not estimates of accuracy. Bias pertaining to analytical recoveries is computed as follows:

$$\text{Percent Bias} = \frac{(\text{Measured Amount} - \text{Amount in Unspiked Sample}) \times 100}{\text{Amount Spiked}}$$

Minimum Requirements for Accuracy	Impact When Minimum Requirements Are Not Met	Corrective Action
<ul style="list-style-type: none"> Field spikes to assess accuracy of non-detects and positive sample results if specified in the SAP. Analytical spikes as specified in the SAP. Use analytical methods (routine methods whenever possible) that specify expected or required recovery ranges using spikes or other QC measures. No chemicals of potential concern detected in the blanks. 	<ul style="list-style-type: none"> Increased potential for false negatives. If spike recovery is low, it is probable that the method or analysis is biased low for that analyte and values of all related samples may underestimate the actual concentration. Increased potential for false positives. If spike recovery exceeds 100%, interferences may be present, and it is probable that the method or analysis is biased high. Analytical results overestimate the true concentration of the spiked analyte. 	<ul style="list-style-type: none"> Consider resampling at affected locations. No correction factor is applied to CLP data on the basis of the percent recovery in calculating the analyte concentration. If recoveries are extremely low or extremely high, the risk assessor should consult with an analytical chemist to identify a more appropriate method for reanalysis of the samples.

Blanks are of primary concern for the analysis of bias involved in sampling because of the difficulty in performing field spikes and the availability of appropriate reference standards and matrix for evaluation samples.

Results from blanks can be used to estimate the extent of high bias in the event of contamination. The following procedures should be implemented to prevent the assignment of false positive values due to blank contamination:

- If the field blanks are contaminated and the laboratory blanks are not, the RPM or risk assessor can conclude that contamination occurred prior to receipt of the samples by the laboratory. If the contamination is significant (i.e., it will interfere with the determination of risk), consider resampling at affected locations.
- If it is not possible to resample, the RPM or risk assessor must assess the effect of the contamination on the potential for false positives. Often, this determination can be made by examining data from samples located nearby. If all samples and blanks show the same level of a particular chemical, the presence of the chemical in the samples is most likely due to contamination.
- If the laboratory blanks are contaminated, the laboratory should be required to rerun the associated analyses. This is especially important in the case of critical analytes or samples. Before reanalyses, the laboratory must demonstrate freedom from contamination by providing results of a clean laboratory blank. Note: If laboratory blanks are contaminated, field blanks will generally also be contaminated.
- If reanalysis is not possible, then the sample data must be qualified. The Functional Guidelines provide examples of blank qualification. Chemicals detected in the associated samples below the action level defined in the Functional Guidelines are considered undetected.

Data qualifiers. All data generated by the routine analytical services of the CLP are reviewed and qualified by Regional representatives according to the guidelines found in the Functional Guidelines as modified to fit the requirements of the individual Regions.

➤ *Use data qualified as U or J for risk assessment purposes.*

Analytes qualified with a U are considered "not detected." If precision and accuracy are acceptable (as determined by the QC samples), data are entered in the data summary tables in the data validation report as the

SQL or corrected quantitation limit (MDL corrected for dilution and percent moisture), and qualified with a U. Note that the same chemical can be reported undetected in a series of samples at different concentrations because of sample differences.

Data qualified with an R are rejected because performance requirements in the sample or in associated QC analyses were not met. For example, if a mass spectrometer "tune" is not within specifications, neither the identification nor quantitation of chemicals can be accepted with confidence. Extremely low recoveries of a chemical in a spiked sample might also warrant an R designation for that chemical in associated samples because of the risk of false negatives (see Appendix VI).

Data qualified with a J present a more complex issue. J-qualified data are considered "estimated" because quantitation in the sample or in associated QC samples did not meet specifications. The justification for qualifying the data should be explained in the validation report. Draft revisions of the Functional Guidelines propose that the justification be included on a qualifier summary table submitted with the validation report.

Data can be biased high or low when qualified as estimated. The bias can often be determined by examining the results of the QC samples. For example, if interfering levels of aluminum are found in inorganic analysis of the interference check sample, the sample results are probably biased high because the signal overlap is added to the signal being reported. When volatile organic compounds are qualified J for holding time violations, the results are usually biased low because some of the volatile compounds may have volatilized during storage.

Data associated with contaminated blanks are not considered estimated and are not flagged J. The presence of the blank contaminant chemical in the analytical samples is questionable at levels up to 5 to 10 times those found in the blank, depending on the nature of the analyte. An action level is determined for each chemical based on the quantity found in the blank. Data above the action level are accepted without qualification and data between the contract required quantitation limit (CRQL) and the action level are qualified U (undetected).

Estimated organics and inorganics data that are below the CRQL or contract required detection limit (CRDL) are qualified as UJ. This qualifier signifies that the quantitation limit is estimated because the QC results did not meet criteria specified in the SAP.

Other qualifiers may be added to the analytical data by the laboratory. A set of qualifiers (or flags) has been defined by the CLP for use by the laboratories to denote

problems with the analytical data. These qualifiers and their potential use in risk assessment are discussed in RAGS (EPA 1989a).

5.6.2 Combining the Assessment of Sampling and Analysis

Once the quality of the sampling and analysis effort has been assessed using the five data quality indicators, combine the results to determine the overall assessment of a particular indicator across sampling and analysis. Combining the assessment for completeness, comparability, and representativeness is discussed in this section as a qualitative procedure. Statistical models are available for combining data sets with different variability and bias. The risk assessor should consult a chemist or statistician if the magnitude of the sampling and analysis effort warrants the use of a formal statistical treatment of comparability.

The basic model for estimating total variability across sampling and analysis components is presented in Exhibit 69. An example of a non-statistical approach to combining the assessment results is given in Exhibit 70. Using this approach, each data quality indicator is

assessed to determine whether a problem exists in either sampling or analysis. This assessment leads to different combinations of problem determination. For example, completeness may have been a problem in sampling [YES] but not a problem in analysis [NO]; the combination is [YES/NO].

Basic guidance is given on the combinations of sampling and analysis once assessment patterns based on the determination of a problem have been established. This guidance is qualitative in nature and is presented to assist in organizing the data assessment problem for the application of professional judgment. If the assessment pattern is [NO/NO], the issue of combining results is not a problem. Conversely, if the pattern is [YES/YES], the issue of combining results is an issue of the effects of the combined magnitudes. Instances of combined sampling and analysis problems for a single indicator will have significant effects on the risk assessment uncertainty. The most complicated assessment pattern to interpret is encountered when a problem occurs in one area but not in another (e.g., in sampling but not in analysis). This situation is briefly discussed for each indicator in the following sections.

EXHIBIT 69. BASIC MODEL FOR ESTIMATING TOTAL VARIABILITY ACROSS SAMPLING AND ANALYSIS COMPONENTS

$$\sigma_t^2 = \sigma_m^2 + \sigma_p^2$$

where σ_t = total variability
 σ_m = measurement variability
 σ_p = population variability

$$\sigma_m^2 = \sigma_s^2 + \sigma_h^2 + \sigma_{ss}^2 + \sigma_a^2 + \sigma_b^2$$

where σ_s = sampling variability (standard deviation)
 σ_h = handling, transportation and storage variability
 σ_{ss} = preparation variability (subsampling variability)
 σ_a = laboratory analytical variability
 σ_b = between batch variability

NOTE: It is assumed that the data are normally distributed or that a normalizing data transformation has been performed.

Source: EPA 1990c.

**EXHIBIT 70. COMBINING DATA QUALITY INDICATORS FROM
SAMPLING AND ANALYSIS INTO A SINGLE ASSESSMENT
OF UNCERTAINTY**

Data Quality Indicators	Assessment of Problems		Combined Sampling and Analytical Determination *
	Sampling	Analytical	
Completeness	<div>YES</div> <div>NO</div>	<div>YES</div> <div>NO</div>	YES/YES YES/NO NO/YES
Comparability	<div>YES</div> <div>NO</div>	<div>YES</div> <div>NO</div>	YES/YES YES/NO NO/YES
Representativeness	<div>YES</div> <div>NO</div>	<div>YES</div> <div>NO</div>	YES/YES YES/NO NO/YES
Precision	<div>YES</div> <div>NO</div>	<div>YES</div> <div>NO</div>	YES/YES YES/NO NO/YES
Accuracy	<div>YES</div> <div>NO</div>	<div>YES</div> <div>NO</div>	YES/YES YES/NO NO/YES

* The combination [NO/NO] indicates that the data quality indicator will not affect the level of uncertainty in data useability.

Completeness. A sample is considered incomplete for all analytes. Analytical incompleteness is usually related to particular analytes. In this instance [YES/YES], the effect on the risk assessment will vary according to chemical. For some chemicals, the data points will be lost in both sampling and analysis.

The effects of a loss in the number of sample points for a particular chemical can be substantial. For example, if collection of 10 samples was planned and one sample could not be collected because of site access problems, one was broken in transport, and the laboratory experienced analysis problems with three samples for the chemical of potential concern causing the data to be rejected, then only five data points remain.

If the assessment pattern is [YES/NO], the effects are distributed across all chemicals involved in the risk assessment. If the pattern is [NO/YES], the effects are localized to the particular chemical affected.

Comparability. Comparability problems in sampling are primarily due to different sampling designs and time periods. Seasonal variations are treated like spatial variations because the risk assessment is calculated as risk over time. Data can be averaged and considered as a single data set. For analytical data, comparability problems are related primarily to the use of different methods and laboratories. A pattern of [YES/YES] will indicate that the risk assessor will have considerable difficulty in combining the various data sets into a single assessment of risk. In situations of [YES/NO] or [NO/YES], the problem of sampling comparability is more difficult to resolve. Models exist for determining comparability between methods and integrating results across laboratories. These models involve the general statistical approach to confirming data sets with different but known variability and bias (Taylor 1987).

Representativeness. Representativeness in sampling is critical to the risk assessment. Non-representativeness affects both false negatives (chemicals not identified) and estimates of concentration and, therefore, affects estimates of RME. Analytical representativeness involves the question of whether the analytical results represent the sample collected. For example, holding times and sample preservation can cause the analytical results not to be representative of the sample collected. These questions should be treated separately in the discussion of effects.

Precision. The contribution to imprecision from sampling variability often exceeds that from analytical variability in the measurement process. If precision is a problem in both sampling and analysis, the risk assessor should focus on the impact of sampling variability on the estimate of RME. Analytical variability will be minimal in comparison to the effects of sampling variability unless the sampling variability is untypically low and the analytical variability is untypically high.

Accuracy. The assessment of accuracy in sampling is focused primarily on recoveries from spiked or performance evaluation samples. Analytical performance and potential blank contamination are reflected in analytical spike recoveries. If the pattern is [YES/YES] for accuracy, this may require assessment of calibration, or of potential blank contaminants, and integration of their possible effects by comparison of results from laboratory and field QC samples.

If the accuracy pattern is [NO/YES], then the issue is analytical performance. Low variability in sampling as measured by low coefficients of variation for chemicals of potential concern should increase the risk assessor's concern over an analytical accuracy problem.

High sampling variability (CV>25%) will greatly reduce the effects of analytical bias on the level of certainty of the risk assessment.

Chapter 6

Application of Data to Risk Assessments

This chapter provides guidance for integrating the assessment of data useability to determine the overall level of uncertainty of risk assessment. This guidance builds on each of the previous chapters.

- Chapter 2 explained the risk assessment process and the roles and responsibilities of key participants. Exhibit 5 defined a continuum of level of certainty in the baseline risk assessment result based on the ability of the risk assessor to quantitate or qualify the level of uncertainty associated with the analytical data.
- Chapter 3 defined six data useability criteria and examined preliminary issues that must be considered while planning sampling and analysis activities to increase the certainty of the analytical data collected for the risk assessment.
- Chapter 4 presented strategies for planning sampling and analysis activities based on the six data useability criteria.
- Chapter 5 described how to use each data useability criterion to determine the effect of sampling and analysis issues on data quality and on the useability of data in baseline risk assessment.

The Data Useability Worksheet (Exhibit 63) assists the risk assessor in summarizing data quality across the various assessment phases. This worksheet is the basis for this chapter's discussion of the impact of analytical data quality on the level of certainty of the risk assessment.

6.1 ASSESSMENT OF THE LEVEL OF CERTAINTY ASSOCIATED WITH THE ANALYTICAL DATA

This section explains how to assess the level of confidence in sampling and analytical procedures in the context of the four major decisions to be made by the risk assessor with environmental analytical data. Exhibits in this section apply the data useability criteria, defined in Chapter 3 and appearing on the Data Useability Worksheet, to these four decisions. Data useability criteria affect the level of confidence involved in each decision. The level of certainty in the data collection and evaluation component of risk assessment affects the overall certainty of the risk estimate.

6.1.1 What Contamination is Present and at What Levels?

The risk assessor's first task is to use analytical data to determine what contamination is present at the site and at what levels (i.e., what potential exists for increased risk from the contamination). Exhibit 71 lists the criteria from the Data Useability Worksheet that affect this decision. The most critical analytical data question to be answered before calculating the risk is the probability of false negatives or false positives. False negatives are of greater concern in risk assessment than false positives, since false negatives may result in a decision that would not be protective of human health. False positives cause the calculated risk to be biased high, and are of concern because taking unnecessary action at a site is costly.

☛ *The major concern with false negatives is that the decision based on the risk assessment may not be protective of human health.*

Probability of false negatives. False negatives occur when chemicals of potential concern are present but are not detected by the sampling design or the analytical method. The probability of false negatives can be determined by using the following parameters from the Data Useability Worksheet: analytical methods, data review, sampling completeness, sampling representativeness, analytical completeness, analytical precision and accuracy, and combined error.

☛ *False negatives can occur if sampling is not representative, if detection limits are above concentrations of concern, or if spike recoveries are very low.*


Sampling strategies can increase the probability of false negatives if too few samples were taken or if sections of the site were not sampled. The probability of false negatives increases if sampling of any exposure pathway was not representative.

Knowledge of analyte-specific detection limits is critical to determining the probability of false negatives. Recovery values from spikes, internal standards,

Acronyms

RAGS	Risk Assessment Guidance for Superfund
SAP	sampling and analysis plan
SOP	standard operating procedure

EXHIBIT 71. DATA USEABILITY CRITERIA AFFECTING CONTAMINATION PRESENCE



21-002-071

surrogates, and system monitoring compounds are used to assess the level of accuracy and precision in laboratory data and determine whether the detection limits stated in the analytical methods have been met.

- The probability of false negatives for an analyte is high if the concentration of concern is at or below the detection limit. This probability should have been documented during planning if no analytical methods were found with detection limits below the concentration of concern. If the concentration of concern is very near the detection limit, a false negative can occur because of "drift" in instrument response. This behavior may not be reflected in data from spike recoveries or blanks.
- The probability of false negatives is low if spike recoveries are acceptable, or biased high as documented during data review, and the detection limits are below the concentration of concern for each analyte.
- The probability of false negatives is directly related to the amount of bias if spike recoveries are biased low and detection limits are below the concentration of concern for each analyte. The effect is more pronounced the closer the concentration of concern is to the detection limits.
- The possibility of false negatives should be carefully evaluated whenever sample extracts have been highly diluted (i.e., diluted beyond normal method specifications).

Probability of false positives. False positives occur when a chemical of concern is detected by an analytical

method but is truly not present at the site. Assessment of the following parameters from the Data Useability Worksheet can be used to determine the probability of false positives: analytical methods, data review, sampling accuracy, analytical completeness, analytical precision and accuracy, and combined error.

❖ *False positives can occur when blanks are contaminated or spike recoveries are very high.*

Sampling and analysis uncertainties connected with false positives can be assessed by examining the results of quality control samples. Blank contamination is the most important indicator of probability of false positives, particularly when accompanied by high spike recoveries. As described in Chapter 5, samples can be contaminated during sampling, storage, or analysis. Field and laboratory blanks identify this problem by determining the level and point of contamination. Sample matrix interferences can also cause false positives. High spike recoveries indicate that matrix interference has occurred.

- The probability of false positives is high if the chemical of potential concern has been detected in any blanks. False positives should be suspected for any sample value less than 5 times the blank concentration (10 times for common laboratory contaminants). High spike recoveries combined with blank contamination increase the likelihood of false positives.
- The probability of a false positive for an analyte is directly related to the amount of bias if chemicals of potential concern are detected in blanks and spike recoveries for the analyte are biased high.

- The probability of false positives is highest when the reported concentration is near the detection limit for an analyte.
- The probability of false positives is low if chemicals of potential concern have not been detected in any blanks and spike recoveries are not biased high.

6.1.2 Are Site Concentrations Sufficiently Different from Background?

Background samples provide baseline measurements to determine the degree of contamination. Background samples are collected and analyzed for each medium of concern in the same manner as other site samples. They require the same degree of quality control and data review. Background samples differ from other samples in that the sampling points, as defined in the sampling and analysis plan (SAP), are intended to be in an area that has not been exposed to the source of contamination. Historical data, when available, are particularly useful in selecting sampling and analysis techniques used to determine the representative concentrations of chemicals of potential concern in background samples. Historical data can help to delineate physical areas that are background and provide a basis for temporal trends in the concentration of chemicals of potential concern. Exhibit 72 lists the criteria from the Data Useability Worksheet that affect this decision.


As part of the risk assessment process, the risk assessor must determine if background samples are uncontaminated. The entire data collection process will be simplified if chemicals of potential concern are not found in background samples. If chemicals of potential concern are found in the background samples, the risk assessor must determine whether they are at naturally

occurring levels, of anthropogenic origin, due to contamination during the sampling process, or are site contaminants.

Both naturally occurring chemicals and anthropogenic chemicals have significance for risk assessment. Naturally occurring chemicals are those expected at a site in the absence of human influence. Metals are naturally occurring chemicals that are often included in risk analysis; they are often present in environmental media in varying concentrations. For example, soils of high organic content, such as humus, would have a low concentration of metals by weight, while soils with a high clay content would contain higher metal levels. Anthropogenic chemicals are defined in RAGS (EPA 1989a) as chemicals that are present in the environment due to man-made, non-site sources (e.g., industry, automobiles). Chemicals of anthropogenic origin may include organic compounds such as phthalates (plasticizers), DDT, or polycyclic aromatic hydrocarbons and inorganic chemicals such as lead (from automobile exhaust). Guidance highlights for background concentration issues for risk assessment are:

- Organic chemicals of potential concern found in background samples should not be considered naturally occurring. They may be present because they are either site contaminants or are of anthropogenic origin. They also could be a result of contamination during sampling.
- The risk assessor may eliminate chemicals from risk assessment calculations if their concentrations fall within naturally occurring levels and are below the concentration of concern.
- Contamination of background samples is indicated if chemical concentrations are higher than naturally occurring levels. Such contamination may come

EXHIBIT 72. DATA USEABILITY CRITERIA AFFECTING BACKGROUND LEVEL COMPARISON



21-002-072

from anthropogenic sources or from problems in sampling or analysis activities. The risk assessor may include analytical data with other site data or perform a separate risk assessment based on best professional judgment.

- Anthropogenic chemicals should not be eliminated from the risk assessment.
- Statistical analysis may be necessary to determine if site levels are distinctly different from those found in background samples when background results approach site concentration levels.
- Statistical analysis may be necessary where chemicals of potential concern are detected in site samples at very low concentrations. It is difficult to distinguish a difference between background and site sample concentrations at levels close to the detection limit.

■ *Statistical analysis may determine if site concentrations are significantly above background concentrations when the differences are not obvious.*

6.1.3 Are All Exposure Pathways and Areas Identified and Examined?

The identification and examination of exposure pathways is discussed in detail in RAGS. Exhibit 73 summarizes the criteria that the risk assessor must assess to determine the probable level of certainty that all exposure pathways and areas have been identified and examined.

The nature of the exposure pathways and areas to be examined is critical to the selection of a sampling design and analytical methods. If the pathways and areas are not identified properly, the resulting characterization may be inappropriate. The risk assessor should determine which pathways and areas are not adequately assessed


and determine the effect on the risk assessment if they are excluded from study. Guidance highlights for exposure pathway identification for risk assessment are:

- Recommend acquisition of additional samples from the inadequately represented exposure pathway or area if feasible. (Sampling considerations presented in Chapter 3 should be re-examined).
- Investigate whether computer simulation modeling is feasible if additional samples cannot be collected from an inadequately represented pathway or area. For example, air flow models could be used to estimate transport of volatile contaminants if the contamination of soil and water at a site is fully characterized but no air samples were obtained.
- Note in the report that the risk could not be determined for a pathway or area, or use simple chemical/physical relationships to estimate exposure if additional samples cannot be collected from an inadequately represented pathway and no simulation models are appropriate. For example, equilibrium partition coefficients can be used to estimate movement in the vadose zone of soil if insufficient data exist to calibrate a groundwater transport model.

6.1.4 Are All Exposure Areas Fully Characterized?

Assessing how well exposure areas have been characterized involves evaluation of completeness, comparability, and representativeness across analytical and sampling data quality indicators. Exhibit 74 lists the criteria from the worksheet that affect this decision. To be fully characterized, the exposure area must have

EXHIBIT 73. DATA USEABILITY CRITERIA AFFECTING EXPOSURE PATHWAY AND EXPOSURE AREA EXAMINATION



21-002-073

been appropriately sampled. Broad spectrum analyses must also have been conducted for the media of concern and analyte-specific methods used where appropriate. The uncertainty in data collection and analysis depends on the evaluation of completeness, comparability and representativeness as discussed in Section 5.6. Based on these indicators, the risk assessor should determine the magnitude of the effect of data confidence on the risk assessment. Guidance highlights for characterization of exposure areas for risk assessment are:

- Use the data but note the level of confidence associated with assessment of the affected exposure area if it is not significant.
- Statistical interpretation procedures (e.g., sensitivity analysis) may be used if the confidence level associated with data for an exposure area is significant but does not warrant resampling and reanalysis.
- If the uncertainty associated with the data is high, the risk assessor may determine that an exposure pathway or area is not fully characterized.

6.2 ASSESSMENT OF UNCERTAINTY ASSOCIATED WITH THE BASE-LINE RISK ASSESSMENT FOR HUMAN HEALTH

The level of certainty in making each of the four decisions discussed in Section 6.1 contributes to the

overall uncertainty in data collection and analysis components of risk assessment. The critical factor in assessing the effect of uncertainty on the environmental analytical data component of risk assessment is not that uncertainty exists, but rather that the risk assessor is able to qualify and/or quantitate the uncertainty so that the decision-maker can make informed decisions. The certainty levels for risk assessment, represented in Exhibit 75, are based on the ability to quantitate the uncertainty in analytical data collection and evaluation. However, data collection and evaluation is only one source of uncertainty in the risk assessment. Other components of the risk assessment process, such as toxicity of chemicals and exposure assumptions, influence the four decisions to be made and contribute significantly to the uncertainty of the baseline risk assessment.

The most quantitative level of risk assessment occurs when the uncertainty in data can be determined quantitatively. The next level occurs when the uncertainty can be determined qualitatively, or the impact of the uncertainty is assessed using sensitivity analysis. The least desirable situation occurs when the uncertainty in data is unknown. This situation can occur if the minimum requirements given in Chapter 5 for the data useability criteria have not been achieved.

➤ *The primary planning objective is that uncertainty levels are acceptable, known and quantifiable, not that uncertainty be eliminated.*

EXHIBIT 74. DATA USEABILITY CRITERIA AFFECTING EXPOSURE AREA CHARACTERIZATION

Worksheet Reference

Data Useability Criterion


Data Collection and Evaluation Decision

1	Reports to risk assessor
2A	Documentation (SAP)
2B	Documentation (SOPs)
2C	Documentation (field records)
3A	Data sources (analytical)
3B	Data sources (non-analytical)
6A	Completeness (sampling and analytical)
6B	Comparability (sampling and analytical)
6C	Representativeness (sampling and analytical)
6D	Precision (sampling)



Are all exposure areas fully characterized?

**EXHIBIT 75. UNCERTAINTY IN DATA COLLECTION AND EVALUATION
DECISIONS AFFECTS THE CERTAINTY
OF THE RISK ASSESSMENT**



21-002-075

Appendices

I.	DESCRIPTION OF ORGANICS AND INORGANICS DATA REVIEW PACKAGES	125
II.	LISTING OF COMMON POLLUTANTS GENERATED BY SEVEN INDUSTRIES	153
III.	LISTING OF ANALYTES, METHODS, AND DETECTION OR QUANTITATION LIMITS FOR POLLUTANTS OF CONCERN TO RISK ASSESSMENT	167
IV.	CALCULATION FORMULAS FOR STATISTICAL EVALUATION	235
V.	"J" DATA QUALIFIER SOURCE AND MEANING	239
VI.	"R" DATA QUALIFIER SOURCE AND MEANING	245
VII.	SUMMARY OF COMMON LABORATORY CONTAMINANTS, CONCENTRATION REQUIRE- MENTS, AND RISK ASSESSMENT IMPLICATIONS	249
VIII.	CLP ANALYTICAL METHODS SHORT SHEETS AND TCL COMPOUNDS	253
IX.	EXAMPLE DIAGRAM FOR A CONCEPTUAL MODEL FOR RISK ASSESSMENT	263

APPENDIX I

DESCRIPTION OF ORGANICS AND INORGANICS DATA REVIEW PACKAGES

The purpose of Appendix I is to familiarize the reader with a model for data review deliverables. This appendix consists of the following items:

- o A description of the data reporting format,
- o An example of a data review summary, and
- o Example data review forms.

Please note that the example forms are designed for the validation of Contract Laboratory Program (CLP) data packages. An example form is included for each analytical fraction (volatiles, semivolatiles, pesticide/Aroclors and metals) and for samples from soil/sediment and aqueous matrices. These forms nevertheless include the necessary information for the review of most types of data (analytical results, sample quantitation/detection limits, data qualifiers, etc.) not associated with the CLP.

1. DATA REPORTING FORMATS

Whenever an analytical laboratory is requested to analyze field samples for a specific site, the RPM (in consultation with the technical project team) must ensure that the laboratory will provide adequate documentation to support all current and future uses of the data. Potential uses of the data can include data validation, monitoring, modeling, risk assessment, site characterization, Record of Decision defense, enforcement, and litigation.

Data packages produced by analytical laboratories should contain all the documents that were produced or used by the laboratory for that particular analysis. The required documents should include a narrative (detailing the exact method performed, deviations from the method, problems encountered, and problem resolution), chain-of-custody records, laboratory logbook pages, and raw data and tabulated summary forms for all standards, quality control and field samples.

The documents should be organized in a logical manner and the entire data package should be paginated. Generally, the laboratory should be required to produce a data package with documents ordered in the following manner:

- 1) Narrative
- 2) Tabulated summary forms for laboratory standards and quality control samples (in chronological order by type of quality control sample/standard by date of analysis by instrument)
- 3) Tabulated summary forms for field sample results (in increasing RAS, SAS, or project sample number order)
- 4) Raw data for field samples (in increasing RAS, SAS, or project sample number order)
- 5) Raw data for laboratory standards and quality control samples (in chronological order by type of quality control sample/standard by date of analysis by instrument)
- 6) Laboratory logbook pages
- 7) Chain-of-custody records

APPENDIX I (continued)

It is often convenient to require that the laboratory data package resemble as closely as possible the data packages required by the current CLP RAS SOWs for organics and inorganics, that the tabulated summary forms provided in those SOWs be utilized and modified appropriately, and that the data qualifiers in those SOWs be applied to the data as appropriate. The following sections describe specific requirements for the content of each document contained in the laboratory data package.

NARRATIVE:

A narrative must be provided describing the analytical methods and exact procedures performed by the laboratory, as well as any deviations from the method. Problems encountered during analysis, problem resolution and any factors which may affect the validity of the data must be addressed. The narrative must include the laboratory name and RAS, SAS, or project sample numbers cross-referenced to the laboratory sample identification numbers, and must be signed and dated by the laboratory manager.

Any telephone communications between the laboratory and sampling personnel (or other parties outside of the laboratory) to resolve sampling discrepancies or analytical problems must be documented in detail on telephone communication logs. Those telephone logs must explicitly detail the problems requiring resolution, the agreed to resolution, and the names and affiliations of the communicating parties. All telephone logs must be appended to the narrative.

An example calculation of a positive hit and a detection/quantitation limit for each type of sample analysis must be provided. All equations, dilution factors and information required to reproduce the laboratory results must be provided.

TABULATED SUMMARY FORMS:

Laboratory Standards and Quality Control Samples

Tabulated summary forms must be provided for all laboratory standards, tunes, blanks, duplicates, spikes, and any other types of laboratory quality control samples/standards. The tabulated summary forms must contain information pertinent to the type of laboratory quality control sample/standard which was analyzed. Typical entries include: concentrations spiked, concentrations detected, spike compound names, results of statistical calculations (%R, %D, RPD, RSD, CV, RRF, SD, etc.), sample identification numbers, dates/times of analysis, instrument IDs, lab file IDs, and QC limits.

The exact format of each tabulated summary form will depend on the particular analysis method requested and the quality control procedures specified in that method. However, comprehensive tabulated summary forms must be prepared for all quality control samples/standards analyzed by the laboratory. For example, typical tabulated summary forms for volatile organics analyses include but are not limited to:

Surrogate results: Tabulate the sample identification numbers, surrogate compounds added, concentration added, percent recoveries, and QC limits for all standards, blanks, quality control samples and field samples. Flag outliers.

Matrix spike and matrix spike duplicate results: Tabulate the matrix spike compounds added, concentration added, percent recoveries and relative percent differences for the spiked compounds, and QC limits. Flag outliers. List the sample identification numbers. Results for

APPENDIX I (continued)

all non-spike compounds must be tabulated on the form used to summarize field sample results.

Method/laboratory blanks: Tabulate the sample identification numbers, lab file IDs, and time analyzed for field samples and matrix spike samples which pertain to each blank on a separate form. The form must also contain the GC column, instrument ID, laboratory sample identification number, lab file ID, and date/time of analysis for the blank itself. Results for each blank must also be tabulated on the form used to summarize field sample results.

Tuning results: Tabulate the m/e, ion abundance criteria, and percent relative abundances and list the tune compound name, instrument ID, lab file ID, and date/time of injection which pertain to each tune analysis on a separate form. The form must also contain tabulated sample identification numbers, lab file IDs, and date/time of analysis for all field samples, matrix spike samples, blanks, and standards which pertain to that tune. Flag outliers.

Initial calibration results: Tabulate the target compound names, relative response factors for each target and surrogate compound at each standard concentration, mean relative response factors and percent relative standard deviations for all target and surrogate compounds, and QC limits for each initial calibration on a separate form. The form must also contain the concentration of the calibration standards, instrument ID, lab file IDs, and dates/times of standard analyses for that initial calibration. Flag outliers.

Continuing calibration results: Tabulate the target compound names, mean relative response factors from initial calibration, relative response factors from continuing calibration, percent differences, and QC limits for all target and surrogate compounds for each continuing calibration on a separate form. The form must also contain the concentration of the continuing calibration standard, instrument ID, lab file ID, and dates/times of initial and continuing calibration standard analyses which pertain to that continuing calibration. Flag outliers.

Internal standard results: Tabulate the sample identification numbers, internal standard compound names, QC limits, retention times and area counts of the quantitation ion for each internal standard compound in the continuing calibration standard and all field samples, matrix spike samples, and blanks which pertain to that continuing calibration on a separate form. The form must also contain the instrument ID, lab file ID, and date/time of continuing calibration standard analysis. Flag outliers.

MDL study results: Tabulate the target compound names, concentrations spiked and detected for each MDL spike analysis, and the standard deviation and calculated MDL for each target compound. (Note: The narrative must explain the MDL procedure utilized to generate the values. The formula and associated constant values utilized in the calculation of the MDL for each analyte must be provided. The column, instrument ID, trap composition, and operating conditions must be clearly displayed on the raw data.)

Field Samples

The exact format of the tabulated summary form for each field sample will depend on the particular analysis method requested. However, comprehensive tabulated summary forms must be prepared for each field sample analyzed by the laboratory. At a minimum, the target compound names, concentration units, positive hits and numerical detection/quantitation limits and any laboratory qualifier flags for each target compound must be tabulated on a separate form. Definitions must be provided for all qualifier flags used by the laboratory. For each

APPENDIX I (continued)

sample, the tabulated form must also contain the RAS, SAS, or project sample identification number, laboratory name, laboratory sample ID, lab file ID, sample matrix type, and level of analysis (low, medium, high). The percent moisture/solids, weights and volumes of sample prepared/purged/extracted/digested/analyzed, initial and final extract/digest and extract clean-up volumes, injection volume, clean-ups performed, dilution factor, measured pH, and dates that sample was received/extracted/digested/analyzed should be included as appropriate to the analysis method.

RAW DATA:

Raw data must be provided by the laboratory for all laboratory quality control samples, blanks, spikes, duplicates, standards, and field samples. The exact format and content of the raw data will depend on the particular analysis method requested. However, any and all instrument printouts, strip chart recordings, chromatograms, quantitation reports, mass spectra and other types of raw data generated by the laboratory for a particular project must be provided in the data package. Typical raw data for organic GC/MS analyses includes but is not limited to:

- o Reconstructed total ion chromatograms,
- o Instrument quantitation reports containing the following information: laboratory sample identification number, RAS, SAS or project sample number, date and time of analysis, RT and/or scan number of quantitation ion with measured area, analyte concentration, copy of area table from data system, GC/MS instrument ID, lab file ID, column, trap composition, and operating conditions,
- o Raw and enhanced mass spectra for all positive field sample results and daily continuing calibration standard reference spectra for all positive field sample results,
- o Mass spectra and three library searched best-match mass spectra for all tentatively identified compounds reported, and
- o Instrument normalized mass listing and the mass spectrum for each tune.

Typical raw data for inorganic analyses includes but is not limited to:

- o Instrument printouts and strip chart recordings containing the following information: laboratory sample identification number, RAS, SAS or project sample number, date and time of analysis, absorbance/emissions values, analyte concentration, instrument ID, lab file ID, and operating conditions, and
- o Standard curve raw data, plotted standard curves, linear regression equations, and correlation coefficients.

LABORATORY LOGBOOK PAGES:

Copies of standards preparation logs, sample preparation/extraction/digestion logs, sample analysis run logs, personal logs, and any hand written project-specific notes must be included. The initial and final volumes of sample prepared/purged/extracted/digested, initial

APPENDIX I (continued)

and final extract/digest and extract clean-up volumes, injection volumes, and dilution factors must be clearly labelled.

CHAIN-OF-CUSTODY RECORDS:

All chain-of-custody records provided to the laboratory during sample shipment or generated by the laboratory during sample receipt, storage, preparation, and analysis must be included. Chain-of-custody records include but are not limited to: signed and dated field chain-of-custody forms, signed and dated shipping airbills, sample tags, SAS packing lists, RAS Traffic Reports, internal laboratory receiving records, and internal laboratory sample/extract/digest transfer records.

APPENDIX I (Continued)

2. DATA REVIEW SUMMARY

ORGANIC DATA SUMMARY FORMS UTILIZED BY REGION III IN THE CLP

DATE:

SUBJECT:

FROM:

TO:

THRU:

OVERVIEW

Case consisted of four (4) low level water and two (2) low level soil samples, submitted for full organic analyses. Included in this data set was one (1) equipment blank and one (1) trip blank. The trip blank was analyzed for volatiles only. The samples were analyzed as a Contract Laboratory Program (CLP) Routine Analytical Service (RAS).

SUMMARY

All samples were successfully analyzed for all target compounds with the exception of 2-Butanone and 2-Hexanone in the volatile fraction. All remaining instrument and method sensitivities were according to the Contract Laboratory Program (CLP) Routine Analytical Service (RAS) protocol.

MAJOR PROBLEM

The response factors (RF) for 2-Butanone and 2-Hexanone were less than 0.05 in one of the continuing volatile calibration. The quantitation limits for this compound in the affected samples were qualified unreliable, "R". (See Table I in Appendix F for the affected samples.)

MINOR PROBLEMS

Several compounds failed precision criteria for initial and/or continuing calibrations. Quantitation limits and the reported results for these compounds may be biased and, therefore, have been qualified estimated, "UJ" and "J", respectively. (See Table I in Appendix F for the affected samples).

2. DATA REVIEW SUMMARY

Page 2 of 3

NOTES

- o The soil semivolatile MS/MSD analyses were originally extracted within the technical and contractual holding times. Re-extractions were required because of surrogate recoveries, and these re-extractions were performed outside of holding times. Surrogate recoveries were again outside of the QC limits, therefore, original sample results are being reported.
- o The maximum concentration of compounds found in the trip blanks, field blanks, or method blanks are listed below. All samples with concentrations of common laboratory contaminants less than ten times (<10X) the blank concentration, and uncommon laboratory contaminants less than five times (<5X) the blank concentration have been qualified "B" in the data summary table. (See Appendix F).

<u>Compound</u>	<u>Concentration (ug/L)</u>
Methylene chloride *	7 J
Acetone *	9 J
Bis(2-ethylhexyl)phthalate *	10 J
* Common Laboratory Contaminant	

- o The semivolatile MS/MSD analyses had compounds other than the spiking compounds present. The following is a table of results and precision estimates for the non-spiked compounds:

MS/MSD Non-Spiked Compounds
Concentration (ug/L)

<u>Compound</u>				<u>%RSD</u>
Phenanthrene	150 J	190 J	140 J	16.5
Fluoranthene	340 J	470 J	440 J	16.3
Benzo(a)anthracene	290 J	310 J	320 J	5.0
Chrysene	290 J	330 J	300 J	6.8
Bis (2-ethylhexyl) phthalate	160 J	200 J	240 J	20.0
Benzo (b)pyrene	190 J	240 J	240 J	12.9
Benzo (k) pyrene	230 J	200 J	220 J	7.1
Benzo (a) pyrene	240 J	190 J	240 J	12.9

RSD= Relative Standard Deviation

APPENDIX I (Continued)

2. DATA REVIEW SUMMARY

Page 3 of 3

- o The pesticide/PCB analyses of all soil samples and associated QC samples had surrogate recoveries in excess of the QC limit. Since no positive results were reported for any pesticide or PCB compounds for any of the samples in this case no data was affected. (See Appendix F).
- o The reported Tentatively Identified Compounds (TIC's) in Appendix D have been reviewed and accepted or corrected.
- o All data for Case were reviewed in accordance with the Functional Guidelines for Evaluating Organic Analyses with modifications for use within Region III. The text of this report addresses only those problems affecting usability.

ATTACHMENTS

APPENDIX A - Glossary of Data Qualifiers

APPENDIX B - Data Summary. These include:

(a) All positive results for target compounds with qualifier codes where applicable.

(b) All unusable detection limits (qualified "R").

APPENDIX C - Results as Reported by the Laboratory for All Target Compounds

APPENDIX D - Reviewed and Corrected Tentatively Identified Compounds

APPENDIX E - Organic Regional Data Assessment Summary

APPENDIX F - Support Documentation

CERCLIS SITE NAME _____

CASE No. _____ SDG No. _____

Sample Location											
Sample Number											
Traffic Report Number											
Remarks											
Sampling date											
Analysis Date											
Inorganic Analytes	IDL(ug/L)										
Aluminum P											
Antimony P											
Arsenic F											
Barium P											
Beryllium P											
Cadmium P											
Calcium P											
Chromium P											
Cobalt P											
Copper P											
Iron P											
Lead F											
Magnesium P											
Manganese P											
Mercury CV											
Nickel P											
Potassium P											
Selenium F											
Silver P											
Sodium P											
Thallium F											
Vanadium P											
Zinc P											
Cyanide C											
Analytical Method		UJ The detection limit is approximated due to limitations identified in the quality									
F Furnace AA NOTE:		control review (data validation).									
P ICP/Flame AA		R Value is rejected.									
CV Cold Vapor		NA Not Analyzed.									
C Colorimetric											
Sample's wet weight (gms)											
for Hg analysis											
for ICP analysis											
for furnace AA analysis											
for Cyanide analysis											

CERCLIS SITE NAME:

CASE No. _____ SDG No. _____

[illegible]

Analytical Method
F Furnace AA NOTE:
P ICP/Flame AA
CV Cold Vapor
C Colorimetric

UJ The detection limit is approximated due to limitations identified in the quality control review (data validation).
R Value is rejected.
NA Not Analyzed.

[illegible]

CURCLIS SITE NAME: _____
CASE NO. _____, SDG NO. _____

Sample Location											
Sample Number											
Traffic Report Number											
Remarks											
Sampling date											
Inorganic analytes		CRDL									
Aluminum	P	200									
Antimony	P	60									
Arsenic	F	10									
Barium	P	200									
Beryllium	P	5									
Cadmium	P	5									
Calcium	P	5000									
Chromium	P	10									
Cobalt	P	50									
Copper	P	25									
Iron	P	100									
Lead	P	3									
Magnesium	P	5000									
Manganese	P	15									
Mercury	CV	0.2									
Nickel	P	40									
Potassium	P	5000									
Selenium	F	5									
Silver	P	10									
Sodium	P	5000									
Thallium	F	10									
Vanadium	P	50									
Zinc	P	20									
Cyanide	C	10									

Analytical Method J Quantitation is approximated due to limitations identified during the quality control review.
 F Furnace R Value is rejected.
 P ICP/Flame AA U Revised Sample Quantitation Limit.
 CV Cold Vapor UJ Quantitation limit is approximate due to limitations identified in the quality control review.
 C Colorimetric NA Not Analyzed.
 Sample results are reported on a dry weight basis.

CIRCLE SITE NAME: _____

CASE NO. _____, SDG NO. _____

Sample Location											
Sample Number											
Traffic Report Number											
Remarks											
Sampling date											
Inorganic analytes	CRDL										
Aluminum	P 200										
Antimony	P 60										
Arsenic	F 10										
Barium	P 200										
Beryllium	P 5										
Cadmium	P 5										
Calcium	P 5000										
Chromium	P 10										
Cobalt	P 50										
Copper	P 25										
Iron	P 100										
Lead	P 3										
Magnesium	P 5000										
Manganese	P 15										
Mercury	CV 0.2										
Nickel	P 40										
Potassium	P 5000										
Selenium	F 5										
Silver	P 10										
Sodium	P 5000										
Thallium	F 10										
Vanadium	P 50										
Zinc	P 20										
Cyanide	C 10										

Analytical Method J Quantitation is approximated due to limitations identified during the quality control review.
 F Furnace R Value is rejected.
 P ICP/Flame AA U Revised Sample Quantitation Limit.
 CV Cold Vapor UJ Quantitation limit is approximate due to limitations identified in the quality control review.
 C Colorimetric NA Not Analyzed.
 Sample results are reported on a dry weight basis.

CERCLIS SITE NAME: _____

CASE NO. _____ SDO NO. _____

Sample Location										
Sample Number										
Traffic Report Number										
Remarks										
Sampling Date										
Analysis Date										
Volatile Organic Compound	CRQL									
Chloromethane	10									
Bromomethane	10									
Vinyl Chloride	10									
Chloroethane	10									
Methylene Chloride	5									
Acetone	10									
Carbon Disulfide	5									
1,1-Dichloroethene	5									
1,1-Dichloroethane	5									
1,2-Dichloroethene(Total)	5									
Chloroform	5									
1,2-Dichloroethane	5									
2-Butanone	10									
1,1,1-Trichloroethane	5									
Carbon Tetrachloride	5									
Vinyl Acetate	10									
Bromodichloromethane	5									
1,2-Dichloropropane	5									
cis-1,3-Dichloropropene	5									
Trichloroethene	5									
Dibromochloromethane	5									
1,1,2-Trichloroethane	5									
Benzene	5									
trans-1,3-Dichloropropene	5									
Bromoform	5									
4-Methyl-2-pentanone	10									
2-Hexanone	10									
Tetrachloroethene	5									
1,1,2,2-Tetrachloroethane	5									
Toluene	5									
Chlorobenzene	5									
Ethylbenzene	5									
Styrene	5									
Xylene (Total)	5									

CRQL Contract Required Quantitation Limit.

J Quantitation is approximate due to limitations identified during the quality control review.

UJ Quantitation limit is approximated due to limitations identified in the quality control review.

R Value is rejected.

CERCLIS SITE NAME: _____

CASE NO. _____, SDG NO. _____

Sample Location												
Sample Number												
Traffic Report Number												
Remarks												
Sampling Date												
Analysis Date												
Volatile Organic Compound	CRQL											
Chloromethane	10											
Bromomethane	10											
Vinyl Chloride	10											
Chloroethane	10											
Methylene Chloride	5											
Acetone	10											
Carbon Disulfide	5											
1,1-Dichloroethene	5											
1,1-Dichloroethane	5											
1,2-Dichloroethene (Total)	5											
Chloroform	5											
1,2-Dichloroethane	5											
2-Butanone	10											
1,1,1-Trichloroethane	5											
Carbon Tetrachloride	5											
Vinyl Acetate	10											
Bromodichloromethane	5											
1,2-Dichloropropane	5											
cis-1,3-Dichloropropene	5											
Trichloroethene	5											
Dibromochloromethane	5											
1,1,2-Trichloroethane	5											
Benzene	5											
trans-1,3-Dichloropropene	5											
Bromoform	5											
4-Methyl-2-pentanone	10											
2-Hexanone	10											
Tetrachloroethene	5											
1,1,2,2-Tetrachloroethane	5											
Toluene	5											
Chlorobenzene	5											
Ethylbenzene	5											
Styrene	5											
Xylene (Total)	5											

CRQL Contract Required Quantitation Limit.

J Quantitation is approximate due to limitations identified during the quality control review.

UJ Quantitation limit is approximate due to limitations identified in the quality control review

R Value is rejected.

CERCLIS SITE NAME: _____
 CASE NO. _____, SDG NO. _____

Sample Location										
Sample Number										
Traffic Report Number										
Remarks										
Sampling Date										
Dilution Factor										
Percent Solids										
Volatile Organic Compound										
Chloromethane										
Bromomethane										
Vinyl Chloride										
Chloroethane										
Methylene Chloride										
Acetone										
Carbon Disulfide										
1,1-Dichloroethene										
1,1-Dichloroethane										
1,2-Dichloroethene (Total)										
Chloroform										
1,2-Dichloroethane										
2-Butanone										
1,1,1-Trichloroethane										
Carbon Tetrachloride										
Vinyl Acetate										
Bromodichloromethane										
1,2-Dichloropropane										
cis-1,3-Dichloropropene										
Trichloroethene										
Dibromochloromethane										
1,1,2-Trichloroethane										
Benzene										
trans-1,3-Dichloropropene										
Bromoform										
4-Methyl-2-pentanone										
2-Hexanone										
Tetrachloroethene										
1,1,2,2-Tetrachloroethane										
Toluene										
Chlorobenzene										
Ethylbenzene										
Styrene										
Xylene (Total)										

Sample Quantitation limits are reported on a dry weight basis.

UJ Quantitation limit is approximated due to limitations during the quality control review.

R Value is rejected.

CERCLIS SITE NAME _____

CASE No. _____, SDG No. _____

Sample Location										
Sample Number										
Traffic Report Number										
Remarks										
Sampling Date										
Dilution Factor										
Volatile Organic Compound										
Chloromethane										
Bromomethane										
Vinyl Chloride										
Chloroethane										
Methylene Chloride										
Acetone										
Carbon Disulfide										
1,1-Dichloroethene										
1,1-Dichloroethane										
1,2-Dichloroethene (Total)										
Chloroform										
1,2-Dichloroethane										
2-Butanone										
1,1,1-Trichloroethane										
Carbon Tetrachloride										
Vinyl Acetate										
Bromodichloromethane										
1,2-Dichloropropane										
cis-1,3-Dichloropropene										
Trichloroethene										
Dibromochloromethane										
1,1,2-Trichloroethane										
Benzene										
trans-1,3-Dichloropropene										
Bromoform										
4-Methyl-2-pentanone										
2-Hexanone										
Tetrachloroethene										
1,1,2,2-Tetrachloroethane										
Toluene										
Chlorobenzene										
Ethylbenzene										
Styrene										
Xylene (Total)										

Sample Quantitation limits are reported on a dry weight basis.

UJ Quantitation limit is approximated due to limitations during the quality control review.

R Value is rejected.

CERCLIS SITE NAME: _____

CASE NO. _____, SDG NO. _____

Sample Location												
Sample Number												
Traffic Report Number												
Remarks												
Sampling Date												
Extraction Date												
Analysis Date												
Semi-Volatile Compound	CRQL											
Phenol	10											
bis (2-Chloroethyl) ether	10											
2-Chlorophenol	10											
1,3-Dichlorobenzene	10											
1,4-Dichlorobenzene	10											
Benzyl Alcohol	10											
1,2-Dichlorobenzene	10											
2-Methylphenol	10											
bis (2-Chloroisopropyl) ether	10											
4-Methylphenol	10											
N-Nitroso-di-n-propylamine	10											
Hexachloroethane	10											
Nitrobenzene	10											
Isophorone	10											
2-Nitrophenol	10											
2,4-Dimethylphenol	10											
Benzoic acid	50											
bis (2-Chloroethoxy) methane	10											
2,4-Dichlorophenol	10											
1,2,4-Trichlorobenzene	10											
Naphthalene	10											
4-Chloroaniline	10											
Hexachlorobutadiene	10											
4-Chloro-3-methylphenol	10											
2-Methylnaphthalene	10											
Hexachlorocyclopentadiene	10											
2,4,6-Trichlorophenol	10											
2,4,5-Trichlorophenol	50											
2-Chloronaphthalene	10											
2-Nitroaniline	50											
Dimethylphthalate	10											
Acenaphthylene	10											
2,6-Dinitrotoluene	10											

CRQL Contract Required Quantitation Limit.

J Quantitation is approximate due to limitations identified during the quality control review.

UJ Quantitation limit is approximated due to limitations identified in the quality control review.

R Value is rejected.

CERCLIS SITE NAME:
CASE NO., SDO NO.

Sample Location									
Sample Number									
Traffic Report Number									
Remarks									
Sampling Date									
Extraction Date									
Analysis Date									
Semi-Volatile Compound	CRQL								
3-Nitroaniline	50								
Acenaphthene	10								
2,4-Dinitrophenol	50								
4-Nitrophenol	50								
Dibenzofuran	10								
2,4-Dinitrotoluene	10								
Diethylphthalate	10								
4-Chlorophenyl-phenylether	10								
Fluorene	10								
4-Nitroaniline	50								
4,6-Dinitro-2-methylphenol	50								
N-Nitrosodiphenylamine	10								
4-Bromophenyl-phenylether	10								
Hexachlorobenzene	10								
Pentachlorophenol	50								
Phenanthrene	10								
Anthracene	10								
Di-n-butylphthalate	10								
Fluoranthene	10								
Pyrene	10								
Butylbenzylphthalate	10								
3,3'-Dichlorobenzidine	20								
Benzo(a)anthracene	10								
Chrysene	10								
bis(2-Ethylhexyl)phthalate	10								
Di-n-octyl phthalate	10								
Benzo(b)fluoranthene	10								
Benzo(k)fluoranthene	10								
Benzo(a)pyrene	10								
Indeno (1,2,3-cd)pyrene	10								
Dibenz(a,h)anthracene	10								
Benzo(g,h,i)perylene	10								

CRQL Contract Required Quantitation Limit.

J Quantitation is approximate due to limitations identified during the quality control review.

UJ Quantitation limit is approximated due to limitations identified in the quality control review.

R Value is rejected.

CERCLIS SITE NAME: _____

CASE NO. _____ SDG NO. _____

Sample Location										
Sample Number										
Traffic Report Number										
Remarks										
Sampling Date										
Extraction Date										
Analysis Date										
Pesticide/PCB Compound	CRQL									
alpha-BHC	0.05									
beta-BHC	0.05									
delta-BHC	0.05									
gamma-BHC (Lindane)	0.05									
Heptachlor	0.05									
Aldrin	0.05									
Heptachlor epoxide	0.05									
Endosulfan I	0.05									
Dieldrin	0.10									
4,4'-DDE	0.10									
Endrin	0.10									
Endosulfan II	0.10									
4,4'-DDD	0.10									
Endosulfan sulfate	0.10									
4,4'-DDT	0.10									
Methoxychlor	0.5									
Endrin ketone	0.10									
alpha-Chlordane	0.5									
gamma-Chlordane	0.5									
Toxaphene	1.0									
Aroclor-1016	0.5									
Aroclor-1221	0.5									
Aroclor-1232	0.5									
Aroclor-1242	0.5									
Aroclor-1248	0.5									
Aroclor-1254	1.0									
Aroclor-1260	1.0									

CRQL Contract Required Quantitation Limit.

J Quantitation is approximate due to limitations identified during the quality control review.

UJ Quantitation limit is approximated due to limitations identified in the quality control review.

R Value is rejected.

CERCLIS SITE NAME: _____
CASE NO. _____, SDG NO. _____

Sample Location										
Sample Number										
Traffic Report Number										
Remarks										
Sampling Date										
Dilution Factor										
Percent Solids										
Semi-Volatile Compound										
3-Nitroaniline										
Acenaphthene										
2,4-Dinitrophenol										
4-Nitrophenol										
Dibenzofuran										
2,4-Dinitrotoluene										
Diethylphthalate										
4-Chlorophenyl-phenylether										
Fluorene										
4-Nitroaniline										
4,6-Dinitro-2-methylphenol										
N-Nitrosodiphenylamine										
4-Bromophenyl-phenylether										
Hexachlorobenzene										
Pentachlorophenol										
Phenanthrene										
Anthracene										
Di-n-butylphthalate										
Fluoranthene										
Pyrene										
Butylbenzylphthalate										
3,3'-Dichlorobenzidine										
Benzo(a)anthracene										
Chrysene										
bis(2-Ethylhexyl)phthalate										
Di-n-octyl phthalate										
Benzo(b)fluoranthene										
Benzo(k)fluoranthene										
Benzo(a)pyrene										
Indeno (1,2,3-cd)pyrene										
Dibenz(a,h)anthracene										
Benzo(g,h,i)perylene										

Sample Quantitation Limits are reported on dry weight basis.

UJ Quantitation Limits are approximate due to limitations identified during the quality control review.

R Value is rejected.

CERCLIS SITE NAME: _____

CASE NO. _____, SDG NO. _____

145

Sample Location										
Sample Number										
Traffic Report Number										
Remarks										
Sampling Date										
Dilution Factor										
Percent Solids										
Semi-Volatile Compound										
Phenol										
bis (2-Chloroethyl) ether										
2-Chlorophenol										
1,3-Dichlorobenzene										
1,4-Dichlorobenzene										
Benzyl Alcohol										
1,2-Dichlorobenzene										
2-Methylphenol										
bis (2-Chloroisopropyl) ether										
4-Methylphenol										
N-Nitroso-di-n-propylamine										
Hexachloroethane										
Nitrobenzene										
Isophorone										
2-Nitrophenol										
2,4-Dimethylphenol										
Benzoic acid										
bis (2-Chloroethoxy) methane										
2,4-Dichlorophenol										
1,2,4-Trichlorobenzene										
Naphthalene										
4-Chloroaniline										
Hexachlorobutadiene										
4-Chloro-3-methylphenol										
2-Methylnaphthalene										
Hexachlorocyclopentadiene										
2,4,6-Trichlorophenol										
2,4,5-Trichlorophenol										
2-Chloronaphthalene										
2-Nitroaniline										
Dimethylphthalate										
Acenaphthylene										
2,6-Dinitrotoluene										

Sample Quantitation Limits are reported on a dry weight basis.

UJ Quantitation limit is approximated due to limitations identified in the quality control review.

R Value is rejected.

CERCLIS SITE NAME: _____
 CASE NO. _____, SDG NO. _____

Sample Location										
Sample Number										
Traffic Report Number										
Remarks										
Sampling Date										
Dilution Factor										
Percent Solids										
Pesticide/PCB Compound										
alpha-BHC										
beta-BHC										
delta-BHC										
gamma-BHC (Lindane)										
Heptachlor										
Aldrin										
Heptachlor epoxide										
Endosulfan I										
Dieldrin										
4,4'-DDE										
Endrin										
Endosulfan II										
4,4'-DDD										
Endosulfan sulfate										
4,4'-DDT										
Methoxychlor										
Endrin ketone										
alpha-Chlordane										
gamma-Chlordane										
Toxaphene										
Aroclor-1016										
Aroclor-1221										
Aroclor-1232										
Aroclor-1242										
Aroclor-1248										
Aroclor-1254										
Aroclor-1260										

Sample Quantitation Limits are reported on dry weight basis.
 UJ Quantitation Limits are approximate due to limitations identified during the quality control review.
 R Value is rejected.

CERCLIS SITE NAME: _____
CASE NO. _____ SDG NO. _____

[illegible]

CRQL Contract Required Quantitation Limit.

Quantitation is approximate due to limitations identified during the quality control review.

II.J Quantitation is approximate due to limitations identified during the quality control review.

R Value is rejected.

CERCLIS SITE NAME: _____
CASE NO. _____, SDO NO. _____

Sample Location									
Sample Number									
Traffic Report Number									
Remarks									
Sampling Date									
Extraction Date									
Analysis Date									
Semi-volatile compound	CROL								
3-Nitroaniline	1600								
Acenaphthene	330								
2,4-Dinitrophenol	1600								
4-Nitrophenol	1600								
Dibenzofuran	330								
2,4-Dinitrotoluene	330								
Diethylphthalate	330								
4-Chlorophenyl-phenylether	330								
Fluorene	330								
4-Nitroaniline	1600								
4,6-Dinitro-2-methylphenol	1600								
N-Nitrosodiphenylamine	330								
4-Bromophenyl-phenylether	330								
Hexachlorobenzene	330								
Pentachlorophenol	1600								
Phenanthrene	330								
Anthracene	330								
Di-n-butylphthalate	330								
Fluoranthene	330								
Pyrene	330								
Butylbenzylphthalate	330								
3,3'-Dichlorobenzidine	660								
Benzo(a)anthracene	330								
Chrysene	330								
bis(2-Ethylhexyl)phthalate	330								
Di-n-octyl phthalate	330								
Benzo(b)fluoranthene	330								
Benzo(k)fluoranthene	330								
Benzo(a)pyrene	330								
Indeno (1,2,3-cd)pyrene	330								
Dibenz(a,h)anthracene	330								
Benzo(g,h,i)perylene	330								

CROL Contract Required Detection Limit.

J Quantitation is approximate due to limitations identified during the quality control review.

UJ Quantitation limit is approximate due to limitations identified in the quality control review.

R Value is rejected.

CERCLIS SITE NAME: _____

CASE NO. _____, SDG NO. _____

Sample Location												
Sample Number												
Traffic Report Number												
Remarks												
Sampling Date												
Extraction Date												
Analysis Date												
Pesticide/PCB Compound	CRQL											
alpha-BHC	8.0											
beta-BHC	8.0											
delta-BHC	8.0											
gamma-BHC (Lindane)	8.0											
Heptachlor	8.0											
Aldrin	8.0											
Heptachlor epoxide	8.0											
Endosulfan I	8.0											
Dieldrin	16.0											
4,4'-DDE	16.0											
Endrin	16.0											
Endosulfan II	16.0											
4,4'-DDD	16.0											
Endosulfan sulfate	16.0											
4,4'-DDT	16.0											
Methoxychlor	80.0											
Endrin ketone	16.0											
alpha-Chlordane	80.0											
gamma-Chlordane	80.0											
Toxaphene	160.0											
Aroclor-1016	80.0											
Aroclor-1221	80.0											
Aroclor-1232	80.0											
Aroclor-1242	80.0											
Aroclor-1248	80.0											
Aroclor-1254	160.0											
Aroclor-1260	160.0											

CRQL Contract Required Quantitation Limit.

J Quantitation is approximate due to limitations identified during the quality control review.

UJ Quantitation is approximate due to limitations identified in the quality control review.

R Value is rejected.

CERCLIS SITE NAME: _____

CASE NO. _____, SDG NO. _____

Sample Location										
Sample Number										
Traffic Report Number										
Remarks										
Sampling Date										
Dilution factor										
Percent Solids										
Semi-Volatile Compound										
Phenol										
bis (2-Chloroethyl) ether										
2-Chlorophenol										
1,3-Dichlorobenzene										
1,4-Dichlorobenzene										
Benzyl Alcohol										
1,2-Dichlorobenzene										
2-Methylphenol										
bis (2-Chloroisopropyl) ether										
4-Methylphenol										
N-Nitroso-di-n-propylamine										
Hexachloroethane										
Nitrobenzene										
Isophorone										
2-Nitrophenol										
2,4-Dimethylphenol										
Benzoic acid										
bis (2-Chloroethoxy) methane										
2,4-Dichlorophenol										
1,2,4-Trichlorobenzene										
Naphthalene										
4-Chloroaniline										
Hexachlorobutadiene										
4-Chloro-3-methylphenol										
2-Methylnaphthalene										
Hexachlorocyclopentadiene										
2,4,6-Trichlorophenol										
2,4,5-Trichlorophenol										
2-Chloronaphthalene										
2-Nitroaniline										
Dimethylphthalate										
Acenaphthylene										
2,6-Dinitrotoluene										

Sample Quantitation Limits are reported on a dry weight basis.

UJ Quantitation limit is approximated due to limitations identified in the quality control review.

R Value is rejected.

CERCLIS SITE NAME: _____

CASE NO. _____, SDG NO. _____

Sample Location										
Sample Number										
Traffic Report Number										
Remarks										
Sampling Date										
Dilution Factor										
Percent Solids										
Semi-Volatile Compound										
3-Nitroaniline										
Acenaphthene										
2,4-Dinitrophenol										
4-Nitrophenol										
Dibenzofuran										
2,4-Dinitrotoluene										
Diethylphthalate										
4-Chlorophenyl-phenylether										
Fluorene										
4-Nitroaniline										
4,6-Dinitro-2-methylphenol										
N-Nitrosodiphenylamine										
4-Bromophenyl-phenylether										
Hexachlorobenzene										
Pentachlorophenol										
Phenanthrene										
Anthracene										
Di-n-butylphthalate										
Fluoranthene										
Pyrene										
Butylbenzylphthalate										
3,3'-Dichlorobenzidine										
Benzo(a)anthracene										
Chrysene										
bis(2-Ethylhexyl)phthalate										
Di-n-octyl phthalate										
Benzo(b)fluoranthene										
Benzo(k)fluoranthene										
Benzo(a)pyrene										
Indeno (1,2,3-cd)pyrene										
Dibenz(a,h)anthracene										
Benzo(g,h,i)perylene										

Sample Quantitation Limits are reported on dry weight basis.

UJ Quantitation Limits are approximate due to limitations identified during the quality control review.

R Value is rejected.

CERCLIS SITE NAME: _____
 CASE NO. _____, SDG NO. _____

Sample Location										
Sample Number										
Traffic Report Number										
Remarks										
Sampling Date										
Dilution Factor										
Percent Solids										
Pesticide/PCB Compound										
alpha-BHC										
beta-BHC										
delta-BHC										
gamma-BHC (Lindane)										
Heptachlor										
Aldrin										
Heptachlor epoxide										
Endosulfan I										
Dieldrin										
4,4'-DDE										
Endrin										
Endosulfan II										
4,4'-DDD										
Endosulfan sulfate										
4,4'-DDT										
Methoxychlor										
Endrin ketone										
alpha-Chlordane										
gamma-Chlordane										
Toxaphene										
Aroclor-1016										
Aroclor-1221										
Aroclor-1232										
Aroclor-1242										
Aroclor-1248										
Aroclor-1254										
Aroclor-1260										

Sample Quantitation Limits are reported on dry weight basis.
 UJ Quantitation Limits are approximate due to limitations identified during the quality control review.

APPENDIX II

LISTING OF COMMON POLLUTANTS GENERATED BY SEVEN INDUSTRIES

Appendix II identifies seven industries that generate waste which contains pollutants that are known to pose human and environmental hazards. This appendix is intended to aid the reader in three ways:

- o To assist in the identification of target compounds and potential exposure pathways.
- o To predict associated contaminants that potentially yield interferences.
- o To assist in early identification of sites that contain high levels of compounds that may not be included as target analytes for routinely available methods.

The data for these tables were obtained by searching the USEPA Toxic Release Inventory System using the Standard Industrial Classification (SIC) codes listed below:

<u>Industry</u>	<u>SIC Code</u>
1 Battery Recycling	3691, 3692
2 Munitions/Explosives	2892
3 Pesticides Manufacturing	2842, 2879
4 Electroplating	3471
5 Wood Preservatives	2491
6 Leather Tanning	3111
7 Petroleum Refining	2911

The appendix consists of seven tables and depicts the pollutants associated with each of the seven industries, the CAS number of each pollutant, and the matrices where each pollutant has been found. The list is not inclusive of all pollutants or industrial sources. The seven industries were selected based on the recommendation of the Risk Assessment Subgroup of the Data Useability Workgroup because of the frequency of occurrence of the pollutants produced by those industries in Superfund sites.

Appendix II
LISTING OF COMMON POLLUTANTS
GENERATED BY SEVEN INDUSTRIES
INDUSTRY 1: BATTERY RECYCLING

Rank ^a	Compound	CAS Number	Air	Water	Soil	Other ^b
1	LEAD	7439921	Y	Y	Y	Y
2	SODIUM SULFATE (SOLUTION)	7757826		Y		
3	SODIUM HYDROXIDE (SOLUTION)	1310732	Y	Y		Y
4	SULFURIC ACID	7664939	Y	Y		Y
5	AMMONIUM SULFATE (SOLUTION)	7783202		Y		
6	MANGANESE	7439965	Y	Y	Y	Y
7	1,1,1-TRICHLOROETHANE	71556	Y	Y		Y
8	METHANOL	67561	Y	Y		Y
9	FREON 113	76131	Y			Y
10	TRICHLOROETHYLENE	79016	Y	Y		Y
11	TOLUENE	108883	Y			Y
12	ZINC	7440666		Y	Y	Y
13	AMMONIA	7664417	Y	Y		Y
14	CADMIUM	7440439	Y	Y	Y	Y
15	ANTIMONY	7440360	Y	Y		Y
16	BARIUM	7440393	Y	Y		Y
17	NICKEL	7440020	Y	Y	Y	Y
18	FORMALDEHYDE	50000	Y			Y
19	ACETONE	67641	Y			
20	XYLENE (MIXED ISOMERS)	1330207	Y			
21	TETRACHLOROETHYLENE	127184	Y			Y
22	DICHLOROMETHANE	75092	Y			Y
23	PHENOL	108952	Y			Y
24	MERCURY	7439976	Y	Y		Y
25	N-BUTYL ALCOHOL	71363	Y			
26	METHYL ETHYL KETONE	78933	Y			Y
27	METHYL ISOBUTYL KETONE	108101	Y			
28	HYDROCHLORIC ACID	7647010	Y	Y		
29	NITRIC ACID	7697372	Y			Y
30	1,1,1-TRICHLOROETHANE (METHYL CHLOROFORM)	71556	Y			
31	COBALT	7440484	Y		Y	Y
32	ARSENIC	7440382	Y			Y
33	COPPER	7440508		Y		Y
34	SILVER	7440224	Y	Y		Y
35	ACETONITRILE	75058	Y			

^a Rank = Order of Frequency of Occurrence

^b Other = Other Matrices (Biota, Hazardous Waste, Sludge, etc.)

Appendix II
LISTING OF COMMON POLLUTANTS
GENERATED BY SEVEN INDUSTRIES
INDUSTRY 2: MUNITIONS/EXPLOSIVES

Rank ^a	Compound	CAS Number	Air	Water	Soil	Other ^b
1	ACETONE	67641	Y	Y	Y	Y
2	NITRIC ACID	7697372	Y	Y	Y	Y
3	AMMONIUM NITRATE (SOLUTION)	6484522	Y	Y	Y	Y
4	PENTACHLOROPHENOL	87865			Y	
5	SODIUM SULFATE (SOLUTION)	7757826		Y		
6	AMMONIA	7664417	Y	Y	Y	
7	SULFURIC ACID	7664939	Y	Y	Y	Y
8	METHYL ETHYL KETONE	78933	Y			Y
9	CYCLOHEXANE	110827	Y			Y
10	CHLORINE	7782505	Y	Y		
11	NITROGLYCERIN	55630	Y	Y	Y	Y
12	DICHLOROMETHANE	75092	Y			Y
13	CALCIUM CYANAMIDE	156627	Y		Y	
14	LEAD	7439921	Y	Y	Y	Y
15	ETHYLENE GLYCOL	107211	Y	Y	Y	
16	N-BUTYL ALCOHOL	71363	Y			
17	TERT-BUTYL ALCOHOL	75650	Y			Y
18	M-XYLENE	108383	Y			
19	METHANOL	67561	Y	Y		Y
20	ASBESTOS (FRIABLE)	1332214				Y
21	1,1,1-TRICHLOROETHANE	71556	Y			Y
22	POLYCHLORINATED BIPHENYLS	1336363				Y
23	COPPER	7440508	Y	Y	Y	Y
24	ALUMINUM	7429905	Y	Y	Y	Y
25	2,4-DINITROTOLUENE	121142	Y	Y		
26	GLYCOL ETHERS	79141	Y			
27	BENZENE	71432	Y	Y	Y	Y
28	BIS(2-ETHYLHEXYL) ADIPATE	103231		Y		
29	ZINC	7440666	Y			
30	DIBUTYL PHTHALATE	84742	Y	Y	Y	
31	SODIUM HYDROXIDE (SOLUTION)	1310732	Y		Y	
32	DIETHYL PHTHALATE	84662		Y		

^a Rank = Order of Frequency of Occurrence

^b Other = Other Matrices (Biota, Hazardous Waste, Sludge, etc.)

Appendix II
LISTING OF COMMON POLLUTANTS
GENERATED BY SEVEN INDUSTRIES
INDUSTRY 3: PESTICIDES MANUFACTURING

Rank ^a	Compound	CAS Number	Air	Water	Soil	Other ^b
1	SODIUM SULFATE (SOLUTION)	7757826		Y	Y	Y
2	AMMONIA	7664417	Y	Y	Y	Y
3	TOLUENE	108883	Y	Y	Y	Y
4	SODIUM HYDROXIDE (SOLUTION)	1310732	Y	Y	Y	Y
5	TITANIUM TETRACHLORIDE	7550450				Y
6	METHANOL	67561	Y	Y	Y	Y
7	DICHLOROMETHANE	75092	Y	Y	Y	Y
8	XYLENE (MIXED ISOMERS)	1330207	Y	Y	Y	Y
9	CHLOROBENZENE	108907	Y	Y		Y
10	HYDROCHLORIC ACID	7647010	Y	Y	Y	Y
11	CHLOROPHENOLS	106489	Y	Y	Y	Y
12	STYRENE	100425	Y	Y		Y
13	ACRYLONITRILE	107131	Y	Y		Y
14	FORMALDEHYDE	50000	Y	Y	Y	Y
15	CARBON TETRACHLORIDE	56235	Y	Y	Y	Y
16	CHLOROTHALONIL	1897456	Y	Y		Y
17	1,2-DICHLOROETHANE	107062	Y	Y	Y	Y
18	ACETONE	67641	Y	Y	Y	Y
19	HEXACHLOROBENZENE	118741	Y	Y		Y
20	1,1,1-TRICHLOROETHANE	71556	Y	Y		Y
21	ETHYLENE GLYCOL	107211	Y	Y	Y	Y
22	GLYCOL ETHERS	79141	Y	Y	Y	Y
23	1,3-BUTADIENE	106990	Y	Y		Y
24	CHLOROMETHANE	74873	Y			Y
25	CAPTAN	133062	Y		Y	Y
26	TETRACHLOROETHYLENE	127184	Y	Y	Y	Y
27	CHLORINE	7782505	Y	Y	Y	Y
28	CARBARYL	63252	Y	Y		Y
29	COPPER	7440508	Y	Y	Y	Y
30	PARATHION	56382	Y			Y
31	ZINEB	12122677				Y
32	PYRIDINE	110861	Y	Y		
33	AMMONIUM NITRATE (SOLUTION)	6484522		Y		
34	PHOSPHORIC ACID	7664382	Y	Y	Y	Y
35	CARBON DISULFIDE	75150	Y		Y	
36	1,2,4-TRICHLOROBENZENE	120821	Y		Y	Y
37	SULFURIC ACID	7664939	Y	Y	Y	Y
38	MALEIC ANHYDRIDE	108316	Y		Y	Y
39	ETHYLBENZENE	100414	Y	Y		Y
40	2,4-D	94757	Y	Y	Y	Y
41	BROMOMETHANE	74839	Y			
42	SEC-BUTYL ALCOHOL	78922	Y	Y		

^a Rank = Order of Frequency of Occurrence

^b Other = Other Matrices (Biota, Hazardous Waste, Sludge, etc.)

Appendix II
LISTING OF COMMON POLLUTANTS
GENERATED BY SEVEN INDUSTRIES
INDUSTRY 3: PESTICIDES MANUFACTURING

Rank ^a	Compound	CAS Number	Air	Water	Soil	Other ^b
43	LEAD	7439921				Y
44	CUMENE	98828	Y	Y		Y
45	M-XYLENE	108383	Y			Y
46	ASBESTOS (FRIABLE)	1332214			Y	Y
47	Freon 113	76131	Y			Y
48	DICHLOROBENZENE (MIXED ISOMERS)	25321226	Y		Y	Y
49	CYCLOHEXANE	110827	Y		Y	Y
50	2,4-DICHLOROPHENOL	120832			Y	Y
51	1,4-DICHLOROBENZENE	106467	Y			
52	DICHLOROBROMOMETHANE	75274	Y			Y
53	TRIFLURALIN	1582098	Y	Y	Y	Y
54	1,2,4-TRIMETHYLBENZENE	95636	Y	Y		Y
55	METHYL ISOBUTYL KETONE	108101	Y	Y		Y
56	1,4-DIOXANE	123911	Y			Y
57	NITRIC ACID	7697372	Y	Y		Y
58	N-BUTYL ALCOHOL	71363	Y	Y		Y
59	FLUOMETURON	2164172	Y	Y		Y
60	2-METHOXYETHANOL	109864				Y
61	BIS(2-ETHYLHEXYL) ADIPATE	103231	Y			Y
62	PHENOL	108952	Y	Y		Y
63	ACRYLIC ACID	79107	Y		Y	Y
64	QUINTOZENE	82688	Y			Y
65	ALUMINUM	1344281	Y	Y	Y	Y
66	BENZOYL PEROXIDE	94360			Y	Y
67	O-XYLENE	95476	Y			
68	CHROMIUM	7440473	Y	Y		Y
69	2-PHENYLPHENOL	90437	Y	Y		
70	HYDROGEN CYANIDE	74908	Y	Y		Y
71	ZINC	7440666	Y	Y	Y	Y
72	HEXACHLOROCYCLOPENTADIENE	77474				Y
73	DICOFOL	115322	Y			Y
74	BIPHENYL	92524	Y	Y		Y
75	4-NITROPHENOL	100027	Y		Y	Y
76	METHYL ETHYL KETONE	78933	Y			Y
77	TRICHLOROETHYLENE	79016	Y		Y	
78	M-CRESOL	108394	Y			Y
79	TETRACHLORVINPHOS	961115				Y
80	DI(2-ETHYLHEXYL) PHTHALATE (DEHP)	117817		Y		Y
81	TEREPHTHALIC ACID	100210	Y			Y
82	DICHLORVOS	62737	Y			Y
83	MANEB	12427382	Y			Y
84	P-XYLENE	106423	Y			Y

^a Rank = Order of Frequency of Occurrence

^b Other = Other Matrices (Biota, Hazardous Waste, Sludge, etc.)

Appendix II
LISTING OF COMMON POLLUTANTS
GENERATED BY SEVEN INDUSTRIES
INDUSTRY 3: PESTICIDES MANUFACTURING

Rank ^a	Compound	CAS Number	Air	Water	Soil	Other ^b
85	METHYLENE BROMIDE	74953	Y			
86	CHLORAMBEN	133904	Y			Y
87	BENZENE	71432	Y			Y
88	HYDROGEN FLUORIDE	7664393	Y	Y		
89	ETHYLENE	74851	Y			
90	C.I. ACID BLUE 9, DISODIUM SALT	3844459		Y		Y
91	DIMETHYL SULFATE	77781	Y			
92	ISOPROPYL ALCOHOL	67630	Y			
93	HYDRAZINE	302012	Y	Y		
94	VINYL CHLORIDE	75014	Y			
95	METHYLENEBIS(PHENYLISOCYANATE)	101688	Y			Y
96	EPICHLOROHYDRIN	106898	Y			
97	PROPYLENE	115071	Y			
98	NITRILOTRIACETIC ACID	139139		Y		
99	ARSENIC	7440382	Y			Y
100	NAPHTHALENE	91203	Y	Y		
101	VINYLDENE CHLORIDE	75354	Y			
102	TRICHLORFON	52686	Y			Y
103	DIBUTYL PHTHALATE	84742		Y		
104	ANILINE	62533	Y	Y		
105	METHOXYCHLOR	72435	Y	Y		Y
106	DIETHANOLAMINE	111422	Y	Y	Y	Y
107	NITROBENZENE	98953	Y	Y		
108	CYANIDE COMPOUNDS	57125	Y	Y		
109	AMMONIUM SULFATE (SOLUTION)	7783202		Y		
110	LINDANE	58899	Y			Y
111	POLYCHLORINATED BIPHENYLS	1336363	Y			Y
112	PROPYLENE OXIDE	75569	Y			
113	2,4-DINITROPHENOL	51285	Y	Y		Y
114	PHOSGENE	75445	Y			
115	HEXACHLOROETHANE	67721	Y			
116	CADMIUM	7440439				Y
117	ETHYLENE OXIDE	75218	Y			
118	BENZYL CHLORIDE	100447	Y	Y		
119	4,6-DINITRO-O-CRESOL	534521	Y			
120	CHLOROBENZILATE	510156	Y			

^a Rank = Order of Frequency of Occurrence

^b Other = Other Matrices (Biota, Hazardous Waste, Sludge, etc.)

Appendix II
LISTING OF COMMON POLLUTANTS
GENERATED BY SEVEN INDUSTRIES
INDUSTRY 4: ELECTROPLATING

Rank	Compound	CAS Number	Air	Water	Soil	Other ^b
1	SULFURIC ACID	7664939	Y	Y	Y	Y
2	HYDROCHLORIC ACID	7647010	Y	Y	Y	Y
3	SODIUM HYDROXIDE (SOLUTION)	1310732	Y	Y	Y	Y
4	1,1,1-TRICHLOROETHANE	71556	Y	Y	Y	Y
5	SODIUM SULFATE (SOLUTION)	7757826	Y	Y		Y
6	NITRIC ACID	7697372	Y	Y	Y	Y
7	DICHLOROMETHANE	75092	Y	Y		Y
8	NICKEL	7440020	Y	Y	Y	Y
9	TRICHLOROETHYLENE	79016	Y	Y		Y
10	CHROMIUM	7440473	Y	Y	Y	Y
11	TETRACHLOROETHYLENE	127184	Y	Y	Y	Y
12	METHYL ETHYL KETONE	78933	Y	Y		Y
13	ZINC	7440666	Y	Y	Y	Y
14	FREON 113	76131	Y		Y	Y
15	ALUMINUM	7429905	Y	Y	Y	Y
16	COPPER	7440508	Y	Y	Y	Y
17	PHOSPHORIC ACID	7664382	Y	Y	Y	Y
18	TOLUENE	108883	Y	Y	Y	Y
19	LEAD	7439921	Y	Y	Y	Y
20	XYLENE (MIXED ISOMERS)	1330207	Y			Y
21	ACETONE	67641	Y	Y		Y
22	CADMIUM	7440439		Y	Y	Y
23	ETHYLBENZENE	100414	Y			Y
24	ETHYLENE GLYCOL	107211	Y	Y	Y	Y
25	CYANIDE COMPOUNDS	57125	Y	Y	Y	Y
26	AMMONIA	7664417	Y	Y		Y
27	FORMALDEHYDE	50000	Y	Y		Y
28	GLYCOL ETHERS	79141	Y	Y		Y
29	CHLORINE	7782505	Y	Y		Y
30	METHANOL	67561	Y	Y		Y
31	ETHYLENE OXIDE	75218	Y			
32	METHYL ISOBUTYL KETONE	108101	Y			Y
33	2-METHOXYETHANOL	109864	Y			Y
34	HYDROGEN FLUORIDE	7664393	Y	Y		Y
35	PHENOL	108952	Y			Y
36	1,2-DICHLOROBENZENE	95501	Y			Y
37	N-BUTYL ALCOHOL	71363	Y			Y
38	TERT-BUTYL ALCOHOL	75650	Y			
39	BARIUM	7440393				Y
40	VINYLDENE CHLORIDE	75354	Y			
41	2-ETHOXYETHANOL	110805	Y			Y
42	ISOPROPYL ALCOHOL	67630	Y			

^a Rank = Order of Frequency of Occurrence

^b Other = Other Matrices (Biota, Hazardous Waste, Sludge, etc.)

Appendix II
LISTING OF COMMON POLLUTANTS
GENERATED BY SEVEN INDUSTRIES
INDUSTRY 4: ELECTROPLATING

Rank ^a	Compound	CAS Number	Air	Water	Soil	Other ^b
43	MANGANESE	7439965	Y			Y
44	HYDROGEN CYANIDE	74908				Y
45	STYRENE	100425	Y			
46	TETRACHLORVINPHOS	961115	Y			
47	MELAMINE	108781				Y
48	N-DIOCTYL PHTHALATE	117840				Y
49	1,4-DIOXANE	123911	Y			
50	COBALT	7440484		Y		
51	NAPHTHALENE	91203				Y
52	AMMONIUM SULFATE (SOLUTION)	7783202				Y
53	SILVER	7440224		Y		Y
54	PROPYLENE	115071	Y			Y

^a Rank = Order of Frequency of Occurrence

^b Other = Other Matrices (Biota, Hazardous Waste, Sludge, etc.)

Appendix II
LISTING OF COMMON POLLUTANTS
GENERATED BY SEVEN INDUSTRIES
INDUSTRY 5: WOOD PRESERVATION

Rank ^a	Compound	CAS Number	Air	Water	Soil	Other ^b
1	CHROMIUM	7440473	Y	Y	Y	Y
2	NAPHTHALENE	91203	Y	Y	Y	Y
3	AMMONIA	7664417	Y		Y	Y
4	PENTACHLOROPHENOL	87865	Y	Y	Y	Y
5	DIBENZOFURAN	132649	Y	Y	Y	Y
6	ANTHRACENE	120127	Y	Y	Y	Y
7	COPPER	7440508	Y	Y	Y	Y
8	ARSENIC	7440382	Y	Y	Y	Y
9	FORMALDEHYDE	50000	Y			
10	BIPHENYL	92524	Y	Y	Y	Y
11	BENZENE	71432	Y	Y		
12	DICHLOROMETHANE	75092	Y			
13	1,1,1-TRICHLOROETHANE	71556	Y			Y
14	AMMONIUM SULFATE (SOLUTION)	7783202		Y	Y	
15	QUINOLINE	91225	Y	Y	Y	Y
16	PHENOL	108952	Y	Y		
17	ZINC	7440666	Y	Y		Y
18	PHOSPHORIC ACID	7664382	Y			
19	O-CRESOL	95487	Y	Y		
20	HYDROCHLORIC ACID	7647010	Y			
21	M-CRESOL	108394	Y	Y		

^a Rank = Order of Frequency of Occurrence

^b Other = Other Matrices (Biota, Hazardous Waste, Sludge, etc.)

Appendix II
LISTING OF COMMON POLLUTANTS
GENERATED BY SEVEN INDUSTRIES
INDUSTRY 6: LEATHER TANNING

Rank	Compound	CAS Number	Air	Water	Soil	Other ^b
1	AMMONIUM SULFATE (SOLUTION)	7783202	Y	Y	Y	Y
2	SULFURIC ACID	7664939	Y	Y	Y	Y
3	SODIUM HYDROXIDE (SOLUTION)	1310732		Y		Y
4	AMMONIA	7664417	Y	Y	Y	Y
5	TOLUENE	108883	Y			Y
6	SODIUM SULFATE (SOLUTION)	7757826		Y		Y
7	METHYL ETHYL KETONE	78933	Y			Y
8	XYLENE (MIXED ISOMERS)	1330207	Y	Y		Y
9	CHROMIUM	7440473	Y	Y	Y	Y
10	GLYCOL ETHERS	79141	Y	Y		Y
11	METHYL ISOBUTYL KETONE	108101	Y	Y		Y
12	2-METHOXYETHANOL	109864	Y	Y		Y
13	ACETONE	67641	Y	Y		Y
14	2-ETHOXYETHANOL	110805	Y	Y		Y
15	N-BUTYL ALCOHOL	71363	Y	Y		Y
16	TETRACHLOROETHYLENE	127184	Y	Y		Y
17	CYCLOHEXANE	110827	Y			Y
18	AMMONIUM NITRATE (SOLUTION)	6484522			Y	Y
19	MANGANESE	7439965		Y	Y	Y
20	1,1,1-TRICHLOROETHANE	71556	Y			
21	DICHLOROMETHANE	75092	Y			
22	DIETHANOLAMINE	111422	Y			Y
23	METHANOL	67561	Y	Y		
24	ISOPROPYL ALCOHOL	67630	Y			Y
25	PHOSPHORIC ACID	7664382		Y		
26	ETHYLENE GLYCOL	107211	Y			
27	FREON 113	76131	Y			
28	PHENOL	108952		Y		
29	ETHYL ACRYLATE	140885	Y			

^a Rank = Order of Frequency of Occurrence

^b Other = Other Matrices (Biota, Hazardous Waste, Sludge, etc.)

Appendix II
LISTING OF COMMON POLLUTANTS
GENERATED BY SEVEN INDUSTRIES
INDUSTRY 7: PETROLEUM REFINING

Rank ^a	Compound	CAS Number	Air	Water	Soil	Other ^b
1	SODIUM SULFATE (SOLUTION)	7757826	Y	Y	Y	Y
2	ALUMINUM	7429905	Y	Y	Y	Y
3	AMMONIA	7664417	Y	Y	Y	Y
4	SODIUM HYDROXIDE (SOLUTION)	1310732	Y	Y	Y	Y
5	SULFURIC ACID	7664939	Y	Y	Y	Y
6	TOLUENE	108883	Y	Y	Y	Y
7	XYLENE (MIXED ISOMERS)	1330207	Y	Y	Y	Y
8	BENZENE	71432	Y	Y	Y	Y
9	METHYL ETHYL KETONE	78933	Y	Y	Y	Y
10	PROPYLENE	115071	Y	Y		Y
11	PHENOL	108952	Y	Y	Y	Y
12	DIETHANOLAMINE	111422	Y	Y	Y	Y
13	ETHYLENE	74851	Y	Y		Y
14	METHANOL	67561	Y	Y	Y	Y
15	CYCLOHEXANE	110827	Y	Y	Y	Y
16	1,2,4-TRIMETHYLBENZENE	95636	Y	Y	Y	Y
17	ETHYLBENZENE	100414	Y	Y	Y	Y
18	PHOSPHORIC ACID	7664382	Y	Y	Y	Y
19	CHROMIUM	7440473	Y	Y	Y	Y
20	METHYL TERT-BUTYL ETHER	1634044	Y	Y	Y	Y
21	ASBESTOS (FRIABLE)	1332214			Y	Y
22	P-XYLENE	106423	Y	Y	Y	Y
23	AMMONIUM SULFATE (SOLUTION)	7783202		Y		Y
24	M-XYLENE	108383	Y	Y	Y	Y
25	CUMENE	98828	Y	Y	Y	Y
26	ACETONE	67641	Y	Y	Y	
27	CRESOL (MIXED ISOMERS)	1319773	Y	Y	Y	Y
28	HYDROGEN FLUORIDE	7664393	Y	Y	Y	Y
29	O-XYLENE	95476	Y	Y	Y	Y
30	NAPHTHALENE	91203	Y	Y	Y	Y
31	NICKEL	7440020	Y	Y	Y	Y
32	CHLORINE	7782505	Y	Y		Y
33	LEAD	7439921	Y	Y	Y	Y
34	METHYL ISOBUTYL KETONE	108101	Y	Y		
35	ETHYLENE GLYCOL	107211	Y	Y	Y	Y
36	MOLYBDENUM TRIOXIDE	1313275	Y	Y	Y	Y
37	ZINC	7440666	Y	Y	Y	Y
38	HYDROCHLORIC ACID	7647010	Y	Y		Y
39	GLYCOL ETHERS	79141	Y	Y	Y	Y
40	BARIUM	7440393	Y	Y	Y	Y
41	COPPER	7440508	Y	Y	Y	Y
42	1,1,1-TRICHLOROETHANE	71556	Y	Y	Y	Y

^a Rank = Order of Frequency of Occurrence

^b Other = Other Matrices (Biota, Hazardous Waste, Sludge, etc.)

Appendix II
LISTING OF COMMON POLLUTANTS
GENERATED BY SEVEN INDUSTRIES
INDUSTRY 7: PETROLEUM REFINING

Rank ^a	Compound	CAS Number	Air	Water	Soil	Other ^b
43	ANTIMONY	7440360	Y	Y	Y	Y
44	1,3-BUTADIENE	106990	Y	Y		Y
45	N-BUTYL ALCOHOL	71363	Y			
46	FORMALDEHYDE	50000	Y	Y	Y	Y
47	EPICHLOROHYDRIN	106898	Y		Y	
48	COBALT	7440484	Y	Y	Y	Y
49	VANADIUM (FUME OR DUST)	7440622	Y		Y	Y
50	CUMENE HYDROPEROXIDE	80159	Y			
51	TERT-BUTYL ALCOHOL	75650	Y		Y	
52	4,4'-ISOPROPYLIDENEDIPHENOL	80057	Y		Y	
53	BUTYRALDEHYDE	123728	Y			
54	BIPHENYL	92524	Y	Y	Y	Y
55	CARBON TETRACHLORIDE	56235	Y	Y	Y	Y
56	STYRENE	100425	Y	Y	Y	Y
57	TRICHLOROETHYLENE	79016	Y	Y		
58	MANGANESE	7439965	Y	Y		Y
59	ETHYLENE OXIDE	75218	Y			
60	AMMONIUM NITRATE (SOLUTION)	6484522		Y		
61	CARBON DISULFIDE	75150	Y	Y		
62	1,2-DICHLOROETHANE	107062	Y	Y	Y	Y
63	POLYCHLORINATED BIPHENYLS	1336363				Y
64	PHOSPHORUS (YELLOW OR WHITE)	7723140				Y
65	QUINOLINE	91225	Y			
66	2-METHOXYETHANOL	109864	Y		Y	Y
67	1,2-DIBROMOETHANE	106934	Y	Y	Y	Y
68	TETRACHLOROETHYLENE	127184	Y	Y	Y	
69	ANTHRACENE	120127	Y	Y	Y	
70	2,4-DIMETHYLPHENOL	105679		Y	Y	
71	HYDROGEN CYANIDE	74908	Y	Y		
72	CHLOROMETHANE	74873	Y			
73	NITROBENZENE	98953		Y		
74	1,2-DICHLOROPROPANE	78875	Y	Y	Y	
75	CARBONYL SULFIDE	463581	Y	Y		
76	ACETONITRILE	75058	Y			
77	SILVER	7440224	Y	Y		Y
78	2-ETHOXYETHANOL	110805	Y			
79	THALLIUM	7440280		Y		Y
80	FREON 113	76131	Y			
81	SELENIUM	7782492	Y	Y	Y	Y
82	DICHLOROMETHANE	75092	Y			
83	MERCURY	7439976		Y	Y	Y
84	CADMIUM	7440439		Y	Y	Y

^a Rank = Order of Frequency of Occurrence

^b Other = Other Matrices (Biota, Hazardous Waste, Sludge, etc.)

Appendix II
LISTING OF COMMON POLLUTANTS
GENERATED BY SEVEN INDUSTRIES
INDUSTRY 7: PETROLEUM REFINING

Rank ^a	Compound	CAS Number	Air	Water	Soil	Other ^b
85	1,1,2-TRICHLOROETHANE	79005	Y	Y		
86	ARSENIC	7440382	Y	Y	Y	Y
87	CYANIDE COMPOUNDS	57125				Y
88	CHLORINE DIOXIDE	10049044	Y			
89	ACRYLIC ACID	79107	Y			
90	1,3-DICHLOROPROPYLENE	542756	Y			
91	1,2-BUTYLENE OXIDE	106887	Y			
92	CHLOROBENZENE	108907				Y
93	1,4-DIOXANE	123911	Y			
94	DI(2-ETHYLHEXYL) PHTHALATE (DEHP)	117817			Y	
95	BERYLLIUM	7440417	Y			
96	CHLOROFORM	67663				Y

^a Rank = Order of Frequency of Occurrence

^b Other = Other Matrices (Biota, Hazardous Waste, Sludge, etc.)

APPENDIX III

LISTING OF ANALYTES, METHODS, AND DETECTION OR QUANTITATION LIMITS FOR POLLUTANTS OF CONCERN TO RISK ASSESSMENT

The purpose of this appendix is to familiarize the reader with the variety of EPA methods that are available for analysis of pollutants of concern in risk assessment. The appendix facilitates appropriate method selection for pollutants in the matrix of interest.

Appendix III consists first of a summary of definitions of commonly used detection limits and quantitation limits. Tables I, II, and III depict detection limit estimates achievable for 33 organic and inorganic pollutants of potential concern to risk assessment in air, soil, and water matrices respectively. The detection limits listed herein are provided for guidance and may not always be achievable. Specific quantitation limits are highly matrix-dependent.

Table IV provides a summary of each method of analysis for these pollutants. The 33 pollutants listed were chosen because they are highly toxic and/or have reported cancer risks, and occur at a frequency of greater than 2% in 141 National Priorities List (NPL) sites.*

Tables V-A and V-B provide an additional comparison of analytical methodologies for selected organic compound classes and inorganic analytes including method detection ranges and the applicable analytical system and preparation procedures.

*Source: CLP Statistical Database (STAT).

APPENDIX III GLOSSARY

Instrumentation

CVAA =	Cold Vapor Atomic Absorption
ECD =	Electron Capture Detector
ELCD =	Electrolytic Conductivity Detector
FID =	Flame Ionization Detector
FLAME =	Flame Atomic Absorption
Fluor =	Fluorescence
FPD =	Flame Photometric Detector
GC =	Gas Chromatography
GC-MS =	Gas Chromatography-Mass Spectrometry
GFAA =	Graphite Furnace Atomic Absorption
HPLC =	High Pressure Liquid Chromatography
HYDAA =	Hydride Atomic Absorption
ICP =	Inductively Coupled Plasma
LC =	Liquid Chromatography
MS =	Mass Spectrometry
NPD =	Nitrogen/Phosphorus Detector
PID =	Photoionization Detector
UV =	Ultraviolet

Quantitation/Detection Limits

CRDL =	Contract Required Detection Limit
CRQL =	Contract Required Quantitation Limit
EDL =	Estimated Detection Limit
MDL =	Method Detection Limit
NA =	Not Available
PQL =	Practical Quantitation Limit

Methods/Sample Preparation

CLP SOW	Contract Laboratory Program Statement of Work
DI	Direct injection of liquid samples; solid samples mixed, then injected
EPA	Guidelines Establishing Test Procedures for the Analysis of Pollutants under the Clean Water Act
EPA AIR	Compendium of Methods for the Determination of Toxic Organic Compounds in Ambient Air
EPA DW	Methods for the Determination of Organic Compounds in Drinking Water
EP Extracts	Extraction procedure toxicity test extracts
MCAWW	Methods for Chemical Analysis of Water and Wastes
QTM	Quick Turnaround Method
SDDC	Silver diethyldithiocarbamate
SMEWW	Standard Methods for the Examination of Water and Wastewater
SW846	Test Methods for Evaluating Solid Waste
TO	Toxic organic
XTN	Extraction methods that could be used include 3510, 3520, 3540 and 3550
3510	Separatory Funnel Extraction of Liquid Samples
3540	Soxhlet Extraction of Solid Samples
3550	Sonication Extraction of Solid Samples
5030	Purge and Trap

APPENDIX III

TABLE I

METHODS AND DETECTION/QUANTITATION LIMITS FOR SPECIFIED ANALYTES OF CONCERN TO RISK ASSESSMENT

AIR MATRICES

ANALYTE/ COMMON NAME CAS NUMBER	METHOD REFERENCE/TITLE OF METHOD	INSTRUMENT- ATION	QUANTITATION/ DETECTION LIMIT
<u>ORGANOCHLORINE PESTICIDES/AROCLORS</u>			
Chlordane 57749	EPA AIR METHOD TO-4 "Method for the Determination of Organochlorine Pesticides and Polychlorinated Biphenyls in Ambient Air"	GC-ECD	EDL = > 1.0 ng/m ³
p,p'-DDE 72559	EPA AIR METHOD TO-4 "Method for the Determination of Organochlorine Pesticides and Polychlorinated Biphenyls in Ambient Air"	GC-ECD	EDL = > 1.0 ng/m ³
p,p'-DDT 50293	EPA AIR METHOD TO-4 "Method for the Determination of Organochlorine Pesticides and Polychlorinated Biphenyls in Ambient Air"	GC-ECD	EDL = > 1.0 ng/m ³
<u>VOLATILE COMPOUNDS</u>			
169 1,1-dichloroethane 75343	EPA AIR METHOD TO-14 "The Determination of Volatile Organic Compounds (VOCs) in Ambient Air Using SUMMA Passivated Canister Sampling and Gas Chromatographic Analysis"	GC-MS	NA
1,1,2-trichloroethane 79005	EPA AIR METHOD TO-14 "The Determination of Volatile Organic Compounds (VOCs) in Ambient Air Using SUMMA Passivated Canister Sampling and Gas Chromatographic Analysis"	GC-MS	NA
1,1,2,2-tetrachloroethane 79345	EPA AIR METHOD TO-14 "The Determination of Volatile Organic Compounds (VOCs) in Ambient Air Using SUMMA Passivated Canister Sampling and Gas Chromatographic Analysis"	GC-MS	NA
1,2-dichloroethane 107062	EPA AIR METHOD TO-2 "Method for the Determination of Volatile Organic Compounds in Ambient Air by Carbon Molecular Sieve Adsorption and Gas Chromatography-Mass Spectrometry (GC-MS)"	GC-MS	NA
1,2-dichloropropane 78875	EPA AIR METHOD TO-14 "The Determination of Volatile Organic Compounds (VOCs) in Ambient Air Using SUMMA Passivated Canister Sampling and Gas Chromatographic Analysis"	GC-MS	NA

APPENDIX III

TABLE I

METHODS AND DETECTION/QUANTITATION LIMITS FOR SPECIFIED ANALYTES OF CONCERN TO RISK ASSESSMENT

AIR MATRICES

ANALYTE/ COMMON NAME CAS NUMBER	METHOD REFERENCE/TITLE OF METHOD	INSTRUMENT- ATION	QUANTITATION/ DETECTION LIMIT
1,4-dichlorobenzene 106467	EPA AIR METHOD TO-1 "Method for the Determination of Volatile Organic Compounds in Ambient Air Using Tenax Adsorption and Gas Chromatography-Mass Spectrometry (GC-MS)"	GC-MS	NA
	EPA AIR METHOD TO-14 "The Determination of Volatile Organic Compounds (VOCs) in Ambient Air Using SUMMA Passivated Canister Sampling and Gas Chromatographic Analysis"	GC-MS	NA
	EPA AIR METHOD TO-3 "Method for the Determination of Volatile Organic Compounds in Ambient Air Using Cryogenic Preconcentration Techniques and Gas Chromatography with Flame Ionization and Electron Capture Detection"	GC-FID/ GC-ECD	NA
Benzene 71432	EPA AIR METHOD TO-1 "Method for the Determination of Volatile Organic Compounds in Ambient Air Using Tenax Adsorption and Gas Chromatography-Mass Spectrometry (GC-MS)"	GC-MS	NA
	EPA AIR METHOD TO-14 "The Determination of Volatile Organic Compounds (VOCs) in Ambient Air Using SUMMA Passivated Canister Sampling and Gas Chromatographic Analysis"	GC-MS	EDL = 6.0 mg/m ³
	EPA AIR METHOD TO-2 "Method for the Determination of Volatile Organic Compounds in Ambient Air by Carbon Molecular Sieve Adsorption and Gas Chromatography-Mass Spectrometry (GC-MS)"	GC-MS	NA
	EPA AIR METHOD TO-3 "Method for the Determination of Volatile Organic Compounds in Ambient Air Using Cryogenic Preconcentration Techniques and Gas Chromatography with Flame Ionization and Electron Capture Detection"	GC-FID/ GC-ECD	NA
Chloroethene (Vinyl Chloride) 75014	EPA AIR METHOD TO-14 "The Determination of Volatile Organic Compounds (VOCs) in Ambient Air Using SUMMA Passivated Canister Sampling and Gas Chromatographic Analysis"	GC-MS	NA
Dichloromethane (Methylene Chloride) 75092	EPA AIR METHOD TO-14 "The Determination of Volatile Organic Compounds (VOCs) in Ambient Air Using SUMMA Passivated Canister Sampling and Gas Chromatographic Analysis"	GC-MS	NA

APPENDIX III
TABLE I
METHODS AND DETECTION/QUANTITATION LIMITS FOR SPECIFIED ANALYTES OF CONCERN TO RISK ASSESSMENT
AIR MATRICES

ANALYTE/ COMMON NAME CAS NUMBER	METHOD REFERENCE/TITLE OF METHOD	INSTRUMENT- ATION	QUANTITATION/ DETECTION LIMIT
Dichloromethane (Methylene Chloride) 75092	EPA AIR METHOD TO-2 "Method for the Determination of Volatile Organic Compounds in Ambient Air by Carbon Molecular Sieve Adsorption and Gas Chromatography-Mass Spectrometry (GC-MS)"	GC-MS	NA
	EPA AIR METHOD TO-3 "Method for the Determination of Volatile Organic Compounds in Ambient Air Using Cryogenic Preconcentration Techniques and Gas Chromatography with Flame Ionization and Electron Capture Detection"	GC-FID/ GC-ECD	NA
Ethenyl Benzene (Styrene) 100425	EPA AIR METHOD TO-14 "The Determination of Volatile Organic Compounds (VOCs) in Ambient Air Using SUMMA Passivated Canister Sampling and Gas Chromatographic Analysis"	GC-MS	EDL = 10 mg/m ³
	EPA AIR METHOD TO-3 "Method for the Determination of Volatile Organic Compounds in Ambient Air Using Cryogenic Preconcentration Techniques and Gas Chromatography with Flame Ionization and Electron Capture Detection"	GC-FID/ GC-ECD	NA
Tetrachloroethene (Tetrachloroethylene) 127184	EPA AIR METHOD TO-1 "Method for the Determination of Volatile Organic Compounds in Ambient Air Using Tenax Adsorption and Gas Chromatography-Mass Spectrometry (GC-MS)"	GC-MS	NA
	EPA AIR METHOD TO-14 "The Determination of Volatile Organic Compounds (VOCs) in Ambient Air Using SUMMA Passivated Canister Sampling and Gas Chromatographic Analysis"	GC-MS	EDL = 50 mg/m ³
	EPA AIR METHOD TO-3 "Method for the Determination of Volatile Organic Compounds in Ambient Air Using Cryogenic Preconcentration Techniques and Gas Chromatography with Flame Ionization and Electron Capture Detection"	GC-FID/ GC-ECD	NA
Tetrachloromethane (Carbon Tetrachloride) 56235	EPA AIR METHOD TO-14 "The Determination of Volatile Organic Compounds (VOCs) in Ambient Air Using SUMMA Passivated Canister Sampling and Gas Chromatographic Analysis"	GC-MS	EDL = 2000 mg/m ³

APPENDIX III

TABLE I

METHODS AND DETECTION/QUANTITATION LIMITS FOR SPECIFIED ANALYTES OF CONCERN TO RISK ASSESSMENT

AIR MATRICES

ANALYTE/ COMMON NAME CAS NUMBER	METHOD REFERENCE/TITLE OF METHOD	INSTRUMENT- ATION	QUANTITATION/ DETECTION LIMIT
Tetrachloromethane (Carbon Tetrachloride) 56235	EPA AIR METHOD TO-2 "Method for the Determination of Volatile Organic Compounds in Ambient Air by Carbon Molecular Sieve Adsorption and Gas Chromatography-Mass Spectrometry (GC-MS)"	GC-MS	NA
	EPA AIR METHOD TO-3 "Method for the Determination of Volatile Organic Compounds in Ambient Air Using Cryogenic Preconcentration Techniques and Gas Chromatography with Flame Ionization and Electron Capture Detection"	GC-FID/ GC-ECD	NA
Trichloromethane (Chloroform) 67663	EPA AIR METHOD TO-14 "The Determination of Volatile Organic Compounds (VOCs) in Ambient Air Using SUMMA Passivated Canister Sampling and Gas Chromatographic Analysis"	GC-MS	EDL = 2000 mg/m ³
	EPA AIR METHOD TO-2 "Method for the Determination of Volatile Organic Compounds in Ambient Air by Carbon Molecular Sieve Adsorption and Gas Chromatography-Mass Spectrometry (GC-MS)"	GC-MS	NA
	EPA AIR METHOD TO-3 "Method for the Determination of Volatile Organic Compounds in Ambient Air Using Cryogenic Preconcentration Techniques and Gas Chromatography with Flame Ionization and Electron Capture Detection"	GC-FID/ GC-ECD	NA

APPENDIX III
TABLE II
METHODS AND DETECTION/QUANTITATION LIMITS FOR SPECIFIED ANALYTES OF CONCERN TO RISK ASSESSMENT
SOIL/SEDIMENT MATRICES

ANALYTE/ COMMON NAME CAS NUMBER	METHOD REFERENCE/ TITLE OF METHOD	INSTRUMENT- ATION	QUANTITATION/ DETECTION LIMIT
<u>INORGANICS</u>			
Arsenic 7440382	CLP SOW METHOD INORG "Statement of Work for Inorganics Analysis - Multi-Media, Multi-Concentration"	GFAA-ICP	CRDL = 2.0 mg/kg
	MCAWW METHOD 206.2/SW846 Method 7060 "Arsenic (Atomic Absorption, Furnace Technique)"	GFAA	MDL = 0.1 mg/kg
	SW846 METHOD 6010 "Inductively Coupled Plasma Atomic Emission Spectroscopy"	ICP	EDL = 5.3 mg/kg
Beryllium 7440417	SW846 METHOD 7061 "Arsenic (Atomic Absorption, Gaseous Hydride)"	HYDAA	MDL = 0.1 mg/kg
	CLP SOW METHOD INORG "Statement of Work for Inorganics Analysis - Multi-Media, Multi-Concentration"	GFAA-FLAME-ICP	CRDL = 1.0 mg/kg
	MCAWW METHOD 210.1/SW846 Method 7090 "Beryllium (Atomic Absorption, Direct Aspiration)"	FLAME	MDL = 0.5 mg/kg
	MCAWW METHOD 210.2/SW846 Method 7091 "Beryllium (Atomic Absorption, Furnace Technique)"	GFAA	MDL = 0.02 mg/kg
	SW846 METHOD 6010 "Inductively Coupled Plasma Atomic Emission Spectroscopy"	ICP	EDL = 0.03 mg/kg
Cadmium 7440439	CLP SOW METHOD INORG "Statement of Work for Inorganics Analysis - Multi-Media, Multi-Concentration"	GFAA-ICP-FLAME	CRDL = 1.0 mg/kg
	MCAWW METHOD 213.1/SW846 Method 7130 "Cadmium (Atomic Absorption, Direct Aspiration)"	FLAME	MDL = 0.5 mg/kg
	MCAWW METHOD 213.2/SW846 Method 7131 "Cadmium (Atomic Absorption, Furnace Technique)"	GFAA	MDL = 0.01 mg/kg

APPENDIX III
TABLE II
METHODS AND DETECTION/QUANTITATION LIMITS FOR SPECIFIED ANALYTES OF CONCERN TO RISK ASSESSMENT
SOIL/SEDIMENT MATRICES

ANALYTE/ COMMON NAME CAS NUMBER	METHOD REFERENCE/ TITLE OF METHOD	INSTRUMENT- ATION	QUANTITATION/ DETECTION LIMIT
Cadmium 7440439	SW846 METHOD 6010 "Inductively Coupled Plasma Atomic Emission Spectroscopy"	ICP	EDL = 0.4 mg/kg
Chromium, Total 7440473	CLP SOW METHOD INORG "Statement of Work for Inorganics Analysis - Multi-Media, Multi-Concentration"	GFAA-ICP-FLAME	CRDL = 2.0 mg/kg
	MCAWW METHOD 218.1/SW846 Method 7190 "Chromium (Atomic Absorption, Direct Aspiration)"	FLAME	MDL = 5.0 mg/kg
	MCAWW METHOD 218.2/SW846 Method 7191 "Chromium (Atomic Absorption, Furnace Technique)"	GFAA	MDL = 0.1 mg/kg
	SW846 METHOD 6010 "Inductively Coupled Plasma Atomic Emission Spectroscopy"	ICP	EDL = 0.7 mg/kg
Chromium, Hexavalent 7440473	SW846 METHOD 7195 "Chromium Hexavalent (Coprecipitation) for EP Extracts"	FLAME-GFAA	MDL = 100 mg/kg
	SW846 METHOD 7196 "Chromium Hexavalent (Colorimetric) for EP Extracts"	Colorimeter	MDL = 10 mg/kg
	SW846 METHOD 7197 "Chromium Hexavalent (Chelation/Extraction) for EP Extracts"	FLAME	MDL = 20 mg/kg
	SW846 METHOD 7198 "Chromium Hexavalent (Differential Pulse Polarography) for EP Extracts"	Polarograph	MDL = 20 mg/kg
Cyanide, Total 57-12-5	CLP SOW for Inorganic Analysis-Multi-Media, High Concentration	Colorimeter	CRDL = 1.0 mg/kg
	SMEWW Method 4500 CN, C, D, E, F, Total Cyanide after Distillation	Colorimeter-Titrimetric-Ion-Selective Electrode	EDL = 2.0 mg/kg EDL = 5.0 mg/kg

APPENDIX III

TABLE II

METHODS AND DETECTION/QUANTITATION LIMITS FOR SPECIFIED ANALYTES OF CONCERN TO RISK ASSESSMENT

SOIL/SEDIMENT MATRICES

ANALYTE/ COMMON NAME CAS NUMBER	METHOD REFERENCE/ TITLE OF METHOD	INSTRUMENT- ATION	QUANTITATION/ DETECTION LIMIT
Cyanide, Total & Amenable to Chlorination	SW846 Method 9010, "Total and Amendable Cyanide (Colorimetric, manual)"	Colorimeter	CRDL = 1.0 mg/kg
Lead 7439921	CLP SOW METHOD INORG "Statement of Work for Inorganics Analysis - Multi-Media, Multi-Concentration"	GFAA-FLAME- ICP	CRDL = 0.6 mg/kg
	MCAWW METHOD 239.1/SW846 Method 7420 "Lead (Atomic Absorption, Direct Aspiration)"	FLAME	MDL = 10 mg/kg
	MCAWW METHOD 239.2/SW846 Method 7421 "Lead (Atomic Absorption, Furnace Technique)"	GFAA	MDL = 0.1 mg/kg
	SW846 METHOD 6010 "Inductively Coupled Plasma Atomic Emission Spectroscopy"	ICP	EDL = 4.2 mg/kg
Mercury 7439976	CLP SOW METHOD INORG "Statement of Work for Inorganics Analysis - Multi-Media, Multi-Concentration"	CVAA	CRDL = 0.1 mg/kg
	MCAWW METHOD 245.5 "Mercury in Sediment (Manual Cold Vapor Technique)"	CVAA	MDL = 0.2 mg/kg
	SW846 METHOD 7471 "Mercury in Solid or Semisolid Waste (Manual Cold-Vapor Technique)"	CVAA	MDL = 0.1 mg/kg
<u>ORGANOCHLORINE PESTICIDES/AROCLORS</u>			
Aroclor 1260 (PCB-1260) 11096825	CLP SOW METHOD ORG "Statement of Work for Organics Analysis - Multi-Media, Multi-Concentration"	GC-ECD	CRQL = 33 ug/kg
	CLP SOW METHOD QTM "Chemical Analytical Services for Multi-Media, Multi-Concentration Samples for Organic Analysis by Quick Turnaround Gas Chromatography Techniques"	GC-ECD	CRQL = 33 ug/kg

APPENDIX III

TABLE II

METHODS AND DETECTION/QUANTITATION LIMITS FOR SPECIFIED ANALYTES OF CONCERN TO RISK ASSESSMENT

SOIL/SEDIMENT MATRICES

ANALYTE/ COMMON NAME CAS NUMBER	METHOD REFERENCE/ TITLE OF METHOD	INSTRUMENT- ATION	QUANTITATION/ DETECTION LIMIT
Chlordane 57749	CLP SOW METHOD ORG "Statement of Work for Organics Analysis - Multi-Media, Multi-Concentration"	GC-ECD	CRQL = 1.7 ug/kg
	CLP SOW METHOD QTM (Alpha and Gamma) "Chemical Analytical Services for Multi-Media, Multi-Concentration Samples for Organic Analysis by Quick Turnaround Gas Chromatography Techniques" (CRQL is for Gamma Chlordane)	GC-ECD	CRQL = 3.3 ug/kg
	SW846 METHOD 8080 "Organochlorine Pesticides and PCBs"	GC-ECD	PQL = 9.0 ug/kg
Dieldrin 60571	CLP SOW METHOD ORG "Statement of Work for Organics Analysis - Multi-Media, Multi-Concentration"	GC-ECD	CRQL = 3.3 ug/kg
	CLP SOW METHOD QTM "Chemical Analytical Services for Multi-Media, Multi-Concentration Samples for Organic Analysis by Quick Turnaround Gas Chromatography Techniques"	GC-ECD	CRQL = 3.3 ug/kg
	SW846 METHOD 8080 "Organochlorine Pesticides and PCBs"	GC-ECD	PQL = 1.3 ug/kg
Heptachlor 76448	CLP SOW METHOD ORG "Statement of Work for Organics Analysis - Multi-Media, Multi-Concentration"	GC-ECD	CRQL = 1.7 ug/kg
	CLP SOW METHOD QTM "Chemical Analytical Services for Multi-Media, Multi-Concentration Samples for Organic Analysis by Quick Turnaround Gas Chromatography Techniques"	GC-ECD	CRQL = 3.3 ug/kg
	SW846 METHOD 8080 "Organochlorine Pesticides and PCBs"	GC-ECD	PQL = 2.0 ug/kg
Lindane 58899	CLP SOW METHOD ORG "Statement of Work for Organics Analysis - Multi-Media, Multi-Concentration"	GC-ECD	CRQL = 1.7 ug/kg
	CLP SOW METHOD QTM "Chemical Analytical Services for Multi-Media, Multi-Concentration Samples for Organic Analysis by Quick Turnaround Gas Chromatography Techniques"	GC-ECD	CRQL = 3.3 ug/kg

METHODS AND DETECTION/QUANTITATION LIMITS FOR SPECIFIED ANALYTES OF CONCERN TO RISK ASSESSMENT

SOIL/SEDIMENT MATRICES

ANALYTE/ COMMON NAME CAS NUMBER	METHOD REFERENCE/ TITLE OF METHOD	INSTRUMENT- ATION	QUANTITATION/ DETECTION LIMIT
p,p'-DDE 72559	CLP SOW METHOD ORG "Statement of Work for Organics Analysis - Multi-Media, Multi-Concentration"	GC-ECD	CRQL = 3.3 ug/kg
	CLP SOW METHOD QTM "Chemical Analytical Services for Multi-Media, Multi-Concentration Samples for Organic Analysis by Quick Turnaround Gas Chromatography Techniques"	GC-ECD	CRQL = 3.3 ug/kg
	SW846 METHOD 8080 "Organochlorine Pesticides and PCBs"	GC-ECD	PQL = 2.7 ug/kg
p,p'-DDT 50293	CLP SOW METHOD ORG "Statement of Work for Organics Analysis - Multi-Media, Multi-Concentration"	GC-ECD	CRQL = 3.3 ug/kg
	CLP SOW METHOD QTM "Chemical Analytical Services for Multi-Media, Multi-Concentration Samples for Organic Analysis by Quick Turnaround Gas Chromatography Techniques"	GC-ECD	CRQL = 3.3 ug/kg
	SW846 METHOD 8080 "Organochlorine Pesticides and PCBs"	GC-ECD	PQL = 8.0 ug/kg
SEMIVOLATILE COMPOUNDS			
3,5,5-trimethyl- 2-cyclohexen-1-one (Isophorone) 78591	CLP SOW METHOD ORG "Statement of Work for Organics Analysis - Multi-Media, Multi-Concentration"	GC-MS	CRQL = 330 ug/kg
	SW846 METHOD 8270 "Gas Chromatography-Mass Spectrometry for Semivolatile Organics: Capillary Column Technique"	GC-MS	PQL = 660 ug/kg
Benzo <a> pyrene 50328	CLP SOW METHOD ORG "Statement of Work for Organics Analysis - Multi-Media, Multi-Concentration"	GC-MS	CRQL = 330 ug/kg
	CLP SOW METHOD QTM "Chemical Analytical Services for Multi-Media, Multi-Concentration Samples for Organic Analysis by Quick Turnaround Gas Chromatography Techniques"	GC-FID	CRQL = 330 ug/kg

APPENDIX III

TABLE II

METHODS AND DETECTION/QUANTITATION LIMITS FOR SPECIFIED ANALYTES OF CONCERN TO RISK ASSESSMENT
SOIL/SEDIMENT MATRICES

ANALYTE/ COMMON NAME CAS NUMBER	METHOD REFERENCE/ TITLE OF METHOD	INSTRUMENT- ATION	QUANTITATION/ DETECTION LIMIT
178 Benzo <a> pyrene 50328	SW846 METHOD 8270 "Gas Chromatography-Mass Spectrometry for Semivolatile Organics: Capillary Column Technique"	GC-MS	PQL = 660 ug/kg
	SW846 METHOD 8310 "Polynuclear Aromatic Hydrocarbons"	HPLC	PQL = 15 ug/kg
	Bis-(2-Dichloroethyl) ether 111444	CLP SOW METHOD ORG "Statement of Work for Organics Analysis - Multi-Media, Multi-Concentration"	GC-MS CRQL = 330 ug/kg
	Bis-(2-ethylhexyl) phthalate 117817	CLP SOW METHOD ORG "Statement of Work for Organics Analysis - Multi-Media, Multi-Concentration"	GC-MS CRQL = 330 ug/kg
	SW846 METHOD 8060 "Phthalate Esters"	GC-ECD	PQL = 1340 ug/kg
N-nitrosodi- phenylamine 86306	SW846 METHOD 8270 "Gas Chromatography-Mass Spectrometry for Semivolatile Organics: Capillary Column Technique"	GC-MS	PQL = 660 ug/kg
	CLP SOW METHOD ORG "Statement of Work for Organics Analysis - Multi-Media, Multi-Concentration"	GC-MS	CRQL = 330 ug/kg
	SW846 Method 8270 "Gas Chromatography-Mass Spectrometry for Semivolatile Organics: Capillary Column Technique"	GC-MS	PQL = 660 ug/kg
<u>VOLATILE COMPOUNDS</u>			
1,1-dichloroethane 75343	CLP SOW METHOD ORG "Statement of Work for Organics Analysis - Multi-Media, Multi-Concentration"	GC-MS	CRQL = 10 ug/kg
	SW846 METHOD 8010 "Halogenated Volatile Organics"	GC-ELCD	PQL = 0.7 ug/kg
	SW846 METHOD 8240 "Gas Chromatography-Mass Spectrometry for Volatile Organics"	GC-MS	PQL = 5.0 ug/kg

APPENDIX III
TABLE II
METHODS AND DETECTION/QUANTITATION LIMITS FOR SPECIFIED ANALYTES OF CONCERN TO RISK ASSESSMENT
SOIL/SEDIMENT MATRICES

ANALYTE/ COMMON NAME CAS NUMBER	METHOD REFERENCE/ TITLE OF METHOD	INSTRUMENT- ATION	QUANTITATION/ DETECTION LIMIT
1,1-dichloroethane 75343	CLP SOW METHOD QTM "Chemical Analytical Services for Multi-Media, Multi-Concentration Samples for Organic Analysis by Quick Turnaround Gas Chromatography Techniques"	GC-PID	CRQL = 40 ug/kg
1,1-dichloroethene 75354	CLP SOW METHOD ORG "Statement of Work for Organics Analysis - Multi-Media, Multi-Concentration"	GC-MS	CRQL = 10 ug/kg
	CLP SOW METHOD QTM "Chemical Analytical Services for Multi-Media, Multi-Concentration Samples for Organic Analysis by Quick Turnaround Gas Chromatography Techniques"	GC-PID	CRQL = 40 ug/kg
	SW846 METHOD 8240 "Gas Chromatography-Mass Spectrometry for Volatile Organics"	GC-MS	PQL = 5.0 ug/kg
1,1,2-trichloroethane 79005	CLP SOW METHOD ORG "Statement of Work for Organics Analysis - Multi-Media, Multi-Concentration"	GC-MS	CRQL = 10 ug/kg
	SW846 METHOD 8010 "Halogenated Volatile Organics"	GC-ELCD	PQL = 0.2 ug/kg
	SW846 METHOD 8240 "Gas Chromatography-Mass Spectrometry for Volatile Organics"	GC-MS	PQL = 5.0 ug/kg
1,1,2,2-tetrachloroethane 79345	CLP SOW METHOD ORG "Statement of Work for Organics Analysis - Multi-Media, Multi-Concentration"	GC-MS	CRQL = 10 ug/kg
	CLP SOW METHOD QTM "Chemical Analytical Services for Multi-Media, Multi-Concentration Samples for Organic Analysis by Quick Turnaround Gas Chromatography Techniques"	GC-ECD	CRQL = 40 ug/kg
	SW846 METHOD 8010 "Halogenated Volatile Organics"	GC-ELCD	PQL = 0.3 ug/kg
	SW846 METHOD 8240 "Gas Chromatography-Mass Spectrometry for Volatile Organics"	GC-MS	PQL = 5.0 ug/kg

TABLE II

METHODS AND DETECTION/QUANTITATION LIMITS FOR SPECIFIED ANALYTES OF CONCERN TO RISK ASSESSMENT

SOIL/SEDIMENT MATRICES

ANALYTE/ COMMON NAME CAS NUMBER	METHOD REFERENCE/ TITLE OF METHOD	INSTRUMENT- ATION	QUANTITATION/ DETECTION LIMIT
1,2-dichloroethane 107062	CLP SOW METHOD ORG "Statement of Work for Organics Analysis - Multi-Media, Multi-Concentration"	GC-MS	CRQL = 10 ug/kg
	CLP SOW METHOD QTM "Chemical Analytical Services for Multi-Media, Multi-Concentration Samples for Organic Analysis by Quick Turnaround Gas Chromatography Techniques"	GC-PID	CRQL = 40 ug/kg
	SW846 METHOD 8010 "Halogenated Volatile Organics"	GC-ELCD	PQL = 0.3 ug/kg
	SW846 METHOD 8240 "Gas Chromatography-Mass Spectrometry for Volatile Organics"	GC-MS	PQL = 5.0 ug/kg
180 1,2-dichloropropane 78875	CLP SOW METHOD ORG "Statement of Work for Organics Analysis - Multi-Media, Multi-Concentration"	GC-MS	CRQL = 10 ug/kg
	SW846 METHOD 8240 "Gas Chromatography-Mass Spectrometry for Volatile Organics"	GC-MS	PQL = 5.0 ug/kg
	SW846 METHOD 8010 "Halogenated Volatile Organics"	GC-ELCD	PQL = 0.4 ug/kg
1,4-dichlorobenzene 106467	SW846 METHOD 8010 "Halogenated Volatile Organics"	GC-ELCD	PQL = 2.4 ug/kg
	SW846 METHOD 8020 "Aromatic Volatile Organics"	GC-PID	PQL = 3.0 ug/kg
	SW846 METHOD 8270 "Gas Chromatography-Mass Spectrometry for Semivolatile Organics: Capillary Column Technique"	GC-MS	PQL = 660 ug/kg
Benzene 71432	CLP SOW METHOD ORG "Statement of Work for Organics Analysis - Multi-Media, Multi-Concentration"	GC-MS	CRQL = 10 ug/kg
	CLP SOW METHOD QTM "Chemical Analytical Services for Multi-Media, Multi-Concentration Samples for Organic Analysis by Quick Turnaround Gas Chromatography Techniques"	GC-PID	CRQL = 40 ug/kg

METHODS AND DETECTION/QUANTITATION LIMITS FOR SPECIFIED ANALYTES OF CONCERN TO RISK ASSESSMENT

SOIL/SEDIMENT MATRICES

ANALYTE/ COMMON NAME CAS NUMBER	METHOD REFERENCE/ TITLE OF METHOD	INSTRUMENT- ATION	QUANTITATION/ DETECTION LIMIT
Benzene 71432	SW846 METHOD 8020 "Aromatic Volatile Organics"	GC-PID	PQL = 2.0 ug/kg
	SW846 METHOD 8240 "Gas Chromatography-Mass Spectrometry for Volatile Organics"	GC-MS	PQL = 5.0 ug/kg
Chloroethene (Vinyl Chloride) 75014	CLP SOW METHOD ORG "Statement of Work for Organics Analysis - Multi-Media, Multi-Concentration"	GC-MS	CRQL = 10 ug/kg
	CLP SOW METHOD QTM "Chemical Analytical Services for Multi-Media, Multi-Concentration Samples for Organic Analysis by Quick Turnaround Gas Chromatography Techniques"	GC-PID	CRQL = 40 ug/kg
	SW846 METHOD 8010 "Halogenated Volatile Organics"	GC-ELCD	PQL = 1.8 ug/kg
	SW846 METHOD 8240 "Gas Chromatography-Mass Spectrometry for Volatile Organics"	GC-MS	PQL = 10 ug/kg
Dichloromethane (Methylene Chloride) 75092	CLP SOW METHOD ORG "Statement of Work for Organics Analysis - Multi-Media, Multi-Concentration"	GC-MS	CRQL = 10 ug/kg
	SW846 METHOD 8240 "Gas Chromatography-Mass Spectrometry for Volatile Organics"	GC-MS	PQL = 5.0 ug/kg
Ethenyl Benzene (Styrene) 100425	CLP SOW METHOD ORG "Statement of Work for Organics Analysis - Multi-Media, Multi-Concentration"	GC-MS	CRQL = 10 ug/kg
	SW846 METHOD 8240 "Gas Chromatography-Mass Spectrometry for Volatile Organics"	GC-MS	PQL = 5.0 ug/kg
Tetrachloroethene (Tetrachloroethylene) 127184	CLP SOW METHOD ORG "Statement of Work for Organics Analysis - Multi-Media, Multi-Concentration"	GC-MS	CRQL = 10 ug/kg

APPENDIX III

TABLE II

METHODS AND DETECTION/QUANTITATION LIMITS FOR SPECIFIED ANALYTES OF CONCERN TO RISK ASSESSMENT
SOIL/SEDIMENT MATRICES

ANALYTE/ COMMON NAME CAS NUMBER	METHOD REFERENCE/ TITLE OF METHOD	INSTRUMENT- ATION	QUANTITATION/ DETECTION LIMIT
Tetrachloroethene (Tetrachloroethylene) 127184	CLP SOW METHOD QTM "Chemical Analytical Services for Multi-Media, Multi-Concentration Samples for Organic Analysis by Quick Turnaround Gas Chromatography Techniques"	GC-PID	CRQL = 40 ug/kg
	SW846 METHOD 8010 "Halogenated Volatile Organics"	GC-ELCD	PQL = 0.3 ug/kg
	SW846 METHOD 8240 "Gas Chromatography-Mass Spectrometry for Volatile Organics"	GC-MS	PQL = 5.0 ug/kg
Tetrachloromethane (Carbon Tetrachloride) 56235	CLP SOW METHOD ORG "Statement of Work for Organics Analysis - Multi-Media, Multi-Concentration"	GC-MS	CRQL = 10 ug/kg
	CLP SOW METHOD QTM "Chemical Analytical Services for Multi-Media, Multi-Concentration Samples for Organic Analysis by Quick Turnaround Gas Chromatography Techniques"	GC-PID	CRQL = 40 ug/kg
	SW846 METHOD 8010 "Halogenated Volatile Organics"	GC-ELCD	PQL = 1.2 ug/kg
	SW846 METHOD 8240 "Gas Chromatography-Mass Spectrometry for Volatile Organics"	GC-MS	PQL = 5.0 ug/kg
Trichloromethane (Chloroform) 67663	CLP SOW METHOD ORG "Statement of Work for Organics Analysis - Multi-Media, Multi-Concentration"	GC-MS	CRQL = 10 ug/kg
	CLP SOW METHOD QTM "Chemical Analytical Services for Multi-Media, Multi-Concentration Samples for Organic Analysis by Quick Turnaround Gas Chromatography Techniques"	GC-PID	CRQL = 40 ug/kg
	SW846 METHOD 8010 "Halogenated Volatile Organics"	GC-ELCD	PQL = 0.5 ug/kg
	SW846 METHOD 8240 "Gas Chromatography-Mass Spectrometry for Volatile Organics"	GC-MS	PQL = 5.0 ug/kg

APPENDIX III
TABLE III
METHODS AND DETECTION/QUANTITATION LIMITS FOR SPECIFIED ANALYTES OF CONCERN TO RISK ASSESSMENT

AQUEOUS MATRICES

ANALYTE/ COMMON NAME CAS NUMBER	METHOD REFERENCE/TITLE OF METHOD	INSTRUMENT- ATION	QUANTITATION/ DETECTION LIMIT
<u>INORGANICS</u>			
Arsenic 7440382	CLP SOW METHOD INORG "Statement of Work for Inorganics Analysis - Multi-Media, Multi-Concentration"	GFAA-ICP	CRDL = 10 ug/L
	MCAWW METHOD 200.7/SW846 Method 6010/SMEWW Method 3120B "Inductively Coupled Plasma-Atomic Emission Spectrometric Method for Trace Element Analysis of Water and Wastes"	ICP	MDL = 53 ug/L, 53 ug/L EDL= 50 ug/L
	MCAWW METHOD 206.2/SW846 Method 7060/SMEWW Method 3113B "Arsenic (Atomic Absorption, Furnace Technique)"	GFAA	MDL = 1.0 ug/L, 1.0 ug/L EDL= 1.0 ug/L
	MCAWW METHOD 206.3/SW846 Method 7061/SMEWW Method 3114B "Arsenic (Atomic Absorption-Gaseous Hydride)" Use method 206.5 for sample preparation	HYDAA	MDL = 2.0 ug/L, 2.0 ug/L EDL= 1.0 ug/L
	MCAWW METHOD 206.4 "Arsenic (Spectrophotometric-SDDC)" Use method 206.5 for sample preparation	Colorimeter	MDL = 10 ug/L
	SMEWW METHOD 3500AS C "Silver Diethyldithiocarbamate Method"	Colorimeter	EDL = 28.6 ug/L
Beryllium 7440417	CLP SOW METHOD INORG "Statement of Work for Inorganics Analysis - Multi-Media, Multi-Concentration"	GFAA-FLAME-ICP	CRDL = 5.0 ug/L
	MCAWW METHOD 200.7/SW846 Method 6010/SMEWW Method 3120B "Inductively Coupled Plasma-Atomic Emission Spectrometric Method for Trace Element Analysis of Water and Wastes"	ICP	EDL = 0.3 ug/L
	MCAWW METHOD 210.1 "Beryllium (Atomic Absorption, Direct Aspiration)"	FLAME	MDL = 5.0 ug/L
	MCAWW METHOD 210.2/SW846 Method 7091/SMEWW Method 3113B "Beryllium (Atomic Absorption, Furnace Technique)"	GFAA	MDL = 0.2 ug/L, 0.2 ug/L EDL=0.2 ug/L

APPENDIX III
TABLE III
METHODS AND DETECTION/QUANTITATION LIMITS FOR SPECIFIED ANALYTES OF CONCERN TO RISK ASSESSMENT

AQUEOUS MATRICES

ANALYTE/ COMMON NAME CAS NUMBER	METHOD REFERENCE/TITLE OF METHOD	INSTRUMENT- ATION	QUANTITATION/ DETECTION LIMIT
Beryllium 7440417	SMEWW METHOD 3111D/SW846 Method 7090 "Direct Nitrous Oxide-Acetylene Flame Method"	FLAME	EDL = 5.0 ug/L, 5.0 ug/L MDL=5.0 ug/L
	SMEWW METHOD 3111E "Extraction/Nitrous Oxide-Acetylene Flame Method"	FLAME	EDL = 5.0 ug/L
	SMEWW METHOD 3500BE D "Aluminon Method"	Colorimeter	EDL = 5.0 ug/L
Cadmium 7440439	CLP SOW METHOD INORG "Statement of Work for Inorganics Analysis - Multi-Media, Multi-Concentration"	GFAA-FLAME-ICP	CRDL = 5.0 ug/L
	MCAWW METHOD 200.7/SW846 Method 6010/SMEWW Method 3120B "Inductively Coupled Plasma-Atomic Emission Spectrometric Method for Trace Element Analysis of Water and Wastes"	ICP	EDL = 4.0 ug/L
	MCAWW METHOD 213.1/SW846 Method 7130/SMEWW Method 3111B "Cadmium (Atomic Absorption, Direct Aspiration)"	FLAME	MDL = 5.0 ug/L, 5.0 ug/L IDL=2.0 ug/L
	MCAWW METHOD 213.2/SW846 Method 7131/SMEWW Method 3113B "Cadmium (Atomic Absorption, Furnace Technique)"	GFAA	MDL = 0.1 ug/L, 0.1 ug/L EDL=0.1 ug/L
	SMEWW METHOD 3111C "Extraction/Air-Acetylene Flame Method"	FLAME	NA
	SMEWW METHOD 3500CD D "Dithizone Method"	Colorimeter	EDL = 20 ug/ml
	CLP SOW METHOD INORG "Statement of Work for Inorganics Analysis - Multi-Media, Multi-Concentration"	GFAA-ICP-FLAME	CRDL = 10 ug/L
Chromium, Total 7440473	MCAWW METHOD 200.7/SW846 Method 6010/SMEWW Method 3120B "Inductively Coupled Plasma-Atomic Emission Spectrometric Method for Trace Element Analysis of Water and Wastes"	ICP	EDL = 7.0 ug/L
	MCAWW METHOD 218.1/SW846 Method 7190/SMEWW Method 3111B "Chromium (Atomic Absorption, Direct Aspiration)"	FLAME	MDL = 50 ug/L, 50 ug/L EDL = 20 ug/L

METHODS AND DETECTION/QUANTITATION LIMITS FOR SPECIFIED ANALYTES OF CONCERN TO RISK ASSESSMENT

AQUEOUS MATRICES

ANALYTE/ COMMON NAME CAS NUMBER	METHOD REFERENCE/TITLE OF METHOD	INSTRUMENT- ATION	QUANTITATION/ DETECTION LIMIT
Chromium, Total 7440473	MCAWW METHOD 218.2 /SW846 Method 7191/SMEWW Method 3113B "Chromium (Atomic Absorption, Furnace Technique)"	GFAA	MDL = 1.0 ug/L, 1.0 ug/L EDL = 2.0 ug/L
	MCAWW METHOD 218.3 "Chromium (Atomic Absorption, Chelation-Extraction)"	FLAME	MDL = 1.0 ug/L
Chromium, Hexavalent	MCAWW METHOD 218.4/SW846 Method 7197 "Chromium, Hexavalent (Atomic Absorption, Chelation-Extraction)"	FLAME	MDL = 10 ug/L, 1.0 ug/L
	MCAWW METHOD 218.5 "Chromium, Dissolved Hexavalent (Atomic Absorption, Furnace Technique)"	GFAA	MDL = 1.0 ug/L
	SMEWW METHOD 3111C "Extraction/Air-Acetylene Flame Method"	FLAME	NA
	SW846 METHOD 7195 "Chromium, Hexavalent (Coprecipitation)"	FLAME, GFAA	MDL = 5.0 ug/L
	SW846 METHOD 7196/SMEWW Method 3500CR D "Chromium, Hexavalent (Colorimetric)"	Colorimeter	MDL = 500 ug/L, NA
Cyanide, Total 57-12-5	SW846 METHOD 7198 "Chromium, Hexavalent (Differential Pulse Polarography)"	Polarograph	MDL = 10 ug/L
	CLP SOW METHOD INORG "Statement of Work for Inorganics Analysis - Multi-Media, Multi-Concentration"	Colorimeter/ Titrimetric	CRDL = 10 ug/L
	SMEWW Method 4500-CN, C, D, E, F "Total Cyanide after Distillation"	Colorimeter/ Titrimetric/ Ion-Selective Electrode	EDL = 20 ug/L EDL = 50 ug/L
	MCAWW Method 335.2 "Cyanide, Total, Titrimetric Spectrophotometric)"	Colorimeter/ Titrimetric	EDL = 20 ug/L

APPENDIX III
TABLE III
METHODS AND DETECTION/QUANTITATION LIMITS FOR SPECIFIED ANALYTES OF CONCERN TO RISK ASSESSMENT
AQUEOUS MATRICES

186

ANALYTE/ COMMON NAME CAS NUMBER	METHOD REFERENCE/TITLE OF METHOD	INSTRUMENT- ATION	QUANTITATION/ DETECTION LIMIT
Cyanide, Total and Amenable to Chlorination	SW846 METHOD 9010A, "Total and Amenable Cyanide (Colorimetric, Manual)	Colorimeter/ Titrimetric	EDL = 20 ug/L
	SW846 METHOD 9012 "Total and Amenable Cyanide (Colorimetric, Automated UV)"	Colorimeter/ Titrimetric	EDL = 20 ug/L
Cyanide, Amenable to Chlorination	SMEWW METHOD 4500-CN,G "Cyanide Amenable to Chlorination after Distillation"	Colorimeter/ Titrimetric/ Ion-Selective Electrode	EDL = 20 ug/L EDL = 50 ug/L
	MCAWW METHOD 335.1 "Cyanide, Amenable to Chlorination"	Colorimeter/ Titrimetric	EDL = 20 ug/L
Cyanide, Weak and Dissociable	SMEWW METHOD 4500-CN, I, D, E, F "Weak and Dissociable Cyanide"	Colorimeter/ Titrimetric/ Ion-Selective Electrode	EDL = 20 ug/L EDL = 50 ug/L
Lead 7439921	CLP SOW METHOD INORG "Statement of Work for Inorganics Analysis - Multi-Media, Multi-Concentration"	GFAA-FLAME- ICP	CRDL = 3.0 ug/L
	MCAWW METHOD 200.7/SW846 Method 6010/SMEWW Method 3120B "Inductively Coupled Plasma-Atomic Emission Spectrometric Method for Trace Element Analysis of Water and Wastes"	ICP	EDL = 42 ug/L, 42 ug/L, 40 ug/L
	MCAWW METHOD 239.1/SW846 Method 7420/SMEWW Method 3111B "Lead (Atomic Absorption, Direct Aspiration)"	FLAME	MDL = 100 ug/L, 100 ug/L EDL = 50 ug/L
	MCAWW METHOD 239.2/SW846 Method 7421/SMEWW Method 3113B "Lead (Atomic Absorption, Furnace Technique)"	GFAA	MDL = 1.0 ug/L, 100 ug/L EDL = 1.0 ug/L
	SMEWW METHOD 3111C "Extraction/Air-Acetylene Flame Method"	FLAME	NA
	SMEWW METHOD 3500PB D "Dithizone Method"	Colorimeter	EDL = 100 ug/L

METHODS AND DETECTION/QUANTITATION LIMITS FOR SPECIFIED ANALYTES OF CONCERN TO RISK ASSESSMENT

AQUEOUS MATRICES

ANALYTE/ COMMON NAME CAS NUMBER	METHOD REFERENCE/TITLE OF METHOD	INSTRUMENT- ATION	QUANTITATION/ DETECTION LIMIT
Mercury 7439976	CLP SOW METHOD INORG/MCAWW Method 245.1 and 245.2 "Statement of Work for Inorganics Analysis - Multi-Media, Multi-Concentration, Mercury Manual ; Mercury Automated Cold Vapor Technique"	CVAA	CRDL = 0.2 ug/L MDL=0.2 ug/L,0.2 ug/L
	SMEWW METHOD 3112B/SW846 Method 7470 "Cold-Vapor Atomic Absorption Spectrometric Method"	CVAA	EDL=1.0 ug/L MDL=0.2 ug/L
	SMEWW METHOD 3500HG C "Dithizone Method"	Colorimeter	EDL = 2.0 ug/L

ORGANOCHLORINE PESTICIDES/AROCLORS

187 Aroclor 1260 (PCB-1260) 11096825	CLP SOW METHOD LC-ORG "Chemical Analytical Services for the Analysis of Low Concentration Water Samples for Organic Compounds by Gas Chromatography-Mass Spectrometry (GC-MS) and Gas Chromatography-Electron Capture (GC-ECD) Techniques"	GC-ECD	CRQL = 0.20 ug/L
	CLP SOW METHOD ORG "Statement of Work for Organics Analysis - Multi- Media, Multi-Concentration"	GC-ECD	CRQL = 1.0 ug/L
	CLP SOW METHOD QTM "Chemical Analytical Services for Multi-Media, Multi-Concentration Samples for Organic Analysis by Quick Turnaround Gas Chromatography Techniques"	GC-ECD	CRQL = 1.0 ug/L
	EPA METHOD 608 "Organochlorine Pesticides and PCBs"	GC-ECD	NA
	EPA METHOD 625 "Base/Neutrals and Acids"	GC-MS	NA
	EPA DW METHOD 505 "Analysis of Organohalide Pesticides and Aroclors in Water by Microextraction and Chromatography"	GC-ECD	MDL = 0.189 ug/L
	EPA DW METHOD 508 "Determination of Chlorinated Pesticides in Water by Gas Chromatography with an Electron Capture Detector"	GC-ECD	NA

METHODS AND DETECTION/QUANTITATION LIMITS FOR SPECIFIED ANALYTES OF CONCERN TO RISK ASSESSMENT

AQUEOUS MATRICES

ANALYTE/ COMMON NAME CAS NUMBER	METHOD REFERENCE/TITLE OF METHOD	INSTRUMENT- ATION	QUANTITATION/ DETECTION LIMIT
Aroclor 1260 (PCB-1260) 11096825	SMEWW METHOD 6410B "Liquid-Liquid Extraction Gas Chromatographic-Mass Spectrometric Method"	GC-MS	NA
	SMEWW METHOD 6630B "Liquid-Liquid Extraction Gas Chromatographic Method I"	GC-MS	NA
	SMEWW METHOD 6630C "Liquid-Liquid Extraction Gas Chromatographic Method II"	GC-ECD	NA
Chlordane 57749	CLP SOW METHOD LC-ORG (CRQL is for alpha and gamma Chlordane) "Chemical Analytical Services for the Analysis of Low Concentration Water Samples for Organic Compounds by Gas Chromatography-Mass Spectrometry (GC-MS) and Gas Chromatography-Electron Capture (GC-ECD) Techniques"	GC-ECD	CRQL = 0.01 ug/L
	CLP SOW METHOD ORG "Statement of Work for Organics Analysis - Multi-Media, Multi-Concentration"	GC-ED	CRQL = 0.05 ug/L
	EPA METHOD 608/SW846 Method 8080 "Organochlorine Pesticides and PCBs"	GC-ECD	MDL = 0.014 ug/L
	EPA METHOD 625 "Base/Neutrals and Acids"	GC-MS	NA
	EPA DW METHOD 505 "Analysis of Organohalide Pesticides and Aroclors in Water by Microextraction and Chromatography"	GC-ECD	MDL = 0.14 ug/L
	EPA DW METHOD 508 "Determination of Chlorinated Pesticides in Water by Gas Chromatography with an Electron Capture Detector"	GC-ECD	NA
	SMEWW METHOD 6410B "Liquid-Liquid Extraction Gas Chromatographic-Mass Spectrometric Method"	GC-MS	NA
	SMEWW METHOD 6630B "Liquid-Liquid Extraction Gas Chromatographic Method I"	GC-MS	MDL = 0.014 ug/L

APPENDIX III
TABLE III
METHODS AND DETECTION/QUANTITATION LIMITS FOR SPECIFIED ANALYTES OF CONCERN TO RISK ASSESSMENT
AQUEOUS MATRICES

ANALYTE/ COMMON NAME CAS NUMBER	METHOD REFERENCE/TITLE OF METHOD	INSTRUMENT- ATION	QUANTITATION/ DETECTION LIMIT
189 Dieldrin 60571	SMEWW METHOD 6630C "Liquid-Liquid Extraction Gas Chromatographic Method II"	GC-ECD	MDL = 0.014 ug/L
	CLP SOW METHOD LC-ORG "Chemical Analytical Services for the Analysis of Low Concentration Water Samples for Organic Compounds by Gas Chromatography-Mass Spectrometry (GC-MS) and Gas Chromatography-Electron Capture (GC-ECD) Techniques"	GC-ECD	CRQL = 0.02 ug/L
	CLP SOW METHOD ORG "Statement of Work for Organics Analysis - Multi-Media, Multi-Concentration"	GC-ECD	CRQL = 0.1 ug/L
	CLP SOW METHOD QTM "Chemical Analytical Services for Multi-Media, Multi-Concentration Samples for Organic Analysis by Quick Turnaround Gas Chromatography Techniques"	GC-ECD	CRQL = 0.1 ug/L
	EPA METHOD 608/SW846 Method 8080 "Organochlorine Pesticides and PCBs"	GC-ECD	MDL = 0.002 ug/L
	EPA METHOD 625 "Base/Neutrals and Acids"	GC-MS	MDL = 2.5 ug/L
	EPA DW METHOD 505 "Analysis of Organohalide Pesticides and Aroclors in Water by Microextraction and Chromatography"	GC-ECD	MDL = 0.012 ug/L
	EPA DW METHOD 508 "Determination of Chlorinated Pesticides in Water by Gas Chromatography with an Electron Capture Detector"	GC-ECD	EDL = 0.02 ug/L
	SMEWW METHOD 6410B "Liquid-Liquid Extraction Gas Chromatographic-Mass Spectrometric Method"	GC-MS	MDL = 2.5 ug/L
	SMEWW METHOD 6630B "Liquid-Liquid Extraction Gas Chromatographic Method I"	GC-MS	MDL = 0.002 ug/L
	SMEWW METHOD 6630C "Liquid-Liquid Extraction Gas Chromatographic Method II"	GC-ECD	MDL = 0.002 ug/L

METHODS AND DETECTION/QUANTITATION LIMITS FOR SPECIFIED ANALYTES OF CONCERN TO RISK ASSESSMENT

AQUEOUS MATRICES

ANALYTE/ COMMON NAME CAS NUMBER	METHOD REFERENCE/TITLE OF METHOD	INSTRUMENT- ATION	QUANTITATION/ DETECTION LIMIT
Heptachlor 76448	CLP SOW METHOD LC-ORG "Chemical Analytical Services for the Analysis of Low Concentration Water Samples for Organic Compounds by Gas Chromatography-Mass Spectrometry (GC-MS) and Gas Chromatography-Electron Capture (GC-ECD) Techniques"	GC-ECD	CRQL = 0.01 ug/L
	CLP SOW METHOD ORG "Statement of Work for Organics Analysis - Multi-Media, Multi-Concentration"	GC-ECD	CRQL = 0.05 ug/L
	CLP SOW METHOD QTM "Chemical Analytical Services for Multi-Media, Multi-Concentration Samples for Organic Analysis by Quick Turnaround Gas Chromatography Techniques"	GC-ECD	CRQL = 0.1 ug/L
	EPA METHOD 608/SW846 Method 8080 "Organochlorine Pesticides and PCBs"	GC-ECD	MDL = 0.003 ug/L
	EPA METHOD 625 "Base/Neutrals and Acids"	GC-MS	MDL = 1.9 ug/L
	EPA DW METHOD 505 "Analysis of Organohalide Pesticides and Aroclors in Water by Microextraction and Chromatography"	GC-ECD	MDL = 0.003 ug/L
	EPA DW METHOD 508 "Determination of Chlorinated Pesticides in Water by Gas Chromatography with an Electron Capture Detector"	GC-ECD	EDL = 0.01 ug/L
	EPA DW METHOD 525 "Determination of Organic Compounds in Drinking Water by Liquid-Solid Extraction and Capillary Column Gas Chromatography-Mass Spectrometry"	GC-MS	MDL = 0.04 ug/L
	SMEWW METHOD 6410B "Liquid-Liquid Extraction Gas Chromatographic-Mass Spectrometric Method"	GC-MS	MDL = 1.9 ug/L
	SMEWW METHOD 6630B "Liquid-Liquid Extraction Gas Chromatographic Method I"	GC-MS	MDL = 0.003 ug/L
	SMEWW METHOD 6630C "Liquid-Liquid Extraction Gas Chromatographic Method II"	GC-ECD	MDL = 0.003 ug/L

TABLE III
METHODS AND DETECTION/QUANTITATION LIMITS FOR SPECIFIED ANALYTES OF CONCERN TO RISK ASSESSMENT

AQUEOUS MATRICES

ANALYTE/ COMMON NAME CAS NUMBER	METHOD REFERENCE/TITLE OF METHOD	INSTRUMENT- ATION	QUANTITATION/ DETECTION LIMIT
Lindane 58899	CLP SOW METHOD LC-ORG "Chemical Analytical Services for the Analysis of Low Concentration Water Samples for Organic Compounds by Gas Chromatography-Mass Spectrometry (GC-MS) and Gas Chromatography-Electron Capture (GC-ECD) Techniques"	GC-ECD	CRQL = 0.01 ug/L
	CLP SOW METHOD "Statement of Work for Organics Analysis - Multi-Media, Multi-Concentration"	GC-ED	CRQL = 0.5 ug/L
	CLP SOW METHOD QTM "Chemical Analytical Services for Multi-Media, Multi-Concentration Samples for Organic Analysis by Quick Turnaround Gas Chromatography Techniques"	GC-ECD	CRQL = 0.1 ug/L
	EPA METHOD 608/SW846 Method 8080 "Organochlorine Pesticides and PCBs"	GC-ECD	MDL = 0.009 ug/L, 0.004 ug/L
	EPA METHOD 625 "Base/Neutrals and Acids"	GC-MS	MDL = 3.1 ug/L
	EPA DW METHOD 505 "Analysis of Organohalide Pesticides and Aroclors in Water by Microextraction and Chromatography"	GC-ECD	MDL = 0.003 ug/L
	EPA DW METHOD 508 "Determination of Chlorinated Pesticides in Water by Gas Chromatography with an Electron Capture Detector"	GC-ECD	EDL = 0.015 ug/L
	EPA DW METHOD 525 "Determination of Organic Compounds in Drinking Water by Liquid-Solid Extraction and Capillary Column Gas Chromatography-Mass Spectrometry"	GC-MS	MDL = 0.1 ug/L
p,p'-DDE 72559	CLP SOW METHOD LC-ORG "Chemical Analytical Services for the Analysis of Low Concentration Water Samples for Organic Compounds by Gas Chromatography-Mass Spectrometry (GC-MS) and Gas Chromatography-Electron Capture (GC-ECD) Techniques"	GC-ECD	CRQL = 0.02 ug/L
	CLP SOW METHOD ORG "Statement of Work for Organics Analysis - Multi-Media, Multi-Concentration"	GC-ECD	CRQL = 0.1 ug/L

APPENDIX III
TABLE III
METHODS AND DETECTION/QUANTITATION LIMITS FOR SPECIFIED ANALYTES OF CONCERN TO RISK ASSESSMENT
AQUEOUS MATRICES

ANALYTE/ COMMON NAME CAS NUMBER	METHOD REFERENCE/TITLE OF METHOD	INSTRUMENT- ATION	QUANTITATION/ DETECTION LIMIT
p,p'-DDE 72559	CLP SOW METHOD QTM "Chemical Analytical Services for Multi-Media, Multi-Concentration Samples for Organic Analysis by Quick Turnaround Gas Chromatography Techniques"	GC-ECD	CRQL = 0.1 ug/L
	EPA METHOD 608/SW846 Method 8080 "Organochlorine Pesticides and PCBs"	GC-ED	MDL = 0.004 ug/L
	EPA METHOD 625 "Base/Neutrals and Acids"	GC-MS	MDL = 5.6 ug/L
	EPA DW METHOD 508 "Determination of Chlorinated Pesticides in Water by Gas Chromatography with an Electron Capture Detector"	GC-ECD	EDL = 0.01 ug/L
	SMEWW METHOD 6410B "Liquid-Liquid Extraction Gas Chromatographic-Mass Spectrometric Method"	GC-MS	MDL = 5.6 ug/L
	SMEWW METHOD 6630B "Liquid-Liquid Extraction Gas Chromatographic Method I"	GC-MS	MDL = 0.004 ug/L
	SMEWW METHOD 6630C "Liquid-Liquid Extraction Gas Chromatographic Method II"	GC-ECD	MDL = 0.004 ug/L
p,p'-DDT 50293	CLP SOW METHOD LC-ORG "Chemical Analytical Services for the Analysis of Low Concentration Water Samples for Organic Compounds by Gas Chromatography-Mass Spectrometry (GC-MS) and Gas Chromatography-Electron Capture (GC-ECD) Techniques"	GC-ECD	CRQL = 0.02 ug/L
	CLP SOW METHOD ORG "Statement of Work for Organics Analysis - Multi-Media, Multi-Concentration"	GC-ECD	CRQL = 0.10 ug/L
	CLP SOW METHOD QTM "Chemical Analytical Services for Multi-Media, Multi-Concentration Samples for Organic Analysis by Quick Turnaround Gas Chromatography Techniques"	GC-ECD	CRQL = 0.1 ug/L
	EPA METHOD 608/SW846 Method 8080 "Organochlorine Pesticides and PCBs"	GC-ECD	MDL = 0.012 ug/L

APPENDIX III
TABLE III
METHODS AND DETECTION/QUANTITATION LIMITS FOR SPECIFIED ANALYTES OF CONCERN TO RISK ASSESSMENT

ANALYTE/ COMMON NAME CAS NUMBER	METHOD REFERENCE/TITLE OF METHOD	INSTRUMENT- ATION	QUANTITATION/ DETECTION LIMIT
p,p'-DDT 50293	EPA METHOD 625 "Base/Neutrals and Acids"	GC-MS	MDL = 4.7 ug/L
	EPA DW METHOD 508 "Determination of Chlorinated Pesticides in Water by Gas Chromatography with an Electron Capture Detector"	GC-ECD	EDL = 0.06 ug/L
	SMEWW METHOD 6410B "Liquid-Liquid Extraction Gas Chromatographic-Mass Spectrometric Method"	GC-MS	MDL = 4.7 ug/L
	SMEWW METHOD 6630B "Liquid-Liquid Extraction Gas Chromatographic Method I"	GC-MS	MDL = 0.012 ug/L
	SMEWW METHOD 6630C "Liquid-Liquid Extraction Gas Chromatographic Method II"	GC-ECD	MDL = 0.012 ug/L
<u>SEMIVOLATILE COMPOUNDS</u>			
3,5,5-trimethyl-2-cyclohexene-1-one (Isophorone) 78591	CLP SOW METHOD LC-ORG "Chemical Analytical Services for the Analysis of Low Concentration Water Samples for Organic Compounds by Gas Chromatography-Mass Spectrometry (GC-MS) and Gas Chromatography-Electron Capture (GC-ECD) Techniques"	GC-MS	CRQL = 5.0 ug/L
	CLP SOW METHOD ORG "Statement of Work for Organics Analysis - Multi-Media, Multi-Concentration"	GC-MS	CRQL = 10 ug/L
	EPA METHOD 609 "Nitroaromatics and Isophorone"	GC-FID	MDL = 5.7 ug/L
	EPA METHOD 609 "Nitroaromatics and Isophorone"	GC-ECD	MDL = 15.7 ug/L
	EPA METHOD 625 "Base/Neutrals and Acids"	GC-MS	MDL = 2.2 ug/L
	SMEWW METHOD 6410B "Liquid-Liquid Extraction Gas Chromatographic-Mass Spectrometric Method"	GC-MS	MDL = 2.2 ug/L
	SW846 METHOD 8270 "Gas Chromatography-Mass Spectrometry for Semivolatile Organics: Capillary Column Technique"	GC-MS	PQL = 10 ug/L

APPENDIX III
TABLE III
METHODS AND DETECTION/QUANTITATION LIMITS FOR SPECIFIED ANALYTES OF CONCERN TO RISK ASSESSMENT

AQUEOUS MATRICES

ANALYTE/ COMMON NAME CAS NUMBER	METHOD REFERENCE/TITLE OF METHOD	INSTRUMENT- ATION	QUANTITATION/ DETECTION LIMIT
Benzo <a> pyrene 50328	CLP SOW METHOD LC-ORG "Chemical Analytical Services for the Analysis of Low Concentration Water Samples for Organic Compounds by Gas Chromatography-Mass Spectrometry (GC-MS) and Gas Chromatography-Electron Capture (GC-ECD) Techniques"	GC-MS	CRQL = 5.0 ug/L
	CLP SOW METHOD ORG "Statement of Work for Organics Analysis - Multi-Media, Multi-Concentration"	GC-MS	CRQL = 10 ug/L
	EPA METHOD 610/SW846 Method 8100 "Polynuclear Aromatic Hydrocarbons"	GC-FID	MDL = 0.023 ug/L
	EPA METHOD 625 "Base/Neutrals and Acids"	GC-MS	MDL = 2.5 ug/L
	EPA DW METHOD 525 "Determination of Organic Compounds in Drinking Water by Liquid-Solid Extraction and Capillary Column Gas Chromatography-Mass Spectrometry"	GC-MS	MDL = 0.04 ug/L
	SMEWW METHOD 6410B "Liquid-Liquid Extraction Gas Chromatographic-Mass Spectrometric Method"	GC-MS	MDL = 2.5 ug/L
	CLP SOW METHOD QTM "Chemical Analytical Services for Multi-Media, Multi-Concentration Samples for Organic Analysis by Quick Turnaround Gas Chromatography Techniques"	GC-ECD	CRQL = 20 ug/L
	SMEWW METHOD 6440B "Liquid-Liquid Extraction Chromatographic Method"	GC-MS	MDL = 0.023 ug/L
	SW846 METHOD 8270 "Gas Chromatography-Mass Spectrometry for Semivolatile Organics: Capillary Column Technique"	GC-MS	PQL = 10 ug/L
SW846 METHOD 8310 "Polynuclear Aromatic Hydrocarbons"		HPLC	MDL = 0.023 ug/L

APPENDIX III
TABLE III
METHODS AND DETECTION/QUANTITATION LIMITS FOR SPECIFIED ANALYTES OF CONCERN TO RISK ASSESSMENT
AQUEOUS MATRICES

ANALYTE/ COMMON NAME CAS NUMBER	METHOD REFERENCE/TITLE OF METHOD	INSTRUMENT- ATION	QUANTITATION/ DETECTION LIMIT
Bis-(2-Chloroethyl) ether 111444	CLP SOW METHOD LC-ORG "Chemical Analytical Services for the Analysis of Low Concentration Water Samples for Organic Compounds by Gas Chromatography-Mass Spectrometry (GC-MS) and Gas Chromatography-Electron Capture (GC-ECD) Techniques"	GC-MS	CRQL = 5.0 ug/L
	CLP SOW METHOD ORG "Statement of Work for Organics Analysis - Multi-Media, Multi-Concentration"	GC-MS	CRQL = 10 ug/L
	EPA METHOD 625 "Base/Neutrals and Acids"	GC-MS	MDL = 5.7 ug/L
	SMEWW METHOD 6040B "Closed-Loop Stripping, Gas-Chromatographic-Mass-Spectrometric Analysis"	GC-MS	EDL = 0.001 ug/L
	SMEWW METHOD 6410B "Liquid-Liquid Extraction Gas Chromatographic-Mass Spectrometric Method"	GC-MS	MDL = 5.7 ug/L
Bis (2-ethylhexyl) phthalate 117817	SW846 METHOD 8250 "Gas Chromatography-Mass Spectrometry for Semivolatile Organics: Packed Column Technique"	GC-MS	MDL = 5.7 ug/L
	CLP SOW METHOD LC-ORG "Chemical Analytical Services for the Analysis of Low Concentration Water Samples for Organic Compounds by Gas Chromatography-Mass Spectrometry (GC-MS) and Gas Chromatography-Electron Capture (GC-ECD) Techniques"	GC-MS	CRQL = 5.0 ug/L
	CLP SOW METHOD ORG "Statement of Work for Organics Analysis - Multi-Media, Multi-Concentration"	GC-MS	CRQL = 10 ug/L
	EPA METHOD 606 "Phthalate Ester"	GC-ECD	MDL = 2.0 ug/L
	EPA METHOD 625 "Base/Neutrals and Acids"	GC-MS	MDL = 2.5 ug/L
	EPA DW METHOD 525 "Determination of Organic Compounds in Drinking Water by Liquid-Solid Extraction and Capillary Column Gas Chromatography-Mass Spectrometry"	GC-MS	MDL = 0.8 ug/L

APPENDIX III
TABLE III

METHODS AND DETECTION/QUANTITATION LIMITS FOR SPECIFIED ANALYTES OF CONCERN TO RISK ASSESSMENT

AQUEOUS MATRICES

ANALYTE/ COMMON NAME CAS NUMBER	METHOD REFERENCE/TITLE OF METHOD	INSTRUMENT- ATION	QUANTITATION/ DETECTION LIMIT
Bis (2-ethylhexyl) phthalate 117817	SMEWW METHOD 6410B "Liquid-Liquid Extraction Gas Chromatographic-Mass Spectrometric Method"	GC-MS	MDL = 2.5 ug/L
	SW846 METHOD 8060 "Phthalate Esters"	GC-ECD	MDL = 2.0 ug/L
	SW846 METHOD 8270 "Gas Chromatography-Mass Spectrometry for Semivolatile Organics: Capillary Column Technique"	GC-MS	PQL = 10 ug/L
	SW846 METHOD 8250 "Gas Chromatography-Mass Spectrometry for Semi-Volatile Organics: Packed Column Technique"	GC-MS	MDL = 2.5 ug/L
196 N-nitrosodi- phenylamine 86306	CLP SOW METHOD LC-ORG "Chemical Analytical Services for the Analysis of Low Concentration Water Samples for Organic Compounds by Gas Chromatography-Mass Spectrometry (GC-MS) and Gas Chromatography-Electron Capture (GC-ECD) Techniques"	GC-MS	CRQL = 5.0 ug/L
	CLP SOW METHOD ORG "Statement of Work for Organics Analysis - Multi-Media, Multi-Concentration"	GC-MS	CRQL = 10 ug/L
	EPA METHOD 607 "Nitrosamines"	GC-ELCD	MDL = 0.81 ug/L
	EPA METHOD 625 "Base/Neutrals and Acids"	GC-MS	MDL = 1.9 ug/L
	SMEWW METHOD 6410B "Liquid-Liquid Extraction Gas Chromatographic-Mass Spectrometric (GC-MS) Method"	GC-MS	MDL = 1.9 ug/L
	SW846 METHOD 8270 "Gas Chromatography-Mass Spectrometry for Semivolatile Organics: Capillary Column Technique"	GC-MS	PQL = 10 ug/L
<u>VOLATILE COMPOUNDS</u>			
1,1-dichloroethane 75343	CLP SOW METHOD LC-ORG "Chemical Analytical Services for the Analysis of Low Concentration Water Samples for Organic Compounds by Gas Chromatography-Mass Spectrometry (GC-MS) and Gas Chromatography-Electron Capture (GC-ECD) Techniques"	GC-MS	CRQL = 1.0 ug/L

APPENDIX III

TABLE III

METHODS AND DETECTION/QUANTITATION LIMITS FOR SPECIFIED ANALYTES OF CONCERN TO RISK ASSESSMENT

AQUEOUS MATRICES

ANALYTE/ COMMON NAME CAS NUMBER	METHOD REFERENCE/TITLE OF METHOD	INSTRUMENT- ATION	QUANTITATION/ DETECTION LIMIT
1,1-dichloroethane 75343	CLP SOW METHOD QTM "Chemical Analytical Services for Multi-Media, Multi-Concentration Samples for Organic Analysis by Quick Turnaround Gas Chromatography Techniques"	GC-PID	CRQL = 20 ug/L
	CLP SOW METHOD ORG "Statement of Work for Organics Analysis - Multi-Media, Multi-Concentration"	GC-MS	CRQL = 10 ug/L
	EPA METHOD 601/SW846 Method 8010/SMEWW Method 6230B "Purgeable Halocarbons"	GC-ELCD	MDL = 0.07 ug/L
	EPA METHOD 624 "Purgeables"	GC-MS	MDL = 4.7 ug/L
	EPA DW METHOD 502.1 "Volatile Halogenated Organic Compounds in Water by Purge and Trap Gas Chromatography"	GC-ELCD	MDL = 0.003 ug/L
	EPA DW METHOD 502.2 "Volatile Organic Compounds in Water by Purge and Trap Capillary Column Gas Chromatography with Photoionization and Electrolytic Conductivity Detectors in Series"	GC-ELCD	MDL = 0.07 ug/L
	EPA DW METHOD 524.1/SMEWW Method 6210B (Method I)/SMEWW Method 6210C (Method II) "Measurement of Purgeable Organic Compounds in Water by Packed Column Gas Chromatography-Mass Spectrometry"	GC-MS	MDL = 0.2 ug/L MDL = 4.7 ug/L
	EPA DW METHOD 524.2/SMEWW Method 6210D "Measurement of Purgeable Organic Compounds in Water by Capillary Column Gas Chromatography-Mass Spectrometry"	GC-MS	MDL = 0.04 ug/L
	SMEWW METHOD 6230C "Purge and Trap Packed-Column Gas Chromatographic Method II"	GC-MS	MDL = 0.07 ug/L
	SMEWW METHOD 6230D "Purge and Trap Capillary-Column Gas Chromatographic Method"	GC-ECD	NA

APPENDIX III
TABLE III
METHODS AND DETECTION/QUANTITATION LIMITS FOR SPECIFIED ANALYTES OF CONCERN TO RISK ASSESSMENT
AQUEOUS MATRICES

ANALYTE/ COMMON NAME CAS NUMBER	METHOD REFERENCE/TITLE OF METHOD	INSTRUMENT- ATION	QUANTITATION/ DETECTION LIMIT
1,1-dichloroethane 75343	SW846 METHOD 8240 "Gas Chromatography-Mass Spectrometry for Volatile Organics"	GC-MS	PQL = 5.0 ug/L
1,1-dichloroethene 75354	CLP SOW METHOD LC-ORG "Chemical Analytical Services for the Analysis of Low Concentration Water Samples for Organic Compounds by Gas Chromatography-Mass Spectrometry (GC-MS) and Gas Chromatography-Electron Capture (GC-ECD) Techniques"	GC-MS	CRQL = 1.0 ug/L
	CLP SOW METHOD ORG "Statement of Work for Organics Analysis - Multi-Media, Multi-Concentration"	GC-MS	CRQL = 10 ug/L
	CLP SOW METHOD QTM "Chemical Analytical Services for Multi-Media, Multi-Concentration Samples for Organic Analysis by Quick Turnaround Gas Chromatography Techniques"	GC-ECD	CRQL = 20 ug/L
	EPA METHOD 624 "Purgeables"	GC-MS	MDL = 2.8 ug/L
	EPA METHOD 601/SMEWW Method 6230B "Purgeable Hydrocarbons"	GC-ELCD	MDL = 0.13 ug/L
	EPA DW METHOD 502.1 "Volatile Halogenated Organic Compounds in Water by Purge and Trap Gas Chromatography"	GC-ELCD	MDL = 0.003 ug/L
	EPA DW METHOD 502.2 "Volatile Organic Compounds in Water by Purge and Trap Capillary Column Gas Chromatography with Photoionization and Electrolytic Conductivity Detectors in Series"	GC-PID	NA
	EPA DW METHOD 502.2 "Volatile Organic Compounds in Water by Purge and Trap Capillary Column Gas Chromatography with Photoionization and Electrolytic Conductivity Detectors in Series"	GC-ELCD	MDL = 0.07 ug/L
	EPA DW METHOD 524.1/SMEWW Method 6210B (Method I)/SMEWW Method 6210C (Method II) "Measurement of Purgeable Organic Compounds in Water by Packed Column Gas Chromatography-Mass Spectrometry"	GC-MS	MDL = 0.2 ug/L MDL = 2.8 ug/L, 2.8 ug/L

APPENDIX III
TABLE III
METHODS AND DETECTION/QUANTITATION LIMITS FOR SPECIFIED ANALYTES OF CONCERN TO RISK ASSESSMENT
AQUEOUS MATRICES

ANALYTE/ COMMON NAME CAS NUMBER	METHOD REFERENCE/TITLE OF METHOD	INSTRUMENT- ATION	QUANTITATION/ DETECTION LIMIT
1,1-dichloroethene 75354	EPA DW METHOD 524.2/SMEWW Method 6210D "Measurement of Purgeable Organic Compounds in Water by Capillary Column Gas Chromatography-Mass Spectrometry"	GC-MS	MDL = 0.12 ug/L
	CLP SOW METHOD QTM "Chemical Analytical Services for Multi-Media, Multi-Concentration Samples for Organic Analysis by Quick Turnaround Gas Chromatography Techniques"	GC-PID	MDL = 20 ug/L
	SMEWW METHOD 6230C "Purge and Trap Packed-Column Gas Chromatographic Method II"	GC-MS	MDL = 0.13 ug/L
	SMEWW METHOD 6230D "Purge and Trap Capillary-Column Gas Chromatographic Method"	GC-PID/ GC-ECD	NA
	SW846 METHOD 8240 "Gas Chromatography-Mass Spectrometry for Volatile Organics"	GC-MS	PQL = 5.0 ug/L
1,1,2-trichloroethane 79005	CLP SOW METHOD LC-ORG "Chemical Analytical Services for the Analysis of Low Concentration Water Samples for Organic Compounds by Gas Chromatography-Mass Spectrometry (GC-MS) and Gas Chromatography-Electron Capture (GC-ECD) Techniques"	GC-MS	CRQL = 1.0 ug/L
	CLP SOW METHOD ORG OLM01.0 "Statement of Work for Organics Analysis - Multi-Media, Multi-Concentration"	GC-MS	CRQL = 10 ug/L
	EPA METHOD 601/SW846 Method 8010/SMEWW Method 6230B "Purgeable Halocarbons"	GC-ELCD	MDL = 0.02 ug/L
	EPA METHOD 624 "Purgeables"	GC-MS	MDL = 5.0 ug/L
	EPA DW METHOD 502.1 "Volatile Halogenated Organic Compounds in Water by Purge and Trap Gas Chromatography"	GC-ELCD	MDL = 0.007 ug/L

APPENDIX III
TABLE III
METHODS AND DETECTION/QUANTITATION LIMITS FOR SPECIFIED ANALYTES OF CONCERN TO RISK ASSESSMENT
AQUEOUS MATRICES

ANALYTE/ COMMON NAME CAS NUMBER	METHOD REFERENCE/TITLE OF METHOD	INSTRUMENT- ATION	QUANTITATION/ DETECTION LIMIT
1,1,2-trichloroethane 79005	EPA DW METHOD 502.2 "Volatile Organic Compounds in Water by Purge and Trap Capillary Column Gas Chromatography with Photoionization and Electrolytic Conductivity Detectors in Series"	GC-ELCD	NA
	EPA DW METHOD 524.2 "Measurement of Purgeable Organic Compounds in Water by Capillary Column Gas Chromatography-Mass Spectrometry"	GC-MS	MDL = 0.1 ug/L
	SMEWW METHOD 6040B "Closed-Loop Stripping, Gas-Chromatographic-Mass Spectrometric Analysis"	GC-MS	EDL = 0.002 ug/L
	SMEWW METHOD 6210B "Purge and Trap Packed-Column Gas Chromatographic-Mass Spectrometric Method I"	GC-MS	MDL = 5.0 ug/L
	SMEWW METHOD 6230C "Purge and Trap Packed-Column Gas Chromatographic Method II"	GC-MS	MDL = 0.02 ug/L
	SMEWW METHOD 6230D "Purge and Trap Capillary-Column Gas Chromatographic Method"	GC-ECD	NA
1,1,2,2-tetrachloroethane 79345	SW846 METHOD 8240 "Gas Chromatography-Mass Spectrometry for Volatile Organics"	GC-MS	PQL = 5.0 ug/L
	CLP SOW METHOD LC-ORG "Chemical Analytical Services for the Analysis of Low Concentration Water Samples for Organic Compounds by Gas Chromatography-Mass Spectrometry (GC-MS) and Gas Chromatography-Electron Capture (GC-ECD) Techniques"	GC-MS	CRQL = 1.0 ug/L
	CLP SOW METHOD ORG, "Statement of Work for Organics Analysis - Multi-Media, Multi-Concentration"	GC-MS	CRQL = 10 ug/L
	CLP SOW METHOD QTM "Chemical Analytical Services for Multi-Media, Multi-Concentration Samples for Organic Analysis by Quick Turnaround Gas Chromatography Techniques"	GC-PID	CRQL = 20 ug/L

APPENDIX III
TABLE III
METHODS AND DETECTION/QUANTITATION LIMITS FOR SPECIFIED ANALYTES OF CONCERN TO RISK ASSESSMENT
AQUEOUS MATRICES

ANALYTE/ COMMON NAME CAS NUMBER	METHOD REFERENCE/TITLE OF METHOD	INSTRUMENT- ATION	QUANTITATION/ DETECTION LIMIT
1,1,2,2- tetrachloroethane 79345	EPA METHOD 601/SW846 Method 8010/SMEWW Method 6230B "Purgeable Halocarbons"	GC-ELCD	MDL = 0.03 ug/L
	EPA METHOD 624 "Purgeables"	GC-MS	MDL = 6.9 ug/L
	EPA DW METHOD 502.1 "Volatile Halogenated Organic Compounds in Water by Purge and Trap Gas Chromatography"	GC-ELCD	MDL = 0.01 ug/L
	EPA DW METHOD 502.2 "Volatile Organic Compounds in Water by Purge and Trap Capillary Column Gas Chromatography with Photoionization and Electrolytic Conductivity Detectors in Series"	GC-ELCD	MDL = 0.08 ug/L
	EPA DW METHOD 524.1/SMEWW Method 6210B "Measurement of Purgeable Organic Compounds in Water by Packed Column Gas Chromatography-Mass Spectrometry"	GC-MS	MDL = 0.4 ug/L MDL = 6.9 ug/L
	EPA DW METHOD 524.2/SMEWW Method 6210D "Measurement of Purgeable Organic Compounds in Water by Capillary Column Gas Chromatography-Mass Spectrometry"	GC-MS	MDL = 0.04 ug/L MDL = 1.11 ug/L
	SMEWW METHOD 6040B "Closed-Loop Stripping, Gas-Chromatographic-Mass-Spectrometric Analysis"	GC-MS	EDL = 50 ug/L
	SMEWW METHOD 6230D "Purge and Trap Capillary-Column Gas Chromatographic Method"	GC-PID	MDL = 0.03 ug/L
1,2-dichloroethane 107062	SW846 METHOD 8240 "Gas Chromatography-Mass Spectrometry for Volatile Organics"	GC-MS	PQL = 5.0 ug/L
	CLP SOW METHOD LC-ORG "Chemical Analytical Services for the Analysis of Low Concentration Water Samples for Organic Compounds by Gas Chromatography-Mass Spectrometry (GC-MS) and Gas Chromatography-Electron Capture (GC-ECD) Techniques"	GC-MS	CRQL = 1.0 ug/L

APPENDIX III

TABLE III

METHODS AND DETECTION/QUANTITATION LIMITS FOR SPECIFIED ANALYTES OF CONCERN TO RISK ASSESSMENT

AQUEOUS MATRICES

ANALYTE/ COMMON NAME CAS NUMBER	METHOD REFERENCE/TITLE OF METHOD	INSTRUMENT- ATION	QUANTITATION/ DETECTION LIMIT
1,2-dichloroethane 107062	CLP SOW METHOD ORG "Statement of Work for Organics Analysis - Multi-Media, Multi-Concentration"	GC-MS	CRQL = 10 ug/L
	CLP SOW METHOD QTM "Chemical Analytical Services for Multi-Media, Multi-Concentration Samples for Organic Analysis by Quick Turnaround Gas Chromatography Techniques"	GC-EC	CRQL = 20 ug/L
	EPA METHOD 601/SW846 Method 8010/SMEWW Method 6230B "Purgeable Halocarbons"	GC-ELCD	MDL = 0.03 ug/L
	EPA METHOD 624 "Purgeables"	GC-MS	MDL = 2.8 ug/L
	EPA DW METHOD 502.1 "Volatile Halogenated Organic Compounds in Water by Purge and Trap Gas Chromatography"	GC-ELCD	MDL = 0.002 ug/L
	EPA DW METHOD 502.2 "Volatile Organic Compounds in Water by Purge and Trap Capillary Column Gas Chromatography with Photoionization and Electrolytic Conductivity Detectors in Series"	GC-ELCD	MDL = 0.03 ug/L
	EPA DW METHOD 524.1/SMEWW Method 6210B (Method I)/SMEWW Method 6210 C (Method II) "Measurement of Purgeable Organic Compounds in Water by Packed Column Gas Chromatography-Mass Spectrometry"	GC-MS	MDL = 0.2 ug/L, 2.8 ug/L, MDL = 2.8 ug/L
	EPA DW METHOD 524.2 "Measurement of Purgeable Organic Compounds in Water by Capillary Column Gas Chromatography-Mass Spectrometry"	GC-MS	MDL = 0.06 ug/L
	SMEWW METHOD 6230C "Purge and Trap Packed Column Gas Chromatographic Method II"	GC-MS	MDL = 0.03 ug/L
	SMEWW METHOD 6230D "Purge and Trap Capillary Column Gas Chromatographic Method"	GC-ECD	NA

METHODS AND DETECTION/QUANTITATION LIMITS FOR SPECIFIED ANALYTES OF CONCERN TO RISK ASSESSMENT

AQUEOUS MATRICES

ANALYTE/ COMMON NAME CAS NUMBER	METHOD REFERENCE/TITLE OF METHOD	INSTRUMENT- ATION	QUANTITATION/ DETECTION LIMIT
1,2-dichloroethane 107062	SW846 METHOD 8240 "Gas Chromatography-Mass Spectrometry for Volatile Organics"	GC-MS	PQL = 5.0 ug/L
1,2-dichloropropane 78875	CLP SOW METHOD LC-ORG "Chemical Analytical Services for the Analysis of Low Concentration Water Samples for Organic Compounds by Gas Chromatography-Mass Spectrometry (GC-MS) and Gas Chromatography-Electron Capture (GC-ECD) Techniques"	GC-MS	CRQL = 1.0 ug/L
	CLP SOW METHOD ORG "Statement of Work for Organics Analysis - Multi-Media, Multi-Concentration"	GC-MS	CRQL = 10 ug/L
	EPA METHOD 601/SW846 Method 8010/SMEWW Method 6230B "Purgeable Halocarbons"	GC-ELCD	MDL = 0.04 ug/L
	EPA METHOD 624 "Purgeables"	GC-MS	MDL = 6.0 ug/L
	EPA DW METHOD 502.1 "Volatile Halogenated Organic Compounds in Water by Purge and Trap Gas Chromatography"	GC-ELCD	NA
	EPA DW METHOD 502.2 "Volatile Organic Compounds in Water by Purge and Trap Capillary Column Gas Chromatography with Photoionization and Electrolytic Conductivity Detectors in Series"	GC-PID	NA
	EPA DW METHOD 502.2 "Volatile Organic Compounds in Water by Purge and Trap Capillary Column Gas Chromatography with Photoionization and Electrolytic Conductivity Detectors in Series"	GC-ELCD	MDL = 0.01 ug/L
	EPA DW METHOD 524.1/SMEWW Method 6210B/SMEWW Method 6210C "Measurement of Purgeable Organic Compounds in Water by Packed Column Gas Chromatography-Mass Spectrometry"	GC-MS	MDL = 0.2 ug/L MDL = 6.0 ug/L, 6.0 ug/L
	EPA DW METHOD 524.2/SMEWW Method 6210D "Measurement of Purgeable Organic Compounds in Water by Capillary Column Gas Chromatography-Mass Spectrometry"	GC-MS	MDL = 0.04 ug/L

APPENDIX III
TABLE III
METHODS AND DETECTION/QUANTITATION LIMITS FOR SPECIFIED ANALYTES OF CONCERN TO RISK ASSESSMENT
AQUEOUS MATRICES

ANALYTE/ COMMON NAME CAS NUMBER	METHOD REFERENCE/TITLE OF METHOD	INSTRUMENT- ATION	QUANTITATION/ DETECTION LIMIT
1,2-dichloropropane 78875	EPA SMEWW METHOD 6230C "Purge and Trap Packed-Column Gas Chromatographic Method II"	GC-MS	MDL = 0.04 ug/L
	SMEWW METHOD 6230D "Purge and Trap Capillary-Column Gas Chromatographic Method"	GC-ECD	NA
	SW846 METHOD 8240 "Gas Chromatography-Mass Spectrometry for Volatile Organics"	GC-MS	PQL = 5.0 ug/L
1,4-dichlorobenzene 106467	CLP SOW METHOD LC-ORG "Chemical Analytical Services for the Analysis of Low Concentration Water Samples for Organic Compounds by Gas Chromatography-Mass Spectrometry (GC-MS) and Gas Chromatography-Electron Capture (GC-ECD) Techniques"	GC-MS	CRQL = 1.0 ug/L
	CLP SOW METHOD ORG "Statement of Work for Organics Analysis - Multi-Media, Multi-Concentration"	GC-MS	CRQL = 10 ug/L
	EPA METHOD 601/SW846 Method 8010/SMEWW Method 6230B "Purgeable Halocarbons"	GC-ELCD	MDL = 0.24 ug/L
	EPA METHOD 602/SW846 Method 8020/SMEWW Method 6220B "Purgeable Aromatics"	GC-PID	MDL = 0.3 ug/L
	EPA METHOD 612 "Chlorinated Hydrocarbons"	GC-ED	MDL = 1.34 ug/L
	EPA METHOD 624 "Purgeables"	GC-MS	NA
	EPA METHOD 625 "Base/Neutrals and Acids"	GC-MS	MDL = 4.4 ug/L
	EPA DW METHOD 502.1 "Volatile Halogenated Organic Compounds in Water by Purge and Trap Gas Chromatography"	GC-ELCD	NA
	EPA DW METHOD 502.2 "Volatile Organic Compounds in Water by Purge and Trap Capillary Column Gas Chromatography with Photoionization and Electrolytic Conductivity Detectors in Series"	GC-PID	MDL = 0.01 ug/L

APPENDIX III
TABLE III
METHODS AND DETECTION/QUANTITATION LIMITS FOR SPECIFIED ANALYTES OF CONCERN TO RISK ASSESSMENT
AQUEOUS MATRICES

ANALYTE/ COMMON NAME CAS NUMBER	METHOD REFERENCE/TITLE OF METHOD	INSTRUMENT- ATION	QUANTITATION/ DETECTION LIMIT
1,4-dichlorobenzene 106467	EPA DW METHOD 502.2 "Volatile Organic Compounds in Water by Purge and Trap Capillary Column Gas Chromatography with Photoionization and Electrolytic Conductivity Detectors in Series"	GC-ELCD	MDL = 0.01 ug/L
	EPA DW METHOD 503.1 "Volatile Aromatic and Unsaturated Organic Compounds in Water by Purge and Trap Gas Chromatography"	GC-PID	MDL = 0.006 ug/L
	EPA DW METHOD 524.1/SMEWW Method 6210B (Method I)/SMEWW Method 6210C (Method II) "Measurement of Purgeable Organic Compounds in Water by Packed Column Gas Chromatography-Mass Spectrometry"	GC-MS	MDL = 2.0 ug/L
	EPA DW METHOD 524.2/SMEWW Method 6210D "Measurement of Purgeable Organic Compounds in Water by Capillary Column Gas Chromatography-Mass Spectrometry"	GC-MS	MDL = 0.03 ug/L
	SMEWW METHOD 6230C "Purge and Trap Packed-Column Gas Chromatographic Method II"	GC-MS	MDL = 0.24 ug/L
	SMEWW METHOD 6230D "Purge and Trap Capillary-Column Gas Chromatographic Method"	GC-PID/ GC-ECD	NA
	SMEWW METHOD 6410B "Liquid-Liquid Extraction Gas Chromatographic-Mass Spectrometric Method"	GC-MS	MDL = 4.4 ug/L
Benzene 71432	SW846 METHOD 8270 "Gas Chromatography-Mass Spectrometry for Semivolatile Organics: Capillary Column Technique"	GC-MS	PQL = 10 ug/L
	CLP SOW METHOD LC-ORG "Chemical Analytical Services for the Analysis of Low Concentration Water Samples for Organic Compounds by Gas Chromatography-Mass Spectrometry (GC-MS) and Gas Chromatography-Electron Capture (GC-ECD) Techniques"	GC-MS	CRQL = 1.0 ug/L

APPENDIX III
TABLE III
METHODS AND DETECTION/QUANTITATION LIMITS FOR SPECIFIED ANALYTES OF CONCERN TO RISK ASSESSMENT
AQUEOUS MATRICES

ANALYTE/ COMMON NAME CAS NUMBER	METHOD REFERENCE/TITLE OF METHOD	INSTRUMENT- ATION	QUANTITATION/ DETECTION LIMIT
Benzene 71432	CLP SOW METHOD ORG "Statement of Work for Organics Analysis - Multi-Media, Multi-Concentration"	GC-MS	CRQL = 5.0 ug/L
	CLP SOW METHOD QTM "Chemical Analytical Services for Multi-Media, Multi-Concentration Samples for Organic Analysis by Quick Turnaround Gas Chromatography Techniques"	GC-ECD	CRQL = 20 ug/L
	EPA METHOD 602/SW846 Method 8020/SMEWW Method 6220B "Purgeable Aromatics"	GC-PID	MDL = 0.2 ug/L
	EPA METHOD 624 "Purgeables"	GC-MS	MDL = 4.4 ug/L
	EPA DW METHOD 502.2 "Volatile Organic Compounds in Water by Purge and Trap Capillary Column Gas Chromatography with Photoionization and Electrolytic Conductivity Detectors in Series"	GC-PID	MDL = 0.01 ug/L
	EPA DW METHOD 503.1 "Volatile Aromatic and Unsaturated Organic Compounds in Water by Purge and Trap Gas Chromatography"	GC-PID	MDL = 0.02 ug/L
	EPA DW METHOD 524.1/SMEWW Method 6210B (Method I)/SMEWW Method 6210C (Method II) "Measurement of Purgeable Organic Compounds in Water by Packed Column Gas Chromatography-Mass Spectrometry"	GC-MS	MDL = 0.1 ug/L, 4.4 ug/L MDL = 4.4 ug/L
	EPA DW METHOD 524.2/SMEWW Method 6210D "Measurement of Purgeable Organic Compounds in Water by Capillary Column Gas Chromatography-Mass Spectrometry"	GC-MS	MDL = 0.04 ug/L
	SMEWW METHOD 6220C "Purge and Trap Gas Chromatographic Method II"	GC-MS	MDL = 0.2 ug/L
	SMEWW METHOD 6230D "Purge and Trap Capillary-Column Gas Chromatographic Method"	GC-ECD	NA

APPENDIX III
TABLE III
METHODS AND DETECTION/QUANTITATION LIMITS FOR SPECIFIED ANALYTES OF CONCERN TO RISK ASSESSMENT

AQUEOUS MATRICES

ANALYTE/ COMMON NAME CAS NUMBER	METHOD REFERENCE/TITLE OF METHOD	INSTRUMENT- ATION	QUANTITATION/ DETECTION LIMIT
Benzene 71432	SW846 METHOD 8240 "Gas Chromatography-Mass Spectrometry for Volatile Organics"	GC-MS	PQL = 5.0 ug/L
Chloroethene (Vinyl Chloride) 75014	CLP SOW METHOD LC-ORG "Chemical Analytical Services for the Analysis of Low Concentration Water Samples for Organic Compounds by Gas Chromatography-Mass Spectrometry (GC-MS) and Gas Chromatography-Electron Capture (GC-ECD) Techniques"	GC-MS	CRQL = 1.0 ug/L
	CLP SOW METHOD ORG "Statement of Work for Organics Analysis - Multi-Media, Multi-Concentration"	GC-MS	CRQL = 10 ug/L
	CLP SOW METHOD QTM "Chemical Analytical Services for Multi-Media, Multi-Concentration Samples for Organic Analysis by Quick Turnaround Gas Chromatography Techniques"	GC-ECD	CRQL = 20 ug/L
	EPA METHOD 601/SW846 Method 8010/SMEWW Method 6230 "Purgeable Halocarbons"	GC-ELCD	MDL = 0.18 ug/L
	EPA METHOD 624 "Purgeables"	GC-MS	NA
	EPA DW METHOD 502.1 "Volatile Halogenated Organic Compounds in Water by Purge and Trap Gas Chromatography"	GC-ELCD	MDL = 0.01 ug/L
	EPA DW METHOD 502.2 "Volatile Organic Compounds in Water by Purge and Trap Capillary Column Gas Chromatography with Photoionization and Electrolytic Conductivity Detectors in Series"	GC-PID	MDL = 0.02 ug/L
	EPA DW METHOD 502.2 "Volatile Organic Compounds in Water by Purge and Trap Capillary Column Gas Chromatography with Photoionization and Electrolytic Conductivity Detectors in Series"	GC-ELCD	MDL = 0.04 ug/L
	EPA DW METHOD 524.1/SMEWW Method 6210B (Method I)/SMEWW Method 6210C (Method II) "Measurement of Purgeable Organic Compounds in Water by Packed Column Gas Chromatography-Mass Spectrometry"	GC-MS	MDL = 0.3 ug/L

APPENDIX III
TABLE III
METHODS AND DETECTION/QUANTITATION LIMITS FOR SPECIFIED ANALYTES OF CONCERN TO RISK ASSESSMENT

AQUEOUS MATRICES

ANALYTE/ COMMON NAME CAS NUMBER	METHOD REFERENCE/TITLE OF METHOD	INSTRUMENT- ATION	QUANTITATION/ DETECTION LIMIT
Chloroethene (Vinyl Chloride) 75014	EPA DW METHOD 524.2/SMEWW Method 6210D "Measurement of Purgeable Organic Compounds in Water by Capillary Column Gas Chromatography-Mass Spectrometry"	GC-MS	MDL = 0.17 ug/L
	SMEWW METHOD 6230C "Purge and Trap Packed-Column Gas Chromatographic Method II"	GC-MS	MDL = 0.18 ug/L
	SMEWW METHOD 6230D "Purge and Trap Capillary Column Gas Chromatographic Method"	GC-PID/ GC-ECD	NA
	SW846 METHOD 8010 "Halogenated Volatile Organics"	GC-ELCD	MDL = 0.18 ug/L
	SW846 METHOD 8240 "Gas Chromatography-Mass Spectrometry for Volatile Organics"	GC-MS	PQL = 10 ug/L
Dichloromethane (Methylene Chloride) 75092	CLP SOW METHOD LC-ORG "Chemical Analytical Services for the Analysis of Low Concentration Water Samples for Organic Compounds by Gas Chromatography-Mass Spectrometry (GC-MS) and Gas Chromatography-Electron Capture (GC-ECD) Techniques"	GC-MS	CRQL = 2.0 ug/L
	CLP SOW METHOD ORG "Statement of Work for Organics Analysis - Multi-Media, Multi-Concentration"	GC-MS	CRQL = 10 ug/L
	EPA METHOD 601/SMEWW Method 6230B "Purgeable Halocarbons"	GC-ELCD	MDL = 0.25 ug/L
	EPA METHOD 624 "Purgeables"	GC-MS	MDL = 2.8 ug/L
	EPA DW METHOD 502.1 "Volatile Halogenated Organic Compounds in Water by Purge and Trap Gas Chromatography"	GC-ELCD	NA
	EPA DW METHOD 502.2 "Volatile Organic Compounds in Water by Purge and Trap Capillary Column Gas Chromatography with Photoionization and Electrolytic Conductivity Detectors in Series"	GC-ELCD	MDL = 0.02 ug/L

APPENDIX III
TABLE III
METHODS AND DETECTION/QUANTITATION LIMITS FOR SPECIFIED ANALYTES OF CONCERN TO RISK ASSESSMENT
AQUEOUS MATRICES

ANALYTE/ COMMON NAME CAS NUMBER	METHOD REFERENCE/TITLE OF METHOD	INSTRUMENT- ATION	QUANTITATION/ DETECTION LIMIT
Dichloromethane (Methylene Chloride) 75092	EPA DW METHOD 524.1/SMEWW Method 6210B (Method I)/SMEWW Method 6210C (Method II) "Measurement of Purgeable Organic Compounds in Water by Packed Column Gas Chromatography-Mass Spectrometry"	GC-MS	MDL = 1.0 ug/L MDL = 2.8 ug/L
	EPA DW METHOD 524.2 /SMEWW Method 6210D "Measurement of Purgeable Organic Compounds in Water by Capillary Column Gas Chromatography-Mass Spectrometry"	GC-MS	MDL = 0.03 ug/L
	SMEWW METHOD 6230C "Purge and Trap Packed-Column Gas Chromatographic Method II"	GC-MS	MDL = 0.25 ug/L
	SMEWW METHOD 6230D "Purge and Trap Capillary-Column Gas Chromatographic Method"	GC-ECD	NA
	SW846 METHOD 8240 "Gas Chromatography-Mass Spectrometry for Volatile Organics"	GC-MS	PQL = 5.0 ug/L
Ethenyl Benzene (Styrene) 100425	CLP SOW METHOD LC-ORG "Chemical Analytical Services for the Analysis of Low Concentration Water Samples for Organic Compounds by Gas Chromatography-Mass Spectrometry (GC-MS) and Gas Chromatography-Electron Capture (GC-ECD) Techniques"	GC-MS	CRQL = 1.0 ug/L
	CLP SOW METHOD ORG "Statement of Work for Organics Analysis - Multi-Media, Multi-Concentration"	GC-MS	CRQL = 10 ug/L
	EPA METHOD 602 "Purgeable Aromatics"	GC-PID	MDL = 0.20 ug/L
	EPA DW METHOD 502.2 "Volatile Organic Compounds in Water by Purge and Trap Capillary Column Gas Chromatography with Photoionization and Electrolytic Conductivity Detectors in Series"	GC-PID	MDL = 0.01 ug/L
	EPA DW METHOD 503.1 "Volatile Aromatic and Unsaturated Organic Compounds in Water by Purge and Trap Gas Chromatography"	GC-PID	MDL = 0.008 ug/L

APPENDIX III
TABLE III
METHODS AND DETECTION/QUANTITATION LIMITS FOR SPECIFIED ANALYTES OF CONCERN TO RISK ASSESSMENT

AQUEOUS MATRICES

ANALYTE/ COMMON NAME CAS NUMBER	METHOD REFERENCE/TITLE OF METHOD	INSTRUMENT- ATION	QUANTITATION/ DETECTION LIMIT
Ethenyl Benzene (Styrene) 100425	EPA DW METHOD 524.1/SMEWW Method 6210C "Measurement of Purgeable Organic Compounds in Water by Packed Column Gas Chromatography-Mass Spectrometry"	GC-MS	MDL = 0.2 ug/L
	EPA DW METHOD 524.2 /SMEWW Method 6210D "Measurement of Purgeable Organic Compounds in Water by Capillary Column Gas Chromatography-Mass Spectrometry"	GC-MS	MDL = 0.04 ug/L
	SW846 METHOD 8240 "Gas Chromatography-Mass Spectrometry for Volatile Organics"	GC-MS	PQL = 5.0 ug/L
210 Tetrachloroethene (Tetrachloroethylene) 127184	CLP SOW METHOD ORG "Statement of Work for Organics Analysis - Multi-Media, Multi-Concentration"	GC-MS	CRQL = 10 ug/L
	CLP SOW LC-ORG "Chemical Analytical Services for Analysis of Low Concentration Water Samples for Organic Compounds by Gas Chromatography-Mass Spectrometry (GC-MS) and Gas Chromatography-Electron Capture (GC-ECD) Technique"	GC-MS	CRQL = 1.0 ug/L
	CLP SOW METHOD QTM "Chemical Analytical Services for Multi-Media, Multi-Concentration Samples for Organic Analysis by Quick Turnaround Gas Chromatography Techniques"	GC-ECD	CRQL = 20 ug/L
	EPA METHOD 601/SW846 Method 8010/SMEWW Method 6230B "Purgeable Halocarbons"	GC-ELCD	MDL = 0.03 ug/L
	EPA METHOD 624 "Purgeables"	GC-MS	MDL = 4.1 ug/L
	EPA DW METHOD 502.1 "Volatile Halogenated Organic Compounds in Water by Purge and Trap Gas Chromatography"	GC-ELCD	MDL = 0.001 ug/L
	EPA DW METHOD 502.2 "Volatile Organic Compounds in Water by Purge and Trap Capillary Column Gas Chromatography with Photoionization and Electrolytic Conductivity Detectors in Series"	GC-PID	MDL = 0.05 ug/L

APPENDIX III
TABLE III
METHODS AND DETECTION/QUANTITATION LIMITS FOR SPECIFIED ANALYTES OF CONCERN TO RISK ASSESSMENT
AQUEOUS MATRICES

ANALYTE/ COMMON NAME CAS NUMBER	METHOD REFERENCE/TITLE OF METHOD	INSTRUMENT- ATION	QUANTITATION/ DETECTION LIMIT
Tetrachloroethene (Tetrachloroethylene) 127184	EPA DW METHOD 502.2 "Volatile Organic Compounds in Water by Purge and Trap Capillary Column Gas Chromatography with Photoionization and Electrolytic Conductivity Detectors in Series"	GC-ELCD	MDL = 0.04 ug/L
	EPA DW METHOD 503.1 "Volatile Aromatic and Unsaturated Organic Compounds in Water by Purge and Trap Gas Chromatography"	GC-PID	MDL = 0.01 ug/L
	EPA DW METHOD 524.1/SMEWW Method 6210B (Method I)/SMEWW Method 6210C (Method II) "Measurement of Purgeable Organic Compounds in Water by Packed Column Gas Chromatography-Mass Spectrometry"	GC-MS	MDL = 0.3 ug/L, 4.1 ug/L MDL = 4.1 ug/L
	EPA DW METHOD 524.2/SMEWW Method 6210D "Measurement of Purgeable Organic Compounds in Water by Capillary Column Gas Chromatography-Mass Spectrometry"	GC-MS	MDL = 0.14 ug/L
	SMEWW METHOD 6040B "Closed-Loop Stripping, Gas-Chromatographic-Mass-Spectrometric Analysis"	GC-MC	EDL = 0.10 ug/L
	SMEWW METHOD 6230C Purge and Trap Packed-Column Gas Chromatographic Method II"	GC-MS	MDL = 0.03 ug/L
	SMEWW METHOD 6230D "Purge and Trap Capillary-Column Gas Chromatographic Method"	GC-PID/ GC-ECD	NA
Tetrachloromethane (Carbon Tetrachloride) 56235	SW846 METHOD 8240G "Gas Chromatography-Mass Spectrometry for Volatile Organics"	GC-MS	PQL = 5.0 ug/L
	CLP SOW METHOD LC-ORG "Chemical Analytical Services for the Analysis of Low Concentration Water Samples for Organic Compounds by Gas Chromatography-Mass Spectrometry (GC-MS) and Gas Chromatography-Electron Capture (GC-ECD) Techniques"	GC-MS	CRQL = 1.0 ug/L
	CLP SOW METHOD ORG "Statement of Work for Organics Analysis - Multi-Media, Multi-Concentration"	GC-MS	CRQL = 10 ug/L

APPENDIX III
TABLE III
METHODS AND DETECTION/QUANTITATION LIMITS FOR SPECIFIED ANALYTES OF CONCERN TO RISK ASSESSMENT

AQUEOUS MATRICES

ANALYTE/ COMMON NAME CAS NUMBER	METHOD REFERENCE/TITLE OF METHOD	INSTRUMENT- ATION	QUANTITATION/ DETECTION LIMIT
Tetrachloromethane (Carbon Tetrachloride) 56235	CLP SOW METHOD QTM "Chemical Analytical Services for Multi-Media, Multi-Concentration Samples for Organic Analysis by Quick Turnaround Gas Chromatography Techniques"	GC-ECD	CRQL = 20 ug/L
	EPA METHOD 601/SW846 Method 8010/SMEWW Method 6230B "Purgeable Halocarbons"	GC-ELCD	MDL = 0.12 ug/L
	EPA METHOD 624 "Purgeables"	GC-MS	MDL = 2.8 ug/L
	EPA DW METHOD 502.1 "Volatile Halogenated Organic Compounds in Water by Purge and Trap Gas Chromatography"	GC-ELCD	MDL = 0.003 ug/L
	EPA DW METHOD 502.2 "Volatile Organic Compounds in Water by Purge and Trap Capillary Column Gas Chromatography with Photoionization and Electrolytic Conductivity Detectors in Series"	GC-ELCD	MDL = 0.01 ug/L
	EPA DW METHOD 524.1/SMEWW Method 6210B (Method I)/SMEWW Method 6210C (Method II) "Measurement of Purgeable Organic Compounds in Water by Packed Column Gas Chromatography-Mass Spectrometry"	GC-MS	MDL = 0.3 ug/L, 2.8 ug/L MDL = 2.8 ug/L
	EPA DW METHOD 524.2/SMEWW Method 6210D "Measurement of Purgeable Organic Compounds in Water by Capillary Column Gas Chromatography-Mass Spectrometry"	GC-MS	MDL = 0.21 ug/L
	SMEWW METHOD 6230C "Purge and Trap Packed-Column Gas Chromatographic Method II"	GC-MS	MDL = 0.12 ug/L
	SMEWW METHOD 6230D "Purge and Trap Capillary-Column Gas Chromatographic Method"	GC-ECD	NA
SW846 METHOD 8240 "Gas Chromatography-Mass Spectrometry for Volatile Organics"		GC-MS	PQL = 5.0 ug/L

APPENDIX III
TABLE III
METHODS AND DETECTION/QUANTITATION LIMITS FOR SPECIFIED ANALYTES OF CONCERN TO RISK ASSESSMENT
AQUEOUS MATRICES

ANALYTE/ COMMON NAME CAS NUMBER	METHOD REFERENCE/TITLE OF METHOD	INSTRUMENT- ATION	QUANTITATION/ DETECTION LIMIT
Trichloromethane (Chloroform) 67663	CLP SOW METHOD LC-ORG "Chemical Analytical Services for the Analysis of Low Concentration Water Samples for Organic Compounds by Gas Chromatography-Mass Spectrometry (GC-MS) and Gas Chromatography-Electron Capture (GC-ECD) Techniques"	GC-MS	CRQL = 1.0 ug/L
	CLP SOW METHOD ORG "Statement of Work for Organics Analysis - Multi-Media, Multi-Concentration"	GC-MS	CRQL = 10 ug/L
	CLP SOW METHOD QTM "Chemical Analytical Services for Multi-Media, Multi-Concentration Samples for Organic Analysis by Quick Turnaround Gas Chromatography Techniques"	GC-ECD	CRQL = 20 ug/L
	EPA METHOD 601/SW846 Method 8010/SMEWW Method 6230B "Purgeable Halocarbons"	GC-ELCD	MDL = 0.05 ug/L
	EPA METHOD 624 "Purgeables"	GC-MS	MDL = 1.6 ug/L
	EPA DW METHOD 502.1 "Volatile Halogenated Organic Compounds in Water by Purge and Trap Gas Chromatography"	GC-ELCD	NA
	EPA DW METHOD 502.2 "Volatile Organic Compounds in Water by Purge and Trap Capillary Column Gas Chromatography with Photoionization and Electrolytic Conductivity Detectors in Series"	GC-ELCD	MDL = 0.02 ug/L
	EPA DW METHOD 524.1/SMEWW Method 6210B (Method I)/SMEWW Method 6210C (Method II) "Measurement of Purgeable Organic Compounds in Water by Packed Column Gas Chromatography-Mass Spectrometry"	GC-MS	MDL = 0.2 ug/L, 1.6 ug/L MDL = 1.6 ug/L
	EPA DW METHOD 524.2/SMEWW Method 6210D "Measurement of Purgeable Organic Compounds in Water by Capillary Column Gas Chromatography-Mass Spectrometry"	GC-MS	MDL = 0.03 ug/L
	SMEWW METHOD 6230C "Purge and Trap Packed-Column Gas Chromatographic Method II"	GC-MS	MDL = 0.05 ug/L

APPENDIX III
TABLE III
METHODS AND DETECTION/QUANTITATION LIMITS FOR SPECIFIED ANALYTES OF CONCERN TO RISK ASSESSMENT

AQUEOUS MATRICES

ANALYTE/ COMMON NAME CAS NUMBER	METHOD REFERENCE/TITLE OF METHOD	INSTRUMENT- ATION	QUANTITATION/ DETECTION LIMIT
Trichloromethane (Chloroform) 67663	SMEWW METHOD 6230D "Purge and Trap Capillary-Column Gas Chromatographic Method"	GC-ECD	NA
	SW846 METHOD 8240 "Gas Chromatography-Mass Spectrometry for Volatile Organics"	GC-MS	PQL = 5.0 ug/L

APPENDIX III
TABLE IV
METHOD TITLES AND APPLICATIONS

METHOD REFERENCE	TITLE OF METHOD	APPLICATION OF METHOD
¹ <u>CLP SOW</u>		
METHOD INORG	"Statement of Work for Inorganics Analysis - Multi-Media, Multi-Concentration," Doc No. ILM02.0	This method is for the analysis of 23 metals and cyanide. Sample matrices compatible with this method include water and soil/sediment.
METHOD LC-ORG	"Chemical Analytical Services for the Analysis of Low Concentration Water Samples for Organic Compounds by Gas Chromatography-Mass Spectrometry (GC-MS) and Gas Chromatography-Electron Capture (GC-ECD) Techniques," 6/91 Draft	This method consists of three separate methods. These methods are for the analysis of 40 volatile compounds, 60 semivolatile compounds and 28 organochlorine pesticides and Aroclors. Sample matrices compatible with this method include drinking water, surface water and groundwater.
METHOD ORG	"Statement of Work for Organics Analysis - Multi-Media, Multi-Concentration," Doc No. OLM01.8 (8/91)	This method consists of three separate methods. These methods are for the analysis of 34 volatile compounds, 65 semivolatile compounds and 27 organochlorine pesticides and Aroclors. Sample matrices compatible with these methods include water and soil/sediment.
²¹⁵ METHOD QTM	"Chemical Analytical Services for Multi-Media, Multi-Concentration Samples for Organic Analysis by Quick Turnaround Gas Chromatography Techniques," Draft 7/91	This method consists of five separate methods. These methods are for the analysis of 21 volatile compounds, 16 polynuclear aromatic hydrocarbons, 16 phenols, 19 pesticides and 8 Aroclors plus toxaphene. Sample matrices compatible with this method include water and soil/sediment.
² <u>EPA</u>		
METHOD 601	"Purgeable Halocarbons"	This method is for the analysis of 29 purgeable halocarbons. Sample matrices compatible with this method include municipal and industrial discharges.
METHOD 602	"Purgeable Aromatics"	This method is for the analysis of seven purgeable aromatic compounds. Sample matrices compatible with this method include municipal and industrial discharges.

¹CLP SOW CONTRACT LABORATORY PROGRAM (CLP) STATEMENT OF WORK, OFFICE OF EMERGENCY AND REMEDIAL RESPONSE

²EPA GUIDELINES ESTABLISHING TEST PROCEDURES FOR THE ANALYSIS OF POLLUTANTS UNDER THE CLEAN WATER ACT FINAL RULE AND INTERIM FINAL RULE AND PROPOSED RULE, 10/84, 40 CFR PART 136

APPENDIX III
TABLE IV
METHOD TITLES AND APPLICATIONS

METHOD REFERENCE	TITLE OF METHOD	APPLICATION OF METHOD
<u>EPA</u>		
METHOD 606	"Phthalate Ester"	This method is for the analysis of six phthalate ester compounds. Sample matrices compatible with this method include municipal and industrial discharges.
METHOD 607	"Nitrosamines"	This method is for the analysis of three nitrosamines. Sample matrices compatible with this method include municipal and industrial discharges.
METHOD 608	"Organochlorine Pesticides and PCBs"	This method is for the analysis of 27 organochlorine pesticides and Aroclors. Sample matrices compatible with this method include municipal and industrial discharges.
METHOD 609	"Nitroaromatics and Isophorone"	This method is for the analysis of four nitroaromatics and isophorone. Sample matrices compatible with this method include municipal and industrial discharges.
METHOD 610	"Polynuclear Aromatic Hydrocarbons"	This method is for the analysis of 16 polynuclear aromatic hydrocarbons. Sample matrices compatible with this method include municipal and industrial discharges.
METHOD 612	"Chlorinated Hydrocarbons"	This method is for the analysis of nine chlorinated hydrocarbons. Sample matrices compatible with this method include municipal and industrial discharges.
METHOD 624	"Purgeables"	This method is for the analysis of 30-33 purgeable organic compounds. Sample matrices compatible with this method include municipal and industrial discharges.
METHOD 625	"Base/Neutrals and Acids"	This method is for the analysis of 80-84 semivolatile compounds. Sample matrices compatible with this method include municipal and industrial discharges.

APPENDIX III
TABLE IV
METHOD TITLES AND APPLICATIONS

METHOD REFERENCE	TITLE OF METHOD	APPLICATION OF METHOD
³ EPA AIR		
METHOD TO-1	"Method for the Determination of Volatile Organic Compounds in Ambient Air Using Tenax Adsorption and Gas Chromatography-Mass Spectrometry (GC-MS)"	This method is for the analysis of 18 nonpolar volatile compounds with boiling points between 80 and 200 degrees °C. Samples are collected on pre-cleaned tenax cartridges.
METHOD TO-14	"The Determination of Volatile Organic Compounds (VOCs) in Ambient Air Using Summa Passivated Canister Sampling and Gas Chromatographic Analysis"	This method is for the analysis of 40 volatile organic compounds. Samples are collected on cleaned and certified SUMMA canisters.
METHOD TO-2	"Method for the Determination of Volatile Organic Compounds in Ambient Air by Carbon Molecular Sieve Adsorption and Gas Chromatography-Mass Spectrometry (GC-MS)"	This method is for the analysis of 11 volatile organic compounds with boiling points between -15 and 120 degrees °C. Samples are collected on pre-cleaned carbon molecular sieves.
217 METHOD TO-3	"Method for the Determination of Volatile Organic Compounds in Ambient Air Using Cryogenic Preconcentration Techniques and Gas Chromatography with Flame Ionization and Electron Capture Detection"	This method is for the analysis of eight volatile organic compounds with boiling points between -10 and 200 degrees °C.
METHOD TO-4	"Method for the Determination of Organochlorine Pesticides and Polychlorinated Biphenyls in Ambient Air"	This method is for the analysis of 11 organochlorine pesticides and Aroclors. Samples are collected on polyurethane foam filters. Samples are prepared using a Soxhlet extraction. Analysis is performed by GC-ECD.

APPENDIX III
TABLE IV
METHOD TITLES AND APPLICATIONS

METHOD REFERENCE	TITLE OF METHOD	APPLICATION OF METHOD
⁴ EPA DW		
METHOD 502.1	"Volatile Halogenated Organic Compounds in Water by Purge and Trap Gas Chromatography"	This method is for the analysis of 40 halogenated volatile organic compounds. Sample matrices compatible with this method include drinking water, source water and water being treated for potability.
METHOD 502.2	"Volatile Organic Compounds in Water by Purge and Trap Capillary Column Gas Chromatography with Photoionization and Electrolytic Conductivity Detectors in Series"	This method is for the analysis of 60 volatile organic compounds. Sample matrices compatible with this method include drinking water, source water and water being treated for potability.
METHOD 503.1	"Volatile Aromatic and Unsaturated Organic Compounds in Water by Purge and Trap Gas Chromatography"	This method is for the analysis of 28 aromatic and unsaturated organic compounds. Sample matrices compatible with this method include drinking water, source water and water being treated for potability.
METHOD 505	"Analysis of Organohalide Pesticides and Aroclors in Water by Microextraction and Chromatography"	This method is for the analysis of 25 organohalide pesticides and Aroclors. Sample matrices compatible with this method include drinking water, source water and water being treated for potability.
METHOD 508	"Determination of Chlorinated Pesticides in Water by Gas Chromatography with an Electron Capture Detector"	This method is for the analysis of 34 chlorinated pesticides and Aroclors. Sample matrices compatible with this method include groundwater and drinking water.
METHOD 524.1	"Measurement of Purgeable Organic Compounds in Water by Packed Column Gas Chromatography-Mass Spectrometry"	This method is for analysis of 48 volatile compounds. Sample matrices compatible with this method include drinking water, source water and water being treated for potability.
METHOD 524.2	"Measurement of Purgeable Organic Compounds in Water by Capillary Column Gas Chromatography-Mass Spectrometry"	This method is for the analysis of 60 volatile organic compounds. Sample matrices compatible with this method include drinking water, source water and water being tested for potability.

⁴EPA DW

APPENDIX III
TABLE IV
METHOD TITLES AND APPLICATIONS

METHOD REFERENCE	TITLE OF METHOD	APPLICATION OF METHOD
<u>EPA DW</u>		
METHOD 525	"Determination of Organic Compounds in Drinking Water by Liquid-Solid Extraction and Capillary Column Gas Chromatography-Mass Spectrometry"	This method is for the analysis of 35 organic compounds. Sample matrices compatible with this method include drinking water, source water and water being treated for potability.
⁵ <u>MCAWW</u>		
METHOD 200.7	"Inductively Coupled Plasma-Atomic Emission Spectrometric Method for Trace Element Analysis of Water and Wastes"	This method is for the analysis of 30 metals. Sample matrices compatible with this method include drinking water, surface water and wastewater.
METHOD 206.2	"Arsenic (Atomic Absorption, Furnace Technique)"	Sample matrices compatible with this method include drinking water, surface water, saline water, waste, sludge and soil/sediment.
METHOD 206.3	"Arsenic (Atomic Absorption-Gaseous Hydride)"	This method is for the analysis of inorganic arsenic. Sample matrices compatible with this method include drinking water, fresh water and saline water.
METHOD 206.4	"Arsenic (Spectrophotometric-SDDC)"	This method is for the analysis of inorganic arsenic. Sample matrices compatible with this method include drinking water, surface water, groundwater and wastes.
METHOD 206.5	"Arsenic (Sample Digestion prior to Total Arsenic Analysis by Silver Diethyldithiocarbamate or Hydride Procedures)"	This method is a preparation procedure for the conversion of organic arsenic to inorganic arsenic. Sample matrices compatible with this method include drinking water, surface water and waste.
METHOD 210.1	"Beryllium (Atomic Absorption, Direct Aspiration)"	Sample matrices compatible with this method include drinking water, surface water, groundwater, waste, sludge and soil/sediment.

APPENDIX III
TABLE IV
METHOD TITLES AND APPLICATIONS

METHOD REFERENCE	TITLE OF METHOD	APPLICATION OF METHOD
<u>MCAWW</u>		
METHOD 210.2	"Beryllium (Atomic Absorption, Furnace Technique)"	Sample matrices compatible with this method include drinking water, surface water, groundwater, waste, sludge and soil/sediment.
METHOD 213.1	"Cadmium (Atomic Absorption, Direct Aspiration)"	Sample matrices compatible with this method include drinking water, surface water, groundwater, waste, sludge and soil/sediment.
METHOD 213.2	"Cadmium (Atomic Absorption, Furnace Technique)"	Sample matrices compatible with this method include drinking water, surface water, groundwater, waste, sludge and soil/sediment.
METHOD 218.1	"Chromium (Atomic Absorption, Direct Aspiration)"	Sample matrices compatible with this method include drinking water, surface water, groundwater, waste, sludge and soil/sediment.
METHOD 218.2	"Chromium (Atomic Absorption, Furnace Technique)"	Sample matrices compatible with this method include drinking water, surface water, groundwater, waste, sludge and soil/sediment.
METHOD 218.3	"Chromium (Atomic Absorption, Chelation- Extraction)"	Sample matrices compatible with this method include drinking water, surface water, groundwater and waste.
METHOD 218.4	"Chromium, Hexavalent (Atomic Absorption, Chelation- Extraction)"	Sample matrices compatible with this method include drinking water, surface water, groundwater and waste.
METHOD 218.5	"Chromium, Dissolved Hexavalent (Atomic Absorption, Furnace Technique)"	Sample matrices compatible with this method include drinking water, surface water and certain filtered wastes.
METHOD 239.1	"Lead (Atomic Absorption, Direct Aspiration)"	Sample matrices compatible with this method include drinking water, surface water, groundwater, waste, sludge and soil/sediment.
METHOD 239.2	"Lead (Atomic Absorption, Furnace Technique)"	Sample matrices compatible with this method include drinking water, surface water, groundwater, waste, sludge and soil/sediment.
METHOD 245.1	"Mercury (Manual Cold Vapor Technique)"	Sample matrices compatible with this method include drinking water, surface water and saline water.

APPENDIX III
TABLE IV
METHOD TITLES AND APPLICATIONS

METHOD REFERENCE	TITLE OF METHOD	APPLICATION OF METHOD
<u>MCAWW</u>		
METHOD 245.2	"Mercury (Automated Cold Vapor Technique)"	Sample matrices compatible with this method include surface water, waste water and effluent.
METHOD 245.5	"Mercury in Sediment (Manual Cold Vapor Technique)"	Sample matrices compatible with this method include bottom deposits, sludge and soil/sediment.
METHOD 335.1	"Cyanide, Amendable to Chlorination"	This method is applicable to the determination of cyanide amenable to chlorination in drinking, surface and saline waters and domestic and industrial wastes.
METHOD 335.2	"Cyanide, Total (Titrimetric, Spectrophotometric)"	This method is applicable to the determination of cyanide in drinking, surface and saline waters and domestic and industrial wastes.
<u>⁶SMEWW</u>		
METHOD 3111B	"Direct Air-Acetylene Flame Method"	This method is for the analysis of 27 metals. Sample matrices compatible with this method include surface water, groundwater and drinking water.
METHOD 3111C	"Extraction/Air-Acetylene Flame Method"	This method is for the analysis of 10 metals at low concentrations. Sample matrices compatible with this method include surface water, groundwater and drinking water.
METHOD 3111D	"Direct Nitrous Oxide-Acetylene Flame Method"	This method is for the analysis of 10 metals. Sample matrices compatible with this method include groundwater, surface water and drinking water.
METHOD 3111E	"Extraction/Nitrous Oxide-Acetylene Flame Method"	This method is for the analysis of aluminum and beryllium. Sample matrices compatible with this analysis include groundwater, surface water and drinking water.

APPENDIX III
TABLE IV
METHOD TITLES AND APPLICATIONS

METHOD REFERENCE	TITLE OF METHOD	APPLICATION OF METHOD
<u>SMEWW</u>		
METHOD 3112B	"Cold Vapor Atomic Absorption Spectrometric Method"	This method is for the analysis of mercury. Sample matrices compatible with this method include groundwater, surface water and drinking water.
METHOD 3113B	"Electrothermal Atomic Absorption Spectrometric Method"	This method is for the analysis of 17 metals in microquantities. Sample matrices compatible with this method include groundwater, surface water and drinking water.
METHOD 3114B	"Manual Hydride Generation/Atomic Absorption Spectrometric Method"	This method is for the analysis of arsenic and selenium. Sample matrices compatible with this method include groundwater, surface water and drinking water.
METHOD 3120B	"Inductively Coupled Plasma (ICP) Method"	This method is for the analysis of 27 metals. Sample matrices compatible with this method include groundwater, surface water and drinking water.
METHOD 3500AS C*	"Silver Diethyldithiocarbamate Method"	This method is for the analysis of arsenic. Sample matrices compatible with this method include groundwater, surface water and drinking water.
METHOD 3500BE D*	"Aluminon Method"	This method is for the analysis of beryllium. Sample matrices compatible with this method include groundwater, surface water and drinking water.
METHOD 3500CD D*	"Dithizone Method"	This method is for the analysis of cadmium. Sample matrices compatible with this method include groundwater, surface water and drinking water.
METHOD 3500CR D*	"Colorimetric Method"	This method is for the analysis of chromium. Sample matrices compatible with this method include groundwater, surface water and drinking water.

* The first two letters after the number represent the element name and the third letter is the method code.

APPENDIX III
TABLE IV
METHOD TITLES AND APPLICATIONS

METHOD REFERENCE	TITLE OF METHOD	APPLICATION OF METHOD
<u>SMEWW</u>		
METHOD 3500HG C*	"Dithizone Method"	This method is for the analysis of mercury. Sample matrices compatible with this method include groundwater, surface water and drinking water.
METHOD 3500PB D*	"Dithizone Method"	This method is for the analysis of lead. Sample matrices compatible with this method include groundwater, surface water and drinking water.
METHOD 4500 CN	"Cyanide"	This method is used for the analysis for cyanide in aqueous and solid matrices. It includes total cyanide, cyanide amenable to chlorination, and weak and dissociable cyanides.
METHOD 6040B	"Closed-Loop Stripping, Gas Chromatographic-Mass Spectrometric Analysis"	This method is for the analysis of volatile organic compounds of intermediate weight. Sample matrices compatible with this method include groundwater, surface water and drinking water.
METHOD 6210B	"Purge and Trap Packed-Column Gas Chromatographic-Mass Spectrometric Method I"	This method is for the analysis of 31 volatile organic compounds. Sample matrices compatible with this method include groundwater, surface water and drinking water.
METHOD 6210D	"Purge and Trap Capillary-Column Gas Chromatographic-Mass Spectrometric Method"	This method is for the analysis of 62 purgeable organic compounds. Sample matrices compatible with this method include drinking water, raw source water and water being treated for potability.
METHOD 6220B	"Purge and Trap Gas Chromatographic Method I"	This method is for the analysis of seven aromatic volatile compounds. Sample matrices compatible with this method include groundwater, surface water and drinking water.
METHOD 6220C	"Purge and Trap Gas Chromatographic Method II"	This method is for the analysis of 28 purgeable aromatic and unsaturated compounds. Sample matrices compatible with this method include drinking water, raw source water, and water being treated for potability.

* The first two letters after the number represent the element name and the third letter is the method code.

APPENDIX III
TABLE IV
METHOD TITLES AND APPLICATIONS

METHOD REFERENCE	TITLE OF METHOD	APPLICATION OF METHOD
<u>SMEWW</u>		
METHOD 6230B	"Purge and Trap Packed Column Gas Chromatographic Method I"	This method is for the analysis of 29 purgeable halocarbons. Sample matrices compatible with this method include municipal and industrial discharges.
METHOD 6230C	"Purge and Trap Packed Column Gas Chromatographic Method II"	This method is for the analysis of 39 purgeable halocarbons. Sample matrices compatible with this method include drinking water, raw source water and water being treated for potability.
METHOD 6230D	"Purge and Trap Capillary-Column Gas Chromatographic Method"	This method is for the analysis of 60 purgeable halocarbons. Sample matrices compatible with this method include drinking water, raw source water and water being treated for potability.
METHOD 6410B	"Liquid-Liquid Extraction Gas Chromatographic-Mass Spectrometric Method"	This method is for the analysis of 81 semivolatile organic compounds. Sample matrices compatible with this method include groundwater, surface water and drinking water.
METHOD 6440B	"Liquid-Liquid Extraction Chromatographic Method"	This method is for the analysis of 16 polynuclear aromatic hydrocarbons. Sample matrices compatible with this method include municipal and industrial discharges.
METHOD 6630B	"Liquid-Liquid Extraction Gas Chromatographic Method I"	This method is for the analysis of 18 organochlorine pesticides. Sample matrices compatible with this method include agricultural discharges.
METHOD 6630C	"Liquid-Liquid Extraction Gas Chromatographic Method II"	This method is for the analysis of 25 organochlorine pesticides. Sample matrices compatible with this method include groundwater, surface water and drinking water.
⁸ <u>SW846</u>		
METHOD 6010	"Inductively Coupled Plasma Atomic Emission Spectroscopy"	This method is for the analysis of 26 metals. Sample matrices compatible with this method include groundwater, soils and wastes.

APPENDIX III
TABLE IV
METHOD TITLES AND APPLICATIONS

METHOD REFERENCE	TITLE OF METHOD	APPLICATION OF METHOD
<u>SW846</u>		
METHOD 7060	"Arsenic (Atomic Absorption, Furnace Technique)"	Sample matrices compatible with this method include groundwater, soils, extracts and wastes.
METHOD 7061	"Arsenic (Atomic Absorption, Gaseous Hydride)"	Sample matrices compatible with this method include groundwater, soils, extracts and wastes.
METHOD 7090	"Beryllium (Atomic Absorption, Direct Aspiration)"	Sample matrices compatible with this method include water and wastes.
METHOD 7091	"Beryllium (Atomic Absorption, Furnace Technique)"	Sample matrices compatible with this method include water and wastes.
METHOD 7130	"Cadmium (Atomic Absorption, Direct Aspiration)"	Sample matrices compatible with this method include water, waste and sludge.
225 METHOD 7131	"Cadmium (Atomic Absorption, Furnace Technique)"	Sample matrices compatible with this method include water, soil and waste.
METHOD 7190	"Chromium (Atomic Absorption, Direct Aspiration)"	Sample matrices compatible with this method include water, soil and waste.
METHOD 7191	"Chromium (Atomic Absorption, Furnace Technique)"	Sample matrices compatible with this method include water, soil and waste.
METHOD 7195	"Chromium, Hexavalent (Coprecipitation)"	This method is for the analysis of dissolved hexavalent chromium in extraction procedure (EP) toxicity extracts and groundwater.
METHOD 7196	"Chromium, Hexavalent (Colorimetric)"	This method is for the analysis of dissolved hexavalent chromium in extraction procedure (EP) toxicity characteristic extracts and groundwater.
METHOD 7197	"Chromium, Hexavalent (Chelation/Extraction)"	This method is for the analysis of dissolved hexavalent chromium in extraction procedure (EP) toxicity extracts and groundwater.

APPENDIX III
TABLE IV
METHOD TITLES AND APPLICATIONS

METHOD REFERENCE	TITLE OF METHOD	APPLICATION OF METHOD
<u>SW846</u>		
METHOD 7198	"Chromium, Hexavalent (Differential Pulse Polarography)"	This method is for the analysis of dissolved hexavalent chromium in extraction procedure (EP) toxicity extracts, natural water and waste water.
METHOD 9010A	"Total and Amenable Cyanide"	This method is for the analysis of inorganic cyanide (total and amenable to chlorination) in waste and leachate. The method detects inorganic cyanides that are present as either soluble salts or complexes.
METHOD 9012	"Total and Amenable Cyanide (Colorimetric, Automated UV)"	This method is for the analysis of inorganic cyanide (total and amenable to chlorination) in waste and leachate. The method detects inorganic cyanides that are present as either soluble salts or complexes.
METHOD 7420	"Lead (Atomic Absorption, Direct Aspiration)"	Sample matrices compatible with this method include water, waste and sludge.
METHOD 7421	"Lead (Atomic Absorption, Furnace Technique)"	Sample matrices compatible with this method include water, waste and soils.
METHOD 7470	"Mercury in Liquid Waste (Manual Cold-Vapor Technique)"	Sample matrices compatible with this method include groundwater, aqueous waste and mobility procedure extracts.
METHOD 7471	"Mercury in Solid or Semisolid Waste (Manual Cold-Vapor Technique)"	This method is for the analysis of inorganic and organic mercury. Sample matrices compatible with this method include soil, sludge and sediment.
METHOD 8010	"Halogenated Volatile Organics"	This method is for the analysis of 34 halogenated volatile organic compounds. Sample matrices compatible with this method include soil/sludge, groundwater, liquid waste and water immiscible waste.
METHOD 8020	"Aromatic Volatile Organics"	This method is for the analysis of seven aromatic volatile organic compounds. Sample matrices compatible with this method include soil/sludge, groundwater, liquid waste and water immiscible waste.

APPENDIX III
TABLE IV
METHOD TITLES AND APPLICATIONS

METHOD REFERENCE	TITLE OF METHOD	APPLICATION OF METHOD
<u>SW846</u>		
METHOD 8060	"Phthalate Esters"	This method is for the analysis of six phthalate esters. Sample matrices compatible with this method include water, soil, sludge and water immiscible waste.
METHOD 8080	"Organochlorine Pesticides and PCBs"	This method is for the analysis of 26 organochlorine pesticides and Aroclors. Sample matrices compatible with this method include water, soil, sludge and water immiscible waste.
METHOD 8100	"Polynuclear Aromatic Hydrocarbons"	This method is for the analysis of 24 polynuclear aromatic hydrocarbons. Sample matrices compatible with this method include groundwater, surface water, drinking water and soil/sediment.
METHOD 8240	"Gas Chromatography-Mass Spectrometry for Volatile Organics Packed Column Technique"	This method is for the analysis of 73 volatile organic compounds. Sample matrices include groundwater, caustic or acid liquors, and soil/sediment.
METHOD 8250	"Gas Chromatography-Mass Spectrometry for Semivolatile Organics: Packed Column Technique"	This method is for the analysis of 113 semivolatile organic compounds. Sample matrices compatible with this method include solid waste, soil and groundwater.
METHOD 8270	"Gas Chromatography-Mass Spectrometry for Semivolatile Organics: Capillary Column Technique"	This method is for the analysis of 131 semivolatile compounds. Sample matrices compatible with this method include groundwater, waste and soil.
METHOD 8310	"Polynuclear Aromatic Hydrocarbons"	This method is for the analysis of 16 polynuclear aromatic hydrocarbons. Sample matrices compatible with this method include waters, soil, waste and sludge.

APPENDIX III

Table V- A
SUMMARY OF ROUTINE METHODS BY PROGRAM AND COMPOUND CLASS
ORGANIC COMPOUNDS

Drinking Water (USEPA, Office of Water)				
<u>Compound Class</u>	<u>EPA Method No.</u>	<u>Analytical System</u>	<u>Sample Introduction/Preparation</u>	<u>Detection Limit/Range (ppb)</u>
Acrolein and Acrylonitrile	603	GC-FID	P&T	0.5-0.6
Base/Neutrals, Acids and Pesticides	625*	GC-MS	XTN	0.09-44.0
Benzidines	605	HPLC/Electrochem	XTN	0.08-0.13
Carbamates and Urea Pesticides	632	HPLC/UV	XTN	0.003-11.1
Chlorinated Acids	515.1	ECD Capillary Column	XTN	EDL, 0.1-1.0
Chlorinated Hydrocarbons	612	GC-ECD	XTN	0.03-1.34
Chlorinated Pesticides	508	ECD Capillary Column	XTN	EDL, 0.01-0.5 (most <0.1)
1,2-Dibromoethane and 1,2-Dibromo-3-Chloropropane	504	GC-ECD	XTN	0.01
Dithiocarbamate Pesticides	630	Colorimetric	CS ₂ Liberation	1.9-15.3
Extractable Organics	525*	GC-MS Capillary Column	XTN	0.1-1.0
Haloethers	611	GC-ELCD	XTN	0.3-3.9
Nitroaromatics and Isophorone	609	GC-FID + ECD	XTN	0.01-15.7
Nitrogen and Phosphorous Containing Pesticide	507	NPD Capillary Column	XTN	EDL (Estimated D.L.) 0.1-5.0 (most <1.0)
Nitrosamines	607	GC-NPD	XTN	0.15-0.81
N-Methylcarbamates and N-Methylcarbamoyloximes	531.1	HPLC Fluorescence Detector	DI	0.5-4.0
Organohalide Pesticides and PCBs	617	GC-ECD	XTN	0.002-0.176
Organophosphate Pesticides	614	GC-FPD or NPD	XTN	0.012-0.015
Organophosphate Pesticides	622	GC-FPD	XTN	0.1-5.0
Perchlorination Screening of PCBs	508A	ECD/ELCD Packed or Capillary Column	XTN	0.1-0.3
Pesticide and PCBs	505*	GC-ECD Capillary Column	XTN	Variable Pesticide 0.005-1.0 Herbicide 0.2-7.0 PCBs 0.1-0.5
Pesticides and PCBs Organochlorine	608*	GC-ECD	XTN	0.002-0.24
Phenols	604	GC-FID	XTN	0.14-16.0
Phthalate Esters	606	GC-ECD	XTN	0.29-3.0
Purgeable Aromatics	602*	GC-PID	P&T	0.2-0.4

* Frequently requested method.

APPENDIX III

Table V-A
SUMMARY OF ROUTINE METHODS BY PROGRAM AND COMPOUND CLASS
ORGANIC COMPOUNDS (continued)

Industrial and Municipal Waste Water (USEPA, Office of Research and Development)

<u>Compound Class</u>	<u>EPA Method No.</u>	<u>Analytical System</u>	<u>Sample Introduction/Preparation</u>	<u>Detection Limit/Range (ppb)</u>
Purgeable Halocarbons	601*	GC-ELCD	P&T	0.02-1.81
Purgeable Organics	524.1	GC-MS Capillary Column	P&T	0.1-1.0
Purgeable Organics	524.2*	GC-MS Capillary Column	P&T	0.02-0.2
Purgeables	624*	GC-MS	P&T	1.6-7.2
Volatile Aromatics and Unsaturated Compounds	503.1	GC-PID	P&T	0.002-0.03
Volatile Halocarbons	502.1	GC-ECD Packed Column	P&T	0.001-0.01
Volatile Halocarbons	502.2*	GC-ELCD/PID Capillary Column	P&T	0.01-0.10
2,3,7,8-Tetrachlorodibenzo-p dioxin	613	GC-MS	XTN	0.002
Triazine Pesticides	619	GC-NPD	XTN	0.03-0.07

Aqueous and Solid Matrices (USEPA, Office of Water)

<u>Compound Class</u>	<u>EPA Method No.</u>	<u>Analytical System</u>	<u>Sample Introduction/Preparation</u>	<u>Detection Range (ppb)</u>
Semivolatile Organics	1625	Isotope Dilution by GC-MS (Capillary Column)	XTN	most 20-100 ppb (dependent on % solids)
Tetra- through octa-chlorinated dioxins and furans	1613	Isotope Dilution by high resolution GC-high resolution MS	XTN	10-100 parts per quadrillion in water 1-10 parts per trillion in soil
Volatile Organics	1624	Isotope Dilution by GC-MS (Capillary Column)	P&T	5-100 ppb (dependent on % solids)

* Frequently requested method.

APPENDIX III

Table V- A
SUMMARY OF ROUTINE METHODS BY PROGRAM AND COMPOUND CLASS
ORGANIC COMPOUNDS (continued)

Solid Matrices (USEPA, Test Methods for Evaluating Solid Waste, SW846, November, 1986.)

<u>Compound Class</u>	<u>EPA Method No.</u>	<u>Analytical System</u>	<u>Sample Introduction/ Preparation</u>	<u>Detection Limit/ Range (ppb)</u>
Acrolein, Acrylonitrile, Acetonitrile	8030	GC-FID	5030	0.5-0.6
Aromatic Volatile Organics	8020*	GC-FID	5030	0.2-0.4
Chlorinated Herbicides	8150	GC-ECD or ELCD	3550	0.1-200
Chlorinated Hydrocarbons	8120	GC-ECD	3550	0.03-1.3
Nitroaromatics and Cyclic Ketones	8090	GC-FID or ECD	3550	0.06-5.0
Organophosphorus Pesticides	8140	GC-FPD or NPD	3550	0.1-5.0
Organochlorine Pesticides and PCBs	8080*	GC-ECD	3550	70-1000
Phenols	8040	GC-FID	3550	0.14-16
Phthalate Esters	8060	GC-ECD	3550	0.29-31
Polynuclear Aromatic Hydrocarbons	8100	GC-FID	3550	Not Reported
Polynuclear Aromatic Hydrocarbons	8310	HPLC/UV and Fluor	3550	0.013-2.3
Purgeable Halogenated Volatile Organics	8010	GC-ELCD	5030	0.03-0.52
Purgeable Non-Halogenated Volatile Organics	8015	GC-FID	5030	Not Reported
Semivolatile Organics	8270*	GC-MS Capillary Column	3550	Not Reported
Volatile Organics	8240*	GC-MS	5030	1.6-7.2

* Frequently requested method.

APPENDIX III
TABLE V-B
SUMMARY OF ROUTINE METHODS BY PROGRAM AND COMPOUND CLASS
INORGANIC ANALYTES

Analyte	EPA Method No.	Analytical System	Sample Preparation	Detection Limit Range (ppb)
Total/Dissolved Metals	1620	ICP	3005,3010	
Total/Dissolved Metals	6010	ICP	3005,3010	
Total/Dissolved Metals	7000	AA	3005,3010	1,000
Aluminum	7020	AA	3005,3010	4300-5700
Antimony	204.2 CLP	GFAA	*	
Antimony	7040	AA	3005,3010	70
Antimony	7041	GFAA	3005,3010,3020	20
Barium	7080	AA	3005,3010	30
Barium	7081	GFAA	Nitric acid, reflux	2.0
Beryllium	7090	AA	3005,3010	50-200
Beryllium	7091	GFAA	3020	1.0-30
Boron	212.3	Spectrophotometric	Hydrochloric acid	200
Calcium	215.2	Titrimetric	*	100,000
Calcium	7140	AA	3005,3010	4800-5200
Cobalt	7200	AA	3005-3010	3400-4600
Cobalt	7201	GFAA	3020	50
Copper	7210	AA	3005,3010	3700-4300
Copper	7211	GFAA	Nitric acid, reflux	1.0
Cyanide	335.2	Total, (Titrimetric, Spectrophotometric)	***	10
Cyanide	335.2	Midi (Distillation, Total, Colorimetric, Automated UV)	***	5.0
Cyanide	355.1	Amenable to Chlorination (Titrimetric, Spectrophotometric)	****	10
Cyanide, Amenable to Chlorination, without distillation	4500-CN-H Standard Method for the Examin- ation of Water and Wastewater 1989	Spectrophotometric	pH > 12	20
Cyanide	335.3	Total, Spec- trophoto- metric	***	10
Gold	231.1	AA	Nitric acid, Aqua Regia	100
Gold	231.2	GFAA	Nitric acid, Aqua Regia	1.0
Iron	7380	AA	3005,3010	4400-5600
Iron	7381	GFAA	Nitric acid, reflux	1.0

APPENDIX III
TABLE V-B
SUMMARY OF ROUTINE METHODS BY PROGRAM AND COMPOUND CLASS
INORGANIC ANALYTES
(continued)

<u>Analyte</u>	<u>EPA Method No.</u>	<u>Analytical System</u>	<u>Sample Preparation</u>	<u>Detection Limit/Range (ppb)</u>
Iridium	235.1	AA	Nitric acid, Aqua Regia	3000
Iridium	235.2	GFAA	Nitric acid, Aqua Regia	30
Magnesium	7450	AA	3005,3010	970-1030
Manganese	7460	AA	3005,3010	10
Manganese	7461	GFAA	Nitric acid, reflux	0.2
Molybdenum	246.1	AA	*	100
Molybdenum	246.2	GFAA	*	1.0
Molybdenum	7480	AA	3005,3010	10,000
Molybdenum	7481	GFAA	3020	-
Nickel	7520	AA	3005,3010	4900-5100
Osmium	252.1	AA	Nitric,sulfuric acids	300
Osmium	252.2	GFAA	Nitric acid	20
Osmium	7550	AA	3005,3010	-
Palladium	253.1	AA	Nitric acid	100
Palladium	253.2	GFAA	Nitric acid	5.0
Platinum	255.1	AA	**	1000
Platinum	255.2	GFAA	**	20
Potassium	7610	AA	3005,3010	1000-2200
Rhenium	264.1	AA	Nitric acid	5000
Rhenium	264.2	GFAA	Nitric acid	200
Rhodium	265.1	AA	Nitric acid Regia	50
Rhodium	265.2	GFAA	Nitric acid	5.0
Ruthenium	267.1	AA	Hydrochloric acid	200
Ruthenium	267.2	GFAA	Hydrochloric acid	20
Selenium	270.3	AA-Hydride	**	-
Selenium	7740	GFAA	3020	3.0-5.0
Selenium	7741	AA Hydride	3005,3010	5.0
Silver	7760	AA	3005,3010	1200-2800
Silver	7761	GFAA	Nitric acid, reflux	0.2
Sodium	7770	AA	3005,3010	4800-5200
Thallium	7840	AA	3005, 3010	-
Thallium	7841	GFAA	3020	1.0-10
Tin	282.1	AA	**	800
Tin	282.2	GFAA	**	5.0
Titanium	283.1	AA	**	400
Titanium	283.2	GFAA	**	10
Vanadium	7910	AA	3005,3010	49400-50600
Vanadium	7911	GFAA	3020	50
Zinc	7950	AA	3005,3010	5.0
Zinc	7951	GFAA	Nitric acid, reflux	0.05

APPENDIX III
TABLE V-B
SUMMARY OF ROUTINE METHODS BY PROGRAM AND COMPOUND CLASS
INORGANIC ANALYTES
(continued)

Sample Preparation Methods

- 3005 Acid Digestion of Waters for Total Recoverable Dissolved Metals for Analysis by Flame Atomic Absorption Spectroscopy or Inductively Coupled Plasma Spectroscopy.
- 3010 Acid Digestion of Aqueous Samples and Extracts for Total Metals for Analysis by Flame Atomic Absorption Spectroscopy or Inductively Coupled Plasma Spectroscopy.
- 3020 Acid Digestion of Aqueous Samples and Extracts for Total Metals for Analysis by Furnace Atomic Absorption Spectroscopy.
- * CLP preparation methods are categorized by water/soil, ICP, AA, and GFAA instrumentation.
- CLP methods are based on the 200 series Methods for Chemical Analysis of Water and Wastes. U.S. Environmental Monitoring Systems Laboratory. Cincinnati, Ohio. March, 1983.
 - Water sample preparation for GFAA uses nitric acid, hydrogen peroxide and mild heat. SOW 788, D-5.
 - Water sample preparation for ICP and AA uses nitric acid, hydrochloric acid and mild heat. SOW 788, D-5.
 - Soil sample preparation for ICP, AA, GFAA uses nitric acid, hydrogen peroxide and mild heat.
 - Hydrochloric acid is used as the final reflux acid for several analytes. SOW 788, D-5,6.
- ** Nitric and hydrochloric acids are used for digestion.
- *** Total cyanide is determined by a reflux-distillation procedure using a sodium hydroxide scrubber.
- **** Cyanide amenable to chlorination is chlorinated at pH greater than 11.

APPENDIX IV CALCULATION FORMULAS FOR STATISTICAL EVALUATION

Appendix IV provides calculation formulas to enable responsible risk assessment personnel to determine the minimum number of samples necessary to meet statistical performance objectives. This appendix also provides statistical guidelines on the probability that a given sampling plan will identify a hot spot, and the probability that no hot spot exists given none was found after sampling.

Calculation Formulas to Determine the Number of Samples Required Given Coefficient of Variation and Statistical Performance Objectives

The minimum number of samples, n , required to achieve a specified precision and confidence level at a defined minimum detectable relative difference may be estimated by the following equation:

For one-sided, one-sample t-test $n \geq [(Z_\alpha + Z_\beta)/D]^2 + 0.5Z_\alpha^2$

For one-sided, two-sample t-test $n \geq 2 [(Z_\alpha + Z_\beta)/D]^2 + 0.5Z_\alpha^2$

where: Z_α is a percentile of the standard normal distribution such that $P(Z \geq Z_\alpha) = \alpha$, Z_β is similarly defined, and $D = \text{MDRD}/\text{CV}$, where MDRD is the minimum detectable relative difference and CV is the coefficient of variation. NOTE: Data must be transformed (Z_α), for example:

Confidence Level			Power		
$1-\alpha$	α	Z_α	$1-\beta$	β	Z_β
0.80	0.20	0.842	0.80	0.20	0.842
0.85	0.15	1.039	0.85	0.15	1.039
0.90	0.10	1.282	0.90	0.10	1.282
0.95	0.05	1.645	0.95	0.05	1.645
0.99	0.01	2.326	0.99	0.01	2.326

As an example of applying the equation above, assume CV = 30%, Confidence Level = 80%, Power = 95%, and Minimum Detectable Relative Difference = 20%. For infinite degrees of freedom (t distribution becomes a normal one), $Z_\alpha = 0.842$ and $Z_\beta = 1.645$. From the data assumed, $D = 20\% / 30\%$. Therefore,

$$n \geq [(0.842 + 1.645)/(20/30)]^2 + 0.5 (0.842)^2$$

$$n \geq 13.917 + 0.354 = 14.269$$

$$n \geq 15 \text{ samples required (round up)}$$

Source: Adapted from EPA 1989c.

Calculation Formulas For The Statistical Evaluation Of The Detection Of Hot Spots

Hot Spot Will Be Identified: Example # 1

These formulas are useful in evaluating the probability that a particular sampling plan will identify a hot spot. Let R represent the radius of a hot spot and D be the distance between adjacent grid points where samples will be collected. The probability that a grid point will fall on a hot spot is easily obtained from a geometrical argument since at least one grid point must fall in any square of area D^2 centered at the center of the hot spot. From this concept, it follows that the probability of sampling a hot spot $P(H/E)$ is given by:

$$\begin{aligned} P(H/E) &= (\pi R^2)/D^2 && \text{if } R \leq D/2 \\ &= \{R^2 [\pi - 2 \arccos (D/(2R))] + (D/4)\sqrt{(4R^2 - D^2)}\}/D^2 && \text{if } D/2 < R < D/\sqrt{2} \\ &= 1 && \text{if } R \geq D/\sqrt{2} \end{aligned}$$

where the angle $D/(2R)$ is expressed in radian measure, H is the case that a hot spot is found, and E is the case that a hot spot exists.

An example is if the grid spacing is $D = 2R$, then the probability of a hit is $\pi/4 = 0.785$, which implies that the probability that this grid spacing would not hit a hot spot if it exists is 0.215.

No Hot Spot Exists: Example # 2

This set of formulas addresses the probability that no hot spot exists (given that none were found). This argument requires the use of a subjective probability, $P(E)$ (where $P(E)$ is the probability that a hot spot exists), based on historical and perhaps geophysical evidence. Then, if E is the case that there are no hot spots at the study site and if H is the case that no hot spot is found in the sample, Bayes formula gives:

$$\begin{aligned} P(E | \bar{H}) &= P(\bar{H} | E) P(E) / [P(\bar{H} | E) P(E) + P(\bar{H} | \bar{E}) P(\bar{E})] \\ &= P(\bar{H} | E) P(E) / [P(\bar{H} | E) P(E) + P(\bar{E})]. \end{aligned}$$

For the case where $D = 2R$, it was found from Example 1 that $P(H/E) = 0.215$. Therefore, if one is given that the chance $P(E)$ of a hot spot is thought to be 0.25 prior to the investigation, the probability of a hot spot existing if the study does not find one is:

$$P(E | \text{no hit}) = 0.215 (0.25) / [0.215 (0.25) + 0.75] = 0.067.$$

Hence, the probability that no hot spot exists is $(1-0.067) = 0.933$.

Source: Adapted from EPA 1989c.

Appendix IV (continued)

Number of Samples Required in a One-Sided One-Sample t-Test to Achieve a Minimum Detectable Relative Difference at Confidence Level (1- α) and Power of (1- β)

Coefficient of Variation (%)	Power (%)	Confidence Level (%)	Minimum Detectable Relative Difference (%)				
			5	10	20	30	40
10	95	99	66	19	7	5	4
		95	45	13	5	3	3
		90	36	10	3	2	2
		80	26	7	2	2	1
	90	99	55	16	6	5	4
		95	36	10	4	3	2
		90	28	8	3	2	2
		80	19	5	2	1	1
	80	99	43	13	6	4	4
		95	27	8	3	3	2
		90	19	6	2	2	2
		80	12	4	2	1	1
15	95	99	145	39	12	7	5
		95	99	26	8	5	3
		90	78	21	6	3	3
		80	57	15	4	2	2
	90	99	120	32	11	6	5
		95	79	21	7	4	3
		90	60	16	5	3	2
		80	41	11	3	2	1
	80	99	94	26	9	6	5
		95	58	16	5	3	3
		90	42	11	4	2	2
		80	26	7	2	2	1
20	95	99	256	66	19	10	7
		95	175	45	13	9	5
		90	138	36	10	5	3
		80	100	26	7	4	2
	90	99	211	55	16	9	6
		95	139	36	10	6	4
		90	107	28	8	4	3
		80	73	19	5	3	2
	80	99	164	43	13	8	6
		95	101	27	8	5	3
		90	73	19	6	3	2
		80	46	12	4	2	2

Source: EPA 1989c

B21-002-80,1

Appendix IV (continued)

Number of Samples Required in a One-Sided One-Sample t-Test to Achieve a Minimum Detectable Relative Difference at Confidence Level (1- α) and Power of (1- β)
(continued)

Coefficient of Variation (%)	Power (%)	Confidence Level (%)	Minimum Detectable Relative Difference (%)				
			5	10	20	30	40
25	95	99	397	102	28	14	9
		95	272	69	19	9	6
		90	216	55	15	7	5
		80	155	40	11	5	3
	90	99	329	85	24	12	8
		95	272	70	19	9	6
		90	166	42	12	6	4
		80	114	29	8	4	3
	80	99	254	66	19	10	7
		95	156	41	12	6	4
		90	114	30	8	4	3
		80	72	19	5	3	2
30	95	99	571	145	39	19	12
		95	391	99	26	13	8
		90	310	78	21	10	6
		80	223	57	15	7	4
	90	99	472	120	32	16	11
		95	310	79	21	10	7
		90	238	61	16	8	5
		80	163	41	11	5	3
	80	99	364	84	26	13	9
		95	224	58	16	8	5
		90	164	42	11	6	4
		80	103	26	7	4	2
35	95	99	775	196	42	25	15
		95	532	134	35	17	10
		90	421	106	28	13	8
		80	304	77	20	9	6
	90	99	641	163	43	21	13
		95	421	107	28	14	8
		90	323	82	21	10	6
		80	222	56	15	7	4
	80	99	495	126	34	17	11
		95	305	78	21	10	7
		90	222	57	15	7	5
		80	140	36	10	5	3

Source: EPA 1989C

B21-002-80.2

APPENDIX V
"J" DATA QUALIFIER SOURCE AND MEANING¹

Appendix V lists the parameters and criteria that produce a "J" flag in accordance with the *National Functional Guidelines for Organic Data Review* (EPA 1991e) and *Laboratory Data Validation Functional Guidelines for Inorganics Analyses* (EPA 1988e) as applied to data from the Contract Laboratory Program. The appendix also indicates the likely implication of this flag on the associated result(s).

The criteria listed in this guidance should be used to flag CLP data as "J," or "estimated concentration" (the associated numerical value is an estimate of the amount actually present in the sample). With proper interpretation, the results of analytes which are flagged "J" can often be used in making decisions.

Data flagged with "UJ" indicates that the value is undetected and quantitation limit may be imprecise. Data flagged with "NJ" indicates that the value is tentatively identified and confirmation is needed in future sampling efforts.

<u>PARAMETER</u>	<u>CRITERIA</u>	<u>ACTION</u>	<u>LIKELY IMPLICATION²</u>
ANALYSIS: Organic (3/90) VOA & BNA			
Holding times	14 < VOA < 30 days 7 < BNA < 22 days	Associated samples (+ results)	Low
Mass Calibration			No generalization
Ion Abundance	Several data elements in expanded window	All associated data	Precision
Calibrations			
-- initial	Average RRF < .05 %RSD > 30%	Compound specific (+ results) Compound specific (+ results)	Low
-- continuing	RRF < .05 %D between initial and continuing calibration > 25%	Compound specific (+ results) Compound specific (+ results)	Precision
Blanks	If associated result is between detection limit and CRQL	Compound specific	High

APPENDIX V (CONTINUED)

<u>PARAMETER</u>	<u>CRITERIA</u>	<u>ACTION</u>	<u>LIKELY IMPLICATION²</u>
Surrogates	If surrogate recoveries are low but > 10%	Fraction specific (+ results) (negative results are flagged w/sample quantitation limit as estimated (UJ))	Low
	Any surrogate in a fraction shows < 10% recovery	Fraction specific (+ results)	Low
	If surrogate recoveries are high	Fraction specific (+ results)	High
Internal standards	If an IS area count is outside -50% or +100% of the associated standard	Associated compounds (+ results) (non-detects flagged w/sample quantitation limit - UJ)	No generalization
TICs	None	All TIC results - (NJ)	No generalization
ANALYSIS: Pesticides (2/88)			
Holding Times	7 < PEST < 22 days	Associated positive results (negative results - UJ)	Low
Instrument Performance	DDT breakdown > 20%	Associated positive DDT results (J) Results for DDD and/or DDE (NJ)	Low
	Endrin breakdown > 20%	Associated positive Endrin results (J); Results for Endrin Ketone (J)	Low

APPENDIX V (CONTINUED)

<u>PARAMETER</u>	<u>CRITERIA</u>	<u>ACTION</u>	<u>LIKELY IMPLICATION²</u>
Calibrations			
-- initial	If criteria for linearity not met	Associated positive results	No generalization
-- continuing	If %D between calibration factors > 15% (20% for compounds being confirmed)	Associated positive results	No generalization
Surrogates	If low surrogate recoveries obtained	Associated results	Low
Compound Quantitation and Detection Limits	Quantitation limits affected by large, <u>off-scale</u> peaks	Estimated quantitation limit (UJ)	No generalization
ANALYSIS: Inorganic (3/90)			
Holding Times/ Preservation	Exceeded	Associated samples > IDL [<u><IDL (UJ)</u>]	Low
Calibrations	Correlation coefficient < 0.995	Associated samples > IDL [<u><IDL (UJ)</u>]	No generalization
	Midrange CN-standard not distilled	Associated samples	Precision
-- ICV or CCV	%R outside windows but within the ranges of 75-89% or 111-125% (CN, 78-84% or 116-130%; Hg, 65-79% or 121-135%)	Associated samples > IDL	Low/High
-- ICS (for ICP)	If ICS recovery > 120%	Associated samples > IDL	High

APPENDIX V (CONTINUED)

<u>PARAMETER</u>	<u>CRITERIA</u>	<u>ACTION</u>	<u>LIKELY IMPLICATION²</u>
	If ICS recovery falls between 50-79%	Associated samples > IDL [$< \text{IDL (UJ)}$]	Low
	Interferents with concentrations comparable to or higher than analyte levels	Associated samples > IDL [$< \text{IDL (UJ)}$]	High
	ICS Al, Ca, Fe, and Mg interfering elements > 2xCRDL and 10% reported concentration of the affected element	Associated samples	High
LCS (Aqueous)	Recovery within range 50-79% or > 120%	Associated samples > IDL [$< \text{IDL (UJ)}$]	Low/High
LCS (Solid)	Recovery outside control limits	Associated samples > IDL	Low/High
	Recovery lower than control limits	Associated samples [$< \text{IDL (UJ)}$]	Low
Duplicate	Outside control limits	Associated samples of same matrix > IDL	Precision
Matrix Spike Sample	Recovery > 125% or < 75%	Associated samples > IDL	Low/High
	Recovery within range 30-74%	Associated samples [$< \text{IDL (UJ)}$]	Low
AA Post Digestion Spike	Duplicate injection outside + 20% RSD (or CV) and sample not rerun once	Associated data > IDL	Precision

APPENDIX V (CONTINUED)

<u>PARAMETER</u>	<u>CRITERIA</u>	<u>ACTION</u>	<u>LIKELY IMPLICATION²</u>
	Rerun sample does not agree within + 20% RSD (CV)	Associated data > IDL	Precision
	Post digestion spike recovery < 40% even after rerun	Associated data > IDL	Low
	Post digestion spike recovery > 115% or < 85%	Associated data [<IDL (UJ)]	High/Low
	If sample absorbance is < 50% of post digestion spike absorbance and if furnace post digestion spike recovery not within 85 - 115%	Associated samples > IDL [<IDL (UJ)]	Low/High
	MSA not done	Associated data > IDL	Precision
	Any samples run by MSA not spiked at appropriate levels	Associated data > IDL	No generalization
	MSA correlation coefficient < 0.995	Associated data > IDL	No generalization
ICP Serial Dilution	Criteria not met	Associated data > IDL	Precision

APPENDIX V (CONTINUED)

¹ Selected Acronym Key

BNA	--	Base/neutral/acid or semivolatile
CRDL	--	Contract required detection limit (inorganics)
CRQL	--	Contract required quantitation limit (organics)
CV	--	Coefficient of variation
ICS	--	Interference check sample
ICV	--	Initial calibration verification
IDL	--	Instrument detection limit
IS	--	Internal standard
PEST	--	Pesticide
RRF	--	Relative response factor
RSD	--	Relative standard deviation
TIC	--	Tentatively identified compound
VOA	--	Volatile

² Implication Key

Low: The associated result may underestimate the true value.

High: The associated result may overestimate the true value.

Precision: The associated result may be of poor precision (high variability).

No generalization: No generalization can be made as to the likely implication.

APPENDIX VI
"R" DATA QUALIFIER SOURCE AND MEANING¹

Appendix VI lists the parameters and criteria that produce an "R" flag in accordance with the *National Functional Guidelines for Organic Data Review* (EPA 1991e) and *Laboratory Data Validation Functional Guidelines for Inorganics Analyses* (EPA 1988e) as applied to data from the Contract Laboratory Program. The appendix also indicates the likely implication of this flag on the associated result(s).

The criteria listed in this guidance should be used to flag CLP data as "R," or "unuseable." If the flagged analytes are of interest, then resampling or reanalysis is necessary.

<u>PARAMETER</u>	<u>CRITERIA</u>	<u>ACTION</u>	<u>LIKELY IMPLICATIONS²</u>
ANALYSIS: Organic (3/90) VOA & BNA			
Holding times	Grossly exceeded	Professional judgment (non-detects)	Low
Mass Calibration	In error	Associated samples	Unuseable
Ion Abundance	Outside expanded windows	Associated samples	Unuseable
Calibrations	Mean RRF or RRF < 0.05	Compound specific (non-detects)	Low
Blanks	Gross contamination (saturated peaks)	Compound specific (associated samples)	High
Surrogates	< 10% Recovery	Entire fraction (negative results)	Low
Internal Standards	Extremely low area counts; Major abrupt drop off	Associated compounds (non-detects)	Low
TICs	Suspected artifacts	Professional judgment	Unuseable

APPENDIX VI (CONTINUED)

<u>PARAMETER</u>	<u>CRITERIA</u>	<u>ACTION</u>	<u>LIKELY IMPLICATION²</u>
ANALYSIS: Pesticides (2/88)			
Holding Times	Grossly exceeded	Professional judgment (non-detects)	Low
Instrument Performance			
-- DDT Retention Time	Inadequate separation	Affected compounds	Unuseable
-- RT	Peaks of concern outside windows	Professional judgment (positive results and quantitation limits)	Unuseable
-- DDT/Endrin Degradation	Not detected and breakdown concentrations positive	Samples following last in-control standard (quantitation limit - DDT and Endrin)	Low
-- Retention Time Check	DBC > 2.0% (packed) > 0.3% (narrow-bore) > 1.5% (wide-bore)	Professional judgment	Unuseable
Surrogates	Not present	Suggested (negative results)	Low
Compound Quantitation and Detection Limits	Large off-scale peaks	Quantitation limits	Unuseable

APPENDIX VI (CONTINUED)

<u>PARAMETER</u>	<u>CRITERIA</u>	<u>ACTION</u>	<u>LIKELY IMPLICATION²</u>
ANALYSIS: Inorganic (3/90)			
Holding Times	Grossly exceeded	Professional judgment (Results < IDL)	Low
Calibrations	Minimum number of standards not used; Not calibrated daily or each time instrument set up	Professional judgment (associated samples)	Precision
-- ICV or CCV	%R outside of 75-125% (CN, 70-130; Hg, 65- 135%)	Associated samples	Low/High
ICS (for ICP)	Al, Ca, Fe or Mg in samples \leq ICS and ICS < 50%	Affected analytes	High
	Results -- 2xIDL for elements which are not present in the EPA-provided solution and levels of Al, Ca, Fe or Mg > 50% of levels found in ICS, and estimated interferences due to Al, Ca, Fe or Mg > 90%	Affected analytes	High
LCS (Aqueous)	Recovery < 50%	Affected analytes	Low
Matrix Spike Sample	Recovery < 30%	Affected samples (results < IDL)	Low
AA Post Digestion Spike	Recovery < 10%	Affected samples (results < IDL)	Low

¹ **Selected Acronym Key**

AA	--	Atomic absorption
BNA	--	Base/neutral/acid or semivolatile
CCV	--	Continuing calibration verification
DBC	--	Dibutyl chloredate
ICP	--	Inductively coupled plasma
ICS	--	Interference check sample
ICV	--	Initial calibration verification
IDL	--	Instrument detection limit
LCS	--	Laboratory control sample
RRF	--	Relative response factor
RT	--	Retention time
TIC	--	Tentatively identified compound
VOA	--	Volatile

² **Implication Key**

Low: The associated result may underestimate the true value.

High: The associated result may overestimate the true value.

Precision: The associated result may be of poor precision (high variability).

No generalization: No generalization can be made as to the likely implication.

Unuseable: Data are probably unuseable without resampling and reanalysis.

APPENDIX VII **SUMMARY OF COMMON LABORATORY CONTAMINANTS, CONCENTRATION** **REQUIREMENTS, AND RISK ASSESSMENT IMPLICATIONS**

Appendix VII lists common organic laboratory contaminants that may appear in blanks. The purpose of this appendix is to inform the reader of chemicals that may appear in analyses but may not be present at the site. Analytes with values above instrument detection limits are reported by laboratories. Some sample concentrations may not be reported through the review process, as explained below, but if they are reported, possibilities of false positives exist. The implications for risk assessment are included.

Common Laboratory Contaminants	Concentration Requirements	Risk Assessment Implications
Target Compound		
Methylene Chloride	Sample concentrations less than 10x that detected in method blanks will be reported as undetected (or flagged B).	<ul style="list-style-type: none"> o Include analyte if concentration is greater than 10x blank. o Include analyte if concentration is less than 10x greater than blank concentration and multiple chlorinated volatile analytes are detected. Exclude analyte in all other situations.
Acetone	Sample concentrations less than 10x that detected in method blanks will be reported as undetected (or flagged B).	<ul style="list-style-type: none"> o Include analyte if concentration is greater than 10x blank. o Include analyte if concentration is less than 10x greater than blank concentration and multiple ketones are detected. o Exclude analyte in all other situations.
Toluene	Sample concentrations less than 10x that detected in method blanks will be reported as undetected (or flagged B).	<ul style="list-style-type: none"> o Include analyte if concentration is greater than 10x blank. o Include analyte if concentration is less than 10x blank concentration and multiple aromatic or fuel hydrocarbons are detected. o Exclude analyte in all other situations.

APPENDIX VII (CONTINUED)

Common Laboratory Contaminants	Concentration Requirements	Risk Assessment Implications
2-Butanone (methyl ethylketone)	Sample concentrations less than 10x that detected in method blanks will be reported as undetected (or flagged B).	<ul style="list-style-type: none"> o Include analyte if concentration is greater than 10x blank. o Include analyte if concentration is less than 10x blank concentration and multiple ketones are detected.
Phthalates (i.e., dimethyl phthalate, diethyl phthalate, di-n-butyl phthalate, butylbenzyl phthalate, bis(2-ethylhexyl) phthalate, di-n-octyl phthalate)	Sample concentrations less than 10x that detected in method blanks will be reported as undetected (or flagged B).	<ul style="list-style-type: none"> o Include analyte if concentration is greater than 10x blank. o Exclude analyte in all other situations.
Tentatively Identified Compounds		
Carbon dioxide	Not reported if present in the method blank.	<ul style="list-style-type: none"> o Exclude analyte in all situations.
Diethyl ether	Not reported if present in the method blank.	<ul style="list-style-type: none"> o Include analyte if concentration is greater than 10x blank. o Exclude analyte in all other situations.
Hexanes	Not reported if present in the method blank.	<ul style="list-style-type: none"> o Exclude if analyte concentration is not 10x method blank. o Exclude if analyte concentration is not 10x field blank (EPA definition). o Exclude if sample is not analyzed within seven days.

APPENDIX VII (CONTINUED)

Common Laboratory Contaminants	Concentration Requirements	Risk Assessment Implications
Freons (e.g., 1,1,2-trichloro-1,2,2-trifluoroethane, fluorotrichloromethane)	Not reported if present in the method blank.	<ul style="list-style-type: none"> o Exclude if analyte concentration is not 10x method blank. o Exclude if analyte concentration is not 10x field blank (EPA definition). o Exclude if sample is not analyzed within seven days.
Solvent preservative artifacts (e.g., cyclohexanone, cyclohexenone, cyclohexanol, cyclohexenol, chlorocyclohexene, chlorocyclohexanol)	Not reported if present in the method blank.	<ul style="list-style-type: none"> o Exclude if artifact concentration is not 10x method blank. o Exclude if artifact concentration is not 10x field blank (EPA definition). o Exclude if sample is not analyzed within seven days.
Aldol reaction products of acetone (e.g., 4-hydroxy-4-methyl-2-pentanone, 4-methyl-penten-2-one, 5,5-dimethyl-2(5H)-furanone)	Not reported if present in the method blank.	<ul style="list-style-type: none"> o Include analyte if concentration is greater than 10x blank. o Include analyte if concentration is less than 10x greater than blank concentration and multiple ketones are detected. o Exclude analyte in all other situations.

APPENDIX VIII

CLP METHODS SHORT SHEETS

TITLE: USEPA CONTRACT LABORATORY PROGRAM
STATEMENT OF WORK FOR ORGANIC ANALYSIS
MULTI-MEDIA, MULTI CONCENTRATION

DOCUMENT NUMBER:	OLM01.0
DOCUMENT DATE:	Not Applicable
EFFECTIVE DATES:	September 28, 1990 through February 1994
CONCENTRATION:	Low to Medium
DATA TURNAROUND:	14 Days or 35 Days
MATRICES:	Aqueous/Soil/Sediment*

SIGNIFICANT FEATURES

- The compounds include volatiles, semivolatiles, and pesticide/PCBs.
- Volatiles and semivolatiles are analyzed by GC/MS; pesticides/PCBs are analyzed by GC/ECD.
- Major Tentatively Identified Compounds (TICs) are reported for GC/MS analyses.
- Second column confirmation by GC/ECD is required for all pesticides/PCBs. Pesticides/PCBs which are identified by GC/ECD at concentrations above 10 ng/uL are confirmed by GC/MS analysis.

REVISIONS/MODIFICATIONS

The following is a list of the significant changes from the 2/88 SOW that are incorporated in the OLM01.0 SOW:

- Selected volatile CRQLs have been raised; pesticide/PCB low soil CRQLs have been lowered; and selected pesticide/PCB aqueous CRQLs have been changed.
- Target Compound List (TCL) changes include the elimination of vinyl acetate from the volatile TCL, the elimination of benzyl alcohol and benzoic acid from the semivolatile TCL, the addition of carbazole to the semivolatile TCL, and the addition of endrin aldehyde to the pesticide TCL. The semivolatile TCL compound bis(2-chloroisopropyl)ether was renamed 2,2'-oxybis(1-chloropropane).
- A new method for analysis of pesticides/PCBs is used. Changes include the use of wide bore capillary columns, new surrogates, and new calibration techniques.
- Pesticide/PCB quantitation is performed using both the primary and secondary columns. The lower value is reported by the laboratory.

The only significant change in the OLM01.1 (December, 1990) and OLM01.1.1 (February, 1991) revisions to the OLM01.1 through OLM01.0 SOW was the lowering of selected semivolatile CRQLs. The significant changes in the OLM01.1 through OLM01.7 revisions to the OLM01.0 SOW were the lowering of selected semivolatile CRQLs and options for either a 14 day or 35 day data turnaround.

RECOMMENDED USES

This Routine Analytical Services (RAS) method is recommended for broad spectrum analysis to define the nature and extent of potential site contamination during SSI, LSI, and RI/FS activities. This method is suitable when a 14 day or 35 day turnaround for results is adequate. It is recommended for samples from known or suspected hazardous waste sites where potential contamination may be present at significant risk levels.

* Sediment samples with high moisture content should be solicited as RAS + SAS (Special Analytical Service) in order to achieve the CRQLs.

COMPOUNDS AND CRQLs

The Target Compound List compounds included in the analysis and their Contract Required Quantitation Limits (CRQLs) are listed in Attachment 1.

**TITLE: USEPA CONTRACT LABORATORY PROGRAM
STATEMENT OF WORK FOR ORGANIC ANALYSIS
MULTI-MEDIA, HIGH CONCENTRATION**

DOCUMENT NUMBER:	Not Applicable
DOCUMENT DATE:	September 1988
EFFECTIVE DATES:	June 7, 1989 through December 26, 1991
CONCENTRATION:	High: Greater than 20 ppm
DATA TURNAROUND:	35 Days
MATRICES:	Liquid/Solid/Multi-phase

SIGNIFICANT FEATURES

- No holding times are designated for high concentration samples.
- The analyses are suitable for highly contaminated samples (>20 mg/Kg).
- The analyses are acceptable for liquid, solid, or multi-phase samples. Multi-phase samples are separated into water miscible liquid, water immiscible liquid, or solid phases. Each phase is analyzed separately.
- Volatile, extractable (semivolatiles and pesticides), and multicomponent extractable (Aroclors and Toxaphene) compounds are included.
- Volatiles and extractables are analyzed by GC/MS; Aroclors and Toxaphene are analyzed by GC/ECD.
- Second column confirmation by GC/ECD is required for Aroclors and Toxaphene.
- Major Tentatively Identified Compounds (TICs) are reported for GC/MS analyses.

REVISIONS/MODIFICATIONS

The 1/89 and 4/89 revisions to the 9/88 SOW do not significantly affect data useability.

RECOMMENDED USES

This Routine Analytical Services (RAS) method is recommended for pre-remedial, remedial, or removal projects where high concentrations of organic contaminants (greater than 20 mg/Kg) are suspected and a 35 day turnaround for results is adequate. It is recommended for samples obtained from drummed material, waste pits or lagoons, waste piles, tanker trucks, onsite tanks, and apparent contaminated soil areas. The waste material may be industrial process waste, byproducts, raw materials, intermediates and contaminated products. Samples may be spent oil, spent solvents, paint wastes, metal treatment wastes, and polymer formulations.

The method is suitable for solids, liquids, or multiphase samples, a phase being either water miscible liquid, water immiscible liquid, or solid. Various methods of phase separation may be utilized depending on the number and types of phases in a sample.

COMPOUNDS AND CRQLs

The Target Compound List compounds included in the analysis and their Contract Required Quantitation Limits (CRQLs) are listed in Attachment 1.

**TITLE: USEPA CONTRACT LABORATORY PROGRAM
STATEMENT OF WORK FOR INORGANIC ANALYSIS
MULTI-MEDIA, MULTI CONCENTRATION**

DOCUMENT NUMBER:	ILM01.0
DOCUMENT DATE:	Not Applicable
EFFECTIVE DATES:	September 7, 1990 through September 26, 1993
CONCENTRATION:	Low to Medium
DATA TURNAROUND:	35 Days
MATRICES:	Aqueous/Soil/Sediment*

SIGNIFICANT FEATURES

- The analyses are suitable for aqueous, soil, or sediment samples at low to medium concentration levels.
- This Statement of Work includes the midi distillation for cyanide analysis and the microwave digestion for GFAA and ICP analyses. These two sample preparation procedures require less sample volume than the traditional Statement of Work sample preparation procedures.

REVISIONS/MODIFICATIONS

None to date

RECOMMENDED USES

This Routine Analytical Service (RAS) method is recommended for broad spectrum analysis to define the nature and extent of potential site contamination during SSI, LSI, and RI/FS activities. This method is suitable when a 35 day turnaround for results is adequate. It is recommended for samples from known or suspected hazardous waste sites where potential contamination may be present at significant risk levels.

* Sediment samples with high moisture content should be solicited as RAS + SAS (Special Analytical Service) in order to achieve the CRQLs.

ANALYTES AND CRQLs

The Target Analyte List analytes included in the analysis and their Contract Required Quantitation Limits (CRQLs) are listed in Attachment 2.

**TITLE: USEPA CONTRACT LABORATORY PROGRAM
STATEMENT OF WORK FOR INORGANIC ANALYSIS
MULTI-MEDIA, HIGH CONCENTRATION**

DOCUMENT NUMBER:	IHC01.2
DOCUMENT DATE:	Not Applicable
EFFECTIVE DATES:	May 15, 1991 through November 30, 1993
CONCENTRATION:	High
DATA TURNAROUND:	35 Days
MATRICES:	Liquid/Solid/Multi-phase

SIGNIFICANT FEATURES

- The analyses are suitable for highly contaminated samples.
- The analyses are acceptable for liquid, solid, or multi-phase samples. Multi-phase samples are separated into water miscible liquid, water immiscible liquid, or solid phases. Each phase is analyzed separately.
- The analyses include conductivity and pH; potassium is not included.

REVISIONS/MODIFICATIONS

The IHC01.1 and IHC01.2 revisions to the IHC01.0 SOW do not significantly affect data useability.

RECOMMENDED USES

This routine Analytical Service (RAS) method is recommended for pre-remedial, remedial, or removal projects where high concentrations of inorganic contaminants are suspected and a 35 day turnaround for results is adequate. It is recommended for samples obtained from drummed material, waste pits or lagoons, waste piles, tanker trucks, onsite tanks, and apparent contaminated soil areas. The waste material may be industrial process waste, byproducts, raw materials, intermediates, and contaminated products. Samples may be spent oil, spent solvents, paint wastes, metal treatment wastes, and polymer formulations.

The method is suitable for solids, liquids, or multiphase samples, a phase being either water miscible liquid, water immiscible liquid, or solid. A phase separation step is applied prior to digestion. Each phase is analyzed and reported as a separate sample.

ANALYTES AND CRQLs

The Target Analyte List analytes included in the analysis and their Contract Required Quantitation Limits (CRQLs) are listed in Attachment 2.

Attachment 1 (Cont'd) Target Compound List and Associated CRQLs

<i>Semi-Volatiles</i>	<i>Semi-Volatiles (1,2) Low to Medium</i>		<i>Extractables (3,4) High Concentration</i>
<i>Compound</i>	<i>Aqueous CRQL (ug/L, ppb)</i>	<i>Low Soil CRQL (ug/kg, ppb)</i>	<i>Liquid/Solid/Multi-Phase CRQL (mg/kg, ppm)</i>
Acenaphthalene	10	330	20
2,4-Dinitrophenol	25*	800*	100
4-Nitrophenol	25*	800*	100
Dibenzofuran	10	330	20
2,4-Dinitrotoluene	10	330	20
Diethylphthalate	10	330	20
4-Chlorophenyl-phenylether	10	330	20
Fluorene	10	330	20
4-Nitroaniline	25*	800*	100
4,6-Dinitro-2-methylphenol	25*	800*	100
N-nitrosodiphenylamine	10	330	20
4-Bromophenyl-phenylether	10	330	20
Hexachlorobenzene	10	330	20
Pentachlorophenol	25*	800*	100
Phenanthrene	10	330	20
Anthracene	10	330	20
Carbazole	10	330	--
Di-n-butylphthalate	10	330	20
Fluoranthene	10	330	20
Pyrene	10	330	20
Butylbenzylphthalate	10	330	20
3,3'-Dichlorobenzidine	10**	330**	40
Benzo(a)anthracene	10	330	20
Chrysene	10	330	20
bis(2-Ethylhexyl)phthalate	10	330	20
Di-n-octylphthalate	10	330	20
Benzo(b)fluoranthene	10	330	20
Benzo(k)fluoranthene	10	330	20
Benzo(a)pyrene	10	330	20
Indeno(1,2,3-cd)pyrene	10	330	20
Dibenzo(a,h)anthracene	10	330	20
Benzo(g,h,i)perylene	10	330	20

* CRQLs previously 5 ug/L and 5 ug/kg in 2/88 SOW
** CRQLs previously 20 ug/L and 600 ug/kg in 2/88 SOW

Note:

- 1 The sample-specific CRQLs for soil samples will be adjusted for percent moisture and will be higher than those listed above.
- 2 Medium level soil CRQL = 120 x Aqueous CRQL reported in ug/kg.
- 3 All CRQLs are based on wet weight and apply to solid and liquid samples.
- 4 Results for both solid and liquid samples are reported as mg/kg, wet weight.

21-002-079

Attachment 1 (Cont'd)
Target Compound List and Associated CRQLs

<i>Semi-Volatiles</i>	<i>Semi-Volatiles (1,2) Low to Medium</i>		<i>Extractables (3,4) High Concentration</i>
<i>Compound</i>	<i>Aqueous CRQL (ug/L, ppb)</i>	<i>Low Soil CRQL (ug/kg, ppb)</i>	<i>Liquid/Solid/Multi-Phase CRQL (mg/kg, ppm)</i>
Acenaphthalene	10	330	20
2,4-Dinitrophenol	25*	800*	100
4-Nitrophenol	25*	800*	100
Dibenzofuran	10	330	20
2,4-Dinitrotoluene	10	330	20
Diethylphthalate	10	330	20
4-Chlorophenyl-phenylether	10	330	20
Fluorene	10	330	20
4-Nitroaniline	25*	800*	100
4,6-Dinitro-2-methylphenol	25*	800*	100
N-nitrosodiphenylamine	10	330	20
4-Bromophenyl-phenylether	10	330	20
Hexachlorobenzene	10	330	20
Pentachlorophenol	25*	800*	100
Phenanthrene	10	330	20
Anthracene	10	330	20
Carbazole	10	330	--
Di-n-butylphthalate	10	330	20
Fluoranthene	10	330	20
Pyrene	10	330	20
Butylbenzylphthalate	10	330	20
3,3'-Dichlorobenzidine	10**	330**	40
Benzo(a)anthracene	10	330	20
Chrysene	10	330	20
bis(2-Ethylhexyl)phthalate	10	330	20
Di-n-octylphthalate	10	330	20
Benzo(b)fluoranthene	10	330	20
Benzo(k)fluoranthene	10	330	20
Benzo(a)pyrene	10	330	20
Indeno(1,2,3-cd)pyrene	10	330	20
Dibenzo(a,h)anthracene	10	330	20
Benzo(g,h,i)perylene	10	330	20

* CRQLs previously 5 ug/L and 5 ug/kg in 2/88 SOW

** CRQLs previously 20 ug/L and 600 ug/kg in 2/88 SOW

Note:

- The sample-specific CRQLs for soil samples will be adjusted for percent moisture and will be higher than those listed above.
- Medium level soil CRQL = 120 x Aqueous CRQL reported in ug/kg.
- All CRQLs are based on wet weight and apply to solid and liquid samples.
- Results for both solid and liquid samples are reported as mg/kg, wet weight.

Attachment 1 (Cont'd) Target Compound List and Associated CRQLs

Compound	Semi-Volatiles (1,2) Low to Medium		High Concentration (3,4)
	Aqueous CRQL (ug/L, ppb)	Low Soil CRQL (ug/kg, ppb)	Liquid/Solid/Multi- Phase CRQL (mg/kg, ppm)
Phenol	10	330	20
bis(2-Chloroethyl)ether	10	330	20
2-Chlorophenol	10	330	20
1,3-Dichlorobenzene	10	330	20
1,4-Dichlorobenzene	10	330	20
1,2-Dichlorobenzene	10	330	20
2-Methylphenol	10	330	20
2,2'-oxybis(1-Chloropropane)	10	330	20
4-Methylphenol	10	330	20
N-nitroso-di-n-dipropylamine	10	330	20
Hexachloroethane	10	330	20
Nitrobenzene	10	330	20
Isochlorophene	10	330	20
2-Nitrophenol	10	330	20
2,4-Dimethylphenol	10	330	20
bis(2-Chloroethoxy)methane	10	330	20
2,4-Dichlorophenol	10	330	20
1,2,4-Trichlorobenzene	10	330	20
Naphthalene	10	330	20
4-Chloroaniline	10	330	20
Hexachlorobutadiene	10	330	20
4-Chloro-3-methylphenol	10	330	20
2-Methylnaphthalene	10	330	20
Hexachlorocyclopentadiene	10	330	20
2,4,6-Trichlorophenol	10	330	20
2,4,5-Trichlorophenol	25*	800*	100
2-Chloronaphthalene	10	330	20
2-Nitroaniline	25*	800*	100
Dimethylphthalate	10	330	20
Acenaphthalene	10	330	20
2,6-Dinitrotoluene	10	330	20
3-Nitroaniline	25	800*	100

* CRQLs previously 5 ug/L and 5 ug/kg in 2/88 SOW

Note:

- 1 The sample-specific CRQLs for soil samples will be adjusted for percent moisture and will be higher than those listed above.
- 2 Medium level soil CRQL = 1000 x Aqueous CRQL reported in ug/kg.
- 3 All CRQLs are based on wet weight and apply to solid and liquid samples.
- 4 Results for both solid and liquid samples are reported as mg/kg, wet weight.

Attachment 1 (Cont'd)
Target Compound List and Associated CRQLs

<i>Semi-Volatiles</i>	<i>Semi-Volatiles Low to Medium</i>		<i>Extractables (1,2) High Concentration</i>
<i>Compound</i>	<i>Aqueous CRQL (ug/L, ppb)</i>	<i>Low Soil** CRQL (ug/kg, ppb)</i>	<i>Liquid/Solid/Multi-Phase CRQL (mg/kg, ppm)</i>
alpha-BHC	0.05	1.7	20
beta-BHC	0.05	1.7	20
delta-BHC	0.05	1.7	20
gamma-BHC (Lindane)	0.05	1.7	20
Heptachlor	0.05	1.7	20
Aldrin	0.05	1.7	20
Heptachlor epoxide	0.05	1.7	20
Endosulfan I	0.05	1.7	20
Dieldrin	0.10	3.3	20
4,4'-DDE	0.10	3.3	20
Endrin	0.10	3.3	20
Endosulfan II	0.10	3.3	20
4,4'-DDD	0.10	3.3	20
Endosulfan sulfate	0.10	3.3	20
4,4'-DDT	0.10	3.3	20
Methoxychlor	0.5	17.0	20
Endrin ketone	0.10	3.3	20
Endrin aldehyde	0.10	3.3	--
alpha-Chlordane	0.05*	1.7	20
gamma-Chlordane	0.05*	1.7	20

Note:

1 All CRQLs are based on wet weight and apply to solid and liquid samples.

2 Results for both solid and liquid samples are reported as mg/kg, wet weight.

Aqueous CRQLs changed from 2/88 SOW to the following:

* Aqueous CRQLs (ug/L) - alpha- and gamma-Chlordane from 0.5 to 0.05.

All low soil CRQLs changed from 2/88 SOW to the following:

** Low Soil CRQLs (ug/kg): alpha-BHC through Endosulfan I from 8.0 to 1.7;
 Dieldrin through 4,4'-DDT and Endrin ketone from 16.0 to 3.3;
 Methoxychlor from 80.0 to 17.0;
 alpha- and gamma-Chlordane from 80.0 to 1.7.

21-002-078,3

Attachment 1 (Cont'd)
Target Compound List and Associated CRQLs

<i>Compound</i>	<i>Semi-Volatiles Low to Medium</i>		<i>Extractables (1,2) High Concentration</i>
	<i>Aqueous CRQL (ug/L, ppb)</i>	<i>Low Soil** CRQL (ug/kg, ppb)</i>	<i>Liquid/Solid/Multi-Phase CRQL (mg/kg, ppm)</i>
Butyl alcohol	--	--	20
Benzoic acid	--	--	100
Monochlorobiphenyl	--	--	100
Dichlorobiphenyl	--	--	100
Trichlorobiphenyl	--	--	100
Tetrachlorobiphenyl	--	--	100
Hexachlorobiphenyl	--	--	100
Pentachlorobiphenyl	--	--	100
Octachlorobiphenyl	--	--	200
Nonachlorobiphenyl	--	--	200
Decachlorobiphenyl	--	--	200
Heptachlorobiphenyl	--	--	100
Toxaphene	5.0*	170.0	50
Aroclor-1016	1.0*	33.0	10
Aroclor-1221	2.0*	67.0	10
Aroclor-1232	1.0*	33.0	10
Aroclor-1242	1.0*	33.0	10
Aroclor-1248	1.0*	33.0	10
Aroclor-1254	1.0	33.0	10
Aroclor-1260	1.0	33.0	10

Note:

- 1 All CRQLs are based on wet weight and apply to solid and liquid samples.
- 2 Results for both solid and liquid samples are reported as mg/kg, wet weight.

Aqueous CRQLs changed from 2/88 SOW to the following:

- * Aqueous CRQLs (ug/L) - Toxaphene from 1.0 to 5.0;
Aroclors-1016, 1232, 1242, and 1248 from 0.5 to 1.0;
Aroclor-1221 from 0.5 to 2.0.

All low soil CRQLs changed from 2/88 SOW to the following:

- ** Low Soil CRQLs (ug/kg): Toxaphene from 160.0 to 170.0;
Aroclor-1016, 1232, 1242, and 1248 from 80.0 to 33.0;
Aroclor-1221 from 80.0 to 67.0;
Aroclor-1254 and 1260 from 160.0 to 33.0.TCL Ex

Attachment 2 Target Analyte List and Associated CRQLs


Analyte	Multi-Concentration (1)		High Concentration (2,3)
	Aqueous CRQL (ug/L, ppb)	Low Soil CRQL (ug/kg, ppb)	Liquid/Solid/Multi-Phase CRQL (mg/kg, ppm)
Aluminum	200	40	80
Antimony	60	12	20
Arsenic	10	2	5
Barium	200	40	80
Beryllium	5	1	5
Cadmium	5	1	10
Calcium	5000	1000	80
Chromium	10	2	10
Cobalt	50	10	20
Copper	25	5	40
Iron	100	20	20
Lead	3	0.6	10
Magnesium	5000	1000	80
Manganese	15	3	10
Mercury	0.2	0.1	0.3
Nickel	40	8	20
Potassium	5000	1000	--
Selenium	5	1	5
Silver	10	2	10
Sodium	5000	1000	80
Thallium	10	2	20
Vanadium	50	10	20
Zinc	20	4	10
Cyanide	10	2	1.5
pH	--	--	N/A
Conductivity	--	--	3.0 (umhos/cm)

Note:

- 1 The sample-specific CRQLs for soil samples will be adjusted for percent moisture and will be higher than those listed above.
- 2 Medium level soil CRQL = 120 x Aqueous CRQL reported in ug/kg.
- 3 Results for both solid and liquid samples are reported as mg/kg, wet weight.

APPENDIX IX **EXAMPLE DIAGRAM FOR A CONCEPTUAL MODEL FOR RISK ASSESSMENT**

This appendix provides a schematic example of a conceptual site model. This example is a copy of Figure 2-2 of *Guidance for Conducting Remedial Investigations and Feasibility Studies Under CERCLA* (EPA 1989i).



Glossary

Accuracy. The degree of agreement of a measured value with the true or expected value of the quantity of concern.

Analyte. The chemical for which a sample is analyzed.

Analyte Speciation. The ability of an analyte to exist in, or change between, chemically different forms (e.g., valence state, complexation state) depending on ambient conditions.

Anthropogenic Background Levels. Concentrations of chemicals that are present in the environment due to human-made, non-site sources (e.g., industry, automobiles).

Audit Sample. A sample of known composition provided by EPA for contractor analysis to evaluate contractor performance.

Average. The sum of a set of observations divided by the number of observations. Other measures of central tendency are median, mode, or geometric mean.

Background Sample. A sample taken from a location where chemicals present in the ambient medium are assumed due to natural sources.

Bias. A systematic error inherent in a method or caused by some artifact or idiosyncrasy of the measurement system.

Biased Sampling. A sampling plan in which the data obtained may be systematically different from the true mean. Biased sampling protocols are appropriate for certain objectives (e.g., clustering of samples to search for hot spots).

Biota. The plants and animals of the study area.

Blank. A clean sample that has not been exposed to the analyzed sample stream in order to monitor contamination during sampling, transport, storage, or analysis.

Broad Spectrum Analysis. An analytical procedure capable of providing identification and quantitation of a wide variety of chemicals.

Calibration. The comparison of a measurement standard or instrument with another standard or instrument to report or eliminate, by adjustment, any variation (deviation) in accuracy of the item being compared. The levels of calibration standards should bracket the range of levels for which actual measurements are to be made.

Cancer Slope Factor. A plausible, upper-bound estimate of the probability of cancer response in an exposed individual, per unit intake over a lifetime exposure period.

Chain-of-Custody Records. Records that contain information about the sample from sample collection to final analysis. Such documentation includes labeling to prevent mix-up, container seals to detect unauthorized tampering with contents and to secure custody, and the necessary records to support potential litigation.

Chemical of Potential Concern. A chemical initially identified or suspected to be present at a site that may be hazardous to human health.

Classical Model. A statistical description of experimental data that assumes normality and independence.

Confidence. Statistically, a measure of the probability of taking action when action is required or that an observed value is correct. A confidence limit is a value above or below a measured parameter that is likely to be observed at a specified level of confidence.

Contract Laboratory Program (CLP). Analytical program developed for analysis of Superfund site samples to provide analytical results of known quality, supported by a high level of quality assurance and documentation.

Contract Required Quantitation Limit (CROL). The chemical-specific quantitation levels that the CLP requires to be routinely and reliably quantitated in specified sample matrices.

Data Assessment. The determination of the quantity and quality of data and their useability for risk assessment.

Data Quality Indicator (DQI). A performance measure for sampling and analytical procedures.

Data Quality Objectives (DQOs). Qualitative and quantitative statements that specify the quality of the data required to support decisions. DQOs are determined based on the end use of the data to be collected.

Data Review. The evaluation process that determines the quality of reported analytical results. It involves examination of raw data (e.g., instrument output) and quality control and method parameters by a professional with knowledge of the tests performed.

Data Useability. The ability or appropriateness of data to meet their intended use.

Data Validation. CLP-specific evaluation process that examines adherence to performance-based acceptance criteria as outlined in *National Functional Guidelines for Organic (or Inorganic) Data Review* (EPA 1991e, EPA 1988e).

Detection Limit. The minimum concentration or weight of an analyte that can be detected by a single measurement above instrumental background noise.

Dilution. Adding solvent to a sample, with an analyte concentration higher than the standard calibration curve, to bring the analyte concentration into a quantifiably measurable range.

Dissolved Metals. Metals present in solution rather than sorbed on suspended particles.

Domain. A mappable subset of the total area containing the populations, after which distinct statistical properties can be described.

Dose-Response Evaluation. The process of quantitatively evaluating toxicity information and characterizing the relationship between the dose of a contaminant administered or received and the incidence of adverse health effects in the exposed populations.

Duplicate. A second sample taken from the same source at the same time and analyzed under identical conditions to assist in the evaluation of sample variance.

Exposure Area. The area of a site over which a receptor is likely to contact a chemical of potential concern.

Exposure Assessment. The determination or estimation (qualitative or quantitative) of the magnitude, frequency, duration, and route of exposure.

Exposure Pathway. The course of a chemical or physical agent from a source to a receptor. Each exposure pathway includes a release from a source, an exposure point, and an exposure route.

Extraction. The process of releasing compounds from a sample matrix prior to analysis.

False Negative (type II or beta error). A statement that a condition **does not** exist when it actually **does**.

False Positive (type I or alpha error). A statement that a condition **does** exist when it actually **does not**.

Field Analyses. Analyses performed in the field using sophisticated portable instruments or instruments set up in a mobile laboratory on site. Results are available in real time or in several hours and may be quantitative or qualitative.

Field Portable. An instrument that is sufficiently rugged and not of excessive weight that can be carried and used by an individual in the field.

Field Screening. Analyses performed in the field using portable instruments. The results are available in real time but are often not compound-specific or quantitative.

Fixed Laboratory Analyses. Analyses performed in an off-site analytical laboratory.

Frequency of Occurrence. The ratio of occurrence of a chemical existing at a site compared to occurrence at all sites or compared to the frequency at which the chemical was tested for.

Geographical Information System (GIS). A computerized database designed to overlay multiple information elements such as maps, annotations, drawings, digital photos, and estimated concentrations.

Geostatistical Model. A statistical or mathematical description of experimental data with special attention to spatial covariance or temporal variation.

Geostatistics. A theory of statistics that recognizes observed concentrations as dependent on one another and governed by physical processes. Geostatistical methods consider the location of data and the size of the site for calculations.

Heterogeneous Distribution. Sample property that is unevenly distributed in the population.

Historical Data. Data collected before the remedial investigation.

Holding Time. The length of time from the date of sampling to the date of analysis. CLP designates the holding time as the date from laboratory receipt of sample until date of analysis.

Homogeneous Distribution. A sample property that is evenly distributed over the population.

Hot Spot. Location of a substantially higher concentration of a chemical of concern than in surrounding areas of a site.

Hydrocarbon. An organic compound composed of carbon and hydrogen.

Identification. Confirmation of the presence of a specific compound or analyte in a sample.

Instrument Detection Limit (IDL). The lowest amount of a substance that can be detected by an instrument without correction for the effects of sample matrix, handling and preparation.

Intake. A measure of exposure expressed as the mass of a substance in contact with the exchange boundary per unit body weight and unit time.

Integrated Risk Information System (IRIS). An EPA database containing verified RfDs, RfCs, slope factors, up-to-date health risks and EPA regulatory information for numerous chemicals. IRIS is EPA's preferred source for toxicity information for Superfund.

Internal Standard. A compound added to organic samples and blanks at a known concentration prior to analysis. It is used as the basis for quantitation of target compounds.

Judgmental/Purposive Sampling. The process of locating sampling points based on the investigator's best judgment from historical data of where the sample should be taken.

Kriging. A procedure utilizing a spatial covariance function and known values at sampling locations to estimate unknown values at unsampled locations. For each estimate, an error of estimate is generated.

Limit of Detection (LOD). The concentration of a chemical that has a 99% probability of producing an analytical result above background "noise" using a specific method.

Limit of Quantitation (LOQ). The concentration of a chemical that has a 99% probability of producing an analytical result above the LOD. Results below LOQ are not quantitative.

Linearity. The agreement between an actual instrument reading and the reading predicted by a straight line drawn between calibration points that bracket the reading.

Lowest-Observable-Adverse-Effect-Level (LOAEL). In dose experiments, the lowest exposure level at which there are statistically or biologically significant increases in frequency or severity of adverse effects between the exposed population and its apparent control group.

Mass Spectrum. A characteristic pattern of ion fragments of different masses resulting from analysis that can be compared with a mass spectral library for analyte identification.

Matrix/Medium. The predominant material comprising the sample to be analyzed (e.g., drinking water, sludge, air).

Measurement Error. The difference between the true sample value and the observed measured value.

Measurement Variability. The difference between an observed measurement and the unknown true value of the property being measured.

Media Variability. Variability attributed to matrix effects.

Method Blank Performance. A measure that defines the level of laboratory background and reagent contamination. It is determined by analyzing a method blank consisting of all reagents, internal standards, and surrogate standards that are carried through the entire analytical procedure.

Method Detection Limit (MDL). The detection limit that takes into account the reagents, sample matrix, and preparation steps applied to a sample in specific analytical methods.

Minimum Detectable Relative Difference. Percent difference between two concentration levels that can be detected in analyses.

Modeling. A mathematical description of an experimental data set.

Natural Variation. Variation in values or properties of a parameter that are primarily determined by natural forces or conditions (e.g., variation in background levels of a chemical of potential concern in soils at a site).

Normal Distribution. A probability density function that approximates the distribution of many random variables and has the form generally called the "bell-shaped curve."

Null Hypothesis. For risk assessment, statistical hypothesis that states on-site chemical concentrations are not higher than background.

Particulate. Solid material suspended in a fluid medium (air or water).

Performance Evaluation Sample. A sample of known composition provided for laboratory analysis to monitor laboratory and method performance.

Performance Objectives. Statements of the type and content of deliverables and results that are necessary to assess the useability of data for risk assessment. For example, documentation (chain-of-custody records) must be available to relate all sample results to geographic locations.

Population Variability. The variation in true pollution levels from one population unit to the next. Some factors that cause this variation are distance, direction, and elevation.

Power. A parameter used in statistics that measures the probability that the result from a specified sampling or analytical process correctly indicates that no further action is required.

Practical Quantitation Limit (POL). The lowest level that can be reliably achieved within specified limits of precision and accuracy during routine laboratory operating conditions.

Precision. A measure of the agreement among individual measurements of the same property, under prescribed similar conditions.

Preliminary Remediation Goals (PRGs). Initial clean-up goals that 1) are protective of human health and the environment and 2) comply with ARARs. They are developed early in the process based on readily available information and are modified to reflect results of the baseline risk assessment. They also are used during analysis of remedial alternatives in the remedial investigation/feasibility study (RI/FS)

Preservation. Treatment of a sample to maintain representative sample properties.

Qualifier. A code appended to an analytical result that indicates possible qualitative or quantitative uncertainty in the result.

Qualitative. An analysis that identifies an analyte in a sample without numerical certainty.

Quality Assurance Project Plan (QAPjP). An orderly assembly of detailed and specific procedures which delineates how data of known and accepted quality is produced for a specific project.

Quantitation Limit. The lowest experimentally measurable signal obtained for the actual analyte using a particular procedure.

Quantitative. An analysis that gives a numerical level of certainty to the concentration of an analyte in a sample.

Random Sampling. The process of locating sample points randomly within a sampling area.

Range of Linearity. The concentration range over which the analytical curve remains linear. The limit within which response is linearly related to concentration.

Reasonable Maximum Exposure (RME). The maximum exposure that could reasonably be expected to occur for a given exposure pathway at a site. The RME is intended to account for both variability in exposure parameters and uncertainty in the chemical concentration.

Receptor. An individual organism or species, or a segment of the population of the organism or species, that is exposed to a chemical.

Recovery. A determination of the accuracy of the analytical procedure made by comparing measured values for a spiked sample against the known spike values.

Reference Concentration (RfC). An estimate, with uncertainty spanning an order of magnitude, of continuous exposure to the human population (including sensitive subgroups) through inhalation that is likely to be without appreciable risk of deleterious effect during a lifetime.

Reference Dose (RfD). An estimate (with uncertainty spanning an order of magnitude or more) of a daily exposure level for a human population, including sensitive subpopulations, that is likely to be without an appreciable risk of adverse health effects over the period of exposure.

Relative Percent Difference (RPD). A measure of precision which is based on the mean of two values from related analyses and is reported as an absolute value.

Relative Response Factor (RRF). A measure of the relative mass spectral response of an analyte compared to its internal standard. RRFs are determined by the analysis of standards and are used in the calculation of concentration of analytes in samples.

Remedial Investigation (RI). A process for collecting data to characterize site and waste and for conducting treatability testing as necessary to evaluate the performance and cost of the treatment technologies and support the design of selected remedies.

Representativeness. The degree to which the data collected accurately reflect the actual concentration or distribution.

Retention Time. The length of time that a compound is retained on an analytical column (common in GC, HPLC, and IC).

Risk*Assistant A software developed for EPA which provides analytical tools and databases to assist exposure and risk assessments of chemically contaminated sites.

Risk Characterization. The process of integrating the results of the exposure and toxicity assessments (i.e., comparing estimates of intake with appropriate toxicological values to determine the likelihood of adverse effects in potentially exposed populations).

Routine Method. A method issued by an organization with appropriate responsibility. A routine method has been validated and published and contains information on minimum performance characteristics.

Sample Integrity. The maintenance of the sample in the same condition as when sampled.

Sample Quantitation Limit (SOL). The detection limit that accounts for sample characteristics, sample preparation and analytical adjustments, such as dilution.

Sampling and Analysis Plan (SAP). A document consisting of a quality assurance project plan, and the field sampling plan, which provides guidance for all field sampling and analytical activities that will be performed.

Sampling Variability. The variability attributed to various sampling schemes, such as judgmental sampling and systematic sampling.

Sensitivity. The capability of methodology or instrumentation to discriminate between measurement responses for quantitative differences in a parameter of interest.

Simple Random Sampling. A sampling scheme where positions, times, or intervals are based on a randomized selection.

Slope Factor. A plausible upper-bound estimate of the probability of a response per unit intake of a chemical over a lifetime. The slope factor is used to estimate an upper-bound probability of an individual developing cancer as a result of a lifetime exposure to a particular level of a potential carcinogen.

Solvent. A liquid used to dissolve and separate analytes from the matrix of origin.

Spatial Variation. The manner in which contaminants vary within a defined area. The magnitude of difference in contaminant concentrations in samples separated by a known distance is a measure of spatial variability.

Spike. A known amount of a chemical added to a sample for the purpose of determining efficiency of recovery; a type of quality control sample.

Split. A single sample divided for the same measurement by two processes for the purpose of monitoring precision, accuracy or comparability of two analyses.

Standard Deviation. The most common measure of the dispersion of observed values or results expressed as the magnitude of the square root of the variance.

Standard Operating Procedures (SOPs). A written document which details an operation, analysis, or action whose mechanisms are thoroughly prescribed.

Stratified Random Sampling. A sampling scheme where the target population is divided into a certain number of non-overlapping parts for the purpose of achieving a better estimate of the population parameter.

Stratified Systematic Sampling. A sampling scheme where a consistent pattern is apportioned to various subareas or domains.

Stratify. To divide a physical volume or area into discrete units (strata) which are assumed to have different characteristics; a numeric procedure to subdivide a set or sets of data.

Surrogate Standard. A standard of known concentration added to environmental samples for quality control purposes. A surrogate standard is not likely to be found in an environmental sample, but has similar analytical properties to one or more analytes of interest.

Surrogate Technique. The use of surrogate analytes to assess the effectiveness of an analytical process (i.e., the ability to recover analytes from a complex environmental matrix).

Systematic Random (Grid) Sampling. A random sampling plan utilizing points predefined by a geometric pattern.

Target Compound/Analyte. The compound/analyte of interest in a specific method. The term also has been used in the Federal Register to denote compounds/analytes of regulatory significance.

Temporal Variation. Variation observed in chemical concentrations that is dependent on time.

Tentatively Identified Compound (TIC). Organic compounds detected in a sample that are not target compounds, internal standards or surrogates.

Toxicity Assessment. The toxicity assessment considers the following: 1) the types of adverse health effects associated with chemical exposures; 2) The relationship between magnitude of exposure and adverse effects; and 3) related uncertainties such as the weight of evidence of a particular chemical's carcinogenicity in humans.

Toxicological Threshold. The concentration at which a compound exhibits toxic effects.

Turnaround Time. The time from laboratory receipt of samples to receipt of a data package by the client.

Uncertainty. The variability in a process that may consist of contributions from sampling, analysis, review, and random error.

95% Upper Confidence Limit (UCL). A value that, when calculated repeatedly for different, randomly drawn subsets of site data, equals or exceeds the true mean 95% of the time.

Useful Range. That portion of the calibration curve that will produce the most accurate and precise results.

Variance. A measure of dispersion. It is the sum of the squares of the differences between the individual values and the arithmetic mean of the set, divided by one less than the number of values.

Viscosity. The physical property of a fluid that offers a continued resistance to flow.

Volatile Organics. The solid or liquid compounds that may undergo spontaneous phase change to a gaseous state at standard temperature and pressure.

Wavelength. The linear distance between successive maxima or minima of a wave form.

Weight-of-Evidence Classification. An EPA classification system for characterizing the extent to which available data indicate that an agent is a human carcinogen. Recently, EPA has developed weight-of-evidence systems for other kinds of toxic effects, such as developmental effects.

References

- Aitchison, J. and Brown, J.A.C. 1957. *The Lognormal Distribution with Special Reference to its Uses in Economics*. Cambridge University Press.
- American Society for Testing and Materials (ASTM). 1979. *Sampling and Analysis of Toxic Organics in the Atmosphere*. ASTM Symposium. American Society for Testing and Materials. Philadelphia, PA.
- Baudo, R., Glesy, J., and Muntan, H., eds. 1990. *Sediments: Chemistry and Toxicity of In-Place Pollutants*. Lewis Publishers, Inc. Ann Arbor, MI.
- Caulcutt, Roland. 1983. *Statistics for Analytical Chemists*. Chapman and Hall. New York.
- Clesceri, et al., eds. 1989. *Standard Methods for the Examination of Water and Wastewater*. 17th Edition. American Public Health Association. Washington, DC.
- Dragun, J. 1988. *The Soil Chemistry of Hazardous Materials*. Hazardous Materials Control Research Institute. Silver Spring, MD.
- Eckel, William P., Fisk, Joan F., and Jacob, Thomas A. 1989. Use of a Retention Index System to Better Identify Non-Target Compounds. *Hazardous Materials Control Research Institute 1989, Proceedings of the 10th National Conference*. pp. 86-90.
- Environmental Protection Agency (EPA). 1983. *Methods for Chemical Analysis of Water and Wastes (EPA 200 and 300 Methods)*. Environmental Monitoring Systems Laboratory. Las Vegas, NV. EPA/600/4-83/020.
- Environmental Protection Agency (EPA). 1984. *Methods for Organic Chemical Analysis of Municipal and Industrial Wastewater (EPA 600 Methods)* as presented in 40 CFR Part 136, Guidelines Establishing Test Procedures for the Analysis of Pollutants under the Clean Water Act.
- Environmental Protection Agency (EPA). 1985. *Methodology for Characterization of Uncertainty in Exposure Assessment*. Office of Research and Development. EPA/600/8-85/009.
- Environmental Protection Agency (EPA). 1986a. *Guidelines for Carcinogenic Risk Assessment*. 51 Federal Register 33992 (September 24, 1986).
- Environmental Protection Agency (EPA). 1986b. *Test Methods for Evaluating Solid Waste (SW846): Physical/Chemical Methods*. Third Edition. Office of Solid Waste.
- Environmental Protection Agency (EPA). 1987a. *Data Quality Objectives for Remedial Response Activities: Development Process*. EPA/540/G-87/003 (NTIS 9B88-131370).
- Environmental Protection Agency (EPA). 1987b. *Field Screening Methods Catalog*. Office of Emergency and Remedial Response.
- Environmental Protection Agency (EPA). 1987c. *A Compendium of Superfund Field Operations Methods*. Office of Emergency and Remedial Response. EPA /540/P-87/001. (OSWER Directive 9355.0-14).
- Environmental Protection Agency (EPA). 1988a. *Review of Ecological Risk Assessment Methods*. Office of Policy Analysis. EPA/230/10-88/041.

- Environmental Protection Agency (EPA). 1988b. *Superfund Exposure Assessment Manual*. Office of Emergency Response. EPA/540/1-88/001. (OSWER Directive 9285.5-1).
- Environmental Protection Agency (EPA). 1988c. *Geostatistical Environmental Assessment Software (GEOEAS)* (database).
- Environmental Protection Agency (EPA). 1988d. *Methods for the Determination of Organic Compounds in Drinking Water* (EPA 500 Methods). Environmental Monitoring Systems Laboratory. Las Vegas, NV. EPA/600/4-88/039.
- Environmental Protection Agency (EPA). 1988e. *Laboratory Data Validation: Functional Guidelines for Evaluating Inorganics Analysis*. Office of Emergency and Remedial Response.
- Environmental Protection Agency (EPA). 1989a. *Risk Assessment Guidance for Superfund, Volume I: Human Health Evaluation Manual, Part A*. Office of Solid Waste and Emergency Response. EPA/540/1-89/002. (OSWER Directive 9285.7-01A).
- Environmental Protection Agency (EPA). 1989b. *Risk Assessment Guidance for Superfund, Volume II: Environmental Evaluation Manual*. Office of Solid Waste and Emergency Response. EPA/540/1-89/001.
- Environmental Protection Agency (EPA). 1989c. *Ecological Assessment of Hazardous Waste Sites: A Field and Laboratory Reference*. Environmental Research Laboratory. EPA/600/3-89/013.
- Environmental Protection Agency (EPA). 1989d. *Integrated Risk Information System (IRIS)* (data base). Office of Research and Development.
- Environmental Protection Agency (EPA). 1989e. *Methods for Evaluating the Attainment of Cleanup Standards, Volume 1: Soils and Solid Media*. Office of Policy, Planning and Evaluation. EPA/230/2-89/042.
- Environmental Protection Agency (EPA). 1989f. *Soil Sampling Quality Assurance User's Guide*. Environmental Monitoring Systems Laboratory. Las Vegas, NV. EPA/600/8-89/046.
- Environmental Protection Agency (EPA). 1989g. *Office of Water Regulations and Standards/Industrial Technology Division (ITD) Methods* (EPA 1600 Methods). Office of Water.
- Environmental Protection Agency (EPA). 1989h. *Data Use Categories for the Field Analytical Support Project*. In Draft. Office of Solid Waste and Emergency Response.
- Environmental Protection Agency (EPA). 1989i. *Guidance for Conducting Remedial Investigations and Feasibility Studies under CERCLA, Interim Final*. Office of Solid Waste and Emergency Response. EPA/540/G-89/004. (OSWER Directive 9355.3-01).
- Environmental Protection Agency (EPA). 1990a. *Health Effects Assessment Summary Tables*. First and Second Quarters FY 1990. Office of Research and Development. (OERR 9200.6-303).
- Environmental Protection Agency (EPA). 1990b. *Geostatistics for Waste Management (GEOPACK)* (database).
- Environmental Protection Agency (EPA). 1990c. *A Rationale for the Assessment of Errors in the Sampling of Soils*. Office of Research and Development. EPA/600/4-90/013.

- Environmental Protection Agency (EPA). 1990d. *Contract Laboratory Program Statement of Work for Inorganic Analysis: Multi-Media, Multi-Concentration*. Document No. ILM01.0. Office of Emergency and Remedial Response.
- Environmental Protection Agency (EPA). 1990e. *Contract Laboratory Program Statement of Work for Organic Analysis: Multi-Media, Multi-Concentration*. Document No. OLM01.0. Office of Emergency and Remedial Response.
- Environmental Protection Agency (EPA). 1991a. *ECO Update*. Office of Emergency and Remedial Response. Publication No. 9345.0-05I.
- Environmental Protection Agency (EPA). 1991b. *Risk Assessment Guidance for Superfund, Volume I: Human Health Evaluation Manual, Part B*. Office of Solid Waste and Emergency Response. EPA/540/1-89/002. (OSWER Directive 9285.7-01A).
- Environmental Protection Agency (EPA). 1991c. *Role of Baseline Risk Assessment in Superfund Remedy Selection Decision*. Office of Solid Waste and Emergency Response. (OSWER Directive 9355.0-30).
- Environmental Protection Agency (EPA). 1991d. *Human Health Evaluation Manual Supplemental Guidance: Standard Default Exposure Factors*. Office of Solid Waste and Emergency Response. (OSWER Directive 9285.6-03).
- Environmental Protection Agency (EPA). 1991e. *National Functional Guidelines for Organic Data Review*. Office of Emergency and Remedial Response.
- Finkel, A.M. 1990. *Confronting Uncertainty in Risk Management: A Guide for Decision-Makers*. Center for Risk Management. Washington, DC.
- Gilbert, R.O. 1987. *Statistical Methods for Environmental Pollution Monitoring*. Van Nostrand. New York, NY.
- Keith, L.H. 1987. *Principles of Environmental Sampling*. American Chemical Society. Washington, DC.
- Keith, L.H. 1990a. *Environmental Sampling and Analysis*. In Print. American Chemical Society. Washington, DC.
- Keith, L.H. 1990b. Environmental Sampling: A Summary. *Environmental Science and Technology*. 24:610-615.
- Koch, George S. and Link, Richard F. 1971. *Statistical Analysis of Geological Data*. Dover Publications. 0-486-64040-X.
- Krige, D.G. 1978. *Lognormal de Wysian Geostatistics for Ore Evaluation*. South Africa Institute of Mining and Metallurgy Monograph Series.
- Manahan, S.E. 1975. *Environmental Chemistry*. Willard Grant Press. Boston, MA.
- Neptune, D.E., Brantly, E.P., Messner, M., and Michael, D.I. 1990. Quantitative Decision Making in Superfund. *Hazardous Materials Control*. pp. 18-27.
- National Research Council (NRC). 1983. *Risk Assessment in the Federal Government: Managing the Process*. National Academy Press. Washington, DC.

Seichel, H.S. 1956. *The Estimation of Means and Associated Confidence Limits for Small Samples from Lognormal Populations*. A Symposium on Mathematical Statistics and Computer Applications in Ore Valuation. South Africa Institute of Mining and Metallurgy. pp. 106-122.

Taylor, J.H. 1987. *Quality Assurance of Chemical Measurements*. Lewis Publishers, Inc. Ann Arbor, MI.

Thistle Publishing 1991. Risk*Assistant (software). Hampshire Research Institute. Alexandria, VA.

Index

A

- Accuracy *See* Data quality indicators (DQIs)
- Analytical
- base/neutral/acid (BNA) 39
 - iron 1, 52, 53
 - oil and hydrocarbons 45, 51, 52, 84, 106, 119
 - polycyclic aromatic hydrocarbons 45, 119
 - phthalates and non-pesticide chlorinated compounds 52
 - volatile organics (VOAs) 55, 57, 78, 80, 113
- Analytical methods 13, 21, 22, 25, 26, 29, 30, 33, 41, 45, 47, 57, 59, 63, 64, 78, 83, 89, 99, 100, 117, 118, 120
- atomic absorption (AA) 47, 55, 58
- gas chromatography-mass spectrometry (GC-MS) 41, 45, 46, 52, 53
- gel permeation chromatography (GPC) 39
- inductively coupled plasma (ICP) 52, 53, 55, 58, 101
- X-ray fluorescence (XRF) 57
- Analytical services 3, 21, 28, 29, 83
- field analyses 2, 21, 28, 29, 57, 58, 84, 88, 89
 - fixed laboratory analyses 21, 29, 54, 57, 58, 84, 89, 100
 - quick turnaround method 28
 - special analytical services (SAS) 29
- Automated data review 35

B

- Background sampling 29, 50, 75, 119
- anthropogenic 2, 75, 119, 120
 - sampling 29, 50
- Baseline human health risk assessment 1, 3, 4, 7
- Biota sampling 39, 83

C

- Chain-of-custody 29, 101
- Chemical intake 14, 15
- Chemicals of potential concern 1, 4, 25, 26, 29, 30, 35, 40, 41, 46, 47, 50, 52, 53, 55, 63-65, 72-74, 77, 78, 80, 83, 84, 87, 88, 117-120
- Comparability *See* Data quality indicators (DQIs)
- Completeness *See* Data quality indicators (DQIs)
- Concentration of concern 10, 33, 34, 47, 48, 83
- Conceptual model 11, 18, 22, 28
- Contract Laboratory Program (CLP) 2, 29, 41, 49, 58, 83, 84, 87, 100, 103, 105, 106, 113
- Contract required detection limit (CRDL) 49
- Contract required quantitation limit (CRQL) 49
- Corrective action 4, 22, 36, 88, 95, 97, 100, 101, 106

D

- Data
- assessment 11, 21, 22, 95, 100-103, 105, 107, 109, 111, 113, 114, 116
 - collection 1-4, 7, 11, 18, 20, 25, 29-31, 33, 34, 36, 37, 50, 51, 63, 81, 101, 106-112, 116
 - qualifiers 4, 100, 113
 - review 2, 3, 4, 20, 22, 23, 25, 29, 34, 35, 89, 99-103, 105, 107, 117-119
 - sources 1, 2, 3, 26, 28, 29, 99, 101, 111
- Data quality indicators (DQIs) 3, 29, 31, 76, 103, 121
- accuracy 25, 29, 31, 33, 34, 39, 49, 51, 55, 58, 99, 101, 102, 105-107, 112, 113, 116-118
 - comparability 33, 57, 76, 78, 80, 99, 105, 107, 108, 112, 114, 116, 121
 - completeness 76-78, 99, 100, 102, 105-107, 114, 116-118, 120, 121
 - precision 29, 34, 49, 99-102, 105-107, 109, 111-113, 116-118
 - representativeness 76, 99, 105, 107-109, 114, 116, 117, 121
- Data quality objectives (DQOs) 2, 11, 13, 31, 34, 63, 100, 110, 111
- Data useability criteria 3, 25, 26, 99, 117, 121
- Design decisions 81, 89
- Detection limits 2, 25, 28, 30, 33, 37, 45-48, 54, 55, 77, 83, 84, 87, 89, 117-120
- contract required detection limit (CRDL) 113
 - contract required quantitation limit (CRQL) 113
 - instrument detection limit (IDL) 47, 48
 - limit of quantitation (LOQ) 49, 50
 - method detection limit (MDL) 2, 47, 48, 49, 50, 102, 113
 - practical quantitation limit (PQL) 49
 - sample quantitation limit (SQL) 2, 22, 23, 48, 49, 50, 84

E

- Exposure 95, 97, 101, 105, 107, 108, 112
- area 4, 11, 13, 18, 20, 25, 26, 33, 54, 55, 63, 65, 72, 74, 77, 78, 80, 89, 120, 121
 - assessment 4, 7, 13, 14, 15, 17, 18, 101, 102, 108
 - pathway 11, 13-15, 17, 18, 33, 58, 63, 80, 89, 117, 120, 121

F

- False negatives 11, 13, 18, 25, 35, 40, 41, 47, 48, 50, 58, 64, 75, 76, 101, 105, 108, 113, 116-118

False positives 11, 13, 25, 30, 35, 41, 45, 47, 48, 50, 53, 64, 76, 101, 105, 113, 117-119

Field analyses *See* Analytical Services

Field records 29

Fixed laboratory analyses *See* Analytical Services

G

Geographical Information System (GIS) 18, 72

H

Hazard Ranking System (HRS) 13, 26

Health Effects Assessment Summary Tables (HEAST) 15

Historical data 11, 18, 26, 28, 41, 45, 52, 73, 74, 78, 119

Hot spots 13, 33, 51, 54, 57, 66, 73-76, 78, 89

I

Integrated Risk Information System (IRIS) 15

L

Laboratory performance 25, 33, 58, 59, 88, 107, 111

Land use alternatives 78

Linearity

limit of linearity (LOL) 50

range of linearity 47

M

Measurement error 33, 37, 38, 50, 76, 109, 111

Media variability 51, 74

N

National Priorities List (NPL) 50

Natural variation 38

P

Performance evaluation 33, 39, 58, 87, 88, 116

Performance measures 63, 76, 80, 88, 110

Performance objectives 4, 25, 29, 33, 50, 97, 105, 111

Precision *See* Data quality indicators (DQIs)

Preliminary remediation goals (PRGs) 2, 48

Q

Qualified data 2, 23, 105, 106, 113

Qualitative/quantitative analysis 57

Quality assurance (QA) 2, 18, 20, 22, 29, 39, 58, 76, 100, 101

Quality assurance project plan (QAPjP) 2, 20, 29, 33

Quality control (QC) 2, 29, 33, 34, 37, 50, 58, 59,

88, 100-103, 105, 107, 108, 111, 113, 116, 118, 119

R

Reasonable maximum exposure (RME) 13, 14, 17, 55, 66, 105, 107, 109, 116

Reference concentrations (RfCs) 15, 17

Reference doses (RfDs) 15, 17

Remedial investigation (RI) 1-4, 11, 18, 20, 21, 25, 26, 28, 29, 63, 65, 81, 95, 100, 105

Remedial project manager (RPM) 1, 4, 11, 18, 20-23, 25, 29, 30, 34-37, 39, 41, 45-47, 51, 53, 58, 59, 63-65, 72, 77, 78, 80, 81, 84, 85, 87-89, 95, 113

Representativeness *See* Data quality indicators (DQIs)

Resource issues 88

Risk Assessment Guidance for Superfund (RAGS) 1-3, 7, 13-15, 17, 18, 102, 114, 119

Risk assessor 1-4, 7, 14, 15, 18, 20-23, 25, 50, 52-55, 58, 63-65, 77, 78, 80, 81, 84, 87-89, 95, 97, 100-102, 106-108, 110, 111, 113, 114, 116

S

Sample

preparation 47, 49, 51, 54, 55, 77, 88, 108, 112

preservation 76, 108, 116

Sampling and analysis plan (SAP) 1, 20-22, 25, 63, 74, 88, 97, 100, 107, 110, 112, 113

Sampling design methods

classical model 65, 72, 78, 88

geostatistical model 65, 66, 73-75, 78, 88

judgmental/purposive model 65, 73, 74

systematic grid sampling 65, 66, 72, 75, 78, 88

Sampling Design Selection Worksheet 63, 65, 72, 80, 83, 89

Sampling variability 64, 65, 74, 77, 108, 109, 110, 116

Scheduling 21

Scoping 11, 25, 28, 29, 41, 88, 105

Site

concentrations 11, 13, 25, 63-66, 72-77, 80, 95, 101, 107-109, 116, 119, 120

inspections 3, 18, 26, 73

Soil 4, 37, 38, 41, 50, 51, 55, 119, 120

data collection 1, 4, 63, 77, 78, 80, 81, 117, 119, 121

location of hot spots 66, 73-75, 78

sampling depth 78, 80

characteristics 11, 80

Soil Depth Sampling Worksheet 37, 63

Standard operating procedures (SOPs) 29, 31, 100,
101

T

Target compound list 4

Tentatively identified compounds (TICs) 41, 45, 52

Toxicity assessment 4, 7, 15, 17, 22

Turnaround time 2, 29, 54, 58, 83, 84, 87, 89

U

Uncertainty 1-4, 7, 10, 11, 14, 15, 17, 18, 25, 33,
37, 38, 50, 51, 55, 63, 76, 80, 81, 89, 95, 97,
102, 105, 107, 111, 114, 117, 121

analytical 7, 10, 14, 15, 17, 18, 80

sampling 63, 76, 77, 80, 81, 89, 118

total 76, 77