



Sanitary Survey Guidance Manual for Ground Water Systems (Draft)

EPA 815-D-07-006

November 2007

Draft

1

2

DISCLAIMER

This manual provides guidance on how to conduct a sanitary survey of public water systems served solely by ground water sources. The U.S. Environmental Protection Agency believes that a comprehensive sanitary survey is an important part of helping water systems protect public health.

The statutory provisions and EPA regulations described in this document contain legally binding requirements. This guidance is not a substitute for applicable legal requirements, nor is it a regulation itself. Thus, it does not impose legally-binding requirements on any party, including EPA, States, or the regulated community. While EPA has made every effort to ensure the accuracy of the discussion in this guidance, the obligations of the regulated community are determined by statutes, regulations, or other legally binding requirements. In the event of a conflict between the discussion in this document and any statute or regulation, this document would not be controlling.

Interested parties are free to raise questions and objections to the guidance and the appropriateness of using it in a particular situation.

Although this manual describes suggestions for complying with GWR requirements, the guidance presented here may not be appropriate for all situations, and alternative approaches may provide satisfactory performance.

Mention of trade names or commercial products does not constitute an EPA endorsement or recommendation for use.

Comments regarding this document should be addressed to:

Michael Finn
U.S. EPA Office of Ground Water and Drinking Water
Standards and Risk Management Division
1200 Pennsylvania Avenue, N.W. 4607M
Washington, DC 20460
Finn.Michael@epa.gov
202-564-5261
202-564-3767 (facsimile)

1
2
3
4
5

ACKNOWLEDGMENTS

CONTENTS

Exhibits	vi
Acronyms	vii
1. Introduction and Scope of This Manual	1-1
1.1 Ground Water Rule (GWR) Requirements	1-2
1.2 Overview of Sanitary Surveys	1-6
1.3 Minimum Elements of the Sanitary Survey	1-8
2. Other Drinking Water Regulations and PWS Requirements.....	2-1
2.1 Definition of PWS.....	2-1
2.2 Safe Drinking Water Act (SDWA)	2-2
2.2.1 National Primary Drinking Water Regulations (40 CFR Part 141).....	2-2
2.2.2 National Primary Drinking Water Regulations Implementation (40 CFR Part 142).....	2-3
2.2.3 Code of Federal Regulations.....	2-4
2.2.4 Source Water Assessment and Protection Program (SWAPP) and Wellhead Protection Program (WHPP)	2-4
2.2.5 Total Coliform Rule (TCR)	2-5
2.2.6 Lead and Copper Rule	2-5
2.2.7 Stage 1 Disinfectants and Disinfection Byproducts (D/DBPs)	2-6
2.2.8 Stage 2 Disinfectants and Disinfection Byproducts (D/DBPs)	2-6
2.2.9 Inorganic and Organic Chemicals.....	2-7
2.2.10 Radiological Contaminants.....	2-7
3. Preparing for the Survey	3-1
3.1 Contact and Location	3-1
3.2 Planning the Sanitary Survey	3-2
3.2.1 Resources Needed	3-2
3.2.2 Personal Safety.....	3-3
3.2.3 Logistics.....	3-3
3.3 Inventory of System Facilities	3-4
3.4 File Review Elements	3-6
3.4.1 Previous Sanitary Surveys	3-7
3.4.2 Source Water Assessments	3-7
3.4.3 Compliance and Enforcement History.....	3-8
3.4.4 Monitoring Plans.....	3-9
3.4.5 Consumer Confidence Reports (CCR)	3-10
3.4.6 Other Required Submittals.....	3-10
3.4.7 Total Coliform Rule (TCR) History	3-11
3.4.8 Variance and Exemptions	3-12
3.4.9 Correspondence.....	3-12
4. Field Survey	4-1
4.1 Logistics.....	4-2

1	4.2	Sources.....	4-3
2	4.2.1	Well Construction.....	4-3
3	4.2.1.1	Surface Features.....	4-5
4	4.2.1.2	Subsurface Features.....	4-8
5	4.2.1.3	Driller's Logs.....	4-10
6	4.2.1.4	Typical Defects.....	4-10
7	4.2.2	Potential Sources of Contamination.....	4-11
8	4.2.2.1	Wellhead Protection Program (WHPP).....	4-12
9	4.2.2.2	Source Vulnerability Assessment.....	4-12
10	4.2.2.3	Abandoned Wells.....	4-13
11	4.2.3	Source Quantity and Capacity.....	4-13
12	4.2.4	Confirm Well Locations.....	4-16
13	4.2.5	Source Water Transmission.....	4-16
14	4.2.6	Site Security.....	4-17
15	4.2.7	General Housekeeping.....	4-18
16	4.2.8	Cross Connections.....	4-19
17	4.3	Treatment.....	4-19
18	4.3.1	Treatment Plant Schematic/Site Plan.....	4-20
19	4.3.2	Capacity of Treatment Facilities.....	4-21
20	4.3.3	Chemicals and Chemical Feed Systems.....	4-22
21	4.3.3.1	Liquid Chemical Feed Systems.....	4-22
22	4.3.3.2	Dry Chemical Feeders (Volumetric and Gravimetric).....	4-23
23	4.3.4	Disinfection.....	4-26
24	4.3.4.1	Dosage and Residual.....	4-26
25	4.3.4.2	Chlorine and Water.....	4-27
26	4.3.4.3	Gas Chlorination.....	4-31
27	4.3.4.4	Liquid Hypochlorination.....	4-34
28	4.3.4.5	Typical Liquid Chlorine System.....	4-34
29	4.3.4.6	Typical Defects.....	4-36
30	4.4	Distribution System.....	4-37
31	4.4.1	Distribution System Mapping.....	4-38
32	4.4.2	Distribution System Pipe Material and Condition.....	4-39
33	4.4.3	Location and Maintenance of Valves.....	4-41
34	4.4.4	Design and Construction Standards.....	4-42
35	4.4.5	Maintaining Adequate Pressure.....	4-44
36	4.4.6	Response to Water Main Breaks.....	4-45
37	4.4.7	Flushing Programs.....	4-46
38	4.4.8	Water Quality Monitoring.....	4-46
39	4.4.8.1	Maintaining a Residual.....	4-47
40	4.4.8.2	Bacteriological Quality (TCR).....	4-48
41	4.4.8.3	Other Water Quality Parameters.....	4-49
42	4.4.8.4	Customer Complaints.....	4-49
43	4.4.9	Cross Connection Control.....	4-50
44	4.5	Finished Water Storage.....	4-52
45	4.5.1	Storage Facility Inventory.....	4-53
46	4.5.2	Capability and Capacity.....	4-56
47	4.5.2.1	Capability.....	4-56
48	4.5.2.2	Storage Capacity.....	4-58
49	4.5.3	Design and Construction.....	4-58

1	4.5.4	Site Security and Sanitary Risks	4-63
2	4.6	Pumps.....	4-64
3	4.6.1	Typical Pumps	4-64
4	4.6.2	Number and Capacity	4-68
5	4.6.3	Routine Maintenance/Lubrication/Exercise.....	4-69
6	4.6.4	Housing	4-70
7	4.6.5	Site Security	4-70
8	4.6.6	Cross Connections	4-70
9	4.7	Emergency Power	4-71
10	4.8	Remote Monitoring/Control/Alarms.....	4-72
11	4.9	Monitoring/Reporting/Data Verification	4-73
12	4.10	Water System Management/Operations	4-75
13	4.10.1	Organization and Management (TMF Capacity).....	4-75
14	4.10.2	Staff Levels	4-77
15	4.10.3	Training.....	4-78
16	4.10.4	Revenue.....	4-78
17	4.10.5	Additional Management Issues.....	4-80
18	4.11	Operator Requirements	4-80
19	4.11.1	General Operator Requirements	4-80
20	4.11.2	Certification Required Based on Size/Treatment	4-80
21	4.12	References.....	4-81
22			
23	5.	Compiling and Reporting the Sanitary Survey Results	5-1
24	5.1	Sanitary Survey Report	5-2
25	5.2	Sanitary Survey Documentation	5-4
26	5.3	Categorizing the Findings	5-5
27	5.4	Corrective Action.....	5-9
28	5.5	Outstanding Performance.....	5-10
29			
30	6.	Report Review and Response.....	6-1
31	6.1	State Actions	6-1
32	6.2	Water System Actions.....	6-3

Appendices

- Appendix A Evaluating Ground Water Treatment for Ground Water Rule Compliance
- Appendix B Using Sanitary Surveys to Update State Source Water Protection Programs

EXHIBITS

Exhibit 1.1	Summary of GWR Requirements.....	1-3
Exhibit 1.2	Sanitary Survey Frequency for PWSs under the GWR	1-4
Exhibit 1.3	Sanitary Survey Requirements.....	1-5
Exhibit 3.1	Communication Activities	3-2
Exhibit 3.2	Example Schematic of a Ground Water PWS with Iron Removal Treatment	3-5
Exhibit 3.3	Records and Retention Period.....	3-8
Exhibit 4.1	Major Components of a Typical Groundwater Well.....	4-4
Exhibit 4.2	Illustrations of a Split Cap and Seal.....	4-6
Exhibit 4.3	An Overlapping Exterior Sanitary Well Seal	4-6
Exhibit 4.4	Top of Casing Illustration for a Well with a Lineshaft Turbine Pump (left) and a Well with a Submersible Turbine Pump and a Split Cap	4-7
Exhibit 4.5	Example Schematic Diagram of a Ground Water Treatment Plant.....	4-21
Exhibit 4.6	Schematic of a Typical Liquid Chemical Feed System	4-23
Exhibit 4.7	Breakpoint Chlorination Curve.....	4-28
Exhibit 4.8	Example of an Air Gap on a Chemical Feed System.....	4-36
Exhibit 4.9	Elevated and Ground Storage Tanks	4-55
Exhibit 4.10	Typical Hydropneumatic Tank Installation.....	4-56
Exhibit 4.11	Components of a Storage Tank.....	4-60
Exhibit 4.12	Types of Pressure Tanks	4-61
Exhibit 4.13	Applications for Centrifugal Pumps	4-66
Exhibit 4.14	Common Centrifugal Pump Types and Components	4-67
Exhibit 4.15	Pump Sizing Criteria	4-68
Exhibit 5.1	Example of Sanitary Survey Deficiencies.....	5-6
Exhibit 6.1	Summary of 40 CFR 142.16(o)(2) – Special Primacy Requirements for Sanitary Survey Requirements of the GWR.....	6-2

ACRONYMS

1		
2		
3		
4	ANSI/NSF	American National Standards Institute/National Sanitary Foundation
5	ASME	American Society of Mechanical Engineers
6	AWWA	American Water Works Association
7	BFP	Backflow Preventer
8	CCR	Consumer Confidence Reports
9	CFR	Code of Federal Regulations
10	CT	Concentration of Residual Disinfectant multiplied by Time of Water Contact
11		(Detention Time)
12	DBP	Disinfection Byproduct
13	D/DBP	Disinfectants/Disinfection Byproducts
14	DHS	Department of Health Services
15	DOT	Department of Transportation
16	EPA	The United States Environmental Protection Agency
17	ETV	Environmental Technology Verification
18	GAC	Granular Activated Carbon
19	GIS	Geographic Information System
20	GLUMRB	Great Lakes Upper Mississippi River Board
21	GPS	Global Positioning System
22	GREP	Generally Recommended Engineering Practice
23	GWR	Ground Water Rule
24	GWUDI	Ground Water Under the Direct Influence
25	HAA5	Haloacetic Acids
26	HDPE	High-density Polyethylene
27	HPC	Heterotrophic Plate Count
28	HSA	Hydrogeologic Sensitivity Assessment
29	IDSE	Initial Distribution System Evaluation
30	IESWTR	Interim Enhanced Surface Water Treatment Rule
31	LRAA	Locational Running Annual Average
32	MCL	Maximum Contaminant Level
33	M-DBP	Microbial-Disinfectants/Disinfection Byproducts
34	MRDL	Maximum Residual Disinfectant Level
35	MWCO	Molecular Weight Cut Off
36	NODA	Notice of Data Availability
37	NPDWR	National Primary Drinking Water Regulations
38	NSF	National Sanitation Foundation
39	NTNCWS	Non-transient Non-community Water System
40	O&M	Operation and Maintenance
41	OSHA	Occupational Safety and Health Administration
42	OWQP	Optimal Water Quality Parameter
43	PB	Polybutylene
44	PE	Polyethylene
45	PVC	Polyvinyl Chloride
46	PWS	Public Water System

1	RPZ	Reduced Pressure Zone
2	SDWA	Safe Drinking Water Act
3	SOC	synthetic Organic Contaminant
4	SOP	Standard Operating Procedure
5	SWAPP	Source Water Assessment and Protection Program
6	SWTR	Surface Water Treatment Rule
7	TCR	Total Coliform Rule
8	TDT	Theoretical Detention Time
9	THM	Trihalomethane
10	TNRCC	Texas Natural Resource Conservation Commission
11	TNCWS	Transient Non-community Water System
12	TTHM	Total Trihalomethane
13	UFTREEO	University of Florida Training, Research, and Education for Environmental
14		Occupations
15	UL	Underwriters Laboratories
16	USGS	United States Geological Survey
17	UV	Ultraviolet Light
18	VOC	Volatile Organic Contaminant
19	WFI	Water Facilities Inventory
20	WHPA	Wellhead Protection Area
21	WHPP	Wellhead Protection Program
22		

1. Introduction and Scope of This Manual

This manual provides guidance on how to conduct a sanitary survey of a Public Water System (PWS) that is served by ground water. A sound sanitary survey program is an essential element of an effective State drinking water program. Sanitary surveys are a proactive public health measure that can identify deficiencies in PWSs that could result in contamination of the public water supply before any contamination occurs.

Sanitary surveys enable States to provide a comprehensive and accurate review of the components of water systems, to assess the operating conditions and adequacy of the water system, and to determine if past recommendations have been implemented effectively. The purpose of the sanitary survey is to evaluate and document the capabilities of the water system's sources, treatment, storage, distribution network, operation and maintenance, and overall management to ensure the provision of safe water. In addition, sanitary surveys provide an opportunity for States to visit the water system and educate operators about proper monitoring and sampling procedures and to provide technical assistance. They are used to evaluate: (1) the capability of a drinking water system to consistently and reliably deliver an adequate quality and quantity of safe drinking water to the consumer; and (2) the system's compliance with Federal drinking water regulations. This guidance manual identifies assessment criteria to evaluate sanitary risks in a typical water system. The manual also describes how to identify significant deficiencies that are causing, or have the potential to cause, the introduction of contamination into the water delivered to consumers and, therefore, require corrective actions.

State agencies should use this manual as a tool to ensure that sanitary surveys are comprehensive, well documented, and meet the primacy requirements. PWS owners and operators will find hands-on information on operation and management of their drinking water systems and drinking water well sources. The manual also helps inspectors understand how each set of Safe Drinking Water Act (SDWA) regulations applies to sanitary surveys.

The overall structure of the guidance manual centers on the four principal stages of a sanitary survey: planning a sanitary survey; conducting the onsite survey; compiling a sanitary survey report; and performing follow-up activities including responding to a sanitary survey. The manual is organized as follows:

- **Chapter 1 – Introduction and Scope of This Manual.** This chapter provides background information, explains the Ground Water Rule (GWR) requirements for sanitary surveys, and discusses the minimum elements of a sanitary survey.
- **Chapter 2 – Other Drinking Water Regulations and PWS Requirements.** This chapter provides information on the regulatory context for sanitary surveys.
- **Chapter 3 – Preparing for the Survey.** This chapter provides guidance as to tasks that should be carried out in the office before an inspector conducts the field component of the sanitary survey.
- **Chapter 4 – Field Survey.** This chapter discusses each of the eight elements of a sanitary survey that meets the requirements of the GWR. The chapter explains each

element's importance for an effective sanitary survey and presents general guidelines (assessment criteria) for evaluating important components of each element. Discussions about each element identify the components of high priority that may be considered significant deficiencies.

- **Chapter 5 – Compiling and Reporting the Sanitary Survey Results.** This chapter provides guidelines for compiling and reporting the sanitary survey results as well as suggestions for keeping adequate documentation of the sanitary survey.
- **Chapter 6 – Report Review and Response.** This chapter describes the follow-up actions that should be taken by the water system operator and the State in response to the findings of a sanitary survey, including those actions that must be taken to correct any identified deficiencies.

1.1 Ground Water Rule (GWR) Requirements

The GWR applies to public ground water systems (systems that have at least 15 service connections, or regularly serve at least 25 individuals daily at least 60 days out of the year). The GWR applies to all PWSs served by ground water except PWSs that combine all their ground water sources prior to treatment then meet the requirements of Subpart H (Surface Water Treatment Rule (SWTR)).


Requirements in the GWR include:

- System sanitary surveys conducted by the State with minimum scope and frequency and identification of significant deficiencies;
- Triggered source water microbial monitoring by systems that do not provide 4-log treatment of viruses for their ground water sources and have a total coliform (TC)-positive result in samples collected under the Total Coliform Rule (TCR) requirements for routine coliform monitoring;
- Corrective action by any system with significant deficiencies or fecal indicator positive source water samples; and
- Compliance monitoring for systems that provide 4-log treatment of viruses for their ground water sources.

The GWR also requires ground water systems, if directed by the State, to conduct assessment source water monitoring for ground water sources. The United States Environmental Protection Agency (EPA) recommends that this assessment monitoring consist of 12 source water samples analyzed for *E.Coli*, coliphage or enterococci, as specified by the State. EPA also recommends hydrogeologic sensitivity assessments (HSAs) for ground water systems drawing from aquifers susceptible to fecal contamination as a basis for assessment source water monitoring. If the State chooses to perform HSAs, the GWR requires systems to provide the State with available information necessary for the State to conduct the HSAs.

A summary of the GWR's requirements is illustrated in Exhibit 1.1.

Exhibit 1.1 Summary of GWR Requirements



Sanitary surveys are required every 3 years for community ground water systems and every 5 years for non-community ground water systems. This is consistent with the 1998 Interim Enhanced Surface Water Treatment Rule (IESWTR) for surface water systems. The survey frequency is shown in Exhibit 1.2.

Exhibit 1.2 Sanitary Survey Frequency for PWSs under the GWR

System Type	Minimum Frequency of Surveys
Community water system	Every 3 years
Community water system with outstanding performance based on prior sanitary surveys OR treats to 4-log inactivation of viruses	Every 5 years
Non-community water system (both non-transient and transient non-community)	Every 5 years

The key components of the GWR's sanitary survey requirements include:


- The State must conduct sanitary surveys that address the minimum 8 elements of the GWR State primacy requirements for all ground water systems.
- The State must have authority to enforce corrective action requirements.
- The State must provide a notice of all significant deficiencies (e.g., those that require corrective action) to the system within 30 days of identification of the deficiencies.
- Systems must consult with the State and take corrective action for any significant deficiencies no later than 120 days after receiving written notification of such deficiencies, or submit a schedule and plan to the State for correcting these deficiencies within the same 120 day period.

Once a ground water system has been identified as having significant deficiencies, it must do one or more of the following:

- Eliminate the source of contamination;
- Correct the significant deficiency;
- Provide an alternate source of water; and
- Provide a treatment that reliably achieves at least 99.99 percent (4-log) inactivation or removal of viruses before or at the first customer.

Exhibit 1.3 provides a flowchart explaining the sanitary survey requirements of the GWR.

Exhibit 1.3 Sanitary Survey Requirements



1 An inspector should review the previous sanitary survey report and other relevant records
2 to determine if a system has an outstanding performance designation. Since this designation
3 affects the required frequency for a survey, it may impact whether that system will be inspected
4 at the current time. When a system is being inspected, a review of the water system's file should
5 be conducted to obtain pertinent information about the physical facility and water quality data
6 before the actual site visit.

8 Community water systems that are classified as having outstanding performance are
9 eligible for having sanitary surveys conducted less frequently than other community systems.
10 Under the GWR, community water systems must have a sanitary survey performed by the State
11 at least once every three years with some exceptions. If the State determines that a community
12 system either treats to 4-log inactivation of viruses or has shown outstanding performance, the
13 survey frequency may be reduced to at least once every five years.

15 Each State, as part of its application for primacy, is required to develop a means for
16 determining whether a system has outstanding performance. A State should have defined
17 outstanding performance and established certain specifications for determining outstanding
18 performance. To determine if a system has outstanding performance, the inspector should
19 review the report from the system's previous sanitary survey to see if the system was considered
20 to have outstanding performance then. If the State includes information on outstanding
21 performance designations in a tracking database, the inspector should check the system's listing
22 in the database. The inspector should also examine the State's records on the facility collected
23 since the last sanitary survey. The records of interest will depend upon the State's criteria for
24 outstanding performance but may include: monitoring data, violation records, and notifications
25 of changes to the physical facility or the operator personnel. This information will help the
26 inspector to determine if there are any changes in performance since the previous survey that
27 indicates the system no longer satisfies the State's definition of outstanding performance.

30 1.2 Overview of Sanitary Surveys

32 In the GWR, a sanitary survey is defined (§141.401(b)) as follows:

34 *"A sanitary survey, as conducted by the State, includes but is not limited to, an*
35 *onsite review of the water source(s) (identifying sources of contamination by*
36 *using results of source water assessments or other relevant information where*
37 *available), facilities, equipment, operation, maintenance, and monitoring*
38 *compliance of a public water system to evaluate the adequacy of the system, its*
39 *sources and operations and the distribution of safe drinking water."*

41 Conducting sanitary surveys on a routine basis is an important element in preventing
42 contamination of drinking water supplies and in maintaining PWS compliance with National
43 Primary Drinking Water Regulations. EPA recognizes the importance of sound sanitary surveys
44 as a proactive public health measure helping water systems protect public health. Sanitary
45 surveys are an opportunity to work and communicate with water systems in a preventive mode.

47 As stated in the December 1995 EPA/State Joint Guidance on Sanitary Surveys, sanitary
48 surveys provide an opportunity for State drinking water officials or approved third party
49 inspectors to establish a field presence at the water system. The surveys also serve to educate the

operators about proper monitoring and sampling procedures, provide technical assistance, and inform them of any upcoming changes in regulations. Sanitary surveys also aid in the process of evaluating a PWS's progress in complying with Federal and State regulations that require the improvement of the capabilities of the system to provide safe drinking water. Sanitary surveys provide the water system with technical and management information regarding the operation of the system from the water source, through the treatment facilities and the distribution system. Under the GWR, States direct or approve corrective actions to address public health risk from significant deficiencies found during sanitary surveys (as well as during other State field visits or investigations).

The *1995 EPA/State Joint Guidance on Sanitary Surveys* lists the following specific benefits of conducting sanitary surveys:

- Operator education;
- Source protection;
- Risk evaluation;
- Technical assistance and training;
- Independent, third party system review;
- Information for monitoring waiver programs;
- Identification of factors limiting a system's ability to continually provide safe drinking water;
- Reduction of monitoring requirements;
- Reduction of formal enforcement actions in favor of more informal action;
- Reduction of oversight by State monitoring and enforcement personnel;
- Increased communication between State drinking water personnel and PWS operators;
- Provision of contact personnel to notify in case of emergencies or for technical assistance;
- Improvement of system compliance with State drinking water regulations;
- Identification of candidate systems for enforcement action;
- Identification of candidates for Comprehensive Performance Evaluations;
- Verification of data validity;

- Validation of test equipment and procedures;
- Reduced risk of waterborne disease outbreaks;
- Encouragement of disaster response planning; and
- Improved system security.

EPA recommends that States work with EPA Regions to use sanitary survey guidance to improve their sanitary survey programs while still addressing the problems and issues specific to the State.

1.3 Minimum Elements of the Sanitary Survey

The GWR requires that sanitary surveys address all of the eight elements of the EPA/State joint guidance. Each of these elements is described in more detail in Chapter 4.

EPA and the States (through the Association of State Drinking Water Administrators) issued a joint guidance on sanitary surveys entitled EPA/State Joint Guidance on Sanitary Surveys (1995). The guidance outlines the following eight elements as integral components of a sanitary survey:

- Source (Protection, Physical Components and Condition),
- Treatment,
- Distribution System,
- Finished Water Storage,
- Pumps/Pump Facilities and Controls,
- Monitoring/Reporting/Data Verification,
- Water System Management/Operations, and
- Operator Compliance with State Requirements.

2. Other Drinking Water Regulations and PWS Requirements

In addition to specifying maximum contaminant levels (MCLs) or treatment technique requirements, the Federal drinking water regulations address sampling location, frequency, recordkeeping and other requirements that should be evaluated during a sanitary survey. This section provides the basic information for inspectors to determine if a water system is a PWS subject to EPA regulations. If so, inspectors should be able to recognize requirements from various provisions of the drinking water regulations.

2.1 Definition of PWS

PWSs are defined as systems for providing water for human consumption through pipes or other constructed conveyances, if such systems have at least 15 service connections or regularly serve at least 25 people at least 60 days a year. A system includes any collection, treatment, storage, and distribution facilities under control of the system operator and used primarily in connection with such a system, and any collection or treatment facilities not under such control that are used primarily in connection with such a system.

Three important field determinations made during a sanitary survey are:

- The number of people served by the system;
- The number of service connections; and
- Whether service is provided for at least 60 days a year.

This information determines whether a system meets the definition of a PWS in SDWA and whether it is subject to the National Primary Drinking Water Regulations (NPDWR).

Although the NPDWR apply to all PWSs, the regulations make a distinction between community and non-community systems. A further distinction is made between transient and non-transient non-community systems.

Community water systems serve a residential population of at least 25 people or 15 service connections on a year-round basis. Users of community systems are likely to be exposed to any contaminants in the water supply over an extended time period and are thus subject to both acute and chronic health effects.

Non-community systems are either transient or non-transient systems. Non-transient non-community water systems (NTNCWS) serve at least 25 of the same persons at least 6 months per year on a regular basis. These systems can expose users to drinking water contaminants over an extended time period (subjecting users to risks of both acute and chronic health effects), similar to community systems. Schools, churches and factories would fall under this definition. Transient non-community water systems (TNCWS) serve short-term users. As a result, the users are exposed to any drinking water contaminants only briefly. Users are subject to experiencing acute health effects. Examples are restaurants, gas stations, hotels, and campgrounds.

1 These distinctions and others, such as the water source and population served, are
2 important because States may regulate these systems differently. An inspector needs to know the
3 characteristics of a system to know whether a system is properly classified and, therefore, which
4 regulations are applicable. The population served also determines sampling frequency in a
5 number of regulations, including the TCR, Lead and Copper Rule, Stage 1 and Stage 2
6 Disinfection and Disinfection Byproducts (D/DBP) Rules, and Phase II and V inorganic and
7 organic chemical monitoring.

8
9 Most water system operators will know how many individual service connections they
10 have within their systems but not necessarily the population served by the system. Some States
11 will use a factor multiplied by the number of service connections to estimate population. During
12 the survey, the inspector should determine if the State records on population and number of
13 service connections are up-to-date. Further evaluation will be needed to determine if changes in
14 population will affect the system's status relative to any SDWA requirements.

15 16 17 **2.2 Safe Drinking Water Act (SDWA)**

18
19 Congress enacted the SDWA in 1974. The Act was intended to ensure the delivery of
20 safe drinking water by PWSs and to protect ground water sources from contamination.

21
22 In 1986, Amendments to SDWA were signed into law. These Amendments greatly
23 expanded the number and type of contaminants to be regulated in drinking water, as well as
24 strengthened EPA's enforcement authority. The passage of these Amendments was the result of
25 heightened concern about the potential contamination of public water supplies by toxic
26 chemicals and an increase in the number of waterborne disease outbreaks caused by
27 microbiological contaminants.

28
29 In 1996, Congress again amended SDWA. The new law for the first time provides for
30 State revolving loan funds to improve water systems. It also requires EPA to base regulations on
31 risk assessment and cost-benefit considerations. The new law requires EPA to identify the best
32 treatment technologies for various sizes of systems and establish guidelines for operator
33 certification. Monitoring relief is provided for small systems. Source water protection and
34 consumer confidence reports are also a part of the new law.

35
36 Brief summaries of important drinking water regulations that form the basis for sanitary
37 surveys of ground water systems are provided in this section.

38 39 40 **2.2.1 National Primary Drinking Water Regulations (40 CFR Part 141)**

41
42 SDWA requires EPA to establish drinking water regulations for contaminants in drinking
43 water that may have an adverse effect on the public health. These regulations are known as the
44 National Primary Drinking Water Regulations (NPDWR) and include MCLs or treatment
45 techniques for over 100 contaminants. Monitoring and testing procedures also are specified. As
46 mentioned above, the NPDWR apply to all PWSs.

47
48 Congress intended SDWA requirements to be implemented primarily by the States.
49 Therefore, SDWA requires EPA to define the requirements for allowing States to implement and

1 enforce State regulations in lieu of the Federal regulations. State regulations must be at least as
2 stringent as the Federal regulations; however, they may also be more stringent. When a State's
3 program has been approved by EPA, the State is granted primary enforcement authority
4 ("primacy") for its drinking water program. Primacy requirements are codified in 40 CFR Part
5 142, NPDWR Implementation. EPA may grant a State primary enforcement authority when the
6 Administrator of EPA determines that a State has met the following requirements:

- 7
- 8 • Defining a PWS consistent with the definition in SDWA;
- 9
- 10 • Having adequate enforcement authority and procedures;
- 11
- 12 • Maintaining an inventory of PWSs;
- 13
- 14 • Having a systematic program for conducting sanitary surveys of PWSs with priority
- 15 given to systems not in compliance with the NPDWR;
- 16
- 17 • Having a program to certify laboratories that will analyze water samples;
- 18
- 19 • Having a certified laboratory that will serve as the State's principal laboratory;
- 20
- 21 • Having a program to review the design and construction of new or modified systems;
- 22
- 23 • Having adequate recordkeeping and reporting requirements;
- 24
- 25 • Having an adequate plan to provide for safe drinking water in emergencies; and
- 26
- 27 • Having variance and exemption requirements as stringent as EPA's if the State
- 28 chooses to allow variances or exemptions.
- 29

30 In primacy States (all but Wyoming, the District of Columbia, and Tribal lands), PWSs
31 are subject to State, as well as Federal drinking water regulations. Therefore, whenever a
32 Federal regulation is cited in this document, the State primacy agency inspector needs to be
33 aware of the equivalent State regulation as well as any additional State requirements.

34

35 **2.2.2 National Primary Drinking Water Regulations Implementation (40 CFR Part 142)**

36 States are required by 40 CFR Part 142(c)(7) to report the month and year the most recent
37 sanitary survey was completed. Similar reports are required for any corrective actions completed
38 under the GWR, and for any ground water PWSs providing 4-log treatment of viruses.

39

40 Section 142.16, Special Primacy Requirements, ensures that States have the legal
41 authority to enforce and implement the GWR. States describe how they will implement a
42 sanitary survey program and the other required elements in 40 CFR Part 141. States must
43 conduct sanitary surveys for all ground water PWSs with a minimum frequency and scope. The
44 first sanitary survey for community water systems must be completed 6 years after promulgation
45 of the final rule, or 8 years after promulgation of the final rule for non-community systems.
46 Subsequent surveys must be conducted every 3 or 5 years, for community systems and non-

community water systems, respectively. The GWR allows a 5 year frequency for sanitary surveys for community PWSs that provide 4-log treatment of viruses or have an outstanding performance record as determined by the State.

2.2.3 Code of Federal Regulations

All final EPA regulations are published (or “promulgated”) in the Federal Register. Federal regulations are compiled annually and codified in the Code of Federal Regulations (CFR). EPA’s regulations are found in Title 40 of the CFR (40 CFR). NPDWR are incorporated or codified in 40 CFR Part 141, which is divided into subparts and sections for specific regulatory provisions. For example, coliform monitoring requirements are found in section 21 of Part 141 (40 CFR 141.21). The CFR is available from the Government Printing Office in Washington, D.C., and EPA’s regulations can be accessed and downloaded from its Web site (http://www.epa.gov/epacfr40/chapt_1.info/chi_toc.htm). The EPA Drinking Water Hotline (800- 426- 4791) provides another easily accessible source of information on SDWA regulations.

2.2.4 Source Water Assessment and Protection Program (SWAPP) and Wellhead Protection Program (WHPP)

Section 1453 of the SDWA is a requirement for States to develop and implement Source Water Assessment and Protection Programs (SWAPPs). The SWAPP must delineate the source water areas for all PWSs in the State, identify the potential sources of contaminants within the areas, and determine the susceptibility of the water systems to the contaminants.

The Source Water Assessment of a ground water system should be reviewed in the file review prior to the field survey. The inspector should note the potential sources of contaminations and review the susceptibility determinations for the ground water source for later use. During the field survey, the inspector should verify that the inventory of potential sources of contamination has not changed.

In the final EPA National Guidance on State Source Water Assessment and Protection Programs, EPA explains that State programs must indicate in their SWAPP submittals that the delineation of source water protection areas for ground water based systems will be in accordance with accepted methods for Wellhead Protection Programs (WHPPs) under Section 1428 of the SDWA. These are described in EPA’s publication entitled *Guidelines for Delineation of Wellhead Protection Areas*, June 1987.

States are further required to develop WHPPs under Section 1428 of the 1986 Amendments to the SDWA. The WHPPs are to:

- Identify the members of a team to develop and implement the WHPP;
- Delineate a wellhead protection area (WHPA) surrounding the well based on “all reasonably available hydrogeologic information”;
- Identify all potential sources of contaminants;

- Describe a program to protect the water supply within the WHPA;
- Include contingency plans for providing drinking water in the event of contamination of the water supply;
- Consider potential pollutant sources for all new wells; and
- State WHPPs provide guidelines and a framework for the development of local, system-based WHPPs. Many systems have used these guidelines to develop their own WHPP to address local water protection concerns.

2.2.5 Total Coliform Rule (TCR)

The TCR applies to all PWSs. The sanitary survey requirements of the TCR have been replaced by newer requirements of the IESWTR (for systems served by surface water or ground water under the direct influence of surface water) and the GWR (for systems served by ground water).

The TCR requires that a water system have a written sample siting plan approved by the State. The inspector should verify that there is an approved plan that is being utilized. The inspector should also evaluate the plan to determine if it is currently meeting the requirements of the TCR. The rule requires collecting samples “that are representative of water throughout the distribution system.” The rule also contains a table that shows the minimum number of samples required based on population served. In reviewing the sample siting plan, the inspector should note that more samples than the minimum may be required in order to be “representative.” Some of the issues to be concerned with are short chlorine contact time to first customer, dead ends, long residence time in the system, multiple sources, storage tanks, areas of low pressure, biofilm, and cross-connections.

2.2.6 Lead and Copper Rule

The Lead and Copper Rule requires PWSs to collect tap water samples to determine lead and copper levels (40 CFR 141.80-.91). The Lead and Copper Rule Minor Revisions of April 2000 and Short-Term Revisions of 2007 modified some of the original Lead and Copper Rule of 1991. Large water systems (serving >50,000) are required to optimize corrosion control. Small and medium water systems (serving ≤ 50,000) that exceed action levels are required to optimize corrosion control. Inspector reviewing PWSs required to optimize corrosion control should refer to the Lead and Copper Rule requirements for determining compliance with optimized corrosion control. EPA has also issued guidance entitled *How to Determine Compliance with Optimal Water Quality Parameters as Revised by the Lead and Copper Rule Minor Revisions* (February 2001). It describes how inspectors determine compliance with the optimal water quality parameter (OWQP) ranges or minimums. Inspectors should also refer to their State’s policy on OWQP monitoring.

An inspector should verify that the system has completed a site sampling plan in compliance with sampling location requirements and is monitoring in accordance with that plan with the required frequency, number and location of samples. Systems using ground water may

1 reduce source water sampling for the Lead and Copper Rule to once in every 9 year compliance
2 cycle under certain conditions (40 CFR Section 141.88(e)), and the inspector should verify these
3 conditions are still being met.
4
5

6 **2.2.7 Stage 1 Disinfectants and Disinfection Byproducts (D/DBPs)**

7

8 40 CFR Part 141, Subpart L, Disinfectant Residuals, Disinfection Byproducts (DBPs),
9 and DBP Precursors, provides requirements for all community and non-transient non-community
10 PWSs that add a chemical disinfectant to their water. Portions of Subpart L also apply to
11 TNCWS that use chlorine dioxide. Components of Subpart L that inspectors must be aware of
12 include:
13

- 14 • MCLs for disinfection by-products including total trihalomethanes (TTHMs),
15 haloacetic acids (HAA5), bromated, and chlorite;
- 16
- 17 • Maximum residual disinfectant levels for chlorine, chloramines, and chlorine dioxide;
18
- 19 • Monitoring plan requirements; and
- 20
- 21 • Enhanced coagulation and enhanced softening requirements to address DBP
22 precursors for Subpart H systems with conventional or softening plants.
23

24 It should be noted that each system affected by this rule must develop and implement a
25 monitoring plan. The system must then maintain the monitoring plan and make it available for
26 inspection by the State and general public (systems serving more than 3,000 people must submit
27 their plans to the State). The inspector should review the monitoring plan while performing the
28 sanitary survey.
29
30

31 **2.2.8 Stage 2 Disinfectants and Disinfection Byproducts (D/DBPs)**

32

33 As with the Stage 1 D/DBP Rule, the Stage 2 D/DBP Rule provides requirements for all
34 community and non-transient non-community PWSs that add a chemical disinfectant to their
35 water. Stage 2 D/DBP Rule requires these system to meet MCLs as an average at each
36 compliance monitoring location (instead of as a system-wide average as in Stage 1 D/DBP) for
37 two groups of DBPs, TTHM and HAA5.
38

39 Under the Stage 2 D/DBP rule, systems will conduct an evaluation of their distribution
40 systems, known as an Initial Distribution System Evaluation (IDSE), to identify the locations
41 with high DBP concentrations. These locations will then be used by the systems as the sampling
42 sites for Stage 2 D/DBP rule compliance monitoring.
43

44 Compliance with the MCLs for two groups of DBPs will be calculated for each
45 monitoring location in the distribution system. This approach, referred to as the locational
46 running annual average (LRAA), differs from Stage 1 D/DBP requirements, which determine
47 compliance by calculating the running annual average of samples from all monitoring locations
48 across the system.
49

1 The Stage 2 D/DBP rule also requires each system to determine if they have exceeded an
2 operational evaluation level, which is identified using their compliance monitoring results. The
3 operational evaluation level provides an early warning of possible future MCL violations, which
4 allows the system to take proactive steps to remain in compliance. A system that exceeds an
5 operational evaluation level is required to review their operational practices and submit a report
6 to their State that identifies actions that may be taken to mitigate future high DBP levels,
7 particularly those that may jeopardize their compliance with the DBP MCLs.
8

9 The compliance schedule for Stage 2 D/DBP requirements is based on system size and
10 sources used (ground water or surface water). The inspector should verify that the IDSE
11 requirements have been met, that the system is conducting compliance monitoring according to
12 an approved plan, and that the system has met the requirements for operational evaluations.
13

14 **2.2.9 Inorganic and Organic Chemicals**

15
16
17 Monitoring requirements for inorganic and organic chemicals are contained in 40 CFR
18 141.23 and 40 CFR 141.24, respectively. For both groups of contaminants, ground water system
19 samples are required at each entry point to the distribution system that is representative of each
20 well after treatment. Inspectors should verify that all sources are appropriately monitored at the
21 entry point(s). If systems have detected inorganic or organic chemicals, the inspector should
22 verify that monitoring frequency is appropriate and review any monitoring waivers.
23

24 **2.2.10 Radiological Contaminants**

25
26
27 Monitoring requirements for radionuclides are contained in 40 CFR 141.66. For this
28 group of contaminants, community ground water systems are required to monitor at each entry
29 point to the distribution system that is representative of all sources being used under normal
30 operating conditions. Inspectors should verify that all sources are appropriately monitored at the
31 entry point(s).
32
33
34

3. Preparing for the Survey

In order to conduct an effective and efficient sanitary survey, the inspector must organize and plan the effort well. Many critical steps are required, beginning with the first phone call to arrange the onsite inspection and ending with the sustainable correction of sanitary defects. The survey should be viewed as a cooperative partnership between the primacy agency and the water purveyor, as both organizations share a common goal of providing safe drinking water to the public.

3.1 Contact and Location

The inspector must contact the water system owner or operator to explain the purpose of the sanitary survey; schedule a meeting location, date, and time when key personnel will be available; and discuss any action that needs to be taken by the water system in preparation for the survey. Telephone contact followed by a short follow-up notification letter is recommended, with sufficient time for system personnel to respond to the notice. If the inspector must change the schedule, it must be done at the earliest possible time.

It is essential that the inspector contact the person directly responsible for the overall management of the system (e.g. CEO, mayor, water commissioner, utility manager) in order to obtain cooperation, gather information, coordinate with other departments or agencies, and transmit the results of the evaluation.

Finally, coordination and communication between the inspector and the primacy agency, local health department, and water system management personnel are essential in preparing for a sanitary survey. The inspector needs to work with each of these entities to be properly prepared for the sanitary survey. Some of the information the inspector should exchange with each of these entities is listed in Exhibit 3.1.

Exhibit 3.1 Communication Activities

Entity	Activities
Primacy agency	The primacy agency should provide the inspector with information for water systems to consider for sanitary surveys (based on when the previous survey was done), past sanitary survey reports, and other information in the agency files for the relevant water systems. The primacy agency should also provide the inspector with agency inspection requirements and guidelines, such as assessment criteria, a list of significant deficiencies, and any sanitary survey forms used by the agency.
Local health department	The inspector should ask the health department if there have been any reported illnesses attributed to drinking water.
Water system management personnel	<p>The inspector should contact the water system and first determine the appropriate personnel for further sanitary survey discussions. With the appropriate personnel, the inspector should describe the purpose of the sanitary survey and the steps of the survey, particularly the onsite inspection (described in Chapter 4). Preliminary discussions should also include:</p> <ul style="list-style-type: none">– a review of previous sanitary survey reports and the system's historical records (including chemical and bacteriological data),– correspondence,– engineering studies,– past violations, and– any records that are needed for review but are not available from the primacy agency's files. <p>The inspector should also schedule the onsite inspection with the water system.</p>

3.2 Planning the Sanitary Survey

In planning the sanitary survey, the inspector needs to estimate the time required to manage his or her time well. The estimate should include time prior to, and after the onsite inspection. Although the time required will vary with the complexity of the water system and the experience of the inspector, a good rule of thumb would be two hours in the office for every hour in the field. Once onsite, the inspector may identify other priority areas that need more attention. If so, the inspector should then adjust the onsite schedule accordingly.

3.2.1 Resources Needed

Prior to the onsite inspection, sanitary survey inspectors should ensure that their field equipment is in good working order. Preventive maintenance is essential for all types of equipment. Equipment that is broken, dirty, in disrepair, out of calibration, or otherwise improperly maintained will not provide dependable, reproducible, or accurate data. For best results, the inspector should follow the manufacturer's specifications for preventive maintenance. The inspector also should check expiration dates and keep up with and use current standard testing procedures and calibration methods. Recommended types of field equipment include but are not limited to:

- Hand held colorimeter, portable spectrophotometer, or other mechanical residual chlorine test kit;
- Accurate pressure gauge;
- Portable Global Positioning System (GPS) equipment;
- Camera with automatic time/date stamp;
- Binoculars;
- Cell phone;
- Small mirror (provides light and allows inspection of areas that are not accessible or are not in the direct line of sight); and
- Flashlight.

3.2.2 Personal Safety

The sanitary survey planning effort needs to address safety considerations, both for the field inspector and the system's operating staff. Safety hazards can include head injuries from low clearance piping, snake and spider bites, insect stings, electrical shock, chemical exposure, drowning, confined space entry, noise, lifting injuries, and slipping, tripping, and falling. Prior to the onsite inspection, the inspector should ensure that personal protective equipment is available. The most frequently used equipment includes safety hats, goggles, gloves, earplugs, and steel-toed safety shoes. Respirators and a self-contained breathing apparatus may also be used in some cases. Sanitary survey inspectors should fully understand their State's policy or the system's procedures on confined space entry and climbing ladders and adhere to the policy or procedures when conducting the field visit.

3.2.3 Logistics

Contact with the system and planning prior to the field survey should include the logistics of completing the field survey including but not limited to:

- Scheduling a time and meeting place;
- Directions;
- Contact phone numbers if lost or running late;
- Any security clearances or special access requirements to enter the water treatment plant or other facilities;

- Availability of PWS staff, treatment operator, water quality staff, distribution system operator, cross connection program etc., to complete the field survey; and
- Budgeting of sufficient time for the onsite visit based on previous experience or inspections.


3.3 Inventory of System Facilities

Prior to each sanitary survey, the inspector should review available information, going back at least to the last sanitary survey, concerning the system involved. Information that should be collected includes the treatment in place, monitoring requirements, the compliance history of the facility, and the condition of the system during the previous sanitary survey. This information is used to identify questions to ask and assessment criteria to apply during the onsite inspection.

A schematic or layout map of the PWS will enable the inspector to obtain a quick understanding of the complete drinking water system. If possible, prior to the site visit, the inspector should obtain a schematic or layout drawings of the portions of the facility that will be evaluated during the survey. The schematic or layout map should start at the source and continue through the treatment facilities and storage facilities to the distribution system.

The primary purpose of the schematic or layout map is to help the inspector quickly understand the basic operation of the system. Therefore, it should be drawn in enough detail to facilitate the inspector's understanding. A schematic typically provides general information on the basic system components and the direction of water flow in the system. Water system schematics should include an identification of source water supply facilities (e.g., well; pumping station; transmission line), the treatment plant, any booster plants, finished water storage (e.g., clearwells, elevated and ground storage tanks, pressure zones), the entrance to the distribution system, any associated facilities (e.g., pumping stations), and any interconnections with other PWSs. A schematic of a typical PWS is provided in Exhibit 3.2.

Exhibit 3.2 Example Schematic of a Ground Water PWS with Iron Removal Treatment



Layout maps are more detailed than schematics and contain more specific information on the location and orientation of physical facilities. In collecting the layout data, an inspector may easily obtain the latitude and longitude data of a PWS by using portable GPS equipment. A water system may have separate layout maps for its treatment plant and distribution system.

For identification purposes, the name and identification number of the PWS, as well as the date of the sketch, should be included on each schematic and layout map. The dated schematics and layout maps will help future inspectors identify water system changes. The schematic and/or map should be current and reflect any changes that have been made since initial construction of the system and since the last sanitary survey.

Suggested criteria for assessing treatment plant schematic or layout map(s):

Does the drawing(s) show the name of the facility and date of the last modification made to the drawing(s)?

This will help future inspectors know if and when sanitary survey modifications took place. Taken together, a chronological set of schematics will help document a system's history.

Does the schematic or map(s) contain a legend that explains key symbols used in the drawing(s)?

With the aid of a legend, the inspector will get a better idea about the location of principal treatment units and appurtenant equipment. The drawing with its legend will provide the inspector with information useful for determining where to start and end the inspection, as well

as areas that the inspector should focus on and inspect in particular detail. It is also helpful if there is a graph scale for the layout.

Are influent, effluent, and residual disposal points clearly shown on the drawing(s)?

If these points are not shown on the schematic or the layout map during the onsite inspection, the inspector should add sketches for these points to the drawing(s) or use a separate sheet and have inspection comments adjacent to the sketches.

Does the schematic or map(s) show all the elements of the water system, from source facilities to the distribution system? Does the schematic or map(s) reflect the actual water system?

The inspector should review the schematic or map(s) to verify that all elements of the treatment system are shown and the drawings are complete. During the onsite inspection, the inspector should compare the drawings to the actual system layout to assess the accuracy of the drawings. Some systems do not update their maps to reflect system modification or have incomplete drawings, limiting their usefulness.

3.4 File Review Elements

In order to efficiently determine a system's compliance with the various regulatory requirements, the inspector must rely on information available in the State primacy agency office as well as that gathered in the field. Various reports, correspondence, engineering studies, and monitoring data for at least the last 5 years are important sources of information for determining a system's compliance and are typically available in the office for review and evaluation.

Office files and files provided by the water system owner and operator will provide insight into the design, construction, operation, maintenance, management, and compliance status of the facility. The sanitary survey inspector should thoroughly review all pertinent documents before the onsite inspection in order to fully understand the site-specific issues. The following subsections describe important types of documentation that the inspector should review if possible. While not all-inclusive, the following subsections discuss significant types of information often available. Information to review includes:

- Previous sanitary surveys;
- Source water assessments, wellhead protection plans, source protection information;
- Compliance and enforcement history;
- Required monitoring;
- Consumer Confidence Reports (CCRs);
- TCR compliance history;

- Waivers and exemptions;
- Water system schematic/layout maps;
- Project reports and construction documents;
- Cross connection control plans;
- Management plan or operations and maintenance plan; and
- Other correspondence about system issues.

3.4.1 Previous Sanitary Surveys

Previous sanitary survey reports provide valuable information on the system's history and compliance status. The sanitary survey report includes a record of system treatment processes, operations, and personnel and their compliance with SDWA requirements. Significant deficiencies identified in the previous sanitary survey indicate some of the areas the sanitary survey inspector should focus on during the inspection to determine if they have been corrected and have not become problem areas again. Review of several previous sanitary survey reports may reveal a pattern of noncompliance in certain aspects of the system. If so, the inspector should pay particular attention to these areas during the onsite inspection and ask appropriate personnel about these problems and how they are being addressed.

3.4.2 Source Water Assessments

An inspector should review the source water assessment and any wellhead protection plans for a system before the sanitary survey's field visit. This information will provide the inspector with a list of potential contamination sources that may require investigation and possibly revision. The information may also identify source control measures that may require inspection to determine if they are being implemented. In addition, the source water assessments will provide valuable information on well integrity and hydrogeologic sensitivity.

During a sanitary survey, the inspector should re-evaluate the system's source water assessments to see if they need to be updated. New potential sources of contamination should be noted. Alternatively, any potential sources of contamination that have been removed should have their status updated in the source water assessment. For example, if a municipality has switched from privately owned septic systems to a public sewer system, the inspector should note this during the survey and update the source water assessment on file. Appendix B provides guidance regarding how to review and revise source water assessments during the sanitary survey.

3.4.3 Compliance and Enforcement History

SDWA and its regulations require self-monitoring and self-reporting by water systems to show compliance with the regulations. The water system should submit reports to the State on a regular basis detailing the system operations and identifying any problems encountered during the month.

An inspector should review all of the operating reports submitted since the last sanitary survey to ascertain any trends (e.g., changes in water quality, chemical usage, flow rates, or chlorine residuals) that may help to focus the inspection. Often there is not enough time available to review all of the reports. Therefore, the inspector should focus on violations or system problems that either the water system reported to the State or were identified during the previous sanitary survey.

The consequences of non-compliance can be severe (e.g., compliance orders and penalties). Errors in information reported to the State can result from ignorance of proper testing procedures and instruments out of calibration. Data falsification is a rare, but serious, occurrence. During a survey the inspector should be alert to errors in data, intentional or unintentional.

There are a number of general recordkeeping requirements specified in 40 CFR 141.33. In addition, the Lead and Copper Rule (40 CFR 141.91) has specific requirements shown in Exhibit 3.3. The inspector should verify the availability of these records at the water system during the sanitary survey.

Exhibit 3.3 Records and Retention Period

Records to Keep	Retention Period
Bacteriological analysis	5 years
Chemical analysis	10 years
Actions to correct violations	3 years
Sanitary survey reports	10 years
Variance or exemption	5 years
Turbidity results	10 years
All lead and copper data	12 years

Federal regulations require the water system to issue notices to the public when the system:

- Violates an MCL or treatment technique requirement; or
- Fails to comply with monitoring requirements or analytical method requirements.

All public notices should include:

- A clear, concise, and simple explanation of the violation;

- A discussion of potential adverse health effects;
- A discussion of any segments of the population that may be at higher risk;
- A list of steps the water system has taken or plans to take to remedy the situation;
- A list of any preventive steps consumers should take;
- Any need for seeking an alternative water supply; and
- The water system's name and telephone number.

The regulations require that public notice:

- Be displayed in a conspicuous way when printed or posted ,
- Not contain overly technical language or very small print,
- Not contain language that nullifies the purpose of the notice, and
- For systems serving a large proportion of non-English speaking consumers, contain information in the appropriate languages regarding the importance of the information and where to obtain a translated copy of the notice or assistance in the appropriate language.

In some cases, depending on the severity of the violation, additional specific requirements (e.g., including mandatory health effects language in the notice) apply. The public notices are to be distributed by mail, hand delivered to all consumers served by the water system, or placed in newspapers widely circulated in the area. Certain violations may also require announcements on radio and television stations serving the area. (40 CFR 141.32)

State regulations may also require the water system to submit a report to the State or issue a public notice under certain conditions (e.g., a system is identified as the source of a waterborne disease outbreak, experiences an unscheduled loss in pressure, or fails to comply with a State order). If the inspector identified such public notification requirements when preparing for the onsite visit, the notification's text and procedure should be reviewed.

3.4.4 Monitoring Plans

EPA drinking water regulations and State equivalents establish minimum requirements for the contaminants to monitor and acceptable concentrations for each in the finished water stream. The monitoring frequency, requirements for repeat or follow-up testing, and sample location are also typically included in the monitoring plans.

Monitoring plans are required to be prepared for:

- Total coliforms;
- Disinfectant residual; and
- DBPs.

Additional monitoring plans may be prepared for:

- Inorganic chemicals;
- Organic chemicals;
- “Unregulated” chemicals;
- Radionuclides; and
- GWR monitoring.

3.4.5 Consumer Confidence Reports (CCR)

CWSs are required to prepare and distribute a CCR annually as well as submit a copy of the CCR to the State. As part of the file review, the inspector should review when and how the CCR was distributed as well as any content issues. Distribution issues include efforts to reach consumers that are not bill-paying customers and distribution to consecutive systems by wholesale systems. Content issues include the required language and information for all CCRs, as well as additional health information required as a result of system-specific violations, variance, exemptions, or detections of specific contaminants (i.e. nitrate, lead, TTHM, arsenic).

3.4.6 Other Required Submittals

The water system may need to submit project reports or plans and schedules to the State for approval before any change in equipment installation or construction of any new water system, water system extension, or improvement, or when requested. The GWR requires that system consult with the State regarding correction of significant deficiencies. For significant deficiencies that are not corrected with 120 days of notification by the State, systems must follow a State-approved plan and schedule

A project report should demonstrate consistency with the State design requirements for water systems or State direction and should include:

- A project description—Why the project is being proposed, how problems are to be addressed, the relationship of the project to other system components, and the impact of the project on system capacity and ability to serve customers. In some States a project description should contain “a statement of determination” related to the State

environmental policy act and include source development information and type of treatment;

- Planning data—General project background with population and water demand forecasts, how the project will impact neighboring water systems, construction schedule, estimated capital, and annual operating costs;
- An analysis of alternatives—Description of options and the rationale for selecting the proposed option;
- A review of water quality—How water quality relates to the purpose of the proposed project, including analytical results of raw water and finished water quality;
- A review of water quantity—Applicable water rights as they relate to the project;
- Engineering calculations—Sizing justification, hydraulic analyses, physical capacity analyses, and other relevant technical considerations necessary to support the project; and
- Design and construction standards—Performance standards, construction materials and methods, and sizing criteria.

The inspector should review any available project reports for proposed, ongoing, and recently completed projects at the water system. These reports may describe upcoming activities that are already planned and may address some of the problems the inspector finds during the sanitary survey.

3.4.7 Total Coliform Rule (TCR) History

The TCR applies to all PWSs. The TCR requires that a water system have a written sample siting plan approved by the State. The inspector should verify that there is an approved plan that is being utilized. The inspector should also evaluate the plan to determine if it is currently meeting the requirements of the TCR. The rule requires collecting samples “that are representative of water throughout the distribution system.” The rule also contains a table that shows the minimum number of samples required based on population served. In reviewing the sample siting plan, the inspector should ensure that at least the minimum required number of samples are being collected and that the sampling locations are representative of the distribution system. Items to be addressed in file review of the TCR history include;

- For larger systems, are TCR samples collected over the entire month and representative of all sources?
- Does the system have a history of failure to conduct TCR monitoring or failure to submit TCR monitoring results?

- If system has a history of coliform detections, has it identified and addressed the source of the problem?
- Does the system have a history of TCR MCL violations?
- Has the system had TCR acute violations or detections of fecal indicators?

3.4.8 Variance and Exemptions

A review of system files should include a review of any SDWA variances or exemptions. If the system is currently operating under a waiver or exemptions file review should verify the following with any needed follow up for the field visit noted.

For systems with variances:

- Are conditions of the variance being met based on the file information?
- Is the system making adequate progress in meeting the variance requirements?
- Is the system still eligible for a variance or should the variance be reviewed?

For systems with exemptions:

- Has the schedule for compliance been met?
- Is the system implementing any required control measures?
- Has the exemption been renewed?

3.4.9 Correspondence

A review of system files should include a review of correspondence between the State and the system. Items that may be important in completing the sanitary survey and survey report include:

- Changes in ownership, operation, population served, and service area;
- Changes in sources or treatment or other system modifications;
- Progress in meeting compliance schedules or other required actions;
- Responses to notices of deficiencies or failures to meet monitoring requirements; and
- Other State reports (i.e. annual water statistics).

4. Field Survey

Previous chapters of this manual have provided a definition of a sanitary survey, the regulatory framework for conducting a survey, and the critical steps for planning a sanitary survey. This chapter presents the essential elements for completing the walk through inspection of an onsite sanitary survey. The onsite sanitary survey includes visiting the water supply source and source facilities, pump stations, the treatment process, storage facilities, the distribution system, and sampling locations. One of the most important functions of the onsite portion of the survey is to determine whether the existing facilities are adequate to meet the needs of the water system's customers at all times. Therefore, this visit should include review and verification of the capability and capacity, construction and operation, and physical condition of the water system's facilities.

There are eight elements that are considered essential for review in the proper conduct of a thorough sanitary survey. These eight elements are listed below:

- Source (Protection, Physical Components, and Condition);
- Treatment;
- Distribution System;
- Finished Water Storage;
- Pumps/Pump Facilities and Controls;
- Monitoring/Reporting/Data Verification;
- Water System Management/Operations; and
- Operator Compliance with State Requirements.

This chapter presents a general description of each element and its importance as part of the sanitary survey, general guidelines for evaluating important components of each element, and a discussion of priority components under each element. The order of the eight elements is not intended to dictate the sequence of survey activities, but to provide a logical division of the essential elements for a sanitary survey. Each element is divided into components and includes a discussion of the issues that an inspector should consider when evaluating a particular component. Guidelines for evaluating the components are provided in the form of a list of assessment criteria. The assessment criteria identify areas that need to be reviewed during a sanitary survey. The criteria are intended to help the inspector identify sanitary risks that may arise due to deficiencies in a particular component.

In conducting the sanitary survey, the inspector should pay particular attention to those areas where deficiencies would be considered significant and thus warrant prompt corrective action. This format allows States flexibility in evaluating the components based on system type,

size, and complexity. The Appendix includes standard forms that can be used to conduct a survey.

4.1 Logistics

The onsite inspection includes the following parts:

Opening interview

- Introductions.
- Review of the purpose of the sanitary survey.
- Review of the parts of the onsite inspection and the schedule for the inspection.
- Review of the facility layout and location of the well(s) and treatment processes.
- General discussion of basic system information; the condition of the system and its operation, staffing, and management; whether relevant plans and procedures have been developed and are adequate.
- Discussion of deficiencies identified in previous sanitary survey reports and any violations/compliance problems since the last survey; and corrective actions taken and their effectiveness in addressing the deficiencies and problems.

Access, Transportation and Safety

- Has access to all facilities been arranged?
- Are the appropriate personnel available for the individual system components or programs?
- Has transportation to the system components been arranged?
- Are there any safety conditions that need to be addressed?(i.e. climbing equipment, confined space)

Walk through

- Physical inspection of all visible system components.
- Asking questions of appropriate personnel for clarification, to determine the knowledge of system personnel, and to check information obtained during records review and other aspects of survey planning and preparation.
- Note taking for documentation and writing up the findings in the sanitary survey report.

Organization of findings and documentation

- Filling in any gaps in inspection notes and add detail where needed.
- Completing sanitary survey checklists/forms (if used).
- Clarification of any remaining issues with water system personnel.
- Obtaining any documentation still needed.
- Preparation for closing interview.

Closing interview/debriefing the system on inspection findings

- Presentation of findings, particularly any significant deficiencies, to the water system.
- Informing water system management of next steps (i.e., writing and submitting the report, corrective action).

4.2 Sources

The water supply source is the beginning of the drinking water system and can be a source of contaminants, pathogens, and particles. Preventing source water contamination is an effective way to prevent contaminants from reaching consumers. Source water protection also helps prevent additional, potentially more costly treatment from being necessary for the removal of contaminants.

The objectives of surveying the raw water source are to:

- Review the major components of the source to determine reliability, quality, quantity, and vulnerability; and
- Determine and evaluate data that define the potential for degradation of the source water quality.


To accomplish these objectives, the inspector needs to review available information on source water facilities and wellhead protection plans where they exist for a system. In the field, the inspector should discuss the water supply source with the operator(s) and verify the information received from the plans with field observations. The following areas should be reviewed as part of the sanitary survey.

4.2.1 Well Construction

Ground water is drawn from underground aquifers. To get the ground water to the distribution system, a well is drilled and a pump is usually installed below the water level. A

major concern in the design of a well is preventing contaminants from entering the aquifer. The major components of a typical groundwater well are shown in Exhibit 4.1.

Exhibit 4.1 Major Components of a Typical Groundwater Well



©Arasmith Consulting Resources
(Source: UFTREEO Center, 1998; Used with permission)

Although there are many well drilling techniques, a typical well may be started by drilling a hole in the ground into a water-bearing aquifer. The drilled hole is supported by solid casing installed to just below the water table. The well casing is usually made of steel or polyvinyl chloride (PVC). It should have walls thick enough to meet collapse strength requirements for its use (Recommended Standards for Water Works, 2003). PVC casing is not recommended at locations where there is a chance that the overlying soil contains hydrocarbons that could permeate the casing and contaminate the deeper water being used.

Screen material is installed below the casing to allow water into the casing while preventing the migration of sand and silt into the bottom of the well. The screen should be constructed of corrosion resistant material that is both strong and hydraulically efficient. The screen's mesh size should be determined based on a sieve analysis of the formation or gravel pack materials. The screen should be installed so the pumping water level remains above the screen under all operating conditions.

Wells are often equipped with submersible pumps and discharge lines that reach down inside the casing into the water. Some wells have a lineshaft turbine pump mounted on top of their casings. Depending on the type of well pump being used, the casing will look different and will be equipped with different kinds of seals and vents. These differences and their potential deficiencies are described in more detail in section 4.3.1.1.

The well casing is usually surrounded by 1 to 2 inches of neat cement or concrete grout. The grout fills the annular opening between the casing's exterior and the edge of the hole drilled in the ground. Ideally, the annular opening should be large enough to allow a minimum of 1 ½ inches of grout around the casing.

4.2.1.1 Surface Features

The well casing should extend at least 18 inches above the pump house floor and ground surface. If the location of the well is prone to flooding, the casing and its vent should extend high enough so they are not submerged during a flood. EPA recommends that, at locations prone to flooding, the top of the casing should stand at least 3 feet above the 100 year flood level or the highest known flood elevation (whichever is higher)(USEPA, 2003).

Wells with submersible pumps should be capped and the cap should be sealed so no water or contamination can enter the well. Seals should fit properly to accommodate all well appurtenances. If the well is not housed, the well cap should be locked and lightning protection should be provided.

One type of well seal used with submersible turbine pumps is a sanitary well seal with an expandable gasket to allow the pump drop pipe, wires and vent to pass through it. This type of seal, shown in Exhibit 4.2, is typically used in wells housed in a well house. Bolts tighten two plates together, expanding the gasket material located between the plates. It seals the openings around the casing, pump drop pipe, the inverted U-type screen vent, and the electrical conduit.

Exhibit 4.2 Illustrations of a Split Cap and Seal




The other type of seal is an overlapping exterior sanitary well seal, illustrated in Exhibit 4.3. It is commonly used in outdoor applications with submersible pumps and pitless adapter units. The vent is under the lip, and gasket material seals all openings around the casing and conduit.

Exhibit 4.3 An Overlapping Exterior Sanitary Well Seal



Wells with a lineshaft turbine pump mounted on top of the casing should have a metal support plate on which a rubber gasket is mounted to provide a sanitary seal. The motor, along with an attached column and discharge head, is mounted on top of the gasket and support plate. During the sanitary survey, this kind of well should be checked to ensure there is a rubber gasket providing a sanitary seal and that the gasket is in good condition.

Exhibit 4.4 Top of Casing Illustration for a Well with a Lineshaft Turbine Pump (left) and a Well with a Submersible Turbine Pump and a Split Cap



Well casings should be vented to the atmosphere. For wells with submersible pumps, the vent should terminate in a downward “U” position, and should be located at or above the top of the casing. The vent’s opening should be screened with a 24 mesh corrosion resistant screen. Wells with turbine pumps mounted on top of the casing frequently are vented to the side of the casing. These vents should be located high enough to prevent water from entering them and should also be properly screened.

The discharge from the well should have a sample tap with a smooth nozzle to allow for sampling before the addition of any chemicals or disinfectants and before any treatment step. A sample of the raw water will allow the water system to test for contaminants that might be present or any changes in source water quality.

The following are suggested assessment criteria for the surface features of a well:

Is the well properly sealed at the surface? Does the casing extend at least 18 inches above the well slab, floor, or ground surface? Does the well vent terminate above the maximum flood level with a turned down gooseneck and corrosion resistant bug screen?

Surface runoff can migrate down the annular space along the outside of the well casing and contaminate the aquifer. Therefore, all sources of leakage should be plugged to prevent contamination. The most visible point of leakage is the encasement at the surface. The construction of the well above the surface should prevent leakage down the outside of the well casing as well as through the casing cap that is located on top of the casing. By extending the casing at least 18 inches above the well slab, surface runoff should not be able to enter the casing. The well casing cap has to be a watertight sanitary seal to prevent water from entering through it. In addition, the casing vent through the cap should extend above flood level to preclude surface runoff from entering the well directly and the end of the vent should be terminated with a downward turned gooseneck and screen to prevent rain and bugs from entering.

What is the general condition of the piping and valving, the site, and the electrical system? Do they appear to be well maintained? Does the electrical system have lightning protection? Can the pump be maintained easily and the water for the system continually supplied?

As the source for the water system, the well should be in good operational condition to ensure that a dependable supply of high quality source water will be available at all times. Good operational condition means that the piping is not leaking or corroded, the valves and controls are operable, and the electrical system is protected from the elements and is not corroded. The well site should be graded to prevent ponding of surface water and to direct drainage away from the wellhead, and the housing and fencing should be properly maintained. Valves and meters should be fully functional and well maintained to keep out contamination. Personnel should have sufficient access to these valves for cleaning. The electrical system should be protected from lightning since the sudden electrical surge caused by lightning striking the wellhead or nearby may cause the electrical components to burn out. If the electrical components of the well are not functional, then the well will not operate. The inspector should check for lightning protection and backup power supplies (see section 4.7 for more information on emergency power). Ground fault protection is important to protect the operator.

4.2.1.2 Subsurface Features

Because the casing is often the only well feature above ground, it is frequently impossible to visually inspect much of a ground water supply well and verify that the proper design and construction methods were followed. The original well construction records (e.g., driller's log, material settling data) and records of after-construction modifications to the well, if available, should be reviewed to verify that the well was properly constructed. The results of inspections and repair work performed by qualified technicians may provide additional information about the construction of the well. The inspector should verify that design and construction methods meet applicable State requirements for wells.

1
2 The following are suggested assessment criteria for the subsurface features of a well:

3
4 **What is the depth of the well?**

5
6 The greater the depth of the aquifer used, the less chance there is that surface
7 contamination will degrade water quality. Deeper aquifers generally have a more consistent
8 quality of water (EPA, 2003).
9

10 **How long is the well casing?**

11
12 Well casing is an important part of proper well construction. The encasement of a well
13 acts as a barrier to surface water and contamination from other aquifers. It also prevents the bore
14 hole from collapsing. The well casing houses the submersible pump and its discharge pipe, and
15 provides a column of water that allows for positive pump suction head. The encasement should
16 be constructed of either steel or plastic, depending on the depth of the well and local regulations,
17 and should adhere to the State's well standards. The encasement should extend up a minimum of
18 18 inches above the natural ground level or finished floor elevation or two to three feet above the
19 maximum flood elevation. The encasement should pass through all undesirable water bearing
20 strata and extend down at least to the depth of the shallowest water bearing strata to be
21 developed.
22

23 **Is the annular space around the well casing filled with grout or bentonite**
24 **clay?**

25
26 The annular space around the casing should be filled with a material, such as bentonite or
27 grout, that will prevent the leakage of water from the surface and intervening water-bearing
28 layers down the outside of the casing into the aquifer. During the sanitary survey, the inspector
29 should review the driller's log, if available, to ensure that the well is grouted to a depth that
30 prevents any contaminated water from overlying aquifers or the well's surface from entering the
31 well water that is being pumped and used. EPA recommends that wells be grouted a minimum
32 20 foot depth below the surface (USEPA, 2003).
33

34 **What is the screen constructed of? What is the depth of the screen?**

35
36 The water-bearing aquifer will typically consist of sand and gravel, but could be rock
37 (e.g., fractured bedrock). A screen allows the maximum amount of water to flow into the well
38 while preventing abrasive sand and gravel from reaching the pump. The screen should be
39 constructed of a material that is strong and will not degrade over time due to exposure to water
40 and surrounding environmental conditions. The material generally chosen for the screen is
41 stainless steel. Some wells do not have screens because they are unnecessary for certain aquifer
42 materials (e.g. rock instead of sand/gravel).
43

44 **Is drawdown measured? Is the pump set below maximum drawdown?**

45
46 Drawdown is the difference between static water levels and pumping water levels.
47 Measuring drawdown is important because changes in static water level or drawdown can
48 indicate problems in the aquifer (declining water levels) or pump. Such changes also can
49 indicate well encrustation. The operator should regularly measure drawdown and record the

1 results. Locating the pump intake below maximum drawdown prevents the pump from running
2 dry and protects against possible pumping of contamination from upper portions of the water
3 table.
4

5 6 **4.2.1.3 Driller's Logs**

7
8 The PWS should have a copy of the well driller's report that shows the following:
9

- 10 • A casing that penetrates a confining stratum of clay, shale, or otherwise impervious
11 material;
12
- 13 • The annulus between the drilled hole and the casing is sealed using bentonite clay,
14 cement slurry, sand-cement grout or other acceptable material; and this seal extends
15 from the surface down and into the confining strata mentioned above;
16
- 17 • The well is grouted for a minimum depth of 20 feet;
18
- 19 • The well is drilled to a depth greater than 50 feet, or is a driven well;
20
- 21 • The well is located at a distance greater than 200 feet from any surface water; and
22
- 23 • The well has been pump tested in accordance with a reviewed and approved
24 yield/drawdown test and results clearly determine the porosity and transmissivity of
25 the aquifer materials.
26

27 28 **4.2.1.4 Typical Defects**

29
30 A well provides a direct conduit from the ground surface to the aquifer. If the well is not
31 constructed properly, surface runoff and shallower aquifers can contaminate the aquifer tapped
32 into by the well.
33

34 The following paragraphs describe typical well defects.
35

36 *Casing Too Low*

37
38 Well casing should extend at least eighteen inches above the floor of the well house or
39 three feet above the maximum flood level and their vents should be facing downward and
40 screened (USEPA, 2003). Wells in areas prone to flooding can flood and allow surface water to
41 wash contaminants into the well. Surface grading, which directs surface runoff toward the well,
42 can also cause contamination. If the casing is not elevated above the floor and turned downward,
43 surface water and atmospheric debris can fall into the well and contaminate it. If the well is
44 housed, the well house should be properly drained so that water does not pool around or near the
45 well.
46

Improper Well Cap

Gaps or holes in the well cap can allow contaminants to enter the well. The well cap should be welded on or have a threaded cap and should be free of any holes caused by corrosion (Recommended Standards for Water Works, 2003). EPA recommends that wells be housed and the well housing be locked and secure. Well caps of wells that are not housed should be locked.

No Sanitary Seal

If a well is not sealed properly, contaminants can enter into the well, either from the surface or from non-potable aquifers. The top of the casing or pipe sleeve should have a well cover with a sanitary seal on it. A more detailed description of sanitary seals is provided in section 4.3.1.1.

Well Not Grouted Properly

The annular casing should be grouted in any area where contaminants might enter the well, including a minimum 20 foot depth below the surface and through any aquifers that may contain contaminated water (USEPA, 2003).

Well not properly ventilated

Proper engineering practices require that a well be vented to the atmosphere (Ten States Standards, 2003) to allow equalization of pressure with the atmosphere and to prevent accumulation of hazardous gases such as hydrogen sulfide or methane. If such gases are present, the vent should terminate outside of any well house or confined space. The well vent should be faced downward and covered with a corrosion resistant mesh to prevent entry of contaminants or vermin.

Well in pit

Wells should not be placed in pits because pits are prone to flooding that can allow contaminants to enter the well. Pits are also usually confined spaces; water system operators entering a pit to tend to their well should be provided with appropriate confined space training. Preferably, pits should be filled in, a pitless adapter should be installed, and the well casing should be extended so it rises at least eighteen inches above the ground once the pit has been filled.

4.2.2 Potential Sources of Contamination

During the field survey, the inspector should verify that the inventory of potential sources of contamination has not changed and that the susceptibility determinations for the source do not need revision. New potential sources of contamination and changes in a well's susceptibility may require modifications to the water quality monitoring requirements for the source. Appendix B provides guidance on how to review and revise source water assessments during the sanitary survey.

4.2.2.1 Wellhead Protection Program (WHPP)

A WHPP is designed to protect the quality of a water system's ground water source by minimizing the impact of activities in the source recharge area as well as the portion of the aquifer that supplies the system. The main components of a WHPP are delineating the wellhead protection area, identifying and locating all potential sources of contamination that could impact the well, and developing and implementing a strategy to manage the wellhead protection area and protect the ground water source from contamination.

Suggested assessment criteria for wellhead protection include:

Is the aquifer recharge area protected?

Has the water system developed a WHPP that protects the well's recharge area? The inspector should learn whether a wellhead recharge area protection plan is in place and being actively implemented.

What is the size of the protected area and who controls it?

To what extent does the owner of the water system have ownership or control of the land around the well(s)? Many systems own the land outright and control activity in that way. Other communities have adopted ordinances or are zoned so that the wellhead area is protected. During the field survey, the sanitary survey inspector should evaluate how effectively an established WHPP seems to be preventing contamination of the water supply.

4.2.2.2 Source Vulnerability Assessment

A vulnerability assessment is used to determine the potential for contaminant sources in a specified area around the well to degrade the public water system's source water quality. The 1996 Amendments to the SDWA require that States determine susceptibility of all their public water systems to contamination. A susceptibility determination includes consideration of several factors, including hydrogeologic sensitivity, contaminant source characteristics (e.g., persistence and mobility of contaminants), contaminant source management and well integrity. A completed SWAPP susceptibility determination may suffice as the source vulnerability assessment for a sanitary survey, and can be considered along with vulnerability assessments performed under monitoring waiver programs, pesticide management plans, or other programs.

Suggested assessment criteria for assessment of source vulnerability include:

Has the hydrogeologic sensitivity of the well been adequately assessed?

The inspector should evaluate what effort has been made to define the water system's wellhead area and identify actual or potential sources of contamination within the defined area. If the well is located in a hydrogeologically sensitive setting, the inspector should evaluate whether additional source water monitoring may be appropriate. If potential sources of contamination are identified near the well, the inspector should determine if and how they are being managed to minimize their potential for contaminating the well, and whether the system's source water protection program is protective enough.

1
2 **Does the system monitor raw water quality? Does monitoring of raw water quality**
3 **indicate an immediate, significant sanitary deficiency?**
4

5 If a well's untreated water has tested positive for an indicator of fecal contamination or
6 for a harmful chemical, the well should not be considered a reliable source. An alternative
7 source should be actively pursued and developed.
8

9 **Is the system using the highest quality source available?**
10

11 A water system should be using the highest quality source water it has available based on
12 what it knows about its source water quality and the well's potential for contamination.
13
14

15 **4.2.2.3 Abandoned Wells**
16

17 Wells that are not properly abandoned can create a pathway that allows contamination to
18 enter an otherwise protected aquifer. Inspectors should ensure that any abandoned test wells and
19 ground water sources have been properly disconnected and filled.
20

21 Suggested assessment criteria for well abandonment include:
22

23 **Is the system confident that all abandoned wells have been identified? Have they**
24 **been properly abandoned?**
25

26 An abandoned well should be sealed in a manner that restores geological conditions that
27 existed before the well was installed (Recommended Standards for Water Works, 2003). The
28 well should be filled, preferably with cement grout or concrete, and sealed to prevent any water
29 from passing into the aquifer.
30
31

32 **4.2.3 Source Quantity and Capacity**
33

34 One of the most important requirements for any water system is the ability to meet the
35 water quantity demands of customers at all times. Similarly, when demands exceed the treatment
36 capacity of the supply, transmission lines, pumps, distribution system piping, or storage
37 facilities, inadequate flow or pressure in the system can result. Inadequate flow or pressure
38 affects customers, hinders fire fighting capabilities, and creates opportunities for other liquids to
39 enter the system through cross-connections and a reduction in positive pressure.
40

41 Each State has a guide for estimating the average daily water use per person for various
42 types of business and residential uses. The values may vary nationally and seasonally due to
43 frequent lawn watering, swimming pools, industrial and commercial process water, cooling
44 water and fire fighting. However, if no specific water consumption figures are available, water
45 consumption estimates can often be found in water supply engineering books such as Water
46 Treatment Principles and Design (Montgomery, 1985) or the Civil Engineering Reference
47 Manual (Lindeburg 1997). These books have national averages for per capita demand and also
48 supply typical factors for peak daily or hourly demands.
49

1 In many places, particularly in arid and heavily populated areas, water conservation is
2 necessary. Water systems should have a water conservation plan that includes short- and long-
3 term goals, education plans, water rationing procedures in case of drought, and water
4 conservation information available to the public. An aggressive water conservation plan can be a
5 cost-effective alternative to the expansion of water production facilities.

6
7 One of the initial steps of the onsite visit should be determining the required capacity of
8 the treatment facilities. The required capacity should be at least equal to the maximum daily
9 demand of the water system over the previous several years or as determined by the rules and
10 regulations of the State primacy agency. EPA recommends that the developed ground water
11 capacity should equal or exceed the design maximum daily demand when the highest producing
12 well is out of service. Reviewing the operating records of the plant should provide the maximum
13 daily demand. Generally, the maximum daily demand occurs during the summer time.
14 However, there have been situations where the maximum daily demand occurred during hard
15 freezes in the winter when customers left faucets running to prevent their water pipes from
16 freezing. Operating records for the last few years should be checked to determine the historic
17 maximum daily demand.

18
19 For example, using Water Treatment: Principles and Design, 2nd Edition (MWH, 2005):

20
21 Average per capita demand = 150 gpcd

22 Maximum hourly demand = 4.5 times average demand

23 Design Demand = system population x (150gpcd)x(4.5) = system population x (675
24 gpcd)

25
26 Suggested assessment criteria for evaluating the adequacy of the source water supply are:

27
28 **If permits are required, is the facility operating within the limits? Are**
29 **permits available?**

30
31 Some States require systems to have operating permits. During the sanitary survey, the
32 inspector should verify that the amount of water being pumped does not exceed the amount of
33 water the system is permitted to withdraw.

34
35 **Does the system have an operational master meter(s)?**

36
37 Without an operational and calibrated master meter, it is difficult for the water system to
38 accurately monitor production. With a master meter in place, the system can monitor overall
39 production and water usage in the system to determine if supply is adequately meeting customer
40 demand. Data from a master meter, combined with information from service connection meters,
41 can be used to identify and track trends in water supply, water usage, and unaccounted for water
42 that may be lost due to distribution system leaks.

43
44 **How many service connections are there?**

45
46 The total number of homes and businesses served by the PWS provides the inspector with
47 an idea of the size of the system.

1 **Are service connections metered?**

2
3 The system should have meters in place to monitor overall production and water usage in
4 the system to determine if supply is adequately meeting customer demand. Data from meters can
5 be used to identify and track trends in both water supply and usage so that any potential future
6 shortages can be noticed earlier and additional supplies obtained.
7

8 **Does the system have interconnections with neighboring systems or a**
9 **contingency plan for water outages?**

10
11 The system should plan for water outages so that water can be restored quickly.
12 Interconnections should only be made with approved sources.
13

14 **Does the system have redundant sources?**

15
16 Emergency supplies should be made available during outages. Many States require
17 community water systems with ground water supplies to have at least two sources in case one is
18 lost.
19

20 **What is the water quantity required to meet the needs of the water system?**

21
22 The water system should be able to supply an adequate quantity of potable water to meet
23 the highest anticipated demand of the customers. If not, then areas of the distribution system
24 may experience little or no pressure due to the lack of water. With the loss of pressure, the
25 contamination potential of the system is heightened significantly. Knowing the maximum water
26 demand of the system and the quantity available from the source, a quick determination can be
27 made of the system's ability to meet the present and future needs of its customers. In addition,
28 the water system should plan for the growth of its service area and look ahead to obtaining an
29 adequate quantity of water to meet any additional future needs. If operating records show
30 decreasing water quantity over time, the system should be investigating additional supply.
31

32 **Is the source adequate to meet the current and future expected needs of the water**
33 **system, even during times of drought? If not, what other sources are being**
34 **investigated to meet the needs? Has the water system developed and implemented a**
35 **water conservation plan?**
36

37 The inspector can verify that an adequate supply is available by checking to see if the
38 source has ever gone dry or if water has ever had to be rationed because of a shortage of source
39 water. A water system may have developed a water conservation plan as part of its overall water
40 system master plan and may already be implementing the water conservation plan regardless of
41 the adequacy of source water quantity. Implementation of a good water conservation plan can be
42 a cost-effective alternative to the expansion of water production facilities as a result of increased
43 demand. If the source water supply appears to be inadequate, the water system should be in the
44 process of implementing further water conservation measures and/or obtaining an additional
45 supply.
46
47

4.2.4 Confirm Well Locations

It is important that the well(s) for a PWS be located as accurately as possible. The well(s) may have been located previously and the inspector need only verify that the location(s) is correct. The inspector may find that a new well has been constructed since the last inspection, either authorized or unauthorized, and a previous one has been abandoned and/or plugged. The inspector should make note of this new condition and advise the system if they should report the new well to the State. A United States Geological Survey (USGS) 7.5-minute topographic quadrangle or similar map can be used to plot the location of the water sources. A GPS can be used to determine the precise location of a well.

The following assessment criteria are suggested for the location of source water facilities:

What is the flood level in the area of the source facility? Can the source facility be flooded?

The source water supply facilities should be able to operate at all times to produce safe, potable water to meet the customers' needs, regardless of the surrounding conditions, either man-made or natural. The source facility should be able to supply water to maintain an adequate pressure in the distribution system that, for safety purposes, would provide water for fire fighting, pressure to keep contaminants out, and meet the basic consumer necessities. If the source facility is flooded, the ability to supply water to satisfy these demands may be compromised. Therefore, the flood level and floor elevations should be checked to determine whether or not the facility can be flooded.

Has the source facility ever been flooded? If so, was the operation of the source facility impaired? If the source facility has been flooded and operation not impaired, what is the access to the source facility during a flood?

Depending on the design of the facility, portions of the plant could have been flooded, yet it was still able to produce potable water. In this situation, access to the source facility needs to be maintained to allow for the ingress/egress of personnel and equipment as needed.

4.2.5 Source Water Transmission

Untreated water travels from the source to the treatment plant through a transmission system of pipes. Some source water facilities are at a considerable distance from treatment facilities. The transmission lines present a potential opportunity for liquids and materials to both enter and leave the system. If the raw water is used before it receives treatment, it presents a sanitary risk and may be unsafe. If the transmission lines are not in good condition, they may allow contaminants to enter the raw water supply or may cause the supply to be interrupted. Transmission lines need to be assessed for sanitary risks during the sanitary survey. The inspector should travel along the raw water transmission lines and speak with the operators to verify information already obtained from maps and other records about the location of transmission lines, air release valves, pressure release valves, drain valves, and other pertinent information.

1 Suggested assessment criteria for the raw water transmission lines include:

2
3 **Do the transmission lines deliver all the raw water directly to the treatment plant?**

4
5 The transmission lines should not contain connections directly to any customers or to the
6 distribution system. The inspector should check for any connections that may deliver untreated
7 water to customers. If there are any connections to customers directly from the transmission
8 lines, the inspector should check if adequate treatment is being provided. If not, the inspector
9 should inform the system that the connections present a sanitary risk and should be removed.

10
11 **Are transmission lines in place that can bypass a treatment plant?**

12
13 If treatment is required, all raw water should be delivered to the treatment plant and
14 should not be able to bypass the plant. The transmission pipes should not contain any valves that
15 could be opened and permit bypassing. Closed valves are generally not considered sufficient to
16 prevent raw water from bypassing treatment. A physical disconnection of the pipe is more
17 appropriate.

18
19 **What are the age and condition of the transmission lines?**

20
21 If the system relies on a single transmission line, a failure of this line could leave the
22 system and consumers without water. The inspector should evaluate the potential for failure of
23 the transmission pipes. If they seem to be in poor condition due to age, deterioration, or natural
24 events (e.g., weather conditions, earthquakes), the inspector should assess the potential for
25 failure and subsequent interruptions to the water supply.

26
27 **Are the transmission facilities redundant?**

28
29 The inspector should evaluate whether the disruption of a single transmission line would
30 leave the system without water, and the potential for such a disruption. Under such
31 circumstances, the inspector should recommend additional transmission lines or an emergency
32 connection to another water supply.

33
34
35 **4.2.6 Site Security**

36
37 There are numerous ways the water supply for a system can be contaminated or
38 interrupted. A well's components can be tampered with or destroyed. A well pump can be
39 damaged or stolen. Contaminants can be intentionally or unintentionally introduced down the
40 well casing. Wellheads located near a parking lot or street can be damaged by traffic accidents.
41 During a sanitary survey, the inspector should review what security is in place to protect each of
42 the components of the water system. Where appropriate, the inspector should confirm that a
43 vulnerability assessment of the system has been completed and an emergency response plan has
44 been developed and is regularly exercised.

1 Suggested assessment criteria for evaluating security of the ground water source and its
2 facility include:

3
4 **Is the wellhead protected from vandalism and accidents?**

5
6 The location of the wellhead will dictate the measures required to protect it from
7 vandalism or physical damage. For instance, a security fence and structurally sound buildings
8 with locked doors and entry alarms would protect the wellhead from intentional vandalism.
9 Bollards around the well may be appropriate to protect it from traffic accidents.

10
11 **Is the area around the wellhead restricted in accordance with primacy agency rules?**

12
13 Typically, the wellhead is unmanned and may be visited once a shift or once per day.
14 Therefore, there may be no continuous means to observe all the activities around the wellhead.
15 Restricting access to the area with fencing and signs will limit the possibility of sabotage or
16 accidental contamination.

17
18 **Are transmission lines vulnerable to disasters or terrorism?**

19
20 Inspectors should evaluate whether transmission lines are exposed to potential destruction
21 due to terrorism or natural disasters. In those situations where tampering or destruction seem
22 more possible, the inspector should find out if the system has a plan for responding to such an
23 interruption of water.

24
25
26 **4.2.7 General Housekeeping**

27
28 The physical condition of the source facility can be a good indicator to the inspector of
29 how often the facility is visited and how well it is maintained. All critical facilities should be
30 visited by the operator frequently to determine that all equipment is operating correctly. If the
31 equipment appears to be in good condition, then the system places value on preventive
32 maintenance. However, if the equipment does not appear to be in good condition then the
33 system may not consider preventive maintenance a high priority. The system may have little
34 money available or allocated for maintenance or inadequate staffing levels to perform
35 maintenance.

36
37 Suggested assessment criteria for evaluating the housekeeping of the source and its
38 facility include:

39
40 **How often is the facility visited?**

41
42 Source facilities should be checked by system personnel frequently based on an
43 established schedule. The schedule should take into consideration the location and vulnerability
44 of the source, treatment provided at the source and historical problems with equipment or
45 vandalism.

1 **Does the facility appear to be well maintained – grass mowed, equipment**
2 **painted, facilities kept clean, etc.?**

3
4 The appearance of the facility does not directly impact the quality of the water, but it
5 does provide an indication of the overall amount of maintenance that the facility probably
6 receives.
7

8 9 **4.2.8 Cross Connections**

10
11 If the well has a blow-off or pump to waste piping the outlet should not be directly
12 connected to storm or sanitary sewers. The outlets of blow-offs and pump to waste piping should
13 be protected from flooding and backsiphonage.
14

15 16 **4.3 Treatment**

17
18 The types of treatment processes and facilities used to achieve safe drinking water are
19 dictated primarily by the quality of the source water and the regulatory requirements that must be
20 met. Typical ground water treatment processes often contrast sharply with treatment for surface
21 water sources, because surface water sources are more generally more vulnerable to
22 contamination by harmful microorganisms such as *Giardia* and *Cryptosporidium*. Therefore,
23 systems that use surface water sources or sources that are ground water under the direct influence
24 (GWUDI) of surface water usually require treatment methods that will physically remove
25 pathogens. Examples of these treatment methods include coagulation/flocculation,
26 sedimentation/clarification, and filtration processes. Additionally, disinfection is required to
27 inactivate any pathogens that are not physically removed.
28

29 Different than surface water or GWUDI of surface water, ground water systems often
30 have natural filtration through the aquifer material and contain little or no turbidity; therefore, the
31 physical removal steps noted above may not be necessary. On the other hand, ground water
32 systems may require treatment to comply with other regulatory requirements (e.g., lead and
33 copper, nitrate/nitrite, SOCs/VOCs (synthetic organic contaminants/volatile organic
34 contaminants), radiological contamination, etc.) or other aesthetic water quality contaminants
35 (e.g., iron, manganese, color, and/or taste and odor).
36

37 The sanitary survey inspector should evaluate all water treatment processes in use at the
38 water system. This evaluation should consider the design, operation, maintenance, and
39 management of the water treatment plant to identify existing or potential sanitary risks. Water
40 treatment facilities are the primary means of preventing unacceptable drinking water quality
41 from being delivered for public consumption. The treatment facilities and processes should be
42 capable of removing, sequestering, or inactivating physical, chemical, and biological impurities
43 in the source water and meeting MCL or treatment technique requirements.
44

45 For ground water systems, the regulatory requirements of the GWR and Stage 2 D/DBP
46 Rule place additional demands on the treatment facilities. While some ground water systems
47 will be installing disinfection as a corrective action to comply with the GWR, those and other
48 systems will be required to meet the Stage 2 D/DBP Rule's Initial Distribution Evaluation and

1 locational TTHM and HAA5 MCL requirements. Ground water systems with disinfection
2 already in place that are having difficulty complying with the Stage 2 D/DBP Rule should
3 evaluate current treatment prior to making adjustments to their disinfection practices that could
4 reduce the level of microbial treatment provided (See the *Stage 2 DBP Rule Operational*
5 *Evaluation Guidance Manual* and the *Simultaneous Compliance Guidance Manual for the Long*
6 *Term 2 and Stage 2 DBP Rules*). The treatment facilities and processes should be evaluated to
7 determine their ability to meet these regulatory requirements and to provide an adequate supply
8 of safe drinking water at all times, including periods of high water demand. A sanitary survey of
9 a treatment facility should

- 10
11 • Analyze all the distinct parts of the treatment process, including but not limited to
12 disinfection, chemical feed systems, hydraulics, controls, and residuals/wastewater
13 management.
- 14
15 • Identify features of the water treatment process that may pose a sanitary risk, such as
16 inadequate treatment, monitoring, or maintenance, lack of reliability, and cross
17 connections.
- 18


19 The inspector will need to review and consider specific regulations that apply to the
20 facility, design criteria, plant records, and past inspection reports that may identify previous
21 compliance problems, in addition to performing the actual inspection of the facility. The
22 following sections discuss specific portions of common treatment facilities that may be evaluated
23 during a sanitary survey inspection.

24 25 26 **4.3.1 Treatment Plant Schematic/Site Plan**

27
28 A schematic or site plan indicating the location of the treatment plant, type(s) of
29 treatment provided, and chemical injection points will enable the inspector to obtain a quick
30 understanding of the treatment type(s). If possible, the inspector should review any schematics or
31 site plans prior to the sanitary survey. The schematic/site plan should be drawn in enough detail
32 to facilitate the inspector's understanding of the treatment facilities.

33
34 Each treatment facility should be assigned a name and identification number.
35 Additionally, the schematic/site plan drawings should be dated to assist future inspectors in
36 identifying changes in the water system. The schematic/site plan drawings should be updated
37 during each subsequent sanitary survey to reflect any changes in the system.

Exhibit 4.5 Example Schematic Diagram of a Ground Water Treatment Plant



4.3.2 Capacity of Treatment Facilities

One of the initial steps for the inspector will be to determine the required capacity of the existing treatment facilities. The State primacy agency may have design standards that specify the capacity requirements for source water supplies and individual treatment units. The existing treatment facilities should be evaluated to determine if the capacity requirements are met.

The following are suggested assessment criteria to determine the adequacy of the treatment facility capacity:

What is the design capacity of the treatment units? What is the maximum daily demand of the system? Given the number of service connections and/or the population served by the system, is the capacity of the treatment facilities reasonable?

The design capacity for the treatment units can often be found in the operating records for the facility. Design and construction documents can also be used to determine capacity. If these records and documents are unavailable, the inspector will need to discuss with the system's operator the purpose of the treatment; the maximum capacity of the treatment units in relation to the system's peak demands; and whether adequate treatment is being provided. Based on this information, the inspector can draw conclusions on whether the treatment facilities can provide adequate treatment during peak demand periods, or whether expansion plans or upgrades should be considered.

1 **If the primacy agency has specific treatment unit capacity requirements, does the**
2 **system meet these requirements?**

3
4 Many primacy agencies have design standards and/or minimum requirements for the
5 capacities of major treatment units. The inspector will need to compare the system's existing
6 treatment capacity with those required by the primacy agency.

7
8 **Are the treatment facilities capable of meeting the required capacity with the largest**
9 **unit out of service?**

10
11 Treatment facilities will require maintenance, repair, and replacement from time-to-time;
12 therefore, redundancy should be provided that will allow the system to provide adequately
13 treated water during these periods. To ensure adequate capacity is available at all times, the
14 capacity of a major treatment process should be determined with the largest treatment unit out of
15 service.

16 17 18 **4.3.3 Chemicals and Chemical Feed Systems**

19
20 Chemical feed systems are common to many ground water treatment plants. These
21 systems can be used to feed treatment chemicals such as disinfectants, oxidizers, corrosion
22 inhibitors, pH adjustment chemicals, chemicals for sequestration, fluoridation, etc. The types of
23 chemicals that are used depend on the specific treatment facilities and the objectives of the
24 treatment processes. Types of chemical feed systems include liquid feed pumps and dry
25 chemical feed.


26 27 28 **4.3.3.1 Liquid Chemical Feed Systems**

29 A typical liquid chemical feed system would include:

- 30
31
 - 32 • Storage tank to hold the chemical solution;
 - 33 • A metering chemical feed pump with a suction line extended into the storage tank;
 - 34 • A discharge line with check valve and an injection valve at the point of application;
 - 35 and
 - 36 • A flow-switch to control the metering pump operation. If the flow switch is
 - 37 automatic, it must be tied to a flow meter or another control sensor.

38
39 A typical liquid chemical feed system is shown in Exhibit 4.6.
40
41
42
43
44

Exhibit 4.6 Schematic of a Typical Liquid Chemical Feed System



4.3.3.2 Dry Chemical Feeders (Volumetric and Gravimetric)

A typical dry chemical feed system would include:

- A volumetric or gravimetric feeder to meter the dry chemical;
- A mixing tank or solution chamber with a mixer; and
- A gravity discharge line to the point of application.

1 The following are suggested assessment criteria for chemical feed systems:

2
3 **What chemicals are in use? Are the chemicals in use approved for use in drinking**
4 **water?**
5

6 The surveyor should inspect chemical containers and discuss with the operator what type
7 of chemicals are used and their purpose. The inspector should check that the chemicals in use
8 carry the NSF or Underwriters Laboratories (UL) markings to ensure the chemicals used
9 conform to all applicable requirements of NSF Standard 60: Drinking Water Chemicals—Health
10 Effects. Treatment plant operators may be using compounds are chemicals that are not approved
11 for drinking water (e.g., household bleach in place of NSF approved sodium hypochlorite).
12

13 **Are the chemicals in use appropriate for the water system?**
14

15 The inspector should discuss with the operator and assess whether the chemicals used in
16 treating the water are appropriate. Water systems may purchase and use chemicals that are not
17 appropriate for their existing plant or treatment objectives (e.g., the operator may be convinced
18 by a sales person the chemical product should be used at the plant, when this product may not be
19 appropriate for the system's water treatment objectives).
20

21 **What are the chemical dosages—minimum, average, and maximum? Are the**
22 **chemical feed facilities appropriately sized for the dosages in use?**
23

24 The inspector should ascertain whether the treatment plant has the capacity to apply the
25 appropriate amount of chemicals at peak demand periods. Often, having chemical feed systems
26 sized to deliver one hundred and fifty percent of maximum is recommended as a rule-of-thumb.
27

28 **Where is each chemical applied?**
29

30 The inspector should examine chemical feed points and note where and how the
31 chemicals are added, whether the feed points are active or for standby, whether the points of
32 application are appropriate, and whether the feed points allow for chemical compatibility. Some
33 chemicals may counteract each other if not properly applied (e.g., if the system was introducing
34 an oxidant (chlorine) prior to the application of chemicals used for sequestration of iron and
35 manganese. In this instance, the chlorine would oxidize the iron and manganese before the
36 sequestering chemicals could work to keep the iron and manganese soluble in the finished
37 water.) As noted earlier, these points of chemical application should be noted on the system site
38 plan or schematic.
39

40 As a general rule, the inspector should know the application points and feed rates of all
41 chemicals used in the system's treatment plants. The purpose of the chemicals must be
42 understood so that the appropriateness of the feed locations and rates can be evaluated. This may
43 require the inspector to perform research on the chemicals the system uses either before or after
44 the sanitary survey.
45

What type of chemical feed equipment is used? What is the condition of the chemical feed equipment? Is chemical feeder redundancy provided?

The inspector should note the type of chemical feed equipment in use and its ability to feed chemicals on a continuous basis. The equipment must be functional and properly maintained. For example, with dry chemical feeders the inspector should watch for problems with “bridging” of the chemical in the hopper. Liquid feeder lines should be checked to see that they are not clogged. Redundant equipment should be provided and should be of sufficient capacity to replace the largest chemical feed unit. The inspector should determine if there is a preventative maintenance program in place and should examine repair records and the system’s supply of the spare parts and/or redundant equipment.

Is the chemical feed equipment calibrated, and how does the operator determine the amount of chemicals used?

Calibration should be completed each time a new batch of chemicals is used. The feed equipment feed rate should be checked at least daily. One method of checking is to use a graduated cylinder to verify the feed rate on a weekly or monthly basis (e.g. “pump catch”)

Is backflow prevention provided on the water lines used for chemical feed makeup?

All lines supplying water for chemical feed makeup should be equipped with backflow prevention devices or an air gap to prevent cross-connections and the potential contamination of potable water.

Is the chemical feed system flow paced?

Pacing the chemical feed pump with flow can be accomplished by a 4-20 mA signal from a flow recorder, or the system may be tied directly to a pump so that the feeder is activated each time the pump is operated and there is flow in the line. However, when the chemical feeder is tied to a pump, it is very important that some type of flow sensing device be used as a fail safe. The chemical feeder should not be allowed to come on until there is a flow in the pipe. Without flow control it is possible for a pump motor starter to engage and not start the pump. If the signal that engaged the starter also starts the chemical feed system, then highly concentrated chemicals can be fed into the line and received by a customer.

What type of chemical storage facilities are provided? Is the storage area for each chemical adequate and safe? Is secondary containment provided? Are incompatible chemicals stored together?

The chemical storage area capacity should be adequate to allow space for free access for loading and unloading of chemicals. A minimum 30-day supply for chemicals is recommended. The bulk storage facility should have indicators for chemicals storage levels. The storage containers should have a convenient method for determining the amount of chemical in each container. The storage facility should have safeguards against accidental spills, and like every other treatment space, should have a clean water source under high pressure and a drain for effective cleaning and decontamination. In the case of some gaseous chemicals, like chlorine, special ventilation equipment and the availability of Occupational Safety and Health Administration (OSHA) approved breathing apparatus may be required. Breathing equipment

1 and other personnel safety equipment and gear should be stored outside the storage area where
2 the equipment can be safely accessed. Incompatible chemicals should be stored separately (e.g.,
3 gasoline for maintenance equipment, strong acids should not be stored near chlorites). The
4 chemicals storage and the storage facility itself should be located so as to not allow a chemical
5 spill to reach the raw water source, the treated water, or water being treated. In addition, every
6 container in the storage area should be labeled and every storage area should be labeled to
7 identify what chemicals supposed to be stored in it.

8
9 **What is the condition of the building/room where the chemicals and chemical feed**
10 **equipment are stored? Is adequate ventilation provided?**

11
12 The inspector should check to ensure that the interior of the building housing the
13 chemicals is kept clean and dry. The general condition of the building housing the chemicals is
14 an indicator of the maintenance standards at the facility. Spills of chemicals can cause unsafe
15 conditions and/or increase corrosion within the building. Adequate ventilation, heating, and air
16 conditioning are important in maintaining the sanitary integrity of the building. Equipment used
17 for controlling and removing dust and vapors should be functional and effective.

18
19
20 **4.3.4 Disinfection**

21
22 The practice of water disinfection has proven to be one of the most important advances in
23 reducing the incidence of waterborne disease. In this regard, disinfection is an important
24 corrective action alternative for the GWR. Disinfection is the process of destroying or
25 inactivating a large portion of the microorganisms in water, with the probability that all
26 pathogenic bacteria or viruses are destroyed or inactivated in the process.

27
28 Chlorination is the most common disinfection method used by water systems in the
29 United States, because of its proven effectiveness, low capital and operating costs, and its
30 established history in the water industry. Free chlorine provides a high level disinfection at the
31 point of application and a measureable residual in the distribution system

32
33
34 **4.3.4.1 Dosage and Residual**

35
36 **Dosage:** The total amount of chlorine fed into a volume of water by the chlorinator is the
37 dosage. This value is correctly calculated in milligrams per liter (mg/L); however, mg/L and
38 parts per million (ppm) are generally interchangeable in water treatment calculations.

39
40 **Demand:** Chlorine is a very active chemical oxidizing agent and combines readily with
41 certain inorganic substances that are able to oxidize (e.g., hydrogen sulfide, ferrous iron,
42 manganese, and nitrite), organic impurities, and organic nitrogen compounds. These reactions
43 use or consume some of the chlorine, and the amount that is used is called the chlorine demand.
44 The reaction time between chlorine and most organic compounds is long (hours to days);
45 therefore, the demand is based on time (i.e., the measurable demand at the end of 20 minutes is
46 less than the measurable demand at the end of one hour of contact, due to the amount of time the
47 chlorine has to react with the organic compounds).

1 **Residual:** Residual is the amount of chlorine present in the water after a specified period
2 of time and is measured in mg/L.


3
4 **Chlorine demand (mg/L) = Chlorine Dose (mg/L) - Chlorine Residual (mg/L)**

5
6
7 **4.3.4.2 Chlorine and Water**

8
9 Regardless of the form of chlorination – chlorine gas or hypochlorite – the reaction in
10 water is essentially the same. Chlorine mixed with water will produce two general compounds,
11 HOCl (hypochlorous acid) and OCl⁻ (hypochlorite ion). The measurement of these compounds
12 is called **free chlorine residual**. If organic or inorganic compounds, especially nitrogen
13 compounds, are available, the HOCl will combine with these compounds to produce chloramines
14 and/or chloro-organic compounds. The measurement of the presence of these compounds in
15 water is called the **combined chlorine residual**.

16
17 **Breakpoint Chlorination:** As stated previously, chlorine will react with inorganic and
18 organic compounds in natural waters. The chlorine will immediately react with (oxidize) iron,
19 manganese, and nitrites. These chemicals are reducing agents (i.e., substances that are oxidized),
20 and no residual can be formed until all of the reducing agents are oxidized. As more chlorine is
21 added, the chlorine will begin to react with organic matter and ammonia to form chloro-organic
22 compounds and chloramines, resulting in the combined chlorine residual mentioned previously.
23 With the addition of more chlorine, the residual will decrease due to the oxidation of chloramines
24 and chloro-organic compounds until chloramines reach a minimum value. Beyond this
25 minimum point, the addition of more chlorine produces an increasing amount of free residual
26 chlorine. This process is called **breakpoint chlorination**. While this process destroys most of
27 the nitrogen compounds, it does not destroy all of them. Those that remain combine with the
28 chlorine to produce what is called the **irreducible combined residual**.

Exhibit 4.7 Breakpoint Chlorination Curve



Free chlorine + Combined chlorine = Total chlorine: For many systems, this results in a residual in the distribution system that includes free and combined residuals. The measurement of both of these residuals together is called the **total chlorine residual**. The combined residuals are the primary contributors to taste and odor problems in a system. Below is a table that shows the threshold of odor of various residuals. It is apparent that free chlorine and monochloramine (NH_2Cl) are likely to produce fewer taste and odor complaints. Note, however, that there is a maximum residual disinfectant level (MRDL) standard of 4 mg/L for chlorine.

Compound	Threshold of Odor
Free HOCl	20 mg/L
Monochloramine (NH_2Cl)	5 mg/L
Dichloramine (NHCl_2)	0.8 mg/L
Nitrogen trichloride (NCl_3)	0.02 mg/L

Taste and Odor Considerations: As seen in the table above, taste and odor complaints primarily result from combined residuals that are formed after enough chlorine is formed to produce dichloramines (NHCl_2) and nitrogen trichloride (NCl_3). If a system has a problem with chlorine taste and odor complaints, it is often recommended that the operator measure both free and total chlorine residuals. As a rule of thumb, if the free chlorine residual is less than 85 percent of the total, the odor and taste problem is a result of combined residuals. This problem may be resolved in two ways:

- Remove the precursors that cause the combined residuals; or

- Increase the chlorine dosage. There may be an insufficient quantity of chlorine (pound to pound with the organics) to oxidize the organic compounds sufficiently to avoid the problem.

Germicidal Effectiveness: It is commonly agreed that a free chlorine residual of HOCl and OCl⁻ are much more effective as a disinfectant than a combined chlorine residual. Additionally, the HOCl portion of the free chlorine residual is approximately 100 times more effective as OCl⁻ as a disinfectant. The factors important to the germicidal effectiveness of chlorine are:

- Concentration and Contact Time;
- Water Temperature;
- Water pH; and
- Substances in the water

Concentration and Contact Time: The effectiveness of chlorination and its ability to destroy or inactivate pathogens is directly proportional to the concentration of chlorine multiplied by the time the chlorine is in physical contact with the organisms. That is if the concentration of chlorine is decreased, the contact time must be increased for chlorine to retain the same germicidal effectiveness. Similarly, if the contact time is decreased, the chlorine concentration must be increased for chlorine to be effective. To determine if disinfection is adequate to destroy pathogens, the GWR requires 4-log treatment of viruses using existing CT tables. CT is measured in milligram-minutes per liter (mg-min/L) and is calculated as follows:

Disinfectant residual concentration in mg/L (C) X contact time in minutes (T) = CT in mg-min/L

In order to obtain primacy for the GWR, a State must explain the process it will use to determine that a ground water system achieves at least 4-log treatment of viruses. Many States will use CT as the foundation for making that determination with respect to disinfection. Appendix A provides a more detailed explanation of CT and how it should be calculated for GWSs.

Water Temperature: Other factors being equal, chlorine is more effective as a germicide at higher water temperatures. At lower temperatures, the destruction of pathogens tends to happen at a slower rate.

Water pH: The pH of water determines the ratio of HOCl to OCl⁻. HOCl is the dominant residual at lower pH, while OCl⁻ is the dominant residual at higher pH. This is noteworthy, because ground waters often have a relatively high pH, resulting in OCl⁻ being the dominant residual. And as stated above, OCl⁻ is much less effective as a germicide than HOCl.

Substances in Water: Chlorine is only effective if it comes in contact with the organisms to be destroyed; therefore, substances in the water (e.g., sand, dirt, or other impurities) can “hide” or protect pathogens from contact with the chlorine and reduce the germicidal

effectiveness of the chlorine. In ground water, this is an issue with systems that pump sand or have other impurities in the water, and removal of these substances may be required for effective chlorination.

The following are suggested assessment criteria for assessing chlorine dosages and residuals:

Does the operator understand the disinfection process?

The operator should be knowledgeable about the disinfection process and the facilities used at the treatment plant to provide adequate disinfection treatment. The lack of knowledge by the operator of the disinfection process and the equipment is an indicator that equipment failure or other problems may not be resolved in a timely manner.

Have there been any interruptions in disinfection? If so, why?

The inspector should assess if there were any interruptions in disinfection and ascertain what steps have been taken to prevent further interruptions.

What disinfectant residual is maintained?

Records of disinfection residuals leaving the plant and in the distribution system (if applicable) should be checked. In addition to verifying that there is a proper residual, determine if the equipment and testing methods are adequate.

Is the contact time between the point of disinfection and the first customer adequate?

As stated previously, the contact time is the interval in minutes (T) that elapses between the time when chlorine is added to the water and the time when that same slug of water passes by the sampling point. A certain minimum period of time, depending on disinfectant residual concentration (C), water temperature and other factors, is required for completion of the disinfecting process. The requirements for contact time (T) and disinfectant residual concentration (C) depend on the pH, temperature and flow rate of the water. These records are especially important if the system is required to meet the 4-log virus inactivation requirements of the GWR.

Are the temperature and pH of the water at the point of chlorine application measured and recorded daily?

The CT value required for proper inactivation of viruses depends on the pH and temperature of the water. Therefore, some ground water systems may be required to take these two measurements regularly and perform CT calculations at peak hourly flow. The pH must be measured with a meter, not with litmus paper or a color comparitor, and the temperature must be measured with a calibrated thermometer.

The following sections discuss gas and liquid chlorination in more detail. Brief explanations of the processes and equipment used for each of these disinfection methods are

described, and potential deficiencies are characterized. Readers are encouraged to refer to Appendix A for more information on disinfection and removal technologies.

4.3.4.3 Gas Chlorination

Equipment used to feed gas chlorine is designed to work either under pressure or under a vacuum. A *vacuum-operated solution feed chlorinator* is by far the most common of the two types of gas chlorinators. The vacuum-operated chlorinator will only feed chlorine gas when the equipment receives a vacuum signal. The gas is mixed with water to form a highly concentrated solution that is fed into the water at the point of application. The *pressure-operated gas feed chlorinator* is the other type of chlorinator and this equipment operates under pressure supplied by the gas and feeds to the point of application. The vacuum operated solution feed chlorinator offers greater safety in operation of the equipment and in the handling of the chlorine gas; additionally, these units provide for greater versatility in the application and control of the chlorine dosage.

The easiest way to tell the difference between a remote vacuum system and a pressure system is to observe the line leading from the cylinder to the chlorinator. If this line is metal, the system uses gas under pressure between the cylinder and the chlorinator. If the line is plastic, the system is a remote vacuum system. Gas is under a vacuum between the cylinder and the chlorinator.

Gas chlorine is provided in 100 pound and 150 pound cylinders, one ton containers, and tank cars (55 to 90 tons). These values are the net weight of liquid chlorine in the container.

With gas chlorination, the inspector will need to focus on the reliability and adequacy of the system to provide disinfection. It should be noted, however, that there are significant dangers involved with gas chlorination systems. Gas chlorine is classified as a poison gas and an inhalation hazard by OSHA, EPA, and Department of Transportation (DOT); therefore, review of safety procedures and inspection of safety equipment is necessary.

Typical Gas Chlorination Facility: The drawing below shows the key points of a gas chlorination facility. In general, these include:

- Containment of the chlorine, should there be a release or leak;
- Air treatment system so that the exiting air does not exceed 50 percent of the PEL (15 ppm is 50 percent);
- Gas leak alarm system;
- Crash bars on doors;
- Negative pressure in the room when the air treatment system is operating;
- Overhead sprinkler system with a 20-minute capacity;

- Containment of the air treatment system and sprinkler water;
- Emergency power for the air treatment system;
- Booster pump to provide pressure to the injector; and
- Scales to weigh the cylinders.

The sanitary deficiencies related to Chemical Feed Systems and Disinfection earlier in this chapter should also be applied to this section. The following are additional suggested assessment criteria for gas chlorination facilities:

How are leaks detected? At what detection concentration are automatic detectors set and have they been tested recently? Is the sensor tube for the automatic detector near the floor level, and is it screened?

Automatic chlorine leak detectors should be tested at least monthly. This can be accomplished by placing a small pan of bleach under the air intake and adding some vinegar.

Are there any cross-connections in the chlorine feed make-up water or injection points?

All service water to operate injectors/eductors should be protected by an appropriate cross-connection control device.

Is there an alarm tied to interruptions in the chlorine feed?

If there is an alarm system, does it work? Low system vacuum and low cylinder pressure are the two most common alarm systems, and the inspector should ask what would initiate an alarm. Does the alarm shut down the flow of water or just alert the operator of a malfunction?

Does the system use automation, pace with flow, chlorine residual analyzer, or other system to adjust feed rates? Does it work?

The inspector should determine whether the system provides adequate residual during high flows and whether the residuals are higher during low flows. It is common to find automatic equipment that does not work.

Is there more than one cylinder, and are they manifolded with an automatic switch-over to prevent running out of chlorine?

The inspector should determine whether the switch-over devices work. If there is only one cylinder, determine if the operator shuts off water flow when the cylinder is changed. If not, then there is an interruption of disinfection.

1 **Are the cylinders on a working scale?**

2
3 A scale must be used in order to determine the amount of chlorine used each day. In
4 order to calculate dosage and signal the amount of chlorine remaining in the cylinders, scales
5 must be maintained and calibrated and kept in working order. Scales often are not working due
6 to excessive corrosion caused by chlorine, and the inspector should determine if new scales are
7 needed.
8

9 **Are the tanks in use a quarter turn open with a wrench in place for quick turnoff?**

10
11 Full feed of 40 pounds per day can be obtained from a cylinder by opening the valve one
12 quarter of a turn. It is not necessary to open the valve more than what provides the needed flow.
13 By only opening it one quarter of a turn and leaving the wrench in place, the operator can
14 quickly shut the cylinder down if there is a release.
15

16 **Are all cylinders properly marked and restrained to prevent falling?**

17
18 Cylinders should be marked and stored in a manner that clearly indicates which cylinders
19 are full and which are empty. All cylinders must be restrained two-thirds of the way from the
20 bottom with a chain that prevents falling. In an earthquake zone they must also be restrained at
21 or near the bottom.
22

23 **Is the proper concentration of ammonia available to test for leaks?**

24
25 Use a concentrated ammonia solution containing 28 to 30 percent ammonia as NH_3 (this
26 is the same as 58 percent ammonium hydroxide or, HN_4OH , commercial 26° Baume).
27 Household ammonia is not strong enough to provide reliable indication of a chlorine leak.
28

29 **What procedures are followed during cylinder changes and maintenance? Has the**
30 **utility provided detailed training on handling and changing cylinders?**

31
32 Check to see if there is a written standard operating procedure (SOP) for maintain
33 changing cylinders. If not, then there are opportunities for disinfection interruptions as well as
34 safety concerns.
35

36 **What is the operating condition of the chlorinator?**

37
38 Gas chlorinators should be disassembled, cleaned, and rebuilt each year. An observation
39 of the rotameter can provide a clue as to the frequency of cleaning. If it is coated on the inside
40 with a heavy green or blackish film, the machine is past due for cleaning.
41

42 In addition, general appearance can also be a key. Check preventative maintenance and
43 repair records, and determine that preventative maintenance is routinely performed. Some
44 indicators of problems for gas chlorination would be valves, piping, and fittings that are
45 damaged, badly corroded, or loose; no gas flow to the chlorinator; or frost on tank, valves or
46 piping.
47

1 **Is redundant equipment available, and are there adequate spare parts?**

2
3 Disinfection must be continuous. Therefore, standby equipment of sufficient capacity to
4 replace the largest unit is recommended. Where standby equipment is not available, flow to the
5 water system should be halted, and critical spare parts should be on hand for immediate
6 replacement. At a minimum, the system must have spare diaphragms and a set of lead gaskets.
7 (Lead gaskets should not be reused.)
8
9

10 **4.3.4.4 Liquid Hypochlorination**

11
12 Many facilities have switched to the use of hypochlorination as a safer and easier method
13 of disinfecting water than gaseous chlorine. The primary disadvantage to liquid chlorination is
14 the increased annual operating cost over gas systems; however, as a result of new safety and
15 environmental regulations, the cost of using chlorine gas has continued to rise, making the
16 hypochlorination systems more common. Systems using hypochlorite should list it in their
17 hazardous materials inventory and have written procedures for handling, using and responding to
18 spills.
19
20

21 **4.3.4.5 Typical Liquid Chlorine System**

22
23 There are two forms of hypochlorite that are used in a liquid chlorine system; sodium
24 hypochlorite (liquid) and calcium hypochlorite (solid). Sodium hypochlorite is more corrosive
25 and degrades over time. The rate of loss of sodium hypochlorite depends on the strength of the
26 chemical and the temperature. The chemical deteriorates faster at higher concentrations and
27 warmer temperatures. If sodium hypochlorite is used, the inspector should determine the amount
28 on hand and its age. Sodium hypochlorite is also corrosive so equipment should be corrosion
29 resistant and checked frequently for signs of corrosion.
30

31 Calcium hypochlorite is more stable than sodium hypochlorite. It is not as soluble,
32 however, especially in hard water. Calcium hypochlorite also frequently contains abrasive
33 material that can lead to more wear on pumps and valves.
34

35 The following are suggested assessment criteria for liquid chlorine systems:

36
37 **Is the disinfectant chemical used appropriately certified?**

38
39 Chemicals introduced into drinking water should be certified as meeting the standards of
40 NSF 60 or an equivalent standard. This certification ensures that no impurities are present that
41 could cause health problems in the consumers of the water.
42

43 **What is the strength of the chemical feed solution?**

44
45 In order to achieve the proper dose of chlorine the strength of the solution must be
46 known. The operators should be familiar with procedures for preparing and testing the solution
47 and determining the dose.
48

1 **Is chemical storage adequate and safe?**

2
3 It is recommended that systems have a 30 day supply of chemicals on hand to prevent
4 running out of chemicals and losing disinfection capability. Chemicals should be stored so that
5 they are safe. Hypochlorite is a strong oxidizer and should be kept away from any combustibles,
6 especially petroleum products. Liquid storage should have spill containment around it. Proper
7 safety equipment such as showers, eyewashes, and respirators should be available.
8

9 **Is equipment operated and maintained properly?**

10
11 Failure of the feed equipment could result in loss of disinfection. Therefore all
12 equipment should be well maintained with a regular preventative maintenance schedule. Feed
13 lines should be checked regularly to make sure they are not clogged. Clear plastic lines should
14 be replaced if they become opaque. Pump valves, control valves, and injection valves should be
15 replaced at least once a year.
16

17 **Is standby equipment available?**

18
19 If a feed pump fails, the system can lose disinfection capabilities. Therefore, the system
20 should have at least one backup feed pump. If a valve fails, the system can lose disinfection
21 capabilities. Therefore, a system should have adequate spare parts on hand to be able to quickly
22 replace any valves in the chlorine feed system.
23

24 **What is the pump model? Stroke and speed settings?**

25
26 The operator should be familiar with the type and model of the chemical feed pumps.
27 Positive displacement pumps should be used. Chemical feed pumps generally have adjustable
28 speed and stroke length that help to determine the feed rate. The pump should be able to deliver
29 the maximum required dose at 85 percent of its maximum speed. Stroke rates should be kept
30 within the manufacturer's specified ranges.
31

32 **Where are they storing their feed solution?**

33
34 The feed solution should be stored in a covered, chlorine resistant tank. It should be in a
35 dry clean area and have the appropriate spill containment surrounding it.
36

37 **How do they make up the chlorine feed solution?**

38
39 The operator should be familiar with the process for mixing the chlorine feed solution.
40 Proper safety equipment should be used for preparing the solution including gloves and goggles.
41

42 **Is the chlorine feed manually or automatically adjusted for flow?**

43
44 Disinfectant dose will need to be varied depending on flow rate. This can be done either
45 by manually adjusting the pump or it can be done by hooking the pump to a flow sensor that
46 adjusts pump rates in proportion to the measured flow rate in the pipe (flow-paced). Chemical
47 feed should not be turned on if there is no flow. The operator should be familiar with calculating
48 the required chlorine dose based on flow and determining if the pumps are delivering sufficient
49 dose.

Are proper cross connection controls in place for the make-up water?

If finished water is used to provide water for chlorine injection , make up water, or preparation of chlorine feed solutions, there must be proper cross connection controls to prevent backflow of the raw water into the finished water lines. This means providing a sufficient air gap if a hose or faucet is used, or installing the appropriate backflow prevention devices if the line is piped into the feed facility. Exhibit 4.8 illustrates an appropriate air gap between a water feed line to a chlorine solution tank and the chlorine solution in the tank.

Exhibit 4.8 Example of an Air Gap on a Chemical Feed System



Air gap between
water feed and
chlorine solution

4.3.4.6 Typical Defects

Equipment Calibration

Ensuring proper disinfection requires that the equipment used to determine the required dose and to measure disinfection efficiency be in proper working order. This includes equipment such as scales, flow meters, feed pumps, turbidimeters, pH meters, chlorine meters, and temperature gauges. If this equipment is not calibrated regularly, adequate disinfection cannot be guaranteed. A good practice is to calibrate chemical feed equipment whenever a new batch of

chemicals used. Frequent verification of pump feed rate “pump catches” should be part or regular operator duties.

Adequate Instrumentation and Controls

There needs to enough instrumentation to provide all the information an operator needs to determine the proper dose is being delivered. These include flow meters, chlorine residual analyzers, and turbidimeters. In addition these instruments must be properly calibrated and in working order. The operator should be able to explain calibration procedures for each instrument and be able to explain how the results of the measurements are used.

Storage

Storage should be located in a clean dry location away from other incompatible chemicals such as petroleum products. Proper spill containment should be included around liquid storage facilities. A supply of 30 days of chemical should be on hand at all times.

4.4 Distribution System

The purpose of the distribution system is to convey potable drinking water from the source to the consumer. A typical water distribution system consists of water mains (usually metal, plastic, or concrete), various types of control valves, service lines which connect customers to the water mains, meters, and fire hydrants. Many systems include finished water storage and pumping stations to increase system pressure or to fill storage facilities. Some distribution systems are equipped with booster disinfection.

Opportunities are plentiful for contamination of potable water in the distribution system before it reaches the consumer. Maintenance activities can expose the system to harmful pathogens. Water system materials themselves can be prone to failure and in some cases can even leach contaminants into the water. Cross connections and improperly constructed or maintained valves can contribute to deteriorating water quality. In addition to external contamination, water quality can naturally degrade in the system as the chlorine residual decreases and bacteria counts increase.

This section provides guidance for conducting sanitary surveys of water distribution systems. Note that guidance for surveying finished water storage and pumps are provided in Sections 4.5 and 4.6, respectively.

The scope of the distribution system survey depends greatly on system size, age, and extent of documentation of infrastructure as well as operations and maintenance programs. Because the majority of it is buried, the distribution system survey is more of a paper review and interviews rather than a visual inspection. The inspector should ask for and review system schematics, operation and maintenance records, standard operating procedures, construction standards, and distribution system water quality data. The field portion of the survey should include a visual inspection of a valves, meters, and backflow prevention devices which are owned maintained by the water system. For larger systems, the inspector may want to select a representative number of each type of valve and backflow preventer (BFP) for the visual inspection.

4.4.1 Distribution System Mapping

Accurate mapping enables the water system to quickly respond to breaks and other unexpected events. Accurate mapping also helps the system plan for future improvements and/or expansion. Typical distribution system components that should be shown on maps include main water lines, service lines, water meters, blow-offs, fire hydrants, and valves.

Suggested assessment criteria for the distribution system mapping include:

Does the system have an up-to-date map of the distribution system showing all major features?

The water system should have an up-to-date distribution system map(s) showing the location and size of all pipelines, valves, blow-offs, service connections, and fire hydrants. The map should also show pressure zone boundaries, interconnections to other systems, water storage facilities, pumping stations, and booster disinfection stations. Systems may use one map to show all major features, or several maps that can be overlaid to give a complete picture of the distribution system. The inspector should check the date of the last map revision (this may be included in the title block or map key). Maps should be updated regularly to document changes or additions to the system.

Are as-built drawings available?

As-built drawings are scaled, construction drawings that show the exact location of facilities. Accessible as-built records help the water system to perform repairs in a timely manner.

Does the system have many dead end water lines?

Dead end lines can result in increased water age and subsequent deterioration of water quality through loss of chlorine residual. In addition, areas served by dead end lines are susceptible to complete water loss in the event of a break or other maintenance problem. Water system lines should be looped wherever possible.

Is the water system interconnected to another system?

Interconnections can provide an alternative water source in the case of emergencies.

Are chambers or manholes containing valves, meters, or other appurtenances prone to flooding?

The inspector should visually inspect valves and meters in the distribution system to evaluate their condition and determine if they are prone to flooding. The inspector should also inquire if the water system has a regular program for visual inspections of valves and other appurtenances located in manholes or pits. If a valve or meter is submerged, non-potable water may enter the distribution system in the event of a pressure drop. Additionally, standing water in a meter pit can accelerate corrosion. Whenever possible, chambers or manholes containing valves, meters, or other appurtenances should not be located in areas subject to flooding.

1 **Are blow-offs connected to sanitary or storm sewers?**

2
3 A direct connection from a blow-off to a storm or sanitary sewer is considered a cross
4 connection and public health hazard.
5

6
7 **4.4.2 Distribution System Pipe Material and Condition**

8
9 The major component of a water distribution system is buried piping. Pipe material
10 should be strong enough to withstand internal water pressure and be non-corrosive. Typical
11 piping materials for water distribution systems include:
12

- 13 • Cast iron;
- 14
- 15 • Ductile iron;
- 16
- 17 • Asbestos cement;
- 18
- 19 • Steel;
- 20
- 21 • PVC- pressure class pipe;
- 22
- 23 • Wood; and
- 24
- 25 • High-density polyethylene (HDPE)
- 26

27 The inspector should review data on pipe material and age for the entire water system.
28 Distribution system piping should meet NSF standard 61 or equivalent.
29

30 Older water systems in particular can experience a high frequency of water main breaks
31 and a high volume of leakage in the distribution system. The inspector should request
32 information on the frequency of water main breaks over the last five to 10 years. The inspector
33 should also ensure that the water system has a standard procedure for recording information on
34 water main breaks, including date and location, type of leak or break, pipe type, pipe depth, and
35 soil condition. The inspector should also request information on estimated water loss in the
36 distribution system and gather information on any kind of leak detection activities.
37

38 Suggested assessment criteria for distribution system material and condition include:
39

40 **Does the system have PVC pipe manufactured before 1977?**

41
42 Pre-1977 PVC pipes contain elevated levels of a vinyl chloride monomer, which are
43 prone to leaching (Permeation and Leaching Issue Paper, USEPA 2002).
44

1 **Does the system contain water service lines made of Polythylene (PE) or Poly**
2 **butylene (PB)?**

3
4 These types of pipes are prone to permeation by diesel and petroleum products
5 (Permeation and Leaching Issue Paper, USEPA 2002).

6
7 **Does the system contain any steel pipe that is more than 35 years old?**

8
9 Steel pipe is typically given a design life of 35 years (USEPA 2003), and can deteriorate
10 more rapidly if the ground is wet and/or of the soil is acidic. Pinhole leaks in steel pipes can
11 increase water loss and provide a potential pathway for contamination

12
13 **Does the system contain lead service lines?**

14
15 If the water is corrosive, lead service lines can leach a significant amount of lead into the
16 drinking water. If a water system exceeds the Federal Action Level for lead after installing
17 corrosion control and/or source water treatment, it is required by the Lead and Copper Rule to
18 replace at least 7 percent of lead service lines per year. In most cases, the water system is
19 responsible for the portion of the service line prior to the water meter.

20
21 **Does the system keep records on water main breaks? How many water main breaks**
22 **does the system typically experience in one year?**

23
24 Water main breaks can result in low or negative pressure in the distribution system and
25 cause backflow events at unprotected cross connections. Water main breaks increase water loss
26 and risk of contamination during repair procedures. Systems should periodically review water
27 main break history to determine if there symptomatic problem in a portion of the system or with
28 one type and/or age of water pipe.

29
30 **Does the water system have a leak detection program?**

31
32 Detecting and repairing leaks is important not only from a water efficiency standpoint,
33 but also to protect public health. The USEPA Distribution System White Paper, “The Potential
34 for Health Risks from Intrusion of Contaminants into the Distribution System from Pressure
35 Transients” notes the following:

36
37 *Efforts to reduce distribution system pipeline leakage are beneficial not only from a*
38 *water conservation standpoint, but also to minimize the potential for microbial intrusion*
39 *into potable water supplies. Leaks are not simply a loss of revenue for a water utility, but*
40 *the leak is a potential pathway for contamination. The public health benefits of leak*
41 *control should be recognized and encouraged. Repair of leaking sewer lines should*
42 *similarly be a top priority, not only to minimize the occurrence of pathogens near*
43 *drinking water pipelines, but to reduce these sources of contamination being transported*
44 *to groundwater supplies and receiving streams, particularly under wet weather*
45 *conditions.*

46
47 Water systems should have a system for estimating leaking on an annual basis, an annual
48 goal for amount of water loss, and a response program if that goal is not met. Typical goals range

1 from 10 to 20 percent depending on age of the system, length of pipe, topography, and other
2 factors.

4 Does the system have a cleaning and lining or pipe replacement program?

6 Water systems should have a plan in place to replace and/or clean and line aging water
7 pipe. Large systems may have capital improvement or asset management plans. This is
8 particularly important for systems that experience a high frequency of main breaks or high water
9 loss in the distribution system.

12 4.4.3 Location and Maintenance of Valves

14 Valves are a critical component of the distribution system. Isolation valves allow for
15 routine maintenance or emergency repairs of distribution system piping. Altitude valves maintain
16 storage tank levels and other control valves are used for pressure and hydraulic control in
17 distribution systems. Common valves are described below.

- 19 • **Isolation valves** are used to isolate a portion of the distribution system for repairs.
20 Gate and butterfly valves are the most common.
- 22 • **Air valves** are used to expel air pockets from within pipelines, which can increase
23 flow and reduce pressure. Typical kinds of air valves are air relief, air release, and air
24 vacuum valves.
- 26 • **Pressure reducing valves (PRV)** are used to reduce or maintain pressure in a portion
27 of the system.
- 29 • **Altitude valves** provide for automatic filling of tanks and reservoirs.

31 Accurate records and diligent valve exercising and maintenance can minimize service
32 disruption and water quality impacts from main breaks and emergencies.

34 Suggested assessment criteria for location of valves include:

36 Are valves inventoried and accurately located on distribution systems maps or in 37 another form (i.e. GIS)?

39 Accurate inventories and locations allows for rapid response and reduced service
40 disruption in the event of a main break or other emergency. Some utility valve programs include
41 marking the valve box so that it can be easily located in the field.

43 Are there enough valves to isolate distribution system zones and storage and 44 pumping facilities?

46 The inability to isolate a pressure zone or storage facility in an emergency can lead to
47 supply pressure losses and water quality degradation in larger parts of the distribution system.

1 The American Water Works Association (AWWA) publication “Criteria for Valve Location and
2 System Reliability” (2007) should be considered as a reference.

3 4 **Are isolation valves maintained and exercised on a regular basis?**

5
6 Maintenance and exercise helps ensure that valves will remain operational and that
7 damaged or inoperable valves are repaired or replaced. Generally, valves in the system should
8 be operated through a full cycle (closed then opened to the original position) at least once per
9 year. Larger systems may prioritize valve maintenance and exercise to ensure that more critical
10 valves receive frequent attention. Large valves that are prone to breakage may need special
11 procedures. Maintenance should include any manufacturer recommended maintenance (e.g.,
12 repacking seals) and cleaning out the valve box or pit.

13 14 **Does the system maintain records of valve maintenance and exercise programs?**

15
16 The system should record maintenance activities for each valve in their system. Records
17 should include the number of turns needed to open and close the valve and the date that the valve
18 was exercised.

19 20 **How does the system confirm operation of automatic PRVs?**

21
22 The failure of a PRV to reduce pressure can result in water main or service line breaks. If
23 the system has automatic PRVs, the inspector should confirm that the devices are working
24 properly. One way to do this is to check the pressure upstream and downstream of each PRV.
25 The downstream pressure should be lower. If it is not, ask the system operator to open a fire
26 hydrant downstream and observe the reaction of the pressure across the valve.

27 28 **Are valves in confined spaces?**

29
30 Large valves are often in vaults, which are considered confined spaces. If operators need
31 to enter a confined space to observe or operate the valve, they should follow a written confined
32 space entry procedure and use gas monitoring equipment. Inspectors should not enter confined
33 spaces during the survey without confined space training and proper equipment.

34 35 36 **4.4.4 Design and Construction Standards**

37
38 The use of design and construction standards ensures that distribution system pipes and
39 appurtenances will operate effectively. Design and construction standards typically specify
40 minimum pipe size, design flow, fire flow, location of water pipe relative to other utilities
41 (particularly sanitary sewers), right-of-way limits, valve selection and design, fire hydrants,
42 meters, pipe material, minimum cover or depth of bury requirement, and installation
43 requirements. An important component of the design standard is a requirement to disinfect new
44 water lines before placing them into service.

45
46 Water systems may have their own, in-house standard or may refer to construction and
47 design standards published by AWWA or the Great Lakes – Upper Mississippi River Board
48 (GLUMRB) of State and Provincial Public Health and Environmental Managers (commonly
49 referred to as “Ten States Standards”). NSF standard 61 is commonly referenced by water

1 systems. This standard applies to products that come into contact with drinking water including
2 pipes, fittings, and valves. Inspectors should verify that a system is following an NSF
3 certification program or equivalent for new construction of distribution system components. The
4 AWWA publication, “Design and Construction of Small Water Systems” (1999) can provide
5 additional information for inspections of small systems.
6

7 Many States have their own design and construction standards. Sanitary survey
8 inspectors should obtain a copy of State standards before going into the field.
9

10 Suggested assessment criteria for design and construction standards include:
11

12 **Does the water system have a design and construction standard?** 13

14 Many large water systems develop their own design and construction standards. If the
15 State also has a standard, the inspector should verify that the water system’s standard is
16 consistent with and at least as protective as the State standard. The design standard should
17 require that distribution system materials are NSF certified or equivalent.
18

19 **Is the standard being followed?** 20

21 The inspector should ask the system how it verifies that design and construction
22 standards are being followed by both in-house staff and contractors. The system should visually
23 inspect pipes and appurtenances prior to installation. Qualified water system personnel should
24 periodically inspect construction activities. To check that the design standard is being
25 followed, inspectors can compare the current standards to a set of blueprints for recent
26 construction.
27

28 **Are pressure and leak tests performed on all new pipe construction?** 29

30 Pressure tests check the integrity of the piping material following installation. Leak tests
31 check the integrity of the pipe joints. Both are recommended by Ten State Standards (2003).
32 The inspector should review the construction standards to determine if these tests are required for
33 new pipe construction.
34

35 **Are pipes stored with protective caps?** 36

37 When pipes are uncovered, they can easily be contaminated with mud, debris, and rain
38 water. The inspector should determine if the water system requires protective caps for on-site
39 storage of water pipe.
40

41 **What method is used to disinfect new water lines? How does the water system 42 ensure that contractors are following this procedure?** 43

44 Systems should require contractors and in-house staff to disinfect new water lines using
45 the procedure outline in AWWA Standard C651-99, “Disinfecting Water Mains” (2005) or
46 equivalent. The system should meet all State requirements for disposal of highly chlorinated
47 water. Systems should require a negative bacteriological test result before the main can be
48 placed into service.
49

4.4.5 Maintaining Adequate Pressure

Maintenance of positive pressure in the distribution systems is an important step in preventing distribution system contamination. Pressure is a function of pipe elevation, water levels within storage facilities, pump settings, and friction losses inside pipes and appurtenances. Many distribution systems are divided into distinct pressure zones which are typically served by individual storage facilities and/or pumping stations. Pressure zones are often identified by a range of operating pressure in units of pounds per square inch (psi) or feet of water.

Suggested assessment criteria for operating pressure include:

Does the system regularly measure pressure in the distribution system?

Pressure in the distribution system varies due to changes in water system demand, tank levels, and pump settings. Water systems should periodically measure and record system pressure at key points in their distribution systems (typically points of lowest and highest elevation). Large systems may use alarms to notify them if pressure drops below a certain level. The frequency of pressure monitoring depends on the size and complexity of the system. At minimum, pressure should be measured when chlorine residuals are measured and in response to customer complaints of low pressure.

What are the maximum and minimum pressures in the system? What is the range of normal operating pressure?

Distribution systems should generally operate between 50 and 80 psi. Excessive pressure (greater than 100 psi) may damage consumer facilities and plumbing fixtures. The inspector should determine if the State requires a minimum operating pressure (35 psi is typical) and if so, check that the system is always operating above this minimum. System pressure should be at least 20 psi at all points in the distribution system and at all flow conditions. Pressures below 20 psi can render that portion of the system vulnerable to backflow at unprotected cross connections, which is serious health concern.

Does the system receive complaints of inadequate pressure?

Customer complaints of inadequate pressure could indicate a problem in the distribution system.

Does the system operate to minimize pressure surges?

Pressure surges can cause water main breaks and potential intrusion of pathogens where there are minor leaks or holes in the system. General strategies to reduce pressure surges include slow valve closure times, avoiding check valve slam, use of surge tanks, pressure relief valves, and air valves.

4.4.6 Response to Water Main Breaks

Water main breaks are due to many factors, including freezing and thawing cycles, corrosion, and soil conditions. Water main breaks open the system to contamination, and frequent breaks increase the potential for introducing waterborne pathogens into the system. Although they cannot be entirely avoided, systems should strive to minimize the number water main breaks.

Suggested assessment criteria for response to water main breaks include:

Are there written procedures for isolating portions of the system and repairing mains?

Written emergency procedures can reduce the time it takes to isolate a water main break and make repairs. For a small system, a written plan is very useful for when the regular operator is not available.

Are adequate repair materials on hand?

The system should have on hand sufficient quantities of disinfectant, repair sleeves, and other materials needed to repair water main breaks.

What disinfection procedure is used during pipe repairs?

It is critical that systems have a standard procedure for disinfecting and flushing repaired water lines. The procedure should conform to AWWA standard C651 or equivalent and should include the following:

- Sprinkling disinfect in the area surrounding the break;
- Swabbing fittings, pipes, and clamps with chlorine; and
- Flushing the line to remove any sediment.

The procedure should include information on safe handling and disposal of disinfectants. Bacteriological testing should be required and should show negative results before the water main is placed back into service. The water system should provide adequate training and follow-up to ensure that maintenance personnel are following the standard procedure.

Does the water system maintain a list of critical customers?

Certain customers, such as hospitals and clinics, can be severely impacted by reduced or shut off water service. The water system should have a list of such customers and should have plans in place to notify those customers of planned or emergency service changes.

4.4.7 Flushing Programs

Routine flushing of the distribution system has many benefits. Flushing can remove accumulated sediment and stagnant water from the system and can reduce disinfectant demand of pipe surfaces. Flushing can also be used to reduce excessive water age at dead ends.

Flushing programs are typically conventional, unidirectional, emergency, or some combination thereof. Conventional flushing is achieved by opening hydrants in the distribution system to remove stagnant water. Unidirectional flushing involves a carefully planned program to move water in one direction through a pipe by closing valves and opening hydrants. Unidirectional flushing achieves higher velocities than conventional flushing and is thus more effective at scouring water mains to remove corrosion products and biofilm. Water systems also often employ spot or emergency flushing in response to a water quality complaint or sampling result that is outside of normal operating parameters.

Suggested assessment criteria for flushing programs include:

Does the water system have a procedure to flush the distribution system on a regular basis?

Most systems should operate hydrants on a regular basis to flush the distribution system. Typical programs strive to flush the entire system in one to three years. Systems should develop a flushing program that meets their specific needs. For example, conventional flushing may be adequate for small systems with plastic piping. Unidirectional flushing programs may be more appropriate for larger systems with a history of biofilm growth and corrosion of cast iron water mains. Larger utilities should consider a targeted flushing program that employs more frequent flushing in areas that routinely experience water quality degradation over time (i.e., increased bacterial activity).

Does the water system keep up-to-date records on flushing activities?

The water system should keep records on which portions of the distribution system are flushed each year. Water quality data should also be recorded and evaluated on a regular basis to assess the effectiveness of the program.

4.4.8 Water Quality Monitoring

Water quality monitoring in the distribution system is an essential part of regular operations. Water systems monitor to comply with various drinking water regulations and may also conduct supplemental monitoring to track of water quality changes in their system. Most systems are required to collect a minimum number of samples for bacteriological quality under the TCR and to assess corrosion in the distribution system under the Lead and Copper Rule. Surface water and GWUDI of Surface Water systems must demonstrate that they are maintaining a detectable disinfectant residual in the distribution system.

Monitoring requirements depend on system size, source water (ground, surface, or GWUDI), and type. PWSs have the most requirements, with typically less monitoring required for NTNCWS and TNCWS. Because States may require additional monitoring compared to

1 Federal rules inspectors should thoroughly review State compliance monitoring requirements
2 before going into the field.
3
4

5 **4.4.8.1 Maintaining a Residual**

6

7 Under the GWR, systems that provide 4-log inactivation of viruses with a chemical
8 disinfectant and do not perform triggered monitoring (or that provide 4-log virus inactivation
9 with a chemical disinfectant as a corrective action) must monitor for and maintain a minimum
10 disinfectant residual (set by the State) at or before the first customer. Some PWSs may also
11 maintain a disinfectant residual in the distribution system or be required by State regulations to
12 maintain a disinfectant residual in the distribution system. Suggested criteria for assessing
13 disinfectant residual maintenance include:
14

15 **Does the system meet State requirements for disinfectant residual monitoring and** 16 **reporting?** 17

18 The inspector should ensure that the system collects the required number of samples for
19 disinfectant residual monitoring and that results meet minimum State requirements. The
20 inspector should also check that monitoring results are reported to the State on a regular basis.
21

22 **Are measurements throughout the system?** 23

24 Sampling locations should be located throughout the distribution system. At least one site
25 should be in the expected area of lowest residual (typically oldest water) to help ensure that a
26 residual is maintained elsewhere.
27

28 **Is there a standard procedure for measuring disinfectant residual in the field?** 29

30 The inspector should review the standard procedure for chlorine residual measurement.
31 Instructions for sample tap flushing and collection, reagents, and method should be checked. The
32 inspector should confirm that the field instruments are calibrated as recommended by the
33 manufacturer.
34

35 **Are operators regularly trained on this procedure?** 36

37 The water system should have a program to provide refresher training to current samplers
38 on a regular basis and comprehensive sampling training for new staff.
39

40 **What is the disinfectant residual level at the time of the field survey?** 41

42 The inspector should consider collecting and analyzing one or more samples for
43 disinfectant residual during the field portion of the survey. Results should be checked against
44 utility data to evaluate for potential method or data management problems.
45
46

4.4.8.2 Bacteriological Quality (TCR)

All CWSs are required to take a minimum number of samples under the TCR. Smaller systems may sample once per month, while larger systems typically sample at multiple locations throughout their distribution system. Many systems also sample for heterotrophic plate count (HPC) to assess bacteriological water quality. Suggested assessment criteria for bacteriological monitoring include:

Do TCR sample sites represent water quality throughout the distribution system?

Total coliform samples must be collected at sites throughout the distribution system according to a written sample siting plan. The inspector should review the plan to ensure that it meets State requirements.

Does the system collect at least the minimum number of required samples?

The inspector should compare recent sample results to State requirements to ensure that the system is collecting and analyzing the right number of samples per month.

Are systems using an approved method for TCR sample collection and analysis?

The system should have a written procedure for collecting and analyzing total coliform samples. The procedure should include instructions for disinfecting the tap and flushing the water for several minutes to clear out stagnant water from the internal building plumbing system. Samplers should use appropriate bottles and should wear gloves during sampling. The inspector should check that the samples are kept refrigerated, do not exceed maximum holding time requirements prior to analysis, and are analyzed using an EPA-approved method. The system should also have a program to regularly train samplers on proper procedures.

Does the system follow repeat sample requirements?

The TCR requires all systems to collect repeat samples if a routine sample is total coliform or fecal coliform positive. Repeat samples must be collected within 24 hours of learning of the routine positive results. At least three repeat samples must be collected, one at the original location, one within five connections upstream of the original locations, and one within five connections downstream of the original location.

Does the system experience a high number of total coliform positives or high HPC counts?

Frequent total coliform positives or high (greater than 500) HPC results may indicate a problem in the distribution system. If this is the case, the water system should be actively trying to address the problem.

Has the system had an E.coli or fecal coliform positive sample in the last several years?

A fecal coliform or E. coli positive sample followed by a repeat positive sample is considered an acute violation of the TCR and considered a serious public health threat. The

1 system should be able to explain the cause of any recent E.coli or fecal coliform positive sample
2 and should have made changes to system operation or maintenance to minimize the chances of
3 contamination occurring in the future.

4
5 **Has the system followed up all TCR-positive samples with source water fecal**
6 **indicator samples as required by the GWR?**
7

8 Any GWS that does not provide 4-log (99.99%) treatment of viruses is required to
9 respond to a TCR-positive sample by collecting fecal indicator source water samples at all
10 sources in use when the TCR-positive sample was collected. The inspector should confirm
11 during the sanitary survey that the appropriate source water samples were collected.
12

13
14 **4.4.8.3 Other Water Quality Parameters**
15

16 Depending on the system's water quality and treatment, the sanitary survey inspector
17 should review additional distribution system monitoring that is either required or conducted
18 voluntarily because it benefits the system's delivery of safe and potable water. Some additional
19 distribution system monitoring issues to consider during the sanitary survey include:
20

- 21 • Is the system collecting samples according to its Stage 1 D/DBP monitoring plan?
- 22
- 23 • Is the system on track with meeting its requirements for the Stage 2 D/DBP Rule's
- 24 IDSE?
- 25
- 26 • Are lead and copper samples being collected correctly? Additional water quality
- 27 parameter testing due to compliance with the Lead and Copper Rule?
- 28
- 29 • If the system uses chloramines is it monitoring nitrification parameters (i.e., nitrate,
- 30 nitrite, ammonia, HPCs)?
31

32
33 **4.4.8.4 Customer Complaints**
34

35 Customers are sensitive to changes in water quality. While sampling is an excellent tool
36 for monitoring water quality, customers are typically the first to notice an unexpected change.
37 The inspector should review historical records documenting the nature of the complaint, the
38 investigation report, and response. Suggested assessment criteria for customer complaints
39 include:
40

41 **Does the system keep records of customer complaints and investigation reports?**
42

43 Customer complaints can alert the system to a water quality issue in the distribution
44 system. Common complaints include red or rusty water, which could be associated with
45 corrosion of cast iron mains, cloudy water, and chlorinous odor. Some States require systems to
46 record the nature of and response to all customer complaints. Large systems should consider
47 mapping customer complaints to proactively address problems.
48

1 **Do frequent or repeat customer complaints indicate a water quality problem?**

2
3 The water system should address repeated customer complaints in a specific area of the
4 distribution system through operational changes or manipulating water quality at the treatment
5 plant.
6

7
8 **4.4.9 Cross Connection Control**
9

10 Plumbing cross-connections, which are defined as actual or potential connections
11 between a potable and non-potable water supply, constitute a serious public health hazard. There
12 are numerous, well-documented cases where cross-connections have been responsible for
13 contamination of drinking water, and have resulted in the spread of disease. All municipalities
14 with public water supply systems should have cross-connection control programs. Those
15 responsible for institutional or private water supplies should also be familiar with the dangers of
16 cross-connections and should exercise careful surveillance of their systems. (USEPA 2003).
17

18 In conducting sanitary surveys of non- community water systems the inspector should
19 note cross connections and the need for protection during the field survey and make the
20 owner/operator aware of the cross connection and the need for protection. Areas of special
21 concern in non-community water systems include auxiliary non- potable water supplies,
22 irrigation and fire suppression systems, chemical or waste processing and manufacturing
23 processes. Some non-community water systems may also have very complex plumbing systems
24 (factories, food processing, power plants) and detailed inspections by a cross connection
25 specialist would identify needed protection.
26

27 In conducting sanitary surveys of community water systems the inspector should review
28 the program with PWS personnel or ask for contact information if the program is managed by
29 another agency. Items to be addressed in a review of the cross connection program include:
30

31 *General*
32

33 Does the system have an active cross-connection control program?
34

35 How is the program administered? (In house, by contract with the water supplier
36 (wholesaler), coordination with a local agency or by another authority?)
37

38 *Ordinance or Rules of Service*
39

40 Has the system adopted an enforceable cross-connection control ordinance or rules of
41 service?
42

43 Are users who are in noncompliance with the cross-connection ordinance or rules of
44 service given written notice to make corrections? What procedures are used when corrections are
45 not made by users?
46

1 *Cross-Connection Surveys*

2
3 Has the system conducted a survey of users to determine specific cross-connection
4 control requirements and problems?

5
6 Are premises re-evaluated periodically for backflow hazards? If yes, what is the
7 procedure?

8
9 Are new services reviewed to establish the need for backflow protection? If yes, what is
10 the procedure and who is responsible for review?

11
12 *Backflow Protection Provisions*

13
14 How are bulk water users (hydrant meters, water tankers) addressed? Are hydrant meters
15 equipped with backflow devices and water tankers inspected?

16
17 How is backflow protection provided? (premise isolation, internal protection,
18 combination)

19
20 Who is responsible for installation of backflow devices?

21
22 If the user is responsible for installation of devices, is a list of approved backflow devices
23 provided?

24
25 Is the installation of approved backflow devices inspected to determine if they have
26 proper clearance, drainage, and security?

27
28
29 *Program Management*

30
31 Does the system (or the responsible authority) have personnel with expertise and
32 authority to conduct cross-connection surveys and to carry out the cross-connection control
33 program?

34
35 *Device Testing and Maintenance*

36
37 Are all backflow devices tested on an annual basis?

38
39 Who tests the backflow devices? (PWS, water user, other agency)

40
41 Who maintains the backflow devices? (PWS, water user, other agency)

42
43 Are follow-up inspections conducted to determine compliance with testing and
44 maintenance requirements?

45
46 Does the system (or someone else) maintain installation, inspection, and testing records
47 for devices?

4.5 Finished Water Storage

Finished or treated water storage facilities provide the following benefits to the operation of a distribution system:

- Allow treatment facilities to operate at or near uniform rates, even though the demands of the system may greatly fluctuate;
- Supply the peak and emergency needs of the system; and
- Maintain an adequate pressure in the system, when designed for that purpose.

Finished water storage facilities also serve an important function in maintaining the quality of drinking water ultimately received by the consumer. Proper design, operation, and maintenance of storage facilities are critical to protecting stored water from loss of chlorine residual, bacteria regrowth, contaminant entry, and other water quality problems.

The objectives of surveying the finished water storage facilities are to:

- Review the design and major components of storage to determine reliability, adequacy, quantity, and vulnerability;
- Evaluate the operation and maintenance and safety practices to determine that storage facilities are reliable;
- Recognize any sanitary risks attributable to storage facilities (UFTREEO Center, 1998); and
- Determine the potential for degradation of the stored water quality.

To accomplish these objectives, the inspector should complete the following tasks:

- Review the information available from State and water system files.
- Perform field inspections to verify the file information, to assess the tank's structural condition, operational readiness, site security and potential sanitary risks.
- Check that maintenance identified in storage facility inspections has been completed.
- Discuss current operation and maintenance (O&M) procedures with water system staff including safety procedures.

Safety is an important consideration in conducting field inspections of storage facilities. Potential safety hazards include confined space issues; exposure to lead during removal of lead-based coatings; falls or scrapes when climbing the tank; and insect bites. In some cases, the results of a recent inspection done by a qualified tank contractor may provide the inspector with the necessary information without climbing the tank. Some States do not allow their staff to climb water towers, so inspectors may need to rely on information from tank contractor

1 inspections, ground level observations, and conversation with water system operators to verify
2 file information and assess the adequacy and condition of storage facilities. Inspectors who are
3 expected to climb storage tanks as part of the tank inspection should receive written inspection
4 procedures and training in appropriate safety procedures (e.g., use of safety belts and cables).

5
6 Specific items to be addressed in the sanitary survey are outlined in the sections below.

7 8 9 **4.5.1 Storage Facility Inventory**

10
11 Before going into the field, the inspector should obtain the information available on all
12 the finished water storage facilities for the water system from the State's files, including the last
13 sanitary survey. The State information should include the type, location, age and installation
14 date, material of construction, storage volume, operating levels and controls. In addition, the
15 inspector should review applicable regulatory requirements and industry guidance.

16
17 Upon arriving at the facility, the inspector should review the available data with system
18 personnel to determine if the information is current. If there have been any changes, the
19 inspector should obtain an updated listing of finished water storage facilities, so that they may be
20 all inspected during the survey. The system may have historical records that can provide
21 additional information on storage facility design, construction, operation, maintenance and
22 current physical condition. These records may include as as-built construction drawings,
23 inspection reports, maintenance records, water quality data, sediment sampling data, operational
24 data and customer complaint records from the facilities' service area.

25 26 *Regulatory Requirements and Industry Guidelines*

27
28 **Design and Construction.** Recommended Standards for Water Works (2003) provides
29 suggested design criteria for tank storage capacity, siting considerations, tank appurtenances and
30 safety features.

31
32 **Operations.** Regulatory requirements pertaining to tank operations may include operator
33 certification requirements, water turnover rates, and emergency operating plans. There are no
34 specific Federal regulatory requirements on water turnover rates in storage facilities, but industry
35 guidance suggests that a complete water turnover be accomplished every 3 to 5 days (Kirmeyer
36 et al. 1999). Most States require that a water system maintain an emergency operations plan
37 which should include emergency operating procedures for storage facilities.

38
39 **Maintenance and disinfection procedures.** There are no Federal regulatory
40 requirements for tank maintenance or cleaning procedures. Many States recommend adhering to
41 AWWA Standards, NSF Standard 61, and Recommended Standards for Water Works (2003).
42 AWWA Standards and guidance that apply to finished water storage facilities include:

- 43
44 • C652 Disinfection of Water Storage Facilities;
- 45
46 • D100 Welded Steel Tanks for Water Storage;
- 47

- D102 Coating Steel Water-Storage Tanks;
- D103 Factory-Coated Bolted Steel Tanks for Water Storage;
- D120 Thermosetting Fiberglass-Reinforced Plastic Tanks;
- G200 Distribution Systems Operation and Management; and
- AWWA Manual M42 Steel Water Storage Tanks

Most States do not recommend a tank cleaning frequency; however some States provide guidelines such as “as often as necessary,” and “at reasonable intervals.” An AwwaRF guidance manual suggests that covered facilities be cleaned every three to five years (Kirmeyer et al. 1999).

Some States have environmental regulations that govern discharge of chlorinated water from storage facilities. Dechlorination of the water may be required prior to disposal.

Water Quality Monitoring. Federal drinking water regulations do not specifically require the utility to monitor water quality conditions within storage facilities. Most States do not require routine water quality monitoring within storage facilities, but some States require that water samples be free of coliform bacteria before a storage facility is returned to service after maintenance. Industry guidelines such as the AwwaRF guidance manual, *Maintaining Water Quality in Finished Water Storage Facilities* (Kirmeyer et al. 1999) recommend monitoring within the storage facility to assess stored water quality.

Safety. Several OSHA regulations apply to finished water storage facilities:

- OSHA Fall Protection Standards
(<http://www.osha.gov/SLTC/fallprotection/standards.html>)
- Lead Exposure in Construction (29CFR1926.62)
http://www.osha.gov/pls/oshaweb/owadisp.show_document?p_table=STANDARDS&p_id=10641
- Confined Space Rule (29 CFR 1910.146)
<http://www.osha.gov/SLTC/confinedspaces/standards.html>

Types of Finished Water Storage Facilities


There are several types of finished water storage facilities that can be categorized by their physical shape, dimensions and location.

Clearwells and Other Chlorine Contact Facilities – These storage facilities are usually considered to be part of the water treatment plant, and not distribution storage. Some utilities have storage facilities at or near the water treatment plant that serve both as storage and for achieving disinfection contact time.

Ground Storage Tanks – Ground storage tanks are used to reduce treatment plant peak production rates and are also used as a source of supply for re-pumping to a higher pressure level. If located at a sufficiently high elevation, a pumping station will not be needed and water can flow by gravity to the distribution system. Ground storage tanks can be below ground, partially below ground, or constructed above ground level in the distribution system. Concrete reservoirs are generally built no deeper than 20 to 25 feet below ground surface. Covered reservoirs may have concrete, structural metal, or flexible covers.

Elevated Storage Tanks - Elevated storage tanks are used to supply peak demand rates and equalize system pressures. The most common types of elevated storage are elevated steel tanks and standpipes. A standpipe is a tall cylindrical tank normally constructed of steel, although concrete may be used as well. It functions somewhat as a combination of ground and elevated storage. Only the portion of the storage volume of a standpipe that provides the required system pressure is considered useful storage for pressure equalization purposes. The lower portion of the storage acts to support the useful storage and to provide a source of emergency water supply. Many standpipes were built with a common inlet and outlet. Elevated tanks are generally located at some distance from the pump station in areas having low system pressures during high water use periods.

Exhibit 4.9 Elevated and Ground Storage Tanks




©Arasmith Consulting Resources
(Source: UFTREEO Center, 1988; Used with permission)

Hydropneumatic Tanks – Hydropneumatic pressure tanks are commonly used by systems serving fewer than 150 service connections. The main purpose of hydropneumatic tanks is to prevent excessive cycling of pumps. These tanks should not be used for fire protection. They contain a fixed volume of air that becomes compressed as water enters the tank. Once the pressure in the tank has reached a predetermined level (i.e. the cut-out pressure) the pump stops and the compressed air starts to expand while it pushes the water into the distribution system. As

1 the water leaves the tank, the pressure in the tank decreases until it reaches a point where the
2 pump will be triggered to start again (i.e. the pump-on level) and the cycle is repeated. The cycle
3 rate is the number of times the pump starts and stops in one hour (typically 10 to 15 cycles per
4 hour).

5
6
7 **Exhibit 4.10 Typical Hydropneumatic Tank Installation**
8



9 ©Arasmith Consulting Resources
10 (Source: UFTREEO Center, 1988; Used with permission)
11
12

13 **4.5.2 Capability and Capacity**

14 **4.5.2.1 Capability**

15 Water systems should have developed and implemented comprehensive programs to
16 operate and maintain finished water storage facilities. The existence of written procedures and
17 policies is especially important for storage facilities to facilitate inter-departmental
18 communications since personnel from several different departments may share responsibility
19 (e.g. operations, maintenance, engineering, laboratory). The sanitary survey inspector should
20 discuss the system's capability for proper operation and maintenance of their storage facility by
21 confirming the acceptability of the system's historical records and recordkeeping practices;
22 inspection program; standard operating practices; maintenance program; and safety program.
23
24

25 *Historical Records and Recordkeeping Practices*

26 *Inspection Program*

27
28 Storage facilities and the grounds surrounding them should be routinely inspected to
29 prevent water quality problems. It is recommended that water utilities have comprehensive
30 inspections of the structural condition of their storage facilities every 3 to 5 years, including
31 areas of the facility that are not normally accessible from the ground. A comprehensive
32 inspection should include a close evaluation of the condition of interior and exterior coatings,
33
34

1 foundation, ladder, vent, hatch, overflow pipe, screens, cathodic protection system, and the depth
2 of the interior sediment.

4 *Standard Operating Procedures*

6 Water utilities are encouraged to have written SOPs for operating their system under
7 normal and emergency conditions. SOPs are an effective way to prevent miscommunication
8 among staff responsible for different aspects of a system's operations and management. SOPs
9 usually include:

- 11 • System description with map;
- 13 • Facility descriptions;
- 15 • Water quality goals;
- 17 • Monitoring plan;
- 19 • Description of the operations procedures;
- 21 • List of responsible parties for each activity; and
- 23 • List of emergency contact people (Kirmeyer et al., 1999).

25 Excessive water age results from under utilization (i.e., lack of flow) and short circuiting
26 within the reservoir. Distribution system operations staff have two effective tools to reduce water
27 age: turn the water over on a routine basis and fluctuate the water levels widely (Kirmeyer et al.
28 1999). In addition to establishing a theoretical turn over rate (i.e. once in 3, 5 or 7 days); the utility
29 may need to establish a water level fluctuation approach that will turn over a majority of the water
30 in one continuous operation. This is especially true for storage facilities with common inlets and
31 outlets such as standpipes. Simply withdrawing 10% or 20% of the volume of a standpipe each
32 day and immediately refilling could still leave a major portion of storage volume stagnant or
33 poorly mixed for long periods. Thus, if feasible, it would be advisable to fluctuate the water level
34 more widely with a target withdrawal of 60% of the volume in one day and then refill it the next.
35 This must be balanced with the need to maintain adequate pressures and emergency storage.

37 *Maintenance Program*

39 Does the system keep operational and maintenance records for each tank including
40 cleaning and painting records, and disinfection procedures (per AWWA G200 standard)?

42 Has the water system established responsibilities and communication procedures regarding
43 finished water storage facility operation, maintenance, water quality etc.?

45 *Safety Program*

47 Does system follow OSHA and other safety standards for fall protection, confined space
48 and lead exposure?

Does the system have a written program and maintain appropriate permits for confined space entry?

Training Programs

Does system provide appropriate training for inspection and maintenance staff including training on OSHA standards, use of safety equipment, and handling of disinfection chemicals?

4.5.2.2 Storage Capacity

Storage tank capacities should be adequate to meet the water demands of the system, should meet applicable State requirements and industry standards, and be consistent with accepted engineering practice. For example, the total capacity of both ground and elevated storage tanks could be based on a recommended level of 200 gallons per connection. For elevated storage tanks alone, a recommended capacity of 100 gallons per connection is often used. For systems using hydropneumatic tanks instead of elevated tanks, recommended capacities are 20 gallons per connection with ground storage and 50 gallons per connection without ground storage. Capacities for pumps and pumping equipment associated with storage tanks are discussed in Section 4.6.

Suggested assessment criteria for the capacity of storage tanks include:

In case of elevated storage tanks, are tanks properly sized and elevated to assure adequate pressures throughout the distribution system?

The water tank should be properly sized and elevated to produce pressures of at least 35 psi at the lowest operating level of the tank. Operating pressures in the distribution system should not be allowed to exceed 100 psi.

Does the system have adequate storage capacity to meet fire flow requirements, emergency storage requirements, system pressures and other site-specific conditions?

For systems that do not provide fire protection, the minimum storage capacity should be equal to the average day demand or lower if source and treatment facilities have sufficient capacity and standby power to help meet peak demands.

For hydropneumatic tanks, the gross storage capacity should equal approximately ten times the largest pump capacity. For example, a 2,500 gallon tank would be advised for a system using a 250 gpm pump. The sizing of the hydropneumatic tank is also affected by chlorine contact time requirements and the system's ability to meet maximum demand conditions.

4.5.3 Design and Construction


The inspector should examine the design criteria of the storage tanks to assess their potential to meet the water demands of the distribution system and retain structural integrity.

1 Design and construction standards need to be appropriate for the intended use of a storage tank.
2 Most small systems use hydropneumatic tanks.
3

4 The series of standards used to design tanks with all the necessary components identified is
5 usually the AWWA D-100 series. The construction material for the tank should also be examined
6 for structural integrity as well as for any sanitary hazards. For example, opportunistic pathogens,
7 such as *Klebsiella* can grow to high levels in wooden storage tanks. Exhibit 4.11 provides a
8 schematic of the various components of a storage tank. The following is a listing of the minimum
9 criteria for a treated water storage tank, whether it is a ground or elevated storage tank:

- 10
- 11 • Roof sloped to prevent standing water;
- 12
- 13 • No leakage through the roof;
- 14
- 15 • A lockable access hatch on the roof, with a raised curb (ten States standards type);
- 16
- 17 • Vent on the roof with openings that face downward, with a fine corrosion resistant
- 18 screen;
- 19
- 20 • Water level measurement device;
- 21
- 22 • Overflow that terminates above ground with a hinged and weighted flap on the end;
- 23
- 24 • Inlet and outlet piping located to ensure proper circulation of water (most have a
- 25 single common line);
- 26
- 27 • Drain to remove accumulated silt from the bottom of the tank;
- 28
- 29 • Access openings on the side (at least 2);
- 30
- 31 • Access ladder with proper safety equipment;
- 32
- 33 • Valves on inlet and outlet for isolation;
- 34
- 35 • Bypass around the tank for maintenance;
- 36
- 37 • Control system to maintain water level in tank;
- 38
- 39 • Alarm system for high/low water levels; and
- 40
- 41 • Ten States standards type “Inverted U” screened vent.
- 42
- 43

Exhibit 4.11 Components of a Storage Tank



©Arasmith Consulting Resources
(Source: UFTREEO, 1998; Used with permission)


Suggested assessment criteria for the minimum design components for storage tanks include:

Does the tank have all the minimum components listed above? Are these components in good condition?

The inspection items listed above are important for maintaining the structural integrity of the tank, thereby minimizing contamination of the water.

The minimum design components for hydropneumatic tanks are significantly different than a ground or elevated storage tank. Hydropneumatic tank systems can use any of several types of pressure storage tanks. Exhibit 4.12 depicts the various types of pressure tanks available. Most small ground water systems use vertical tanks like the two on the right side of the exhibit.

Exhibit 4.12 Types of Pressure Tanks



©Arasmith Consulting Resources

Suggested assessment criteria for the minimum design components for hydropneumatic tanks include:

Are air/water interface or captive-air (bladder type) hydropneumatic or pressure tanks operating as designed?

Design features may include:

- Tank is located completely above ground.
- Tank meets American Society of Mechanical Engineers (ASME) standards with an ASME name plate attached.
- Access port for periodic inspections.
- Pressure relief device with a pressure gauge.
- Control system to maintain proper air/water ratio for the air/interface.
- Air injection lines equipped with filters to remove contaminants from the air line.
- Sight glass to determine water level for proper air/water ratio.
- Slow closing valves and time delay pump controls to prevent water hammer.

Does the tank have all the minimum components as required? Are these components in good condition? Is the tank capacity adequate?

The inspection items listed above are important for maintaining the structural integrity of the tank, thereby minimizing contamination of the water.

1 Additional criteria to consider during the sanitary survey when evaluating a water system's
2 tanks include:

3
4 **Does the system maintain adequate system pressure?**

5
6 **Is the storage system designed for direct plumbing or floating on the distribution**
7 **system?**

8
9 **Do any tanks operate below the system hydraulic grade line?**

10
11 **Do any tanks have stored water age > 7 days?**

12
13 **Are newly constructed facilities inspected and documented on as built drawings?**

14
15 **Are overflow, drain lines and air vents covered and screened to prevent**
16 **animal/insect entry? Are they turned downward and terminated at least 2 pipe**
17 **diameters above the ground?**

18
19 **Do tanks have design features that allow maintenance to occur?**

20
21 **Can the tanks be isolated from the system?**

22
23 **Is there a bypass line around the tank for maintenance?**

24
25 **Access openings on side of tank?**

26
27 **Separate drain to remove accumulated silt from the bottom of the tank?**

28
29 **Tank drain pipe allows tank to be drained without causing pressure loss in the**
30 **distribution system?**

31
32 **Accessible roof hatches?**

33
34 **Are access ladders equipped with proper safety equipment?**

35
36 **Do tanks have design features that prevent contamination from external sources?**

37
38 **All storage facilities covered?**

39
40 **Roof sloped to prevent standing water?**

41
42 **Is roof watertight? Are all pipe and equipment penetrations into the roof**
43 **watertight?**

44
45 **Roof hatches - locked; raised curb and a watertight seal.**

46
47 **Are access ladders inaccessible to the public?**
48

1 **Are valve pits vandal proof?**

2
3 **Ground level elevation of standpipes and reservoirs above the 100 year flood**
4 **elevation and placed at normal ground surface?**

5
6 **Drains and overflow pipe are not directly connected to sewers or storm drains?**

7
8 **Do tanks have design features that prevent degradation of water quality?**

9
10 **Inlet and outlet piping located to ensure proper circulation of water?**

11
12 **Is cathodic protection provided for steel tanks?**

13
14 **Has the installation of appurtenances including antennae completed without**
15 **damage to tank structure, coatings or water quality?**

16 17 18 **4.5.4 Site Security and Sanitary Risks**

19
20 The inspector should assess the site security of the water system to determine the potential
21 for intruder access. Any potable water storage tank should be enclosed by an intruder-resistant
22 fence with lockable access gates. In addition, all access hatches should be locked. The inspector
23 should assess the site security of the water system to determine the potential for intruder access.
24 To be intruder-resistant, the Texas Natural Resource Conservation Commission (TNRCC)
25 recommends that the fence around the storage tank be at least six feet tall with three strands of
26 barbed wire extending outward at a 45 degree angle, and be constructed of wood, masonry,
27 concrete or metal.

28
29 Suggested assessment criteria for site security include:

30
31 **Is the fence surrounding the tank site intruder-resistant?**

32
33 **Are access hatches locked?**

34
35 **Have there been any incidents at the system's storage facilities where site security**
36 **was breached, accidents occurred, or water quality was compromised?**

37
38 **Are there any tank sites with particular security or vandalism issues?**

39
40 **Do access manholes, buildings and any other structures have locked entry ways?**

41
42 **Are there any potential sanitary hazards within 50 feet of the storage tank (e.g.**
43 **sewers, drains, standing water)? If so, what and where are the hazards? (e.g. bird**
44 **droppings on tank roofs, evidence of insects or animal activity near vents, drain**
45 **pipes; evidence of unauthorized human access to site).**

46
47 **Are there any physical features on or around the site that could damage the tank?**
48

1 **Is the site well-maintained?**

2
3 **Is there adequate surface drainage around tank?**

4
5 **Is the site subject to flooding?**

6
7 **Are there any structural gaps in the storage facilities that would allow untreated**
8 **water or contaminants to enter the storage facility?**

10 11 **4.6 Pumps**

12
13 In addition to transporting water through the system, pump applications include chemical
14 feed systems, sludge removal, air compression and sampling (UFTREEO Center, 1998). For a
15 given application, there could be several viable pumping options. However, there are usually
16 only one or two types of pumps that will be the best fit for the intended use. In this section, the
17 prime movers of water will be discussed. There are numerous applications for other types of
18 pumps in other sections of this document.

19
20 The objectives of surveying the pumps/pump facilities and controls are to:

- 21
22 • Review the design, uses, and major components of water supply pumps;
- 23
24 • Evaluate the operation and maintenance as well as safety practices to determine that
- 25 water supply pumping facilities are reliable; and
- 26
27 • Recognize any sanitary risks attributable to water supply pumping facilities
- 28 (UFTREEO Center, 1998).

30 31 **4.6.1 Typical Pumps**

32
33 Before going into the field, the inspector should obtain the information available on all
34 the pumping facilities for the water system from the State's files, including the last sanitary
35 survey. The information on pumping facilities should include the type, location, age and
36 installation date, and design conditions of the system's pump(s), pumping facilities, and controls.

37
38 In addition, the inspector should review the regulatory requirements for pumps, if any, to
39 assist in the evaluation of the pumping facilities. The regulatory requirements could include, but
40 not necessarily be limited to, State rules and regulations, American National Standards
41 Institute/National Sanitary Foundation (ANSI/NSF) Standards 60 and 61, as well as appropriate
42 guidance manuals.

43
44 Upon arriving at the facility, the inspector should review the available data on pumps
45 with system personnel to determine if the information is current. If there have been any changes,
46 the inspector should obtain an updated listing of the pumps used within the system, so that they
47 may be all inspected during the survey. For most systems, the inspector will either have a list of
48 pumps or pump data from a previous sanitary survey or have a list supplied by the system

operator. If a system does not have a pump listing, the inspector should work with the system operator to develop a new listing so that all pumps may be inspected during the survey.

There are two main classes of pumps used in a water treatment facility. They are positive displacement pumps and centrifugal pumps. Positive displacement pumps deliver water at a constant rate regardless of the pressure it must overcome (USEPA 1991). Typical pumps that can be found in a treatment plant are:

- **Helical or Spiral Rotor Pump** – This pump consists of a shaft with a spiral surface that rotates in a rubber sleeve. Water is trapped between the shaft depressions and the sleeve and is forced to the upper end of the sleeve as the shaft rotates.
- **Regenerative Turbine Pump** – This pump contains an impeller or a rotating wheel with fins or little buckets on its outer edge. The rotating wheel is inside a stationary enclosure (cast). As the wheel rotates at a high speed, it forces water through the pump cast (also called raceway) at a pressure that is several times that which can be generated by centrifugal mechanisms (USEPA, 1991).
- **Reciprocating Pump** – This pump consists of a piston moving back and forth in a cylinder. As the cylinder is driven back and water is driven into the cylinder, the intake valve closes and forces the water through the check valve. As the cylinder is driven forward, the water is discharged through a discharge pipe while the check valve is closed (USEPA, 1991).
- **Positive Displacement Pump** – This pump is typically used for online chemical application (i.e., application of chemicals into pressurized water line).

Centrifugal pumps are used when an even flow rate is needed to meet the demands placed on it. The operating curve for a centrifugal pump shows that the pumping rate varies with the discharge pressure of the water at discharge from the pump (i.e., as the discharge pressure increases, the rate of pumping decreases).

With a rotating impeller (i.e., rotor blade) driven by a power source, such as a motor, a centrifugal pump increases the velocity of the water and discharges it into the pump casing. In the pump, the velocity of the water is converted to pressure. Typically, a centrifugal pump has only one impeller, and it is called a single-stage pump. If more pressure is needed, multiple impellers or multi-stages are used to generate the necessary discharge pressure at the pump. Multiple impellers only increase the discharge pressure, not the pumping rate (UFTREEO Center, 1998).

A centrifugal pump cannot create a negative pressure at the suction inlet to pull water into the pump, like a self-priming pump. Therefore, the pressure at the impeller must be positive (i.e., water level is higher than the impeller) in order for the pump to operate.

There are three types of centrifugal pumps that are normally used in a water system for the many pumping applications: submersible, vertical (lineshaft) turbine, end suction (close coupled) and split case. The most common application of each pump is provided in Exhibits 4.13 and 4.14 shows some of the types as well as the basic components of a centrifugal pump.


The three types of centrifugal pumps are described below:

- **Vertical Turbine Pump** – This is a multistage centrifugal pump. The pumping unit must be located below the drawdown level of the water source. A vertical shaft connects the pumping assembly to a drive mechanism located above the pumping assembly. The discharge casing, pump housing, and inlet screen are suspended from the pump base at ground surface.
- **Submersible Pump** – This is a centrifugal pump driven by a closely coupled electric motor constructed for underwater operation as a single unit.
- **End Suction and Split Case Pumps** – These are single-stage pumps. The end suction pump is a vertically split case pump, while the split case pump is horizontally split. The advantage of the split case pump over the end suction pump is that it is easier to open and repair. The advantage of the end suction pump is its lower cost.

Exhibit 4.13 Applications for Centrifugal Pumps

Application	Type of Pump
Well Pump	Submersible or vertical turbine
Raw Water Pump	Submersible or vertical turbine
Backwash Pump	Vertical turbine or split case
Transfer Pump	Vertical turbine, end suction, or split case
Finished Water Pump	Vertical turbine, end suction, or split case
Booster Pump	Split case or end suction
Sludge Pump	End suction
Backwash Recycle Pump	End suction

Exhibit 4.14 Common Centrifugal Pump Types and Components



©Arasmith Consulting Resources
(Source: UFTREEO, 1998; Used with permission)

Suggested assessment criteria for the types of pumps include:

What types of pumps are provided for the system?

The inspector should check the types of pumps used by the water system to ensure they are appropriate for the intended use. Typically, the pump selection is reviewed by the primacy agency at the time of installation; however, the inspector should confirm that the pump has not been replaced with another type of pump without approval from the primacy agency.

1 **Does the information in the files reflect the actual type, number, and capacity**
2 **of pumps in the system? If not, is there a potential problem?**
3

4 If the inspector finds that the actual type, number or capacity of the pumps is different
5 from the design that was approved by the primacy agency, then the inspector should note the
6 actual configuration for the sanitary survey report. The operators should be questioned as to why
7 and when the modification to the pumps took place, and advised to submit the revised plan to the
8 primacy agency for their review, if necessary.
9

10
11 **4.6.2 Number and Capacity**
12

13 The pump capacity or size required is typically dependent on the application or purpose,
14 as well as vulnerability of the pump(s). Typically, State rules will specify the sizing criteria for
15 each critical application. For example, Exhibit 4.15 provides the sizing criteria for different
16 pump applications used by the TNRCC for many water systems. These criteria are in general
17 agreement with standard engineering practice. However it should be noted that the criteria for a
18 PWS depend on the size and type of system. For example, 25 connections would require a 15
19 gpm pump.
20
21

22 **Exhibit 4.15 Pump Sizing Criteria**
23

Application	Sizing Criteria
Raw Water Pump	0.6 gpm per connection with the largest pump out of service
Backwash Pump	Dependent on filter size
Transfer Pump	0.6 gpm per connection with the largest pump out of service
Finished Water Pump	Two or more pumps that have a capacity of 2.0 gpm per connection, or that have a total capacity of at least 1,000 gpm and the ability to meet peak hourly demands with the largest pump out of service, whichever is less
Booster Pump	Two or more pumps that have a capacity of 2.0 gpm per connection, or that have a total capacity of at least 1,000 gpm and the ability to meet peak hourly demands with the largest pump out of service, whichever is less

24 (Source: TNRCC, 1997)
25
26

27 When designing or checking a pumping facility, the maintenance (preventative or
28 emergency) of the pumps should be anticipated. For instance, a system has two raw water
29 pumps, and each is sized to pump one-half the capacity of the water treatment facility. If one
30 pump has to be taken out of service for repairs, then the supply for this system is reduced
31 substantially. During the summer, when the peak demand typically occurs, this system may not
32 be able to meet that demand for a time, because of the repairs to the pump. During this time, the
33 system may experience pressure problems in the distribution system due to an inadequate supply,
34 which could lead to greater problems, such as backsiphonage. The number of pumps for any
35 application is an important consideration that cannot be overlooked. In general, there should be
36 at least two pumps (usually more) for any critical pumping application to allow for maintenance.
37

1 With two or more pumps, how should the capacity of a pump or pumping facility be
2 determined? The firm capacity of any pumping facility should be determined with the largest
3 pump out of service to ensure that adequate capacity is available to meet all expected
4 demand/supply conditions. The firm capacity of a pumping facility is the capacity that is
5 available at any time assuming any one pump is out of service for maintenance or repairs. The
6 total capacity of a pumping facility is the sum of the capacities of all associated pumps and is
7 larger than firm capacity.

8
9 Suggested assessment criteria for the capacity of pumps include:

10
11 **What are the capacities of the pumps? How many pumps are located at each**
12 **facility?**

13
14 The capacity of a pump is sometimes listed on the motor plate along with the horsepower,
15 motor speed and other pertinent information. The inspector should note the capacity or other
16 information provided on each pump and compare this information to the approved design for the
17 pump station. The actual capacity of the pump may be less than the rated capacity as a result of
18 wear or an increase in the operating head. Actual pump capacity can be measured if an accurate
19 flow metering device is installed on the pump discharge line.

20
21 **What is the firm capacity and the total capacity of each pumping facility?**

22
23 The inspector should confirm that the firm capacity of the pumping facility, or the
24 capacity of the facility with its largest pump out of service is consistent with the minimum
25 capacity approved by the primacy agency.

26
27 **Is priming adequate?**

28
29 The inspector should ensure that prime waters must not be of a lesser sanitary quality
30 than that of the water pumped. It should be ensured that there are adequate backflow prevention
31 devices. When an air-operated ejector is used, the screened intake should draw clean air from a
32 point at least 10 feet above the ground or other possible sources of contamination.

33
34 **Are the pumps compliant with State rules?**

35
36 If the inspector finds that the actual type, number, or capacity of the pumps is different
37 from the design that was approved by the primacy agency, then the inspector should note the
38 actual configuration for the sanitary survey report. The operators should be questioned as to why
39 and when the modification to the pumps took place, and advised to submit the revised plan to the
40 primacy agency for their review, if necessary.

41
42
43 **4.6.3 Routine Maintenance/Lubrication/Exercise**

44
45 The inspector should ask whether the system has a pump maintenance program and how
46 it is being implemented. Backup pumps should be exercised routinely and all pumps should be
47 operational. Pumps should be accessible so they can be properly maintained and repaired
48 without physically disrupting other elements of the water system. Most well houses will have a

1 hatch in the roof or a similar structural arrangement to provide access to the well in case the
2 submersible pump needs to be removed.

3
4 For any wells where contact is made with the water, food grade lubricants should be
5 used. Many States require lubricants used under such conditions (e.g., oi-lubricated well shaft
6 bearings, check valves) to be ANSI or NSF-approved. This is not usually a requirement for
7 lubricants that do not come in contact with the water. All lubricants should be applied according
8 to manufacturer's specifications.

11 **4.6.4 Housing**

13 Pumps are found in a variety of buildings including well houses, treatment plants and
14 booster stations. As part of the sanitary survey, these buildings should be inspected to ensure
15 they are providing secure physical protection to the pumps. A pumping station should be at least
16 three feet above flood level, and the land around it should be graded so that surface runoff drains
17 away from the building. Inside, floor drains should be able to accommodate a large volume of
18 water due to a pipe break in the building. Below-ground pump stations should be checked to
19 make sure they are dry and properly sealed so that water cannot seep through walls or enter from
20 the surface. Dry pits should include a sump and sump pump. Pump stations should be properly
21 ventilated and electrical controls and motors should not be subject to flooding.

24 **4.6.5 Site Security**

26 Pumping stations and well houses should be secure. Doors and windows should be
27 locked and no unauthorized entry should be allowed. Any electrical panels, switches and valves
28 located outside of the building should be secured and within a fenced perimeter.

31 **4.6.6 Cross Connections**

33 When pumps are being inspected during the survey, any situation where there is a
34 potential for backflow should be identified. Cross connections can be found in

- 36 • Water lubricated bearing systems,
- 38 • Pump seal water lubrication systems,
- 40 • Air/vacuum release discharge lines, and
- 42 • Priming lines for suction-lift pumps (USEPA, 2003).

44 Situations where there is the potential for backflow should be equipped with an air gap or
45 an approved backflow prevention device.

4.7 Emergency Power

During a sanitary survey, the inspector should consider whether a system needs auxiliary power to maintain a reliable source of potable water to its customers. Systems with auxiliary power units should be exercising them routinely, and operators should have a clear understanding of what the unit powers and how it is activated. The sanitary survey inspector should establish whether auxiliary power is triggered manually or automatically, and that the system has a reliable program in place for switching to the emergency power supply.

Suggested assessment criteria for evaluating emergency power include:

Is auxiliary power needed?

Auxiliary power may be necessary for the continuous operation of a water system. When assessing whether a system needs auxiliary power, consider how long the system can reliably continue to provide water when it loses power. Also consider how frequently the system loses power and the duration of power outages. Systems with limited storage may not be able to sustain water production for very long. Systems relying on pumps to move water to their distribution system may not be able to provide sufficient water and maintaining adequate pressure throughout their distribution systems.

How is it activated?

Auxiliary power should be automatically activated when the primary power supply is lost. There should be a switch that automatically transfers the load to the auxiliary power unit. An alarm should notify the operator when the auxiliary power unit is turned on. Although auxiliary power should be automatically activated, operators should have the capability of manually operating their generators.

Small ground water systems that do not have generators on site should, at a minimum, be able to hook up a generator quickly and safely. Pump houses or treatment plants can be wired so generators can be connected quickly at the time of the power outage. If such an arrangement is observed during the sanitary survey, information should be gathered about the location of the generator that would be used during an outage and the system's plan for responding and installing the generator in a way that does not result in interruption of service.

What does it supply power for?

The operator should know what steps of water production, treatment and delivery would be powered by emergency power in the case of a power outage. During the sanitary survey, the inspector should determine whether the quantity and quality of water needed by the system's customers could be maintained and for how long. In addition to the well pump, auxiliary power should operate any automatic controls and chemical feed systems related to the source that is being pumped. Lights, heat and ventilation in the pump house and treatment plant should also be provided with emergency power.

Where is the fuel tank?

The sanitary survey inspector should locate the fuel tank for the auxiliary power unit and evaluate if it presents a contamination risk to the well or water that is being stored before or after treatment. Fuel tanks that are stored above ground should be mounted inside a spill containment vessel.

Is the unit exercised?

Auxiliary power units should be exercised at least once a week with an operator in attendance (USEPA, 2003). It is preferred that the unit be tested under a load during the exercising period, using it as the source of power for any well, treatment and service pumps that would be powered by the unit under emergency conditions. The system should keep records of when and how the unit was exercised, including engine and generator gauge readings, and the inspector should review these records during the sanitary survey.

Is it well-maintained?

Regular maintenance of the auxiliary power unit should be provided according to its manufacturer's specifications. If the water system has a preventive maintenance program, the inspector should ask whether the unit is included in the plan. The inspector should visually check for signs of leaking fluids or lubricants. Any vents in the building housing the unit should be screened to prevent animals from entering and to maintain security. The unit should not be accessible to the public.

4.8 Remote Monitoring/Control/Alarms

Many water systems have some element of remote signaling or operation. Often, a pressure transducer in a storage tank relays a signal that turns the well on or off when the tank level reaches a set level. Some alarms with automatic dialing systems notify operators under emergency conditions. More and more, plants equipped with SCADA systems are being operated remotely.

The sanitary survey inspector should understand the roles of any remote control monitoring and alarms at a water system. During the survey, each step of the water system's operation should be considered and it should be determined whether the step is carried out manually or automatically.

Some assessment criteria to consider when reviewing remote monitoring/control/alarms include:

How are the well pumps controlled?

The inspector should evaluate the control system and determine if it is suitable for its application. Automatic well pump controls should be equipped with resets and a manual override switch. Pumps supplying water to the distribution system should be equipped with a switch that is triggered based on distribution system pressure.

Are pressure tanks properly plumbed?

Pressure tanks whose primary goal is to control the cycling of pumps should be equipped with a pressure switch that cycles the pump on and off. In order for this to operate correctly, the inspector should make sure there is no shut-off valve between the pressure switch and the pump. If such a valve is closed, the system will call for water and the pump will begin pumping against a closed valve, most likely damaging the pump.

Are appropriate alarms in place and operational?

Well houses, treatment plants and booster stations should be equipped with alarms to notify their operators when there is a problem with the pumping, treatment or delivery of the water. Some of these alarm systems are much more sophisticated than others. The sanitary survey operator should determine whether the approach a system has to notify its operators in case of an emergency is sufficient for effectively maintaining the operation of that system.

4.9 Monitoring/Reporting/Data Verification

An important part of any industry that produces a product for the consumer is quality control. Quality control is a defined method of checking the product to ensure the consumer it meets or exceeds regulatory requirements as well as their minimum expectations. For the water industry, quality control consists of monitoring water from the source to the tap with in-house as well as outside laboratory testing for confirmation. A monitoring plan provides the operator with data to assist in identifying potential problems and adjusting treatment processes accordingly. It is important that all water systems create a water quality monitoring plan and document monitoring results. For most water systems, regulatory requirements, either State or Federal, dictate the minimum scope of a water quality monitoring plan.

The objectives of surveying the water quality monitoring/reporting/data verification are to:

- Review the water quality monitoring plan of the PWS for conformance with regulatory requirements;
- Verify that the water quality monitoring plan is being followed by checking test results;
- Verify that all in-house testing as well as equipment and reagents being used conform to accepted test procedures;
- Verify the data submitted to the regulatory agency; and
- Evaluate the procedures an operator follows to identify any problems with the process, determine the changes needed to correct the problem, and how adjustments to the process are approved and performed as needed.

1 If there are no violations or orders, and the required monitoring data are available, it is an
2 indication that the water system has accepted its assigned responsibilities and is trying to
3 complete its duties accordingly. In general, the inspector will only have to verify that all
4 sampling and monitoring plans are up-to-date based on the latest regulatory changes, if any. In
5 addition, the inspector will verify that the data reported to the agency are accurate based on the
6 records kept by the system. Self-monitoring data, monthly operating reports, and daily logs
7 should be reviewed to determine if data are of questionable quality and to evaluate the potential
8 for data falsification.

9
10 If there are no violations or orders, but the required monitoring data are not available, it
11 may be difficult to determine if the water system is in compliance with all requirements.
12 Laboratory results for bacteriological, chemical, and radiological monitoring must be kept for
13 specific time periods. The inspector should review the records to determine if they are kept for
14 the required time period in accordance with each regulation.

15
16 The inspector should carefully review the compliance plans required as a result of a
17 violation or by any orders and verify that the plan is being followed by the system. If all the
18 required monitoring data are not available, the inspector should determine the reason.

19
20 Suggested assessment criteria for data collection include:

21
22 **Are there any violations or orders for the subject system? If so, is there a**
23 **compliance plan? If so, what documentation is there to verify compliance?**
24

25 If the treatment plant has submitted a compliance plan, the inspector should take copies
26 of the plan to verify that the compliance plan is being properly implemented.

27
28 **Have the required sampling plans been submitted and approved? If no,**
29 **what action is being taken to prepare and submit the plans?**
30

31 Every water system has to submit a sampling plan to be approved by the State. Such a
32 plan should include the number of samples for each parameter, where samples are taken, at what
33 time and frequency, who is the person in charge of taking the samples, how they are going to be
34 handled, and who is going to analyze them.

35
36 **Are all the required monitoring data submitted? If so, do the data appear**
37 **reasonable? Do the data reported match field log books?**
38

39 If a plant has complete, up-to-date, reasonable monitoring data, this is an indication that it
40 is well managed. However, it is still necessary to verify field log books with submitted reports to
41 rule out any human error in copying the data.

42
43 **Are records of the monitoring program maintained in an organized and complete**
44 **manner?**
45

46 The results of the monitoring program should be kept in an organized system and should
47 be accessible for review.
48

Additional questions that an inspector should consider during the sanitary survey include:

Are treatment systems monitored (e.g. flows, pressures, tank elevations, pumps) appropriately? Are treatment adjustments made as a result of monitoring results?

Are records kept of when and how treatment steps are taken and chemical mixtures (e.g., feed solutions) are prepared?

Does the water system have a preventive maintenance program and records?

Does the system document when repairs are made?

Do they have a system for logging and responding to customer complaints?

4.10 Water System Management/Operations

Management and/or administration is a major factor that affects the performance of a water system. Management provides the direction, funding, and support that is needed for a PWS to continually supply safe drinking water. For instance, if management does not understand the requirements to produce and provide the quality of drinking water demanded by the consumer, policies may be implemented that hinder the performance of the system and its ability to provide what the consumer wants. Therefore, management and staff need to work together to create an environment that facilitates meeting the goal of providing the best possible quality of drinking water to the consumer.

The objectives of surveying the water system management/operation are to:

- Review the water quality goals and evaluate any plan(s) the system has to either accomplish or maintain the stated goals;
- Identify and evaluate the basic information on the system, management, staffing, operations, and maintenance;
- Review and evaluate the plan(s) for safety, emergency situations, maintenance, and security to maintain system reliability; and
- Evaluate the system's revenue and budget for drinking water to establish the long-term viability of meeting water quality goals (UFTREEO Center, 1998).

4.10.1 Organization and Management (TMF Capacity)

The direction of the system is controlled by the system's management through the implementation of the budget and policies. During the inspection, the knowledge and experience of these individuals concerning drinking water should be verified. As an example, if the individual at the top of the management structure has little or no experience with a water system, then the implemented budget and policies may reflect that lack of knowledge in determining how

1 the system is operated and maintained. If the individual has the knowledge, then the water
2 system will probably be operated and maintained differently. Therefore, the knowledge and
3 experience that management has with water systems plays an important role in how a system is
4 operated and maintained.

5
6 Another impact that management can have is on the morale of the personnel. A positive
7 atmosphere is generated if the management encourages an open dialogue between all levels.
8 This open communication allows the workers to express their opinion without fear of reprisal.
9 Encouraging the training and advancement of personnel will also foster a positive morale.
10 Although, there will be some expenses incurred on the part of the utility, this effort shows that
11 management wants their employees to gain the knowledge necessary to further their careers.

12
13 Suggested assessment criteria for system management include:

14
15 **What is the management structure, and who are the individuals at the**
16 **various levels? What is their experience level with water systems?**
17

18 If the water system has an organizational chart, the inspector should review the chart to
19 gain an understanding of the system's management structure and that individuals are responsible
20 for the different elements of system operation and management. The system needs to have a
21 means of clearly indicating to its own staff who has the responsibility for various functions and
22 who has the authority to make decisions and approve changes to policies, procedures, system
23 operations, and other areas pertinent to treatment plant performance and water supply quality.
24 Personnel in positions of responsibility and management should be experienced with and
25 knowledgeable about drinking water systems and their operation, and have detailed knowledge
26 about their own system and its performance and needs, as well as the regulatory requirements
27 that apply to their system.

28
29 **Does the water system have a planning process? Does the planning process**
30 **appear to be implemented?**
31

32 Water system management should be actively involved in planning for the system.
33 Efforts should include both short-term and long-range planning horizons. The system should
34 have a process for developing and updating plans required under applicable regulations, such as
35 compliance monitoring, source protection, and cross-connection control, as well as other plans
36 integral to a well-functioning water system, such as annual and long-term budgets, equipment
37 purchases, and facility expansion.

38
39 **Does open, effective communication occur between management and system**
40 **personnel?**
41

42 Open, effective communication between management and operations staff is integral to
43 the achievement of a system's water quality goals for the production of a reliable, high-quality
44 water supply. System personnel should have a means of adequately conveying to management
45 the need for additional equipment and personnel and changes in facility policies and procedures,
46 and for providing input to budgeting and system expansion plans. Management needs to be
47 receptive to staff input and committed to seeking it and using it.

4.10.2 Staff Levels

The inspector should determine if a list of job descriptions for system personnel is available. The inspector can use this information to assess whether or not the system seems to have an adequate number of qualified personnel to perform all the necessary work within the system from operations to maintenance. One indicator of sufficient personnel is that little or no overtime is required to adequately perform operations and maintenance. The inspector should also evaluate the relative distribution of personnel between operations and maintenance positions. If the PWS is operated under contract to a private company, the availability of staff familiar with the plant should be assessed. To have a well operated and maintained facility, there should be a good mix of responsibilities and personnel, and personnel should have some cross-training between operations and maintenance.

Suggested assessment criteria for system staffing include:

Is the number of personnel adequate to perform the work required?

The size of the facility and the types of treatment largely determine what level of personnel is sufficient. The system should have enough personnel to enable continuous operation of the treatment plant at all times, including periods when some staff are absent (e.g., vacations, weekends, holidays). Staff should be able to perform operations and maintenance tasks regularly with little or no overtime hours. In addition to having an adequate number staff overall, the system should have staff appropriately assigned to operations tasks and maintenance tasks.

Is plant coverage adequate given the alarm systems used by the plan? Do variations in finished water quality when the plant is unattended indicate the need for additional plant coverage?

During periods when the plant is unattended or treatment processes are monitored by alarm systems rather than personnel, fluctuations in finished water quality may increase. The inspector should evaluate whether the system's personnel and its use of alarm systems are adequate to promptly address variations in finished water quality.

Do staff have clearly defined responsibilities and the decision making authority necessary to carry out their responsibilities?

System staff need to clearly understand their responsibilities and have the authority to make any decisions, such as hiring and scheduling personnel and altering elements of treatment plan operation (e.g., equipment shutdowns for maintenance, changes to chemical doses), that are necessary to fulfill their responsibilities in a timely manner. System staff should also sufficiently understand the responsibilities of other personnel so they know who to approach with issues or questions.

Is there cross-training required of the individuals within the system?

Some cross-training of employees between operations and maintenance provides the facility with staffing options during unexpected periods of staff absences (e.g., illnesses) and times when the work load balance between operations and maintenance shifts. Cross-training

1 may also enable staff to better carry out their responsibilities because they have a better
2 understanding of other aspects of water treatment.

3 4 5 **4.10.3 Training**

6
7 Water system personnel are encouraged to receive training on an ongoing basis. Most
8 operators are required to obtain continuing education credits in order to maintain their
9 certification. Operators can also learn from their peers by actively participating in their local
10 water works association's conferences and workshops. Inspectors should confirm that operators
11 know what their continuing education requirements are, and they are encouraged to provide
12 operators with any information they may have about suitable upcoming classes.

13
14 Suggested assessment criteria for adequacy of training include:

15 16 **Are water system staff prepared and capable of performing their duties?**

17
18 Staff should understand all compliance requirements including monitoring,
19 recordkeeping and reporting requirements. Operators should be properly trained so they
20 understand how they should be running and maintaining their system. Sanitary survey inspectors
21 should verify that operators have been appropriately trained to run any new kind of treatment
22 that has been installed.

23 24 **Are operators receiving the training required for them to maintain their** 25 **certification?**

26
27 The inspector should check that operators understand their continuing education
28 requirements and that opportunities for satisfying those requirements become available to them.

29 30 31 **4.10.4 Revenue**

32
33 When reviewing the budget and rate structure, one of the most important questions to
34 consider when determining adequacy is "Is the system a self-supporting utility?" A self-
35 supporting utility means that the revenues are such that all budgetary requests are met, with some
36 excess reserves remaining for future improvements or emergencies. These reserves would
37 normally stay within the utility budget. However, some systems may apply these reserves to
38 other portions of the overall budget of the city or board. In other words, the water system may
39 subsidize other departments within the city or board.

40
41 After reviewing the budget and revenues to determine if the system is self-supporting, the
42 budget should be reviewed to determine that there is adequate funding allocated to the
43 maintenance of the equipment within the system, as well as for providing an adequate number of
44 personnel to operate and maintain the system properly. Data from other systems may help in this
45 analysis. In comparing two similarly sized systems, any significant differences between the two
46 systems can be evaluated to see if they may be part of the reason for any problems being
47 experienced.

1 Suggested assessment criteria for adequacy of revenues/budget include:

2
3 **Is the system self-supporting?**
4

5 Water rates should be set at a level such that fees collected adequately cover operating,
6 maintenance, and replacement costs. If there is an imbalance, the inspector should evaluate how
7 the imbalance may be impacting the system's performance and its ability to provide a reliable
8 supply of high-quality water.
9

10 **Is there money to provide the appropriate maintenance and to support the**
11 **number of personnel to operate the system correctly?**
12

13 System funding needs to adequately support facility operation and maintenance, and
14 should include funding for an appropriate level of staff that are properly trained. Funds need to
15 be budgeted for future expenses such as equipment purchases and facility expansion, as well as
16 current expenses associated with staff salaries and training, electricity, chemical stocks and
17 equipment replacement parts, and other day-to-day expenses. The system should have a method
18 for prioritizing its needs so that funds are expended on the most essential items first. The
19 inspector should ask operations and maintenance staff about its procedures for and past
20 experiences with obtaining needed supplies, equipment, and staff to determine if staff encounter
21 difficulties due to budget problems. The system should have a reserve or sinking fund where
22 excess revenues are held and accumulated for use on future purchases and improvements and
23 emergencies.
24

25 **Does the water system subsidize other departments within the city or board?**
26 **If so, is funding that is returned to the water utility sufficient to meet**
27 **operation and maintenance requirements and address future growth?**
28

29 To assess this, the inspector should interview personnel that are responsible for the water
30 system budget, ask operator about plant funding, and examine the budget.
31

32 **How does this system compare to others?**
33

34 If the inspector has financial data on other systems, comparisons can be made that may
35 aid in determining the adequacy of a system's budget/revenues.
36

37 **Are financial reserves available to the system if it needs to make significant changes**
38 **to its treatment or infrastructure? Does the system have a Capital Improvement**
39 **Plan?**
40

41 The inspector should ask whether the water system has a plan to address long-term
42 infrastructure upgrades and new regulatory requirements.
43
44

4.10.5 Additional Management Issues

The sanitary survey inspector should learn the status of other management issues that are related to the water system as it seems appropriate. Additional questions that should be considered include:

Is overall security effectively maintained for the water system?

Has the system prepared a vulnerability assessment? Do they have an Emergency Response Plan that is exercised regularly?

Does the system have a systematic repair and replacement program for the components of its source, treatment plant, storage and distribution systems?

Is there effective communication between management staff, operations staff and the regulatory agency?

Are the operational, managerial, and fiscal arms of the water utility working together in a cooperative manner? If not, are their problems adversely affecting the treatment and delivery of acceptable drinking water?

Does the system participate in any mutual aid agreements?

4.11 Operator Requirements

4.11.1 General Operator Requirements

The need for qualified professionals to operate and maintain water systems is becoming increasingly important in the water supply industry. Proper operation and maintenance of a water system requires staffs that are trained and knowledgeable about drinking water treatment and distribution. One means of ensuring that system personnel have a certain minimum level of knowledge is through operator certification. All States are required to have operator certification programs as a condition of primacy. Each State establishes its own operator certification program.

4.11.2 Certification Required Based on Size/Treatment

States generally require a certain level of operator certification based on the size and type (community or non-community) of the system and/or the type of treatment, if any, used in the system. The requirements for operator certification vary from State to State, but they generally require a certain amount of classroom training, on-the-job training and experience as well as requirements for continuing education. As an individual advances, the training requirements increase also. In addition, operator certifications must be renewed after a set time period and the continuing education requirements must be met for renewal.

Suggested assessment criteria for operator certification include:

Does the system employ an operator(s) of the appropriate certification level(s), as specified in State requirements?

A system should have an operator(s) that possesses current certification at the level(s) specified in State requirements for the size and type of the system and any treatment. The inspector should verify that the levels and types of certification are still appropriate for the system (i.e. no new treatment, system has not expanded). The inspector should ask for proof of certification if it is not openly displayed.

Is the number of operators adequate for the system?

A system should have enough operators to ensure continued reliable operation of the system. Operator levels should be sufficient to meet daily duties (i.e. rounds, monitoring and reporting) as well as repairs and preventative maintenance. Operator levels should be sufficient to meet the needs of the system during off-duty time periods (weekends, vacations etc). For larger systems or system with treatment plants, the inspector should review the number and certification level of operators available per shift. If the system has only a part-time operator or where the operator has additional unrelated duties, the inspector should inquire about the amount of time spent on water system duties and how the system addresses preventative maintenance, repairs and emergencies.

Is training provided for new operators, new regulatory requirements or when new equipment is installed?

The system should provide training for new operators so they become familiar with the system and their operating responsibilities and regulatory requirements Operators should be provided with training (or allowed time to pursue training) for new regulatory requirement as well as operation and preventative maintenance of new equipment.

4.12 References

- ANSI/AWWA, 2005. Standard C651/05: Disinfecting Water Mains.
- ANSI/AWWA, 2004. Standard G200-04: Distribution Systems Operation and Management.
- AWWA, 2007. Criteria for Valve Location and System Reliability.
- AWWA, 1999. Design and Construction of Small Water Systems.
- American Water Works Association and American Water Works Association Research Foundation. 1992. Water Industry Database: Utility Profiles. AWWA, Denver, CO.
- Great Lakes – Upper Mississippi River Board of State and Provincial Public Health and Environmental Managers, 2003. Recommended Standards for Water Works. Albany, NY.

- 1 Kirmeyer, G.J., M. Friedman, K. Martel, D. Howie, M. LeChevallier, M. Abbaszadegan, M.
2 Karim, J. Funk and J. Harbour. 2001. Pathogen Intrusion Into the Distribution System. Denver,
3 Colo.: AWWARF and AWWA.
4
5 Lindeburg, Michael R. 1997. Civil Engineering Reference Manual for the Pe Exam. Sixth
6 edition. Professional Publications, Inc. Belmont, CA.
7
8 MWH. 2005. Water Treatment Principles and Design, 2nd Edition. Wiley-Interscience. Hoboken,
9 NJ.
10
11 USEPA, 1999. Conducting Sanitary Surveys of Public Water Systems-Surface Water and
12 Ground Water under the Direct Influence of Surface Water. 815-R-99-016.
13
14 USEPA. "The Potential for Health Risks from Intrusion of Contaminants into the Distribution
15 System from Pressure Transients". Office of Ground Water and Drinking Water, Washington,
16 DC.
17
18 USEPA, 2003. How to Conduct a Sanitary Survey of Small Water Systems, A Learner's Guide.
19 816-R-03-12.

5. Compiling and Reporting the Sanitary Survey Results

This chapter provides guidelines for compiling and reporting the sanitary survey results as well as suggestions for keeping adequate documentation of the sanitary survey. The GWR requires States to notify systems in writing of any significant deficiencies within 30 days of identifying the deficiency. The State may identify significant deficiencies during the sanitary survey or during other field visits or office investigations. The notification, which can include State direction to take a specific corrective action, can be accomplished by;

- Written notice at the time of the sanitary survey or at the time the significant deficiency is identified;
- Written notice within 30 days of the sanitary survey or the time when the significant deficiency is identified; or
- As part of the sanitary survey report, if the report is provided to the system within 30 days of completing the sanitary survey.

The sanitary survey report is a final written report that is used to notify water system owners and operators of the results of the survey, any deficiencies or recommendations for improvement, and assists in facilitating corrective action where deficiencies are noted. Final written reports should be prepared for every sanitary survey in a format that is consistent Statewide. Once a sanitary survey has been conducted, appropriate documentation is needed for follow-up activities and for development of reports. Not only does documentation need to be complete, but the results of surveys should be interpreted consistently from one surveyor to another. Specifically, as part of documentation and follow-up, the inspector should complete the following activities:

- Complete documentation and prioritize sanitary risks, including significant deficiencies that were identified during the onsite investigation;
- Notify the water utility of any variances in the sanitary survey report from that provided in the oral debriefing at the site;
- Complete the formal sanitary survey report;
- Notify appropriate organizations of the results (e.g., other State or local agencies affected by survey findings) ;
- Provide options for correcting the deficiencies, including sources of technical assistance;
- Follow-up on questions asked by water utility personnel and on consultation regarding selecting corrective actions; and
- Assess whether the system should be considered to have outstanding performance.

1 The remainder of this chapter provides additional detail on compiling the sanitary survey
2 report. Areas addressed include: preparing the sanitary survey report; preparing adequate sanitary
3 survey documentation; categorizing the findings; developing corrective actions; and determining
4 outstanding performance.

5.1 Sanitary Survey Report

9 The sanitary survey report officially communicates the results of the survey to the owners
10 and operators of the water system. The purposes of the survey report are to:

- 12 • Notify the system of the State's assessment of the system's condition and overall
13 compliance;
- 15 • Notify the water system owners and operators of system deficiencies;
- 17 • Request corrective action under a specified schedule or, if necessary, direct corrective
18 actions;
- 20 • Provide recommendations for improvements;
- 22 • Provide a written record for future inspections (including a recommendation on
23 outstanding performance since this can affect the frequency of future surveys); and
- 25 • Provide important information that may be useful in emergencies.

27 The report can be brief but should be detailed enough to provide the water utility with
28 sufficient information on what deficiencies exist and what corrective actions are needed. The
29 survey report should indicate why corrective actions are necessary. Compliance schedules or
30 requests for a correction date should be included for all deficiencies. The GWR requires a State-
31 approved compliance schedule for all significant deficiencies that are not corrected within 120
32 days of being identified by the State.

34 The survey report provides a record for future inspecting parties and provides technical
35 information that may be useful during emergency situations. It is also an important tool for
36 tracking compliance with the SDWA and for evaluating a particular system's compliance strategy.
37 The sanitary survey report needs to contain adequate documentation of survey results. Types of
38 documentation are discussed in Section 5.2.

40 The report should be completed promptly and reflect the information provided to water
41 utility personnel at the end of the onsite evaluation. If the written evaluation is different from the
42 oral debriefing, the water system manager should be notified of such changes.

44 At a minimum, the survey report should include the following elements:

- 46 • Date and time of survey;

- Name(s) of survey inspector(s);
- Name(s) of those present during the survey, besides the inspector(s);
- A schematic drawing of the system and, where appropriate, photographs of key system components;
- A statement of system capacity, including source, treatment, and distribution;
- A summary of survey findings, with the signatures of survey personnel;
- A listing of deficiencies based on a regulatory reference;
- A summary of all analyses and measurements done during the sanitary survey;
- Recommendations for improvement, in order of priority, with a timeline for compliance;
- A copy of the survey form; and
- A recommendation on whether a system has outstanding performance.

The report needs to identify all the deficiencies noted during the inspection. The sanitary survey report should provide more detailed information when a system has a significant problem that could affect human health. If the State has not directed corrective action, the report should also provide options for corrective actions that the system may take to address any significant deficiencies. As described above, States must provide systems with written notification that describes and identifies all significant deficiencies no later than 30 days after the significant deficiency has been identified. Systems must consult with the State within 30 days of the notice (if the State has not directed corrective action) and take corrective action for any significant deficiencies no later than 120 days (or earlier if directed by the State) of receiving written notification of such deficiencies, or submit a schedule and plan to the State for correcting these deficiencies within the same 120 day period. States must confirm that the deficiencies have been addressed within 30 days after the scheduled correction of the deficiencies either by a follow-up field visit or by written notification from the system.

The sanitary survey report should describe the actions that the State will take if the deficiencies that require action by the system owner/operator are not corrected on schedule.

The State should develop standard language (“boilerplate”) for use in sanitary survey reports and correspondence with water systems after a sanitary survey. This standard language includes the text that will not change significantly from report to report. The standard language should be used, when applicable, to save report preparation time and to maintain uniformity in correspondence between the State agency and water systems. Standard language could be developed for sanitary survey report discussions pertaining to each of the eight elements of a sanitary survey. For example, a State could develop standard language that describes its operator certification requirements and says whether or not the water system operator(s) meets those requirements. The inspector would insert the applicable language based on the results of the

inspection. A State should consider consulting with its legal staff to ensure that the standard boilerplate language is accurate within its authorities.

5.2 Sanitary Survey Documentation

Adequate documentation of survey results is essential in the sanitary survey process, especially if the survey may result in corrective or enforcement actions. It is the inspector's responsibility to the water system and to the public to provide an accurate and detailed description of system condition, improper operations or system deficiencies in the sanitary survey report. Detailed documentation should be recorded in a sanitary survey report and sanitary survey forms.

The suggested minimum documentation for sanitary survey record files includes:

- A cover memorandum or letter with a list of deficiencies, if any, and any pertinent information and recommended or required actions for the PWS. The list of deficiencies should identify any significant deficiencies separately and describe the required action, correction or response by the PWS. Deficiencies uncorrected from a previous survey or inspection should also be identified separately with the required action, correction or response by the PWS. Reference to any applicable State or Federal regulatory provision and State policies should be included with each deficiency. The items listed below should be included:
 - Water system name;
 - Water system ID Number;
 - Water system location;
 - Survey date;
 - Surveyor's name/affiliation; and
 - State contact phone number.;
- A completed survey form or checklist for the water system (if used by the State);
- Any necessary additional pages of comments, drawings or sketches, and water sampling data;
- Any significant changes to the system since the last sanitary survey;
- An accurate map, if not already on file showing the location of the system;
- A summary of the components of the water system. This summary should identify any modifications made to the system;

- A listing of system operators, including the certification status; and
- Updated contact information, emergency notification plans etc.

5.3 Categorizing the Findings

While conducting sanitary surveys, inspectors often discover a wide range of problems, or deficiencies with the ground water system. There is a wide range of risks associated with significant deficiencies, ranging from those with a significant likelihood of introducing microbial contamination to the finished water, to those that the continued unaltered operation of the system poses a serious imminent health threat to the population served.

State drinking water programs should draw on their extensive experience to develop objective procedures for determining which deficiencies are significant. States, therefore, will need to establish procedures and criteria for inspectors to use to determine which deficiencies are significant. The GWR requirement for State primacy agencies defines significant deficiencies generally as including, but not limited to “defects in design, operation, or maintenance, failure or malfunction of the sources, treatment, storage, or distribution system that the State determines to be causing, or have potential for causing, the introduction of fecal contamination into the water delivered to consumers.” (§142.16(o)) The State’s primacy application for the GWR must define at least one specific significant deficiency in each of the eight sanitary survey elements. The State also has to have discretion to identify additional significant deficiencies on a case-by- case or system-specific basis. Under the GWR, systems must consult with the State regarding corrective actions for significant deficiencies. States may also prescribe specific corrective actions as well as require interim corrective measures (e.g. temporary disinfection). Failure to correct significant deficiencies within 120 days of being notified by the State or in accordance with a State-approved plan and schedule is a violation of the treatment technique requirements of the GWR and could result in State or EPA enforcement actions.

Exhibit 5.1 illustrates one possible approach to categorization of some of the common deficiencies by the degree of their threat to public health. The listing in Exhibit 5.1 includes examples of deficiencies that may be considered significant public health issues. This list is not intended to be comprehensive, but serves as a guide to the State for categorizing significant deficiencies. Other deficiencies could be deemed significant public health issues.

Exhibit 5.1 Example of Sanitary Survey Deficiencies¹

Finding	Minor	Moderate	Significant
No approved construction drawings		X	
Failure to update the water distribution map	X		
Stopping work on system improvements		X	
Well casing is improperly sealed			X
Application of treatment chemicals not paced to flow		X	
Raw water transmission main can bypass treatment			X
Inadequate storage for maintaining distribution system pressure			X
System has exceeded the maximum number of service connections allowed		X	
System not operating in compliance with water system plan		X	
No auxiliary power available to keep system under positive pressure during commonly experienced power outages			X
System is not using a certified laboratory			X
Failure to complete required Public Notice			X
Inadequate number of operators			X

¹ This table is for illustrative purposes only and does not represent any Federal or State policy. Additional potentially significant deficiencies are listed below and should be included as appropriate for each State.

Sanitary surveys serve as proactive public health measure for States. When properly conducted, sanitary surveys can provide important information on a water systems design and operations and can identify minor and significant deficiencies for correction before they become major problems and improve overall system compliance. The following are additional examples of significant deficiencies organized by each of the eight minimum sanitary elements required under the GWR. These examples are intended for illustrative purposes only and are not intended to be all inclusive, or exclusive, of possible significant deficiencies identified by the States. State experience with specific deficiencies in their systems should be used to address the deficiencies on a system-specific basis.

Source

- Activities or pollution sources in the immediate well head area that will cause sanitary risks.
- The well is vulnerable to surface water runoff or in a flood plain.
- The well casing is cracked, not sealed, or is improperly sealed.
- The vent for the well casing is not screened and turned downward.
- Top of casing is not elevated to prevent contamination from flooding or ponding.

- Well is not secure and susceptible to vandalism and tampering.
- Cross connections to storm drains, sanitary sewers, non potable water supplies, pump bearing cooling water.
- Unapproved source is being used.
- Non- microbial indicators of well susceptibility to fecal contamination (e.g. MBAS, chloride, caffeine).

Treatment

- System is not in compliance with applicable treatment technique requirements.
- Inadequate disinfection contact time, disinfectant concentration, disinfectant dose, or disinfection is not continuous.
- Inadequate application of treatment chemicals, not paced to flow.
- Unapproved treatment chemicals used.
- Lack of treatment process monitoring, failure alarms, or automatic process shutdown.
- Cross connections at chemical tanks, filter backwash, membrane cleaning processes.
- Loss of membrane integrity or lack of monitoring of membrane integrity.
- Auxiliary power is not available, power outages can cause a complete shutdown of treatment.
- Lack of redundant components.
- Failure to act in an emergency situation.

Distribution and Transmission

- Customers are receiving raw water from the raw water transmission main.
- The raw water transmission main is equipped with a bypass around the treatment plant.
- Repeated or frequent TCR violations or detections of fecal indicators.
- The TCR sampling plan is not representative of the distribution system.
- The system receives numerous complaints of colored and/or odorous water.

- Required disinfection residual levels are not met.
- Compliance monitoring is not conducted at the required frequency and locations.
- Pressures in parts of the distribution system fall below 20 psi during periods of high demand.
- The system is subject to contamination from hazardous cross connections.
- Failure to have a cross connection control program when one is required.
- High leakage rates that pose risks of backsiphonage.
- Inadequate separation between distribution system mains and sewer lines.

Finished water storage

- Inadequate storage to maintain adequate distribution system pressure.
- The tanks vents or overflows are not screened or protected.
- Tanks overflows or drains are subject to flooding.
- Holes or other failures of tank roof or structure, faulty roof, or floating cover drainage.
- In ground tanks subject to flooding.
- The entry hatch tank is not of the overlapping shoe-box type and is subject to runoff from the tank roof.
- Cathodic protection covers missing, loose, or not watertight.
- The tanks entry hatch or access ladders are not secured.
- The storage tank has not been inspected for sanitary defects for an extended period of time.

Pumps, pump facilities, and controls

- Unapproved oil is used for pump lubrication.
- The air/water relief valves are cross connected to the floor drains.
- Auxiliary power needed to keep the system under positive pressure during commonly experienced power outages is not available.

- There is a lack of redundant pumps.
- Cross connections to non potable supplies, pump, or generator cooling water.

Monitoring, reporting, and data verification

- The system has been found to be in significant non-compliance for one or more contaminants.
- Operators are using improper procedures and/or methods when conducting onsite laboratory analyses.
- The system does not have a compliance or microbial monitoring plan.
- The system is not using a certified laboratory.
- Failure to complete Operational Evaluation Reports.

System management and operation

- System security is inadequate.
- Failure to complete required Public Notice.
- Failure to notify the State of MCL violations or ground water source fecal contamination.
- Variance or exemption conditions or schedules not met.
- Failure to comply with enforcement actions and compliance agreements.
- System does not have adequate Technical, Managerial or Financial capacity, or revenue to ensure continued operation.

Operator compliance with State requirements

- The operator is not certified at the level/grade required by the State.
- Inadequate number of operators.

5.4 Corrective Action

If the State determines that a significant deficiency exists in a system subject to the GWR, corrective action is required. To ensure that the sanitary risks are minimized, the sanitary survey report should provide the water utility with options or recommendation for correcting significant defects if the State does not specify corrective actions.

1 The GWR requires that those systems notified in writing by the State of significant
2 deficiencies implement corrective action, including one or more of the following:

- 3
- 4 • Eliminate the source of contamination,
- 5
- 6 • Correct the deficiency,
- 7
- 8 • Provide an alternative water source, or
- 9
- 10 • Provide a treatment that reliably achieves at least 4-log (99.99%) inactivation or
- 11 removal of viruses before or at the first customer.
- 12

13 Once a system has received written notification of a significant deficiency, the system
14 will then consult with the State regarding corrective action (if the State does not specify
15 corrective action) within 30 days of the notice. The system must take the appropriate corrective
16 action no later than 120 days (or earlier if directed by the State) after notification, or submit a
17 schedule and plan to the State for correcting these deficiencies within the same 120 day period.
18 The States must then confirm that the deficiencies have been addressed within 30 days after the
19 scheduled correction of the deficiencies.

20

21 Upon receiving the sanitary survey report or other notice of significant deficiency from
22 the State, PWSs should carefully plan the corrective measures that are to be adopted and
23 implemented to correct the identified significant deficiencies. There may be a number of
24 adequate corrective actions or combination of actions that may be applied to a significant
25 deficiency. The system and the State, must, before proceeding, know that the planned corrective
26 actions will eliminate the deficiency without creating new sanitary risks or other compliance
27 problems. For example, if a system replaced a substandard well that was determined by the State
28 to have a significant deficiency without obtaining the States review and concurrence, the action
29 could result in another substandard well and a finding of noncompliance with the States
30 construction and permitting standards. This example and many others often require
31 modifications that, in many States, must be subsequently reviewed and approved by the State.
32 Therefore, in all cases the PWS should seek the advice and concurrence of their primacy agency
33 prior to taking corrective action.

34

35

36 **5.5 Outstanding Performance**

37

38 As noted in Chapter 1, community systems that are classified as having outstanding
39 performance are eligible for having future sanitary surveys conducted at the less frequent interval
40 of at least once every 5 years, rather than at least once every 3 years. Based on the findings of a
41 sanitary survey, an inspector should include in the report a recommendation on whether a system
42 should be considered to have outstanding performance at the time of the survey. This
43 recommendation should be based on the State's specifications for determining if a system has
44 outstanding performance. Along with the inspector's recommendation, the report should
45 include standard State language ("boilerplate") noting that the recommendation for outstanding
46 performance status is contingent upon the system continuing to meet the State's specifications
47 for that status.

48

1 In general, outstanding performance means that a system is well-operated and managed,
2 has a good record of performance in past sanitary surveys, and has not had any violations (at
3 least in recent years). A State's specifications for outstanding performance may include factors
4 such as the following:
5

- 6 • No violations of MCLs since the last sanitary survey;
7
- 8 • No violations of monitoring and reporting requirements since the last sanitary survey;
9
- 10 • No violations of primary drinking water regulations during the past 5 years (or similar
11 time period);
12
- 13 • Past sanitary surveys containing no significant deficiencies;
14
- 15 • Existence of emergency preparedness measures and backup facilities;
16
- 17 • Meeting exceptional performance standards a specified high percentage of the time;
18
- 19 • Expert management of system (e.g., managers are knowledgeable about providing
20 quality drinking water; low staff turnover; well-established water quality goals);
21
- 22 • Expert operation of the system (e.g., skilled, certified personnel) in adequate
23 numbers; existence of quality O&M manuals that are used by the staff; adequate
24 budget and revenues);
25
- 26 • Effective cross-connection program developed and implemented;
27
- 28 • In-house programs applicable to improved system performance;
29
- 30 • Active public outreach programs (e.g., citizen participation committees);
31
- 32 • Stable water source (no interruptions in supply);
33
- 34 • No identified significant risk of future violations or problems (e.g., equipment past its
35 service life);
36
- 37 • System capacity sufficient to meet anticipated growth; and
38
- 39 • Asset management program and Capital Improvement Plan
40

41 As noted above, each State should have its own specifications for determining if a system
42 has outstanding performance. The State may choose to use some or all of the above factors,
43 different factors that have been developed by the State, or a combination of both.
44
45

6. Report Review and Response

The previous chapters of this guidance manual described how to prepare, conduct, and report the results of a sanitary survey. This chapter describes the follow-up actions that should be taken by the water system operator and the State in response to the findings of a sanitary survey, including those actions that must be taken to correct any identified deficiencies. The State then needs to monitor the water system's implementation of corrective actions to ensure that deficiencies are resolved. The remainder of this chapter discusses these follow-up actions.

6.1 State Actions

For a State to be granted primacy authority for the GWR, it must submit information to EPA that the State has met the requirements for a determination of primacy enforcement responsibility found in 40 CFR 142.16. The special primacy requirements related to sanitary surveys are summarized in Exhibit 6.1. In addition to meeting minimum scope and frequency for sanitary surveys, States must have authority to address findings of significant deficiencies.

The GWR requires that the State notify systems findings of significant deficiencies no later than 30 days after the significant deficiency is identified. Unless the States directs corrective action or earlier compliance, the system must consult with the State within 30 days and take corrective action, or be in compliance with a State-approved schedule, within 120 days of being notified of the significant deficiency. States are required to confirm that the significant deficiencies have been addressed within 30 days after the scheduled correction of the deficiencies. Deficiencies of a minor nature may require no more response than to notify the system operator of the violation and set a time frame for the operator to correct the situation.

For significant deficiencies, the State should inform the system of the deficiency as soon as possible. Under the GWR, the State may inform the system in writing at the time of the sanitary survey or identification of the significant deficiency. In severe cases, the significant deficiency may be such that a boil water notice must be issued to the customers in order to protect public health. In other cases, other immediate interim measures to protect public health may be needed. Under the GWR, the State may specify interim corrective measures during the 120 day period the system is completing final corrections or completing its correction plan and schedule and during the approved schedule for final correction. The State should inform the system of the time frame required for a response to the notice of significant deficiencies and the consequences of failing to respond. In addition to a potential for violation of the GWR and associated enforcement action, the consequences could include revocation of the operating permit, suspension of the permit until the deficiency is corrected, and fines or penalties levied against the system operator. When significant deficiencies require an extended period for correction, a consent agreement, administrative order, or litigation by the appropriate court may be necessary to ensure correction. The State should make regular and continued inspections of the facility until all significant deficiencies have been corrected.

Other State activities include maintaining a tracking system for enforcement. The 1995 *EPA/State Joint Guidance on Sanitary Surveys* States that the deficiencies disclosed in a survey must be followed up on to ensure that timely corrective action is taken, especially to correct

deficiencies that have the potential to substantially affect public health. States should develop a program for following up on recommendations made in their sanitary surveys. Computer programs are useful for sanitary survey tracking and reporting.

Exhibit 6.1 Summary of 40 CFR 142.16(o)(2) – Special Primacy Requirements for Sanitary Survey Requirements of the GWR

In addition to the general requirements for sanitary surveys contained in §142.10(b)(2), the special primacy requirements for the GWR related to sanitary surveys include the following:

- 1) States must conduct sanitary surveys that address the minimum eight sanitary survey components no less frequently than every 3 years for community water systems. The initial sanitary survey for each community water system must be conducted by December 31, 2012, and for each non-community water system must be conducted by December 31, 2014.
- 2) States may use a phased review process to meet the requirements if all the minimum applicable minimum eight sanitary survey elements are evaluated within the required interval.
- 3) States may conduct sanitary surveys once every 5 years for community water systems if the system either provides at least 4-log treatment of viruses (using inactivation, removal, or a State-approved combination of 4-log inactivation and removal) before or at the first customer for all its ground water sources, or if it has an outstanding performance record, as determined by the State and documented in previous sanitary surveys and has no history of total coliform MCL or monitoring violations under §141.21 of this chapter since the last sanitary survey. In its primacy application, the State must describe how it will determine whether a community water system has an outstanding performance record.
- 4) A State must define and describe in its primacy application at least one specific significant deficiency in each of the eight sanitary survey elements. Significant deficiencies include, but are not limited to, defects in design, operation, or maintenance, or a failure or malfunction of the sources, treatment, storage, or distribution system that the State determines to be causing, or have potential for causing, the introduction of contamination into the water delivered to consumers.
- 5) States must provide ground water systems with written notice describing any significant deficiencies no later than 30 days after the State identifies the significant deficiency. The notice may specify corrective actions and deadlines for completion of corrective actions. The State may provide the written notice at the time of the sanitary survey.
- 6) States must have the authority contained in statute or regulation to ensure that ground water systems take the appropriate corrective actions including interim measures, if necessary, needed to address significant deficiencies.
- 7) States must have the authority contained in statute or regulation to ensure that ground water systems consult with the State regarding corrective action(s).

6.2 Water System Actions

As stated above, the severity of the deficiency in a sanitary survey should dictate the appropriate response from the water system operator. The GWR requires the system to consult with the State and complete corrective actions approved by the State or be in compliance with State-approved schedule for correction for any significant deficiencies within 120 days (or earlier if directed by the State) of the sanitary survey or other notice of a significant deficiency. The system operator, upon receipt of the sanitary survey report or notice of significant deficiency, should prepare a response to address the survey findings that may include deficiencies of varying degrees of severity. The response should include:

- A statement of the deficiency, including any real or potential impacts to delivered water quality;
- The approach to correcting the deficiency;
- The time required to correct the deficiency;
- The source of funding, if capital construction is required;
- Measures put in place to prevent the situation from recurring; and
- Additional follow-up actions planned.

The GWR does not change the requirement for a water system to maintain copies of sanitary survey written reports and correspondence associated with sanitary surveys for a period of at least 10 years, as specified in 40 CFR 141.33 (c). In addition to this requirement, the water system should follow any applicable State implementing regulations related to sanitary survey record keeping. Under the GWR, the presence of a fecal indicator in a source water sample requires Tier 1 public notice. By notifying the public of source water fecal contamination within 24 hours the PWS will minimize the likelihood of serious public health consequences. This immediate public notification is also necessary to alert customers to the potential need to obtain alternative drinking water sources, if necessary.

GWR treatment technique violations are subject to Tier 2 public notification. The GWR (§141.404) defines treatment technique violations as:

- A GWS with a significant deficiency that does not complete corrective action within 120 days (or earlier if directed by the State) or in accordance with a State-approved schedule.
- A GWS that detects fecal contamination and does not complete corrective action within 120 days (or earlier if directed by the State) or in accordance with a State-approved schedule.
- A GWS that provides 4-log treatment of viruses and does not conduct triggered source water monitoring under the GWR, is in violation of the treatment technique if

1 it fails to provide 4-log virus treatment and the failure is not corrected within 4 hours.

2
3 The GWR also requires CWSs to notify the public of any detections of fecal indicators in
4 their ground water source(s) or of any uncorrected significant deficiencies in the system's
5 Consumer Confidence Report. Non-community water systems must notify the public of any
6 significant deficiencies that are not corrected within 12 months in a manner approved by the State.
7 Notice of uncorrected significant deficiencies must continue annually for both CWSs and NCWSs
8 until the significant deficiencies are corrected.
9
10

Appendix A

Evaluating Ground Water Treatment for Ground Water Rule Compliance

A.1 Introduction

This appendix provides information to assist States in evaluating ground water treatment for systems that provide and monitor ground water treatment and do not conduct GWR triggered monitoring after a TCR-positive or for systems that use ground water treatment as a corrective action.

Under the GWR, ground water systems that provide at least 4-log (99.99%) treatment of viruses (through inactivation, removal, or a State-approved combination of inactivation and removal) and also meet the compliance monitoring requirements of the GWR are not required to conduct triggered source water monitoring after a routine TCR-positive sample. States may also approve or require 4-log treatment of viruses as a corrective action for fecal contamination of ground water sources or as a corrective action for significant deficiencies.

To meet the requirements of the GWR, 4-log treatment of viruses may be accomplished through inactivation (i.e. disinfection), removal (i.e. filtration) or a State-approved combination of inactivation and removal. This appendix describes common inactivation and filtration technologies and their applicability to GWR treatment technique requirements. This appendix is not intended to be inclusive, or exclusive, of all possible treatment technologies, or combinations of technologies, to meet the GWR treatment technique requirements. States may approve alternative treatment technologies, or combinations of technologies, that provide 4-log treatment of viruses to meet the GWR treatment technique requirements.

A.2 Inactivation of viruses

Inactivation of viruses is accomplished with sufficient disinfectant concentration and disinfectant contact time for chemical disinfectants or sufficient dose for inactivation with ultraviolet light (UV). Chemical disinfectants capable of providing 4-log treatment of viruses as a stand-alone treatment include chlorine, chlorine dioxide, chloramine and ozone. Chemical disinfection and UV inactivation are discussed separately below.

A.2.1 Chemical disinfection

Inactivation of pathogens, including viruses, using a chemical disinfectant is based on the CT concept where C is the measured concentration of the chemical disinfectant residual and T is the contact time between the point of application of the disinfectant and the point where the disinfectant residual is measured.

C, the concentration of the disinfectant, is measured at or before the first customer receiving water or the first connection providing water to the public from the system. For a system using chlorine or chloramine, the residual concentration can be measured with a portable kit or with a continuous monitor using an EPA approved measurement method. A list of EPA

1 approved methods can be found on-line at www.epa.gov/waterscience/methods or from the US
2 EPA Water Resource Center at (202)-566- 1729 or center.water.resource@epa.gov. Your State
3 may have a list of approved measurement methods as well. T, the contact time of the
4 disinfectant, is based on system flow and components. Determining flow and T are discussed
5 later in this section.
6

7 Once C is measured and T is determined from the flow and the size of the system
8 components, the product CH T (CT) is compared to EPA or State information of the CT needed
9 for the inactivation, through disinfection, of a pathogen. EPA has produced tables of CT values
10 and your State may have information it uses for this purpose. Exhibits B.1, B.2, and B.3,
11 respectively, are CT tables for inactivation of viruses by chlorine, chlorine dioxide and ozone
12 respectively. CT tables for chloramine are not included here because the CT values required for a
13 4-log inactivation of viruses are not likely to be practical for applications in most ground water
14 systems. CT values for inactivation of viruses by chloramine can be found in the Guidance
15 Manual for Compliance with the Filtration and Disinfection Requirements for Public Water
16 Systems Using Surface Water Sources (USEPA, 1990) and could be used for ground water
17 systems using chloramines.
18

19 For the GWR, if a chemical disinfection system can achieve a CT at least equal to the CT
20 needed for a 4-log inactivation of viruses for the disinfectant being used, the system is not
21 required to meet the triggered monitoring requirements of the rule. However, such a system
22 would have to comply with the treatment and compliance monitoring requirements of the GWR
23 and any additional requirements set by the State. If approved or required by the State, such a
24 system would also meet the corrective action requirements of the GWR for fecally contaminated
25 ground water source or for significant deficiencies. The special primacy requirements of the
26 GWR require State to specify a minimum disinfectant residual for system using disinfection to
27 meet the treatment technique requirements of the rule. The CT concept would be used to set this
28 minimum disinfectant residual.
29

30 The following minimum information is needed to determine if a chemical disinfection
31 system is providing a 4-log inactivation for the purposes of the GWR:
32

- 33 1. C, the measured disinfectant residual at or before the first customer or connection
34 serving the public. It is measured in mg/l or in ppm.
35
- 36 2. Length (in feet) of each pipe between the point where disinfectant is applied and
37 the point where it is measured.
38
- 39 3. Size (diameter) of each pipe between the point where disinfectant is applied and
40 the point where it is measured. The diameter in inches must be converted to
41 diameter in feet (1 inch=1/12 foot).
42
- 43 4. Volume of water (in gallons) in any storage tanks used to determine CT provided
44 by the system.
45
- 46 5. Maximum daily flow, in gallons per minute, (gpm) of the system. This could be
47 as measured by a flow meter, the maximum capacity of the well pump, or another
48 measurement acceptable to the State.
49

The following example illustrate how this information may be used to calculate CT and to determine if a chemical disinfection system is providing a 4-log inactivation of viruses.

Example A.1

The Redwood Road water system serves 4 commercial businesses and a service station. The water supply is provided by a single well on the property that is operated by a pressure activated switch. The information supplied with the well pump that was purchased for the system says it has a capacity of 5 gpm. A hypochlorite solution is injected using a drum of prepared solution and an injection pump inside the well house. The operator wants to determine how much virus inactivation the disinfection system provides.

To determine the inactivation the system provides through disinfection, the operator needs to calculate the CT achieved by the hypochlorination system.

- The operator must determine T, the contact time, from the size of the system=s components and measure C, the disinfectant residual concentration, at or before the first service connection.
- The operator knows the well pump has a capacity of 5 gallons per minute (gpm) from the manufacturer's information. This is the maximum flow through the water system. T, the contact time in the system is the volume (in gallons) of the system divided by the maximum flow.
- The operator knows there is 100 feet of 2 inch pipe between the well house and the first service connection, the service station. The volume of the pipe in cubic feet and then in gallons is determined. The volume of the pipe in gallons is divided by the flow to find the contact time.

The diameter of the pipe is 2 inches or 2/12 feet.

The area of the pipe is $[\pi \times (\text{diameter}^2)] \div 4$ and $\pi=3.14$, or the area is also $0.785 \times \text{diameter}^2$

So the area of the pipe is $0.785 \times (2/12 \text{ feet})^2 = 0.022 \text{ sq. ft.}$

The volume of the pipe in cubic feet = $100 \text{ feet} \times (0.022 \text{ sq. ft.}) = 2.2 \text{ cubic feet}$

The volume of the pipe in gallons is $2.2 \text{ cubic feet} \times 7.48 \text{ gallons/cubic foot} = 16.4 \text{ gallons}$

The contact time, T, in the pipe is the volume of the pipe divided by the flow
 $T = 16.4 \text{ gallons} \div 5 \text{ gpm} = 3.3 \text{ minutes}$

The operator measures the chlorine residual at the service station and finds it to be 0.5 mg/l. So, the CT provided by the system is $0.5 \text{ mg/l} \times 3.3 \text{ minutes} = 1.6 \text{ mg/l-minutes}$

1 The CT needed for 4-log inactivation of viruses using chlorine is provided in Exhibit B.1.
2 The operator has measured the temperature of the water as 10°C and the last chemical analysis
3 done for the well found a pH of 7.4 for the well water. Looking in Exhibit B.1 the CT for that
4 temperature and pH for a 4-log inactivation with chlorine disinfection is 6 mg/l-minutes.
5

6 To provide 4-log inactivation, the CT provided by the system must be equal to or greater
7 than the CT required from Table 1 (or the ratio of CT required/CT achieved must be 1.0 or
8 more). Since the CT provided by the system, 1.6 mg/l-minutes, is less than the CT required from
9 Table 1 (6 mg/l-minutes), the system does not provide enough CT to achieve 4-log inactivation
10 of viruses. If the system was required to provide 4-log inactivation or wished to provide it to
11 avoid triggered monitoring, the CT provided by the system would need to be greater.
12
13

14 **A.2.2 Determining Contact Time, “T”, for CT calculations**

15

16 In determining contact time for flow in pipes, as in the previous example, contact can be
17 assumed to be equal to the hydraulic detention at a particular flow rate (e.g. plug flow
18 conditions). However, that is not the case for storage tanks and reservoirs and treatment plant
19 processes. In these cases, contact time should be determined using tracer studies or using other
20 methods approved by the State.
21

22 Appendix C of the Guidance Manual for Compliance with the Filtration and Disinfection
23 Requirements for Public Water Systems Using Surface Water Sources (USEPA, 1990) provides
24 a description of tracer studies and tracer study methods. In general, tracer studies should
25 represent the range of flow and operational conditions expected in the system and should have
26 data quality criteria (i.e. % tracer recovered). Tracer chemicals used should be conservative (high
27 % recovery) and should be acceptable to the State for use in public water supplies.
28

29 Ground water systems may not have tracer study data available and conducting tracer
30 may be beyond the capacity of many ground water systems. States may use other methods to
31 determine contact time for use in CT calculations and determining minimum disinfectant residual
32 for GWR compliance purposes.
33

34 One alternate method is to use “rule of thumb” fractions representing tracer studies that
35 have been conducted for various types and geometries of various basins and storage facilities.
36 Exhibit B.5 presents fractions that can be used under a given set of conditions to estimate contact
37 time for CT calculation. For a particular tank or process, the baffling factor (also known as the
38 T10/T ratio) is estimated based on the information available or a conservative assumption is
39 made if no information regarding the tank is available. The baffling factor is used to reduce the
40 contact time in the basin for CT calculations. Operating conditions in the basin (i.e. overflow
41 levels) also need to be considered in determining actual basin volume. Example B.2 presents the
42 use of baffling factors in determining contact time in a storage tank.
43

44 **Example A.2**

45

46 The operator of the Myrtle town water system wants to estimate the contact time in the system’s
47 single storage tank. The operator has calculated that the minimum capacity of the tank is 11,000
48 gallons based on the level of the float switch that signals the well pump to turn on and off. The

operator has records from the flow meter at the tank outlet and the maximum daily flow over the past 12 months was 55 gallons per minute.

The storage tank has a single baffle in front of the inlet pipe and the inlet and outlet are located on opposite sides of the tank. The operator chooses a baffling factor of 0.3.

The theoretical hydraulic detention time in the tank is $11,000 \text{ gallons} \div 55 \text{ gallons/minute}$ or 220 minutes. Using the baffling factor of 0.3, the estimated contact time in the tank under maximum flow conditions is $0.3 \times 220 \text{ minutes} = 60 \text{ minutes}$.

To determine the virus inactivation provided by the Myrtle town system, the estimated contact time is multiplied by the disinfectant residual measured at or before the first customer to find the “CT” provided. If the Myrtle town system used chemical disinfection for compliance with the GWR (either as a corrective action or in lieu of triggered monitoring), the system would be required to provide a minimum residual level determined by the State using the CT approach.

A.2.3 Setting a Minimum Disinfectant Residual

The GWR requires that the State specify a minimum disinfectant residual, to be met prior to the first customer, for systems using chemical disinfection to provide virus treatment for their ground water sources. The minimum disinfectant residual is established using the CT concept. In setting a minimum disinfectant level, which becomes a compliance criterion for the system, the following information should be reviewed and considered:

- System configuration and operations (e.g. location of first customer, operation of storage, bypass of storage);
- The range of operating conditions (e.g. continuous or intermittent, peak flows);
- The range of expected water quality affecting disinfection (e.g. temperature, pH, disinfectant demand);
- Residual monitoring equipment (e.g. grab sample/portable kit, continuous monitoring);
- Condition of monitoring equipment, reagents and other supplies, maintenance and calibration of continuous monitoring equipment; and
- Disinfection system reliability features (e.g. alarms, automatic shutdown)

A.2.4 UV Disinfection

In the proposed GWR (USEPA, 2000) EPA included UV light in the regulatory text as a stand-alone treatment technology that could provide 4-log virus inactivation. However, data published subsequent to the GWR proposal indicated that some viruses, particularly adenoviruses, are very resistant to UV light. The GWR proposal was based on information

1 available at the time of the proposal regarding UV doses required to provide 4-log inactivation of
2 Hepatitis A Virus (HAV) and the design doses achieved by available UV reactors, which are
3 lower than the UV doses needed to achieve 4-log inactivation of adenovirus. EPA is concerned
4 that fecally-contaminated ground water may contain adenoviruses, or other viruses, that are more
5 resistant to UV inactivation than HAV.
6

7 EPA believes that UV reactors must undergo challenge testing to validate the dose level
8 delivered so that effective treatment is provided in systems using UV disinfection. At present,
9 EPA is unaware of available challenge testing procedures that can be used to validate the
10 performance of UV reactors at dose levels needed for a 4-log inactivation of adenovirus.
11

12 However, UV technology can be used in a series configuration or in combination with
13 other inactivation or removal technologies to provide a total 4-log treatment of viruses to meet
14 this rule's requirements. The GWR allows States to approve and set compliance monitoring and
15 performance parameters for any alternative treatment, including UV light or UV light in
16 combination with another treatment technology, that will ensure that systems continuously meet
17 the 4-log virus treatment requirements.
18

19 UV reactors should undergo validation testing to determine the operating conditions
20 under which the UV reactor delivers the UV dose required for the virus inactivation level
21 required. Exhibit B.6 presents a UV dose table for virus inactivation. In general, the operating
22 conditions determined in validation testing would include flow rate, UV intensity as measured by
23 a UV sensor and UV lamp status. These operating conditions, as well as any State-specified
24 monitoring or operating conditions, would be both a part of State approval of an alternative
25 treatment process that meet the requirement of the GWR and part of compliance monitoring for
26 an alternative treatment process for GWR compliance. The *Ultraviolet Disinfection Guidance*
27 *Manual for the Final Long Term 2 Enhanced Surface Water Treatment Rule* (EPA 815-R-06-
28 007) (USEPA, 2006a) provides additional information on UV disinfection, planning and design
29 of UV facilities, validation of UV reactors and start-up and operation of UV facilities.
30

31 EPA believes that a UV reactor dose verification procedure for 4-log inactivation of a
32 range of viruses may be developed in the future. With the future development of UV validation
33 procedures, it may become feasible for systems to demonstrate that they can achieve 4-log
34 inactivation of viruses with a single UV light reactor.

Exhibit A.1 CT Values for a 4 -log Inactivation of Viruses by Free Chlorine ^{1,2}

Temperature (°C)	Log Inactivation					
	2.0		3.0		4.0	
	pH		pH		pH	
	6-9	10	6-9	10	6-9	10
0.5	6	45	9	66	12	90
5	4	30	6	44	8	60
10	3	22	4	33	6	45
15	2	15	3	22	4	30
20	1	11	2	16	3	22
25	1	7	1	11	2	15

¹ Guidance Manual for Compliance with the Filtration and Disinfection Requirements for Public Water Systems Using Surface Water Sources, USEPA, 1990.

² Basis for values given in Appendix F, Guidance Manual for Compliance with the Filtration and Disinfection Requirements for Public Water Systems Using Surface Water Sources, USEPA, 1990.

Exhibit A.2 CT Values for Inactivation of Viruses by Chlorine Dioxide ^{3,4}

Temperature (°C)						
Inactivation	<=1	5	10	15	20	25
2-log	8.4	5.6	4.2	2.8	2.1	1.4
3-log	25.6	17.1	12.8	8.6	6.4	4.3
4-log	50.1	33.4	25.1	16.7	12.5	8.4

³ Guidance Manual for Compliance with the Filtration and Disinfection Requirements for Public Water Systems Using Surface Water Sources, USEPA, 1990.

⁴ Basis for values given in Appendix F, Guidance Manual for Compliance with the Filtration and Disinfection Requirements for Public Water Systems Using Surface Water Sources, USEPA, 1990.

Exhibit A.3 CT Values for Inactivation of Viruses by Ozone ^{5,6}

Temperature (°C)						
Inactivation	<=1	5	10	15	20	25
2-log	0.9	0.6	0.5	0.3	0.25	0.15
3-log	1.4	0.9	0.8	0.5	0.4	0.25
4-log	1.8	1.2	1.0	0.6	0.5	0.3

⁵ Guidance Manual for Compliance with the Filtration and Disinfection Requirements for Public Water Systems Using Surface Water Source, USEPA, 1990.

⁶ Basis for values given in Appendix F, Guidance Manual for Compliance with the Filtration and Disinfection Requirements for Public Water Systems Using Surface Water Sources, USEPA 1990.

Exhibit A.4 Baffling Classifications⁷

Baffling Conditions	Baffling Factor (T_{10}/T)	Baffling Description
Unbaffled (mixed flow)	0.1	None, agitated basin, very low length to width ratio, high inlet and outlet flow velocities, common inlet/outlet
Poor	0.3	Single or multiple unbaffled inlets and outlets, no intra-basin baffles
Average	0.5	Baffled inlet or outlet with some intra-basin baffles
Superior	0.7	Perforated inlet baffle, serpentine or perforated intra-basin baffles, outlet weir or perforated launders
Perfect (plug flow)	1.0	Very high length to width ratio (pipeline flow) perforated inlet, outlet, and intra-basin baffles

⁷ Adapted from *Guidance Manual for Compliance with the Filtration and Disinfection Requirements for Public Water Systems Using Surface Water Sources*, USEPA, 1990.

Exhibit A.5 UV Dose Table for Virus Inactivation Credit⁸

Log Credit	Virus UV Dose (mJ/cm^2) ⁹
0.5	39
1.0	58
1.5	79
2.0	100
2.5	121
3.0	143
3.5	163
4.0	186

⁸ Adapted from 40 CFR 141.720(d) (USEPA 2006b)

⁹ mJ/cm^2 = millijoule per centimeter squared

1 **A.3 Removal of Viruses**

2
3 4-log treatment of viruses to meet the requirement of the GWR may also be accomplished
4 through removal (i.e. filtration) or a State-approved combination of inactivation and removal.
5 This section describes common filtration technologies and their applicability to GWR treatment
6 technique requirements. States may approve alternative treatment technologies, or combinations
7 of technologies, that provide 4-log treatment of viruses to meet the GWR treatment technique
8 requirements.
9

10 The following are commonly used filtration technologies that provide some level
11 of virus removal. While these technologies are more commonly used in systems treating surface
12 water, systems treating ground water (i.e. for iron and/or manganese removal) may also use these
13 technologies:

- 14 • Conventional Treatment;
- 15 • Direct filtration;
- 16 • Slow sand filtration; and
- 17 • Diatomaceous Earth Filtration
- 18
- 19
- 20
- 21
- 22

23 When properly designed and operated, these technologies are capable of achieving at
24 least 1-log removal of viruses (USEPA, 1990)
25

26 Membrane filtration technologies provide some level of virus removal and the GWR
27 includes specific requirements for the use of membrane filters. States may also approve
28 alternative filtration technologies if those technologies can demonstrate (and monitor to
29 demonstrate to continuing removal efficacy) removal of viruses.
30

31 **A.3.1 Membrane Technologies**

32 Membrane technologies used to provide 4-log removal of viruses to meet GWR
33 requirements must have an absolute molecular weight cut off (MWCO), or an alternate
34 parameter that describes the exclusion characteristics of the membrane, that reliably achieves at
35 least 4-log removal of viruses.
36

37 Generally, only ultrafiltration, nanofiltration, and reverse osmosis membranes provide
38 virus removal (USEPA, 2005). Manufacturers of membrane technologies may have performed
39 challenge or demonstration studies according to State or other protocols to demonstrate virus
40 removal performance. Manufacturers may have also participated in treatment device certification
41 programs such as the National Sanitation Foundation (NSF) (<http://www.nsf.org>) or EPA's
42 Environmental Technology Verification (ETV) Program (<http://www.epa.gov/etv>). Appendix E
43 of the *Membrane Filtration Guidance Manual* (USEPA, 2005) provides additional information
44 on the application of membrane filtration for virus removal.
45
46
47

1 The GWR also requires that membrane technologies used to provide 4-log removal of
2 viruses to meet GWR requirement be operated in accordance with State-specified performance
3 requirements and show that the integrity of the membrane is intact. The most accurate method of
4 demonstrating membrane integrity currently available is direct integrity testing. Continuous
5 indirect integrity monitoring, using turbidity, particle counts or other surrogate water quality
6 parameters, may be used to assess membrane integrity on a continuous basis and establish
7 performance criteria. However, direct integrity testing to demonstrate virus removal may not be
8 feasible and some methods of indirect integrity monitoring may not have sufficient accuracy to
9 serve as more than gross measures of membrane integrity for virus removal (USEPA, 2005).

10
11 For most ground water sources, turbidity and particles are not likely to be present at
12 levels high enough to set performance criteria or use in continuous monitoring and States may
13 need to use other water quality parameters (e.g. TDS, conductivity) or operating parameters (e.g.
14 transmembrane pressure, flux rate) as performance indicators. Monitoring some parameters may
15 require laboratory analysis or additional monitoring equipment. As with other treatment
16 technologies, membranes may be combined with another treatment technology to provide a total
17 of 4-log treatment of viruses. Combining a membrane technology with chlorine disinfection
18 would provide multiple virus barriers with a level of redundancy.

19 20 21 **A.3.2 Alternative Filtration Technologies**

22
23 As with membrane technologies, manufacturers of alternative filtration technologies may
24 have performed challenge or demonstration studies according to State or other protocols to
25 demonstrate virus removal performance. Manufacturers may have also participated in NSF, ETV
26 or other treatment device certification programs. The GWR requires that alternative filtration
27 technologies used to provide 4-log removal of viruses to meet GWR requirement be operated in
28 accordance with State-specified performance requirements. These performance requirements
29 could include continuous, indirect measures of performance using water quality parameters (e.g.
30 TDS, conductivity) as performance indicators. Alternative filtration technologies may be
31 combined with another treatment technology to provide a total of 4-log treatment of viruses and
32 additional treatment could provide multiple virus barriers with a level of redundancy.

33 34 35 **A.4 References**

36
37 USEPA, 1990. Guidance Manual for Compliance with the Filtration and Disinfection
38 Requirements for Public Water Systems Using Surface Water Sources, October 1990

39
40 USEPA, 2005. Membrane Filtration Guidance Manual, EPA 815-R-009, November 2005.

41
42 USEPA, 2006a. Ultraviolet Disinfection Guidance Manual for the Final Long Term 2 Enhanced
43 Surface Water Treatment Rule, EPA 815-R-06-007, November, 2006.

44
45 USEPA, 2006b. National Primary Drinking Water Regulations: Long Term 2 Enhanced Surface
46 Water Treatment Rule: Final Rule, 71FR 654, January 5, 2006.

**Appendix B Using Sanitary Surveys to Update State Source Water
Protection Programs**

APPENDIX B: USING SANITARY SURVEYS TO UPDATE STATE SOURCE WATER PROTECTION PROGRAMS

Note: In the examples below, the states use the term “Source Water Assessment program”.

Sanitary surveys (Surveys) can be adapted to support source water assessments. Three short examples and one extended example are presented below. These approaches could be utilized by other states wanting to take advantage of the Survey process to enhance or update their Susceptibility Determinations (SDs).

Example 1: State of New York

As part of their agreement with the state, counties in the state of New York will collect additional information about their PWSs during Surveys and site inspections and enter the data into an add-on that the state developed for the SDWIS database. The Basic Facility Data form was modified for use with the Source Water Assessment Program to contain state-specific information: contaminant history, locations of potential contaminant sources and well logs. These data were incorporated into assessments as Discrete Contaminant Source Public Water Supply Inventory and as sensitivity drivers and other information pertinent to overall susceptibility.

Example 2: State of Louisiana

Sanitarians in the Louisiana Department of Health and Hospitals have conducted sanitary surveys that have proven useful for updating Source Water Assessment Program data. Health and Hospitals has access to the Source Water Assessment Program reports and checks them against the information obtained during sanitary surveys. Health and Hospitals notifies the Louisiana Department of Environmental Quality if there are any errors in the report, such as wells that are incorrectly numbered or no longer active. Health and Hospitals also notifies Environmental Quality if new wells have been drilled, if a system has been closed, or if a new system has come online; new systems are added to the source water assessment database.

One Health and Hospitals staff person works with Environmental Quality to update the contaminant source inventories. This staffer performs the field work and then Environmental Quality updates the database. Currently, source water areas are

prioritized for updating based on well-update information provided by the Health and Hospitals sanitarians, or on a request from such individuals and entities as the public, a government agency, or a water system. In the future, further prioritization would be based on susceptibility to contamination (as indicated by Source Water Assessment Program data).

Example 3: State of Michigan

The Source Water Assessment Score provides a susceptibility determination for Michigan’s non-community wells. One element of the Score is non-community PWS-well construction, maintenance, and use, which are determined as part of the sanitary-survey process. States, the PWS, or Source Water Protection Partners could take advantage of this scoring system to re-evaluate well integrity as information becomes available during the sanitary-survey cycle.

